
Yet Another Gamecube Documentation

(but one that's worth printing)

December 23, 2006



this is the result of myself pasting together various freely available documents aswell as adding some of my own findings. have fun... additions and corrections welcome :)

THIS IS WORK IN PROGRESS! INFORMATION CONTAINED IN THIS DOCUMENT MAY BE MISSING, INCOMPLETE OR EVEN PLAIN WRONG! NO F****N' WARRANTY IMPLIED! IF THE USE OF THE INFORMATION CONTAINED HERE RESULTS IN ULTRA REALISTIC SMOKE EFFECTS, BRAIN DAMAGE OR LOSS OF PHYSICAL AND/OR MENTAL HEALTH PLEASE DON'T COME BACK AND SAY YOU HAVEN'T BEEN WARNED! YOU SHOULDN'T BE USING THIS IN THE FIRST PLACE!

Contents

1	Intr	oductio	nal Rant		17
	1.1	Things	that are in	n this document	. 17
	1.2	Things	that are n	not in this document	. 17
	1.3	Conve	ntions		. 18
	1.4	legal B	abble		. 18
2	Gan	necube l	Hardware	e Introduction	19
	2.1	enhanc	ed Power	PC 750 Specification	. 19
	2.2	Consu	mer Units		. 20
		2.2.1	Nintendo	0	. 20
			2.2.1.1	HW1	. 20
			2.2.1.2	HW2	. 20
			2.2.1.3	HW2 'second edition'	. 20
			2.2.1.4	HW2 'third edition'	. 20
		2.2.2	Panasoni	ic Q	. 20
	2.3	Develo	pment Un	nits	. 20
	2.4	Hardw	are Parts I	List	. 20
		2.4.1	Connecte	ors	. 21
			2.4.1.1	Memory Card Slots (P4,P5)	. 21
			2.4.1.2	High-speed Port (P8)	. 21
			2.4.1.3	SDRAM/Parallel Port (P10)	. 22
			2.4.1.4	BBA/Modem Connector (P6)	. 22
			2.4.1.5	DVD Interface Connector (P9)	. 23
			2.4.1.6	Power Supply Connector (P1)	. 24
		2.4.2	Semi-Co	onductors	. 24
			2.4.2.1	IPL (U10)	. 25
	2.5	Details	on the m	otherboard buses	. 25
	2.6	Details	on the M	facronix (MX) Chips	. 25
	2.7	DVD F	Protection		. 25
		2.7.1	Filesyste	em	. 25
		2.7.2	Barcode		. 25
		2.7.3	Encrypti	on	. 26
			2.7.3.1	Cyphertext algorithm	. 26
	2.8	IPL/BI	OS Encry	rption	. 26
		2.8.1	Flipper d	decryption logic bug	. 26
		2.8.2	Cypherte	ext algorithm	. 28
		2.8.3	replacing	g the IPL	. 28

3	Gek	ko CPU	Overview	v	29
	3.1	Registe	ers		29
	3.2	Calling	g convention	ons	29
	3.3	PPC In	structions		30
		3.3.1	Integer Ir	nstructions	30
		3.3.2	Floating-	Point Instructions	32
		3.3.3	Integer L	oad and Store Instructions	33
		3.3.4	Floating-	Point Load and Store Instructions	34
		3.3.5	Branch In	nstructions	34
		3.3.6	Condition	n Register Logical Instructions	34
		3.3.7	Misc Inst	ructions	35
	3.4	additio	nal Gekko	Instructions	35
		3.4.1	FPR form	nat in paired-single mode	36
		3.4.2	Arithmet	ic Instructions	36
			3.4.2.1	PS_ABS	36
			3.4.2.2	PS_ADD	37
			3.4.2.3	PS_CMPO0	37
			3.4.2.4	PS_CMPO1	37
			3.4.2.5	PS_CMPU0	37
			3.4.2.6	PS_CMPU1	37
			3.4.2.7	PS_DIV	38
			3.4.2.8	PS_MERGE00	38
			3.4.2.9	PS_MERGE01	38
			3.4.2.10	PS_MERGE10	38
			3.4.2.11	PS_MERGE11	38
			3.4.2.12	PS_MR	38
			3.4.2.13	PS_NABS	38
			3.4.2.14	PS_NEG	38
			3.4.2.15	PS_RES	38
			3.4.2.16	PS_RSQRTE	38
			3.4.2.17	PS_SUB	39
			3.4.2.18	PS_MADD	39
			3.4.2.19	PS_MADDS0	39
			3.4.2.20	PS_MADDS1	39
			3.4.2.21	PS_MSUB	39
			3.4.2.22	PS_MUL	39
			3.4.2.23	PS_MULS0	39

		3.4.2.24	PS_MULS1	39
		3.4.2.25	PS_NMADD	39
		3.4.2.26	PS_NMSUB	39
		3.4.2.27	PS_SEL	40
		3.4.2.28	PS_SUM0	40
		3.4.2.29	PS_SUM1	40
	3.4.3	Load and	Store Instructions	40
		3.4.3.1	psq_lx	40
		3.4.3.2	psq_lux	40
		3.4.3.3	psq_stx	40
		3.4.3.4	psq_stux	40
		3.4.3.5	psq_1	40
		3.4.3.6	psq_lu	40
		3.4.3.7	psq_st	40
		3.4.3.8	psq_stu	40
	3.4.4	modified	floating point instructions	41
		3.4.4.1	fadds	41
		3.4.4.2	fsubs	41
		3.4.4.3	fmuls	41
		3.4.4.4	fdivs	41
		3.4.4.5	fmadds	41
		3.4.4.6	fmsubs	41
		3.4.4.7	fnmadds	41
		3.4.4.8	fnmsubs	41
		3.4.4.9	fres	41
		3.4.4.10	frsp	41
		3.4.4.11	fsel	41
		3.4.4.12	$fmr \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	41
3.5	Progra	mming Tip	os and additional information	42
	3.5.1	Machine	State Register	42
	3.5.2	Caches		42
	3.5.3	branch ui	nit	42

4	Men	nory M	ар	43
	4.1	Overv	iew	43
	4.2	RAM	usage	43
		4.2.1	Dolphin-OS globals	43
			4.2.1.1 Boot Info	43
			4.2.1.1.1 DVD Disc ID	43
			4.2.1.1.2 system Info	44
			4.2.1.2 Debugger info	44
			4.2.1.3 Debugger Hook	44
			4.2.1.4 Dolphin OS Globals	45
		4.2.2	Exception Handlers	45
		4.2.3	Dolphin-OS globals	46
		4.2.4	User Memory	46
			4.2.4.1 user program area	46
			4.2.4.2 stack area	47
			4.2.4.3 heap area	47
			4.2.4.4 'high memory'	47
5			Registers	48
	5.1		Command Processor	48
		5.1.1	Token register	49
	5.2		ixel Engine	50
	5.3	VI - V	ideo Interface	51
		5.3.1	Video Modes	61
	5.4	PI - Pr	ocessor Interface	62
		5.4.1	Operation	63
			5.4.1.1 FIFO/Write Gather Pipe	63
			5.4.1.2 Interrupts	63
			5.4.1.3 hotreset	63
	5.5	MI - N	Memory Interface	64
	5.6	DSP -	Digital Signal Processor Interface	67
		5.6.1	internal DSP Registers	70
		5.6.2	Operation	72
			5.6.2.1 play raw audio sample	72
			5.6.2.2 transfer from/to ARAM	72
			5.6.2.3 reset DSP	73
			5.6.2.4 Boot DSP Task	73

5.7	DI - D	VD Interfa	ce	73
	5.7.1	Drive Co	mmands	77
	5.7.2	Drive De	bug Commands	78
	5.7.3	Operation	n	79
		5.7.3.1	Drive Info (Inquiry)	79
		5.	7.3.1.1 Structure of the Drive Info Data	79
		5.7.3.2	Read Disc ID / Init Disc	79
		5.7.3.3	Read Sector	79
		5.7.3.4	Seek	79
		5.7.3.5	Request Error	79
		5.	7.3.5.1 Error Codes	79
		5.7.3.6	Play Audio Stream	79
		5.7.3.7	Request Audio Status	80
		5.7.3.8	Stop Motor	80
		5.7.3.9	DVD Audio Disable	80
		5.7.3.10	DVD Audio Enable	80
		5.7.3.11	Write Mem debug command	80
	5.7.4	DVD-RC	OM Subsystem	80
		5.7.4.1	Memory Map	81
5.8	SI - Se	rial Interfa	ice	81
	5.8.1	Operation	n	87
		5.8.1.1	Serial Send Buffer	87
		5.8.1.2	Serial Get Result	87
5.9	EXI - I	External In	ıterface	87
	5.9.1	Operation	n	91
		5.9.1.1	Initializing the EXI Bus	91
		5.9.1.2	Selecting a Specific EXI Device on an EXI Channel	91
		5.9.1.3	Deselecting EXI Devices on an EXI Channel	91
		5.9.1.4	Performing an IMM Operation on a EXI Device	91
		5.	9.1.4.1 IMM Read	91
		5.	9.1.4.2 IMM Write	92
		5.9.1.5	Performing a DMA Operation on a EXI Device	92
		5.	9.1.5.1 DMA Read	92
		5.	9.1.5.2 DMA Write	92
		5.9.1.6	Wait for EXI transfer completed	92
5.10	AI - A	udio Strea	ming Interface	92
5 11	GX FI	FO (Graph	ic dienlay lists)	94

		5.11.2	internal CP Registers	128
		5.11.3	internal XF Memory	135
		5.11.4	internal XF Registers	136
		5.11.5	GP packet description	148
			5.11.5.1 Command Type	148
			5.11.5.1.1 opcodes	148
			5.11.5.2 Drawing Commands	149
			5.11.5.2.1 Quads	149
			5.11.5.2.2 Triangles	149
			5.11.5.2.3 Trianglestrip	150
			5.11.5.2.4 TriangleFan	150
			5.11.5.2.5 Lines	150
			5.11.5.2.6 Linestrip	150
			5.11.5.2.7 Points	150
			5.11.5.3 NOP - No Operation	150
			5.11.5.4 CALL DL - Call Display List	150
			5.11.5.5 Invalidate Vertex Cache	150
			5.11.5.6 BP command (Bypass Raster State Registers)	150
			5.11.5.7 CP command (Command Processor Registers)	150
			5.11.5.8 XF command (Transform Unit Registers)	151
			5.11.5.9 Indexed XF command	151
6	Exce	eption a	nd Interrupt Processing	152
	6.1	_	are Exception Sources	152
		6.1.1	System Reset Interrupt	152
		6.1.2	Machine Check Interrupt	
		6.1.3	DSI Interrupt	152
		6.1.4	ISI Interrupt	
		6.1.5	External Interrupt	
			6.1.5.1 Setup	152
			6.1.5.2 Handling	153
		6.1.6	Alignment Interrupt	153
		6.1.7	Program Interrupt	153
		6.1.8	FP unavailable Interrupt	153
		6.1.9	Decrementer Interrupt	153
		6.1.10	System Call Interrupt	153

	6.1.11	Trace Interrupt
	6.1.12	Performance Monitor Interrupt
	6.1.13	IABR Interrupt
	6.1.14	Thermal Interrupt
6.2	Externa	al Interrupt Sources
	6.2.1	HSP - High Speed Port
		6.2.1.1 TX Mailbox Interrupt
		6.2.1.2 RX Mailbox Interrupt
		6.2.1.3 ID Interrupt
	6.2.2	Debug
	6.2.3	CP - Command Processor
		6.2.3.1 FIFO underflow
		6.2.3.1.1 setup
		6.2.3.1.2 handling
		6.2.3.2 FIFO overflow
		6.2.3.2.1 setup
		6.2.3.2.2 handling
	6.2.4	PE - Pixel Engine Finished
		6.2.4.1 setup
		6.2.4.2 handling
	6.2.5	PE - Pixel Engine Token
		6.2.5.1 setup
		6.2.5.2 handling
	6.2.6	VI - Video Interface
		6.2.6.1 Setup
		6.2.6.2 Handling
	6.2.7	Memory Interface
		6.2.7.1 protection fault
		6.2.7.1.1 Setup
	<i>(</i> 2 0	6.2.7.1.2 Handling
	6.2.8	DSP Interface
		6.2.8.1 Audio DMA finished
		6.2.8.1.1 Setup
		6.2.8.1.2 Handling
		6.2.8.2 ARAM transfer complete <
	629	Audio Streaming Interface
	V.4.7	/ 1999// 1995/1997 1995/1995

		6.2.10	EXI	156
			6.2.10.1 DMA Transfer finished (TCINT channel 0, channel 1)	156
			6.2.10.2 Ethernet Adapter (EXIIRQ channel 2)	156
			6.2.10.2.1 setup	156
			6.2.10.2.2 handling	157
			6.2.10.3 Memory Card removed (EXTINT channel 0, channel 1)	157
			6.2.10.3.1 setup	157
			6.2.10.3.2 handling	157
		6.2.11	Serial Interface	157
		6.2.12	DVD Interface	157
			6.2.12.1 Break Complete	157
			6.2.12.2 DMA finished	157
			6.2.12.3 Device Error	157
			6.2.12.4 Cover State changed	157
		6.2.13	Reset Button	157
			6.2.13.1 setup	157
			6.2.13.2 handling	157
		6.2.14	Error	157
7	Vide	o Proces	sing	158
7	Vide 7.1	o Proces Used VI	sing	
7		Used V		158
7	7.1	Used VI	[terms	158 158
7	7.1	Used VI init VI 7.2.1	[terms	158 158 158
7	7.1 7.2	Used VI init VI 7.2.1 render to	Videomodes	158 158 158 158
7	7.1 7.2 7.3 7.4	Used VI init VI 7.2.1 render to vertical	Videomodes	158 158 158 158 158
	7.1 7.2 7.3 7.4 7.5	Used VI init VI 7.2.1 render to vertical set XFB	Videomodes	158 158 158 158 158 158
7 8	7.1 7.2 7.3 7.4 7.5 3D (Used VI init VI 7.2.1 render to vertical set XFB	Videomodes O XFB retrace Address Processing	158 158 158 158 158 158 158
	7.1 7.2 7.3 7.4 7.5	Used VI init VI 7.2.1 render to vertical set XFB Graphics basic op	Videomodes O XFB retrace Address Processing perations	158 158 158 158 158 158 158
	7.1 7.2 7.3 7.4 7.5 3D (Used VI init VI 7.2.1 render to vertical set XFB Graphics basic op 8.1.1	Videomodes O XFB retrace Address Processing perations load BP Register	158 158 158 158 158 158 158 159
	7.1 7.2 7.3 7.4 7.5 3D (Used VI init VI 7.2.1 render to vertical set XFB Graphics basic op 8.1.1 8.1.2	Videomodes	158 158 158 158 158 158 159 159 160
	7.1 7.2 7.3 7.4 7.5 3D (Used VI init VI 7.2.1 render to vertical set XFB basic op 8.1.1 8.1.2 8.1.3	Videomodes O XFB Processing Perations load BP Register load CP Register load XF Register	158 158 158 158 158 158 159 159 160 160
	7.1 7.2 7.3 7.4 7.5 3D (8.1	Used VI init VI 7.2.1 render to vertical set XFB basic op 8.1.1 8.1.2 8.1.3 8.1.4	Videomodes O XFB retrace Address Processing rerations load BP Register load CP Register load XF Register load XF Register Indexed	158 158 158 158 158 158 159 159 160 160
	7.1 7.2 7.3 7.4 7.5 3D (Used VI init VI 7.2.1 render to vertical set XFB basic op 8.1.1 8.1.2 8.1.3 8.1.4 example	Videomodes O XFB retrace Address Processing rerations load BP Register load CP Register load XF Register load XF Register Indexed reprocessing loop	158 158 158 158 158 159 159 160 160 160
	7.1 7.2 7.3 7.4 7.5 3D (8.1	Used VI init VI 7.2.1 render to vertical set XFB Graphics basic op 8.1.1 8.1.2 8.1.3 8.1.4 example 8.2.1	Videomodes	158 158 158 158 158 159 159 160 160 160 160
	7.1 7.2 7.3 7.4 7.5 3D (8.1	Used VI init VI 7.2.1 render to vertical set XFB basic op 8.1.1 8.1.2 8.1.3 8.1.4 example 8.2.1	Videomodes O XFB retrace Address Processing rerations load BP Register load CP Register load XF Register load XF Register Indexed reprocessing loop	158 158 158 158 158 159 159 160 160 160 160

			8.2.1.3 send setup frame	
			8.2.1.3.1 Videomodes	
		8.2.2	begin frame	
		8.2.3	draw frame	
		8.2.4	end frame	
			8.2.4.1 copy EFB to XFB	
			8.2.4.2 copy EFB to Texture	
		8.2.5	close GX	
9	Iov-l	Bus Dev	ices 162	,
	9.1		Device List	
	9.2		d Controller	
	J.2	9.2.1	Init	
		9.2.2	Read Controller Status	
		9.2.3	rumble Motor On	
		9.2.4	rumble Motor Off	
	9.3		ırd	
		9.3.1	Types	
			9.3.1.1 ASCII	
			9.3.1.2 Datel	
			9.3.1.3 Tototek Adapter	j
		9.3.2	Scancodes	j
		9.3.3	Init)
		9.3.4	Read Keyboard	
	9.4	GBA .)
	9.5	Wavebi	rd)
	9.6	steering	g wheel)
	9.7	DKong	as)
		9.7.1	Read Controller Status	i
	9.8	Reside	nt Evil4 Chainsaw	,
10	EXI	Devices	168	}
-			nannel and Device List	
			ing the ID of an EXI Device	
			OM	
			Memory Map (Europe/PAL)	
			Memory Map (USA/NTSC)	

	10.3.3	Memory Map (Japenese/NTSC)
	10.3.4	Memory Map (Japenese/NTSC - Panasonic Q)
	10.3.5	Font Encoding
	10.3.6	Font Layout
		10.3.6.1 SJIS Font (ROM Font #1)
		10.3.6.2 ANSI Font (ROM Font #2)
	10.3.7	Operation
		10.3.7.1 read
10.4	RTC (F	Real-Time Clock)
	10.4.1	Operation
		10.4.1.1 read
		10.4.1.2 write
10.5	SRAM	170
	10.5.1	Memory Map
	10.5.2	Operation
		10.5.2.1 read
		10.5.2.2 write
	10.5.3	Checksums
10.6	AD16	
	10.6.1	Operation
		10.6.1.1 init
		10.6.1.2 write
		10.6.1.3 read
	10.6.2	Trace-Step Values
		10.6.2.1 BS
		10.6.2.2 BS2
10.7		ry Cards
		Commands
	10.7.2	Operation
		10.7.2.1 unlocking
		10.7.2.2 get ID
		10.7.2.2.1 Card IDs
		10.7.2.3 get Status
		10.7.2.3.1 Status Bits
		10.7.2.4 clear Status
		10.7.2.5 read Block
		10.7.2.6 erase Card

10.7.2.7 erase Sector		174
10.7.2.8 write Block		175
10.8 Ethernet Adapter		175
10.8.1 registers		175
10.8.2 command-registers		181
10.8.3 Operation		182
10.8.3.1 selecting a register for reading		182
10.8.3.2 selecting a register for writing		182
10.8.3.3 selecting command-register for reading		182
10.8.3.4 selecting command-register for writing		182
10.8.3.5 init		183
10.8.3.6 challenge/response calculation		183
10.8.3.7 send packet (outside interrupt)		184
10.8.3.8 poll received packets (outside interrupt)		184
10.8.3.9 received packet format		185
10.9 UART		185
10.10SD Cards		185
10.11 Viper 'Modchip'		185
10.12Ripper III GC 'Modchip'		185
10.13Qoob 'Modchip'		185
10.14NinjaMOD 'Modchip'		185
10.15 Mario Party Microphone		186
11 HCD Daviess		187
11 HSP Devices 11.1 GB Player		187
11.1 Ob Flayer	• •	107
12 Memory Card Structure		188
12.1 Overview		188
12.2 Header		188
12.3 Directory		188
12.3.1 Directory Entries		189
12.3.1.1 Image Data		190
12.3.1.1.1 Banner Image		190
12.3.1.1.2 Icon Image		190
12.3.1.1.3 Palettes		190
12.4 Block Allocation Map		190
12.5 Checksums		191

13

13	DVD	Structure	192
	13.1	Disk header	192
	13.2	Disk header Information	192
	13.3	Apploader	193
	13.4	Format of the FST	193
		13.4.1 Format of a File Entry	193
14	gene	ral File Formats	194
	Ü	BNR (Banner file format)	194
	14.2	DOL (Gamecube Executable)	194
	14.3	ELF (Executable and linkable Format)	194
		GCB (QOOB Flash Files)	
	14.5	GCM (Gamecube Disc Image)	195
	14.6	GCI (Gamecube Game Save)	195
	14.7	GCP (Gamecube Memorycard Image)	195
	14.8	TGC	195
		14.8.1 Header	196
		14.8.2 embedded GCM	196
	14.9	VGC (Viper Flash Files)	196
15	Gam	e File Formats	198
	15.1	AFC (audio stream)	198
	15.2	AST (audio stream)	198
	15.3	ARC (RARC Archive)	198
		15.3.1 Header	198
		15.3.2 Nodes	198
		15.3.3 File Entries	199
	15.4	ARC (audio stuff)	199
	15.5	ASN	199
	15.6	AW ("audio wave"?)	199
	15.7	BAS ("audio script" ?)	199
	15.8	BCA	199
	15.9	BCK (animation of a .bmd skeleton)	199
	15.10	BDL	199
	15.11	BFN (font)	199
	15.12	BIN (binary file)	199
	15 13	BBLO (screen layout for dialog screens)	200

	15.14BMD (3d model with texture and skeleton)	200
	15.15BMG	200
	15.16BMP (window bitmap (!))	200
	15.17BMT	200
	15.18BCK ("Pack" file)	200
	15.19BRK	200
	15.20BTI	200
	15.20.1 Texture Header	201
	15.21BTP	201
	15.22BTK	201
	15.23COL (collision triangles)	201
	15.24DZB	201
	15.25H4M	202
	15.26JPA (particle data)	202
	15.27JPC	202
	15.28MTH ('Mute thp?')	202
	15.29PAD	202
	15.30PRM ('Parameters?')	202
	15.31REL (relocatable module)	202
	15.32SB	202
	15.33SZS (packed RARC Archive)	202
	15.34THP (video format)	202
	15.34.1 Header data	203
	15.34.2 Components structure	203
	15.34.3 VideoInfo Structure	203
	15.34.4 AudioInfo Structure	203
	15.34.5 Frame data	204
	15.34.6 Video Frames	204
	15.34.7 Audio Frames	204
	15.35TPL (Texture Palette)	205
	15.36YMP (height map)	206
16	Compression Formats	207
10	16.1 Yay0	207
	16.1.1 compression	207
	-	207
	16.1.3 Font Data	207
	16.2 Yaz0	209
	16.2.1 de-compression Code	209
	19.2.1 40 00111010001011 0040	~~/

17	Graphic Formats	211
	17.1 YCbYCr	211
	17.2 I4 (4bit indexed)	212
	17.3 IA4 (4bit indexed with alpha)	212
	17.4 I8 (8bit indexed)	212
	17.5 IA8 (8bit indexed with alpha)	212
	17.6 CI4 (compressed 4bit indexed)	212
	17.7 CIA4 (compressed 4bit indexed with alpha)	212
	17.8 CI8 (compressed 8bit indexed)	212
	17.9 CIA8 (compressed 8bit indexed with alpha)	212
	17.10RGB4A3	212
	17.10.1 RGB4A3 Pixel Format	212
	17.11RGB5A1	212
	17.11.1 RGB5A1 Pixel Format	212
	17.12RGB565	213
	17.12.1 RGB565 Pixel Format	213
	17.13RGBA8	213
	17.13.1 RGBA8 Pixel Format	213
	17.14S3TC	213
	17.14.1 CMPR	214
10	Amondin	216
10	Appendix 18.1 GCC Quick How To	
	-	
	18.1.1 compile ASM to object:	
	18.1.2 compile C to object:	
	18.1.3 compile C++ to object:	
	18.1.4 link objects	
	18.1.5 remove unneeded sections (debug info etc) from object	
	18.1.6 convert object to plain binary	
	18.1.7 convert absolute address into filename/line number/function	
	18.1.8 Building a Crosscompiler	
	18.1.9 Linker Script	
	18.1.10 Startup Code	
	18.2 Boot Process Details	
	18.2.1 BS - Bootstrap 1	
	18.2.2 BS2 - Bootstrap 2	
	18 2 2 1 short description of start() routine	218

20	Cred	lits	243
	19.1	Sources	242
19	Refe	rences	241
	18.7	Terms and Acronyms	236
	18.6	Easter Eggs	236
		chip simelarities	
	18.4	Macronix Chip IDs	234
		18.3.3 Makercodes	232
		18.3.2 Game Serial ID	232
		18.3.1 Gamecodes	232
	18.3	Game and Maker Codes	232
		18.2.4 Main DOL executable	231
		18.2.3 Apploader	226
		18.2.2.3 Map of IPL Library code	225
		18.2.2.2 IPL main() reversing	218

17

1 Introductional Rant

If you don't know what programming a machine down to the metal is all about, go away! no really, this document is not for you! if you are seeking for advice on using existing solutions, such as SDKs or libraries, you will find little to none information that is of any use for you and you might only become frustrated by figuring out how little you know. If you however aren't afraid of numbers and want to dare jumping into the snake-pit of semi-accurate information based on guesswork done by a bunch of freaks - feel invited. this was made to give you what you need in the most compressed and visually pleasing form possible. *Stuff that matters*.

1.1 Things that are in this document

just about everything explicitly and specifically related to the gamecube hard- and software internals and its programming. everything inside the box is subject to be documented, may it be relevant for actual programming or not. its meant as a reference for everyone who wants to know in all possible detail what makes this thing tick.

one more thing: please notice that this is a technical documentation which is presented for pure educational purposes and higher learning, and not a moral lesson. i have decided against leaving out any information since i believe that information by itself should not be crippled in any way. if you choose to abuse this information for any kind of illegal activities (**PLEASE DON'T!**) so be it, but don't bother me with it.

1.2 Things that are *not* in this document

several things were decided to not being put into this document because they didn't fit into the 'technical documentation' type of concept. They may be documented separatly some time but not now and not here. These things are:

- □ Tips on Emulating the Gamecube on another Host system (this kind of information is only useful for a very limited number of people, and additionally might be highly confusing and/or misleading for those who are writing actual gamecube programs)
- > Explanation of the PSO (Phantasy Star Online) Exploit that lets you run code on the Gamecube
- ▷ Explanation of the Codes used with Datels Action Replay
- ▷ Instructions on using any tools that let you upload and execute code on the Gamecube, or any other development related tools except anything related to setting up and using gcc as a cross-compiler targeted to the gamecube.
- > anything related to gaming, cheat-codes and the like. (this is a tech-doc not a gaming FAQ!)
- ▷ information on using the datel action replay to patch itself in order to execute code.
- be detailed and/or complete sourcecode, except when a formal explanation would just over-complicate things. (this is a documentation, not a code library)
- ▷ building and/or using a custom interface to connect a gamecube memory card to another host and read/write data
- > anything related to playing/booting/copying pirated games (as you may have noticed, we do not support piracy!)

some of these may be arguable, so if you think they should be here - probably along the lines of the appendix - don't hesitate to write the chapter in question and send it to me. i might include it if you write it, but other than that i won't care (there is still enough other stuff to complete).

18

1.3 Conventions

- ⊳ we count bits starting from 0, the most significant bit of a byte is bit 7. when visualising a byte the most significant bit comes first (left), and the least significant bit comes last (right).
- ⊳ when dealing with 16- or 32 byte values all figures are in big endian byte order. this means that the most significant byte comes first (left), and the least significant byte comes last (right).
 - Please notice that the above is different to what IBM is using in their PPC documents. They have the (to many people strange and wrong) idea of applying 'big endian' to the order of bits and showing them the other way around as we do in this document.
- ▷ absolute memory addresses are shown as if the gamecube had been initialized by the original IPL and address translation had not been changed. For this matter we dont use physical addresses to avoid confusion for the majority of our readers.

Description	Symbol
logical or bitwise AND	&
logical or bitwise OR	
logical or bitwise exclusive OR	^
logical or bitwise NOT (inverse)	!
equality or assignment	=
addition	+
substraction	-
multiplication	*
division	/

please notice that -outside code- we do not make a difference between logical and bitwise operations. if in doubt the operation is bitwise, it should however be clearly visible from the context.

1.4 legal Babble

Everything in this Document has been reverse-engineered from legally aquired software (Games), publicly available Patents and Documentation for the sole purpose of writing interoperable Software. This is explicitly allowed (almost encouraged:)) by Sect. 1201 (f), Reverse Engineering exception of the DMCA.

2 Gamecube Hardware Introduction

The GameCube is a powerful piece of hardware. The whole system is based on the IBM PowerPC Gekko processor and the custom ATI Flipper video system. The PowerPC Gekko processor is really just a PowerPC 750 with a few enhancements.

2.1 enhanced PowerPC 750 Specification

- > 200 MHz 64-bit bus width to main memory (1.6 Gigabytes per second maximum)
- ⇒ 32KB associative L1 Icache
- > 32KB associative L1 Dcache with 16KB data scratchpad
- > Super-scalar microprocessor with five different execution units:
 - ▷ 2 integer units, 1 FPU, and 1 load\store unit and branch unit
- > DMA unit servicing 16KB data scratchpad.
- DMA request queue 15-entry.
- ⊳ Embedded 256KB 2-way set-associative L2 unified cache.
- ▷ 2 32-bit Integer Units (IU)
- ▷ 1 FPU, 32 and 64-bit bus width
- ▷ The FPU supports Floating Point Paired Singles (FP/PS)
- > Branch Unit provides static AND dynamic branch prediction

The enhanced PowerPC Gekko processor also contains many features for minimization of processor delays because of data accessing and for maximization of processing throughput:

- ⊳ Non-blocking caches
- ▷ Branch prediction through use of the Branch Unit (BU)
- ⊳ 8-way set-associative caches
- ≥ 256KB L2 transfer cache
- > Out-of-order execution capabilities

The instruction set of the PowerPC Gekko processor seems to be almost identical to the one of the PowerPC 750 processor. The only visible differences at the moment are that the PowerPC Gekko processor has a few AltiVec\SIMD opcodes added to its final instruction set.

2.2 Consumer Units

- 2.2.1 Nintendo
- **2.2.1.1 HW1** HW1 was an initial, buggy version of the GameCube hardware that wasnt sold at retail.
- **2.2.1.2** HW2 is the first hardware that was sold in stores to the public.
- **2.2.1.3 HW2 'second edition'** The second edition models are missing the "Serial Port 2" that the first edition had. The plastic cover is still on the bottom of the cube, where the port used to be, but there's just a metal plate underneath it, and no connector.
- **2.2.1.4 HW2 'third edition'** The third edition Gamecubes are missing both the "Serial Port 2", and the Digital A/V connector.

2.2.2 Panasonic Q

There is a Gamecube combined with dvd-player manufactured by Panasonic called 'Panasonic-Q'. It seems to be exactly the same as HW2 for the Gamecube part, except that the dvd drive is different.

2.3 Development Units

Nintendo provides development hardware units to official, licensed GameCube developers. There are namely two different versions: the GDEV and the DDH hardware development kit units. These units are the same as retail GameCube HW2 units with some changes: They have PC communications features (either through SCSI or USB) and they have DVD emulation hardware instead of a proprietary mini-DVD drive. GameCube development units also seem to have slower processor speeds than retail GameCubes, this clock speed ranges from around 150MHz to 400MHz. Development GameCubes also seem to contain more RAM than retail ones, namely around 40MB. SNSystems also provides their own development kit, authorized by Nintendo, called the TDEV. According to specifications directly from SNSystems, the TDEV development hardware contains twice as much memory as retail GameCubes for debugging and a direct PC<->TDEV USB connection for fast uploading of code and\or data. Finally, there is also another proprietary development kit called the NR-Reader. NR-Reader's contain less debugging capabilities than the other development kits and are mostly meant for developers to efficiently get their demos\games to beta testers or media. However, SNSystems reports that their ProDG development kit can be used with a special USB adapter of theirs for directly sending program (debug) code to NR-Reader GameCubes. Also, NR-Reader GameCubes contain different mini-DVD drives than retail GameCubes, but still use a proprietary writing\reading format which is currently unknown. The DVD drives of NR-Readers can only read special DVDs that can only be written correctly with NR-Writer hardware (which is really just a Panasonic\Matshita SW-9501 with modified firmware). Also, the official debug development kits possibly contain J-TAG support, which is a method for debugging hardware. If so, there is a possibility that J-TAG support still remains in retail GameCubes as well, but this is purely hypothesis. If, in fact, retail Game-Cubes contain J-TAG debugging support then it should be possible for (homebrew) code to be uploaded through a J-TAG cable) directly to a GameCube's RAM and executed.

2.4 Hardware Parts List

▷ "MBU" and "MBB" will be used to refer to parts on the top and bottom sides of the GameCube's mother-board respectively.

- ▷ "DVDB" will be used to refer to parts on the DVD controller board.
- ▷ "CB" will be used to refer to parts on the controller pad board.

2.4.1 Connectors

The are 10 different connectors on the GameCube's mother-board. The following table contains an ID key and a short functional description.

ID	Description
P1	Motherboard Power Connector - MBB - Top Left
P2	Digital Video Output Connector - MBU - Bottom Left
Р3	Controller Pad Board Connector - MBU - Middle Right
P4	Memory Card Slot Connector A - MBU - Top Right
P5	Memory Card Slot Connector B - MBU - Bottom Right
P6	Serial Port Connector 1 - MBB - Top Right
P7	Analog Video Output Connector - MBU - Middle Left
P8	Serial Port Connector 2 - MBB - Top Right
Р9	Mini-DVD Drive Port Connector - MBU - Top Right
P10	Hi-Speed Parallel Port Connector - MBB - Bottom Left

2.4.1.1 Memory Card Slots (P4,P5)

pin	Signal
1	EXTIN
2	GND
3	INT
4	3.3V
5	DO
6	5V
7	DI
8	3.3V
9	CS
10	Ground (Shield)
11	CLK
12	EXTOUT

2.4.1.2 High-speed Port (P8)

pın	Signal
1	3.3V
2	GND
3	INT
4	CLK
5	DO
6	DI
7	CS
8	Ground (Shield)

pin	Signal
1	VCC
2	Ground
3	DQ0
4	DQ7
5	DQ1
6	DQ6
7	DQ2
8	DQ5
9	DQ3
10	DQ4
11	VCC
12	Ground
13	write enable
14	DQM
15	CAS
16	Clock
17	RAS
18	A12
19	CS (Chip Select)
20	A11
21	BA0
22	A9
23	BA1
24	A8
25	A10
26	A7
27	A0
28	A6
29	A1
30	A5
31	A2
32	A4
33	A3
34	INT
35	VCC
36	Ground

2.4.1.3 SDRAM/Parallel Port (P10)

2.4.1.4 BBA/Modem Connector (P6)

pin	Signal
1	EXTIN
2	Ground (Shield)
3	INT
4	CLK
5	12V
6	DO
7	3.3V
8	3.3V
9	DI
10	CS
11	Ground
12	Ground

pin	Signal
1	AISLR (audio bus)
2	5V
3	AISD (audio bus)
4	5V
5	AISCLK (audio bus)
6	5V
7	DIHSTRB
8	5V
9	DIERRB
10	Ground
11	DIBRK
12	DICOVER
13	DIDSTBR
14	DIRSTB
15	DIDIR
16	Ground
17	DID7
18	Ground
19	DID6
20	Ground
21	DID5
22	Ground
23	DID4
24	Ground
25	DID3
26	Ground
27	DID2
28	MONI
29	DID1
30	MONOUT
31	DID0
32	Ground

2.4.1.5 DVD Interface Connector (P9)

pin	Signal
1	Ground
2	Ground
3	3.3V
4	3.3V
5	Ground
6	Ground
7	Ground
8	Ground
9	1.8V
10	1.8V
11	1.8V
12	1.8V
13	1.55V
14	1.55V
15	1.55V
16	Ground
17	Ground
18	Ground
19	Thermo detect
20	12V
21	5V
22	5V

2.4.1.6 Power Supply Connector (P1)

2.4.2 Semi-Conductors

ID	Description
U1	Customized NEC Flipper Chip - MBU - Middle
U2	Customized IBM PowerPC Gekko Chip - MBU - Bottom
U3	MoSys (MS3M23B-5 A) 12MB 1-T SRAM - MBU - Top Right
U4	MoSys (MS3M23B-5 A) 12MB 1-T SRAM - MBU - Top Right
U5	NEC (D4891281G5 0125XU621) 16MB ARAM - MBU - Top Left
U6	A\V Encoder (AVE N -DOL RS5C5828) - MBB - Middle Left
U7	Amplifier? (AMP - DOL 128 124) - MBB - Top Left
U8	MX Clock Generator (Part Number?) - MBU - Bottom Left
U9	MX Clock Generator (Part Number?) - MBU - Bottom Right
U10	MX RTC/IPL (8013108-M RTCN-DOL 1R6022A1)

Pin	Signal
1	Clock
2	
3	
4	
5	CS
6	serial in
7	Ground
8	
9	serial out
10	
11	
12	osc - xtal2
13	osc - xtal1
14	

2.4.2.1 IPL (U10)

2.5 Details on the motherboard buses

The GameCube has three main external buses on its mother-board: the North-Bridge, the South-Bridge, and the East-Bridge. The fastest bus is the South-Bridge which connects the two 12MB 1T-SRAM chips to the Flipper. The South-Bridge bus has a bus-width of 64 bits, and data is exchanged through it at rates of about 324MHz. The North-Bridge bus connects the IBM PowerPC Gekko processor to the Flipper and is another 64 bit bus-width bus, however, it is only half as fast as the South-Bridge bus and is clocked at around 162MHz. Finally, the East-Bridge bus connects the 16MB Audio RAM chip to the Flipper chip. This bus only has a bus-width of 8 bits and is by far the slowest one, clocked at only 81MHz.

2.6 Details on the Macronix (MX) Chips

An outer inspection of the two MX chips does not reveal anything of much interest. Both chips are TSOP packages containing 14 pins each. One of the chips has "CLK" inscripted on it, and the other "RTC". It can be easily inferred that the "CLK" chip functions as some sort of a clock controller\generator and the "RTC" chip contains the GameCube's Real-Time Clock unit. Two of the RTC chip's pins are connected to an external crystal which regulates the RTC's timing rate. Another pin is connected to a battery located on the controller board. At least two pins are used for both VCC and GND. That leaves nine unknown pins. The RTC MX chip also contains the GameCube's BIOS. While 14 pins is not nearly enough for parallel Flash ROM, EEPROM, mask ROM, etc., it is quite adequate for a serial connection.

2.7 DVD Protection

The DVD Protection is based on a custom data format on an otherwhise pretty standard dvd.

2.7.1 Filesystem

The custom Filesystem (which is described somewhere else in this Document) by itself is not related to the actual protection mechanism. However, since it is not standard, that alone would already make it hard to read (and create) in a regular (pc-) environment.

2.7.2 Barcode

The Barcode is used to authenticate the Disc in the Drive.

2.7.3 Encryption

The entire content of a Gamecube DVD is XORed with a constant cyphertext and it is transparently decrypted by the Disc-Controller when reading from the DVD.

2.7.3.1 Cyphertext algorithm todo

2.8 IPL/BIOS Encryption

if you XOR an NTSC with a PAL bios (or any other two different ones), you will notice that because they have different sizes, there are some obviously zero encoded areas in one files, giving you plaintext in the other one which proves:

- > encryption is a simple XOR with a constant ciphertext.
- > the key used to generate the cyphertext is the same for different bios's

so we do the math:

given Ci = ciphertext, Cl = cleartext, K = key

encoding data goes like:

 $Ci1 = Cl1 ^ K$ $Ci2 = Cl2 ^ K$

If C11 or C12 is nothing but zero, the resultant Ci is just K

decoding it would be:

 $Cl = Ci ^ K$

for the areas where Cl is nothing but zeroes in one bios, we know K

2.8.1 Flipper decryption logic bug

The hardware decryption logic has a really nasty bug which allows us to read almost the full Cleartext (and thus a large part of the cyphertext, by XORing it with encrypted data).

This, combined with the features of the XOR encryption makea the whole encryption useless (at least very insecure) and implementing a new bios is a straight-forward task (provided that "high speed" (30Mhz) programmable logic with enough memory attached to it is available.). The Bios chip, which also includes sram and rtc (but that won't matter here), is attached to the EXI0 bus. The Exi bus (nothing new here, just to refresh it is an SPI-like bus. SPI is nothing complicated, just four interesting lines: CS (used mainly for syncing, since you need a defined start point, and you can easily attach multiple devices (memory card, ...) to the same bus with seperate CS lines), SI (aka MOSI, master out, slave in - the CPU is always master, the IPL-chip is slave. so SI is gamecube -> device), SO (device -> gamecube, tristated when a device is not active), and CLK (generated by the master). a transfer is basically:

- lower CS (it's low active)

for every bit do:

- set SI bit
- clock
- read SO bit

then:

- put CS high again.

(the exact timing (WHEN to sample SO, clock polarity) is different for different SPI modes, and the one descriped here is not necessarily the one used in the GC. anyway, it doesn't matter here)

so, based on that, we can transfer n-bit messages in BOTH DIRECTIONS. technically this is implemented with a 32bit shift register, with every clock cycle one bit is shifted out (to SI), and one bit is shifted in (to SO). so after n clock cycles, you have n new bits in the shift register and shifted n bits out. the used protocol on the Bus is in most cases very simple but device dependant. In the case of the IPL chip, it's the following:

GC -> IPL

1 bit read/write (0 for read, 1 for write, the latter only valid for RTC/Sram of course)

1 unknown bit

1 bits selection (0 for ROM, 1 for RTC/Sram)

23 bits address

6 bits dummy

after that, the data transfer starts. the 6 dummy cycles are mainly to give the IPL time to read out the first byte.

So you send 32 bits of data (the "address"), and start receiving the ROM bytes. but hey - we said the SPI bus always transfers 2 bits per clock cycle (in marketing terms), since it's fullduplex (in technical terms). we transfer one bit TO the device, and one BACK. we HAVE to. there's no way to NOT send a bit - but it doesn't matter, since for example the bits send from the IPL to the GC in the first 32bits are just ignored - they would contain most probably only zeros, ones, or the bus might be tristate. it's simply not defined, so there's no data to be expected. the same goes for the transfer of the data. the IPL chip sets the correct data at the SO line, but the gamecube - well, sends dummy bits, too. normally you would send zeros, ones, or whatever. it's ignored by the IPL chip anyway (unless it's a write, that would turn the whole thing upside down) now since technically the SPI port is implemented by a shifting register of 32bit length. after transferring 32bits, we would have to read out the new value, store it into memory, and "start the next transfer". but what's about CLEARING the register before? yes, they didn't. in the next transfer, the last 32bit are shifted out as dummy bits. well, one might say, it's just the data just shifted in, so it's completely uninteresting. BUT: the decryption of the loader is done in hardware. it's a part between the SO line of the IPL and the DI port of the shift register. (the encryption is build into the flipper, so no way to intercept the content AFTER decryption).so because the (decrypted) data just shifted in (and stored into memory) is shifted out again - we can get the decrypted data. if you sniff the SI line to the IPL chip, you will get a log like this:

```
00 00 40 00 (address written to the IPL, in this case: 0x100) FF FF FF FF (well just dummy data) xx xx xx xx (the data from the last 4 bytes, decrypted) ... xx xx xx xx (the data from the n-1 transfer, decrypted)
```

so in the end you get every 32bit words except one. For every transfered block you miss 32bits of plaintext data, but you'll get the rest. This should be enough to decrypt huge parts of the bios, and thus recover a large part of K.

2.8.2 Cyphertext algorithm

todo

2.8.3 replacing the IPL

using the above gained knowledge it is possible to create a small bootrom replacement (using the, yet incomplete, cyphertext), and get more (most) of the IPL Cleartext.

The Gekko boots from 0x100, that's what you read in almost any ppc instruction manual - the reset vector. well, this isn't the complete truth - it boots from it's exception base + 0x100. And the exception base is normally zero, BUT, as the ppc manual states: there's a bit in a HID (i think) register, which turns the exception base to 0xFFF00000. and this bit is "set usually at boot time". So the processor starts to fetch instructions at 0xFFF000100. If you read a bit further, you'll notice that the CPU always reads 64bits at once for code. The memory at 0xFFF00000 is mapped inside the flipper to an automated exi transfer (with that shift register), with the decryption logic active. so the processor starts executing the decrypted instructions, reading 8 bytes at a time, of which we get 4 bytes in plain - not much, (although enough to make some funny experiments, but that's another topic). Luckily, the IPL itself (the cube menu) isn't executed this way since that wouldn't be possible thanks to the "dumb" decryption logic The first ~0x800 bytes start to read data out of the IPL chip and store it to memory (still using the hardware decryption logic), and jump there, they read 1024 bytes at once. Well - now we know 1020 bytes of each transfer, enough to have a complete block of code we can exchange (we have the ciphertext Cl^K = Ci on SO, and the plaintext (delayed by 32bits on SI), and can XOR them to get Cl^K^Ci = K. now we can encrypt our code with K). so now we can make a small code which just dumps the whole IPL - well, to the EXI bus or whereever you can receive it. Now we have all Cl, and thus we can compute all K, thus we can get the complete Plaintext of all available IPLs aswell as encode a larger custom IPL ourselves.

a small note on why you can not recover the plaintext of the original loader this way:

The decryption logic is, whatever it is, a PRNG. It generates a stream of ciphertext ("K"), which has random properties (non-repeating, at least not in the range of some MB), but is always the same. it is incremented with every EXI-transfer. the address is NOT used in the calculation. thus reading from 0xFFF00100 more than one time will give you each time another result. the first time you get $Ci(0)^{K}(0)$ (the correct result), the second time you get $Ci(0)^{K}(1)$ etc., i.e. wrong results. Since we never get the K(n) for odd n, i see no chance of recovering it this way, even if we can read at 0xFFF00000+x (and we can do this if we don't set a specific bit to disable the logic).

29

3 Gekko CPU Overview

3.1 Registers

- □ General purpose registers (r0-r31)
 - ⊳ r1 sp stackpointer
 - ▷ r2 rtoc global pointer to _SDA2_BASE_
 - ⊳ r13 global pointer to _SDA_BASE_
- ⊳ Floating point registers (fp0-fp31)
- ▷ Segment registers (sr0-sr15) unused in regular (SDK/DolphinOS) applications
- - ⊳ spr8 (lr) link register
 - ⊳ spr920 HID2
 - ⊳ spr1010 instruction breakpoint address
 - ⊳ spr1013 data breakpoint address

spr920	4	r/w	HID2

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
2	PSE - Paired-Single load and store instructions enabled
1	
0	LSQE - Paired-Single mode enabled

3.2 Calling conventions

parameters are passed in r3 (1st) r4 (2nd) and r5 (third) up to r12 (9th), further parameters are passed through the stack.

3.3 PPC Instructions

3.3.1 Integer Instructions

Mnemonic	Opcode	Description
addi		
addis		
add		
addo		
subf		
subfo		
addic		
subfic		
addc		
addco		
subfc		
subfco		
adde		
addeo		
subfe		
subfeo		
addme		
addmeo		
subfme		
subfmeo		
addze		
addzeo		
subfze		
subfzeo		
neg		
nego		
mulli		
mullw		
mullwo		
mulhw		
mulhwu		
divw		
divwo		
divwu		
divwuo		
cmpi		
cmp		
cmpli		
cmpl		

Mnemonic	Opcode	Description
andi		
andis		
ori		
oris		
xori		
xoris		
and		
or		
xor		
nand		
nor		
eqv		
andc		
orc		

Mnemonic	Opcode	Description
extsb		
extsh		
cntlzw		
rlwinm		
rlwnm		
rlwimi		
slw		
srw		
srawi		
sraw		

3.3.2 Floating-Point Instructions

Mnemonic	Opcode	Description
fadd		
fadds (*)		
fsub		
fsubs (*)		
fmul		
fmuls (*)		
fdiv		
fdivs		
fres (*)		
frsqrte		
fsel (*)		
fmadd		
fmadds (*)		
fmsub		
fmsubs (*)		
fnmadd		
fnmadds (*)		
fnmsub		
fnmsubs (*)		
frsp (*)		
fctiw		
fctiwz		
fcmpu		
fcmpo		
mffs		
mcrfs		
mtfsfi		
mtfsf		
mtfsb0		
mtfsb1		
fmr (*)		
fneg		
fabs		
fnabs		

 $(\sp{*})$ - modified for paired singles

3.3.3 Integer Load and Store Instructions

Mnemonic	Opcode	Description
lbz		
lbzx		
lbzu		
lbzux		
lhz		
lhzx		
lhzu		
lhzux		
lha		
lhax		
lhau		
lhaux		
lwz		
lwzx		
lwzu		
lwzux		
stb		
stbx		
stbu		
stbux		
sth		
sthx		
sthu		
sthux		
stw		
stwx		
stwu		
stwux		
lhbrx		
lwbrx		
sthbrx		
stwbrx		
lmw		
stmw		
lswi		
lswx		
stswi		
stswx		

3.3.4 Floating-Point Load and Store Instructions

Mnemonic	Opcode	Description
lfs		
lfsx		
lfsu		
lfsux		
lfd		
lfdx		
lfdu		
lfdux		
stfs		
stfsx		
stfsu		
stfsux		
stfd		
stfdx		
stfdu		
stfdux		
stfiwx		

3.3.5 Branch Instructions

Mnemonic	Opcode	Description
b		unconditional Jump
ba		
bl		branch and link
bla		
bc		
bca		
bcl		
bcla		
bclr		
bclrl		
bcctr		
bcctrl		

3.3.6 Condition Register Logical Instructions

Mnemonic	Opcode	Description
crand		
cror		
crxor		
crnand		
crnor		
creqv		
crandc		
crorc		
mcrf		

3.3.7 Misc Instructions

Mnemonic	Opcode	Description
twi		
tw		
sc		
rfi		
mtcrf		
mcrxr		
mfcr		
mtmsr		
mfmsr		
mtspr		
mfspr		
lwarx		
stwcx.		
sync		
mftb		
eieio		
isync		
dcbt		
dcbtst		
dcbz		
dcbz_l		
dcbst		
dcbf		
dcbi		
icbi		
eciwx		
ecowx		
mtsr		
mtsrin		
mfsr		
mfsrin		
tlbie		
tlbsync		

3.4 additional Gekko Instructions

The Gekko has some additional (and some modified respectivly) instructions in its Paired-single mode which are useful for fast vector and matrix calculations and which are analog to Intel (and other x86 series) processors "streamed instructions", known as SSE. This extension is unique for the Gekko processor and used to calculate two single-precision numbers ("floats" in C) in one clock cycle. The floating-Point Registers of the Gekko (FPRs) are modified in the following way: one half is used for the first single number, and other for the second. These parts are named as "PS0" and "PS1". PS instructionset is divided into two parts: Load and Store Quantization and Paired-Single Arithmetic instructions. Load and Store Quantization instructions are used for fast integer-float type casting and some specific memory operations, using PS0 and PS1 parts of FPR. If you try to execute any PS instruction without HID2[PSE] and HID2[LSQE] bit set, an illegal instruction exception will be generated.

36

3.4.1 FPR format in paired-single mode

63	56	55	48	57	40	39	32
1111	1111	1111	1111	1111	1111	1111	1111
31	24	23	16	15	8	7	0
0000	0000	0000	0000	0000	0000	0000	0000

bit(s)		description
32-63	1	PS1
0-31	0	PS0

3.4.2 Arithmetic Instructions

Mnemonic	Opcode	Description
ps_abs	000100 DDDDD 00000 BBBBB 01000 01000 R	absolute value
ps_add	000100 DDDDD AAAAA BBBBB 00000 10101 R	add
ps_cmpo0	000100 DDD00 AAAAA BBBBB 00001 00000 0	compare ordered high
ps_cmpo1	000100 DDD00 AAAAA BBBBB 00011 00000 0	compare ordered low
ps_cmpu0	000100 DDD00 AAAAA BBBBB 00000 00000 0	compare unordered high
ps_cmpu1	000100 DDD00 AAAAA BBBBB 00010 00000 0	compare unordered low
ps_div	000100 DDDDD AAAAA BBBBB 00000 10010 R	divide
ps_merge00	000100 DDDDD AAAAA BBBBB 10000 10000 R	merge high
ps_merge01	000100 DDDDD AAAAA BBBBB 10001 10000 R	merge direct
ps_merge10	000100 DDDDD AAAAA BBBBB 10010 10000 R	merge swapped
ps_merge11	000100 DDDDD AAAAA BBBBB 10011 10000 R	merge low
ps_mr	000100 DDDDD 00000 BBBBB 00010 01000 R	move register
ps_nabs	000100 DDDDD 00000 BBBBB 00100 01000 R	negate absolute value
ps_neg	000100 DDDDD 00000 BBBBB 00001 01000 R	negate
ps_res	000100 DDDDD 00000 BBBBB 00000 11000 R	reciprocal estimate
ps_rsqrte	000100 DDDDD 00000 BBBBB 00000 11010 R	reciprocal square root estimate
ps_sub	000100 DDDDD AAAAA BBBBB 00000 10100 R	substract
ps_madd	000100 DDDDD AAAAA BBBBB CCCCC 11101 R	multiply and add
ps_madds0	000100 DDDDD AAAAA BBBBB CCCCC 01110 R	multiply and add scalar high
ps_madds1	000100 DDDDD AAAAA BBBBB CCCCC 01111 R	multiply and add scalar low
ps_msub	000100 DDDDD AAAAA BBBBB CCCCC 11100 R	multiply and substract
ps_mul	000100 DDDDD AAAAA 00000 CCCCC 11001 R	multiply
ps_muls0	000100 DDDDD AAAAA 00000 CCCCC 01100 R	multiply scalar high
ps_muls1	000100 DDDDD AAAAA 00000 CCCCC 01101 R	multiply scalar low
ps_nmadd	000100 DDDDD AAAAA BBBBB CCCCC 11111 R	negative multiply and add
ps_nmsub	000100 DDDDD AAAAA BBBBB CCCCC 11110 R	negative multiply and substract
ps_sel	000100 DDDDD AAAAA BBBBB CCCCC 10111 R	select
ps_sum0	000100 DDDDD AAAAA BBBBB CCCCC 01010 R	vector sum high
ps_sum1	000100 DDDDD AAAAA BBBBB CCCCC 01011 R	vector sum low

Note : R opcode field (comparsion of result with zero) is unused. (=0)

3.4.2.1 PS_ABS absolute value

Clear bit 0 of PS0[B] and copy result to PS0[D] Clear bit 0 of PS1[B] and copy result to PS1[D]

3.4.2.2 PS_ADD add

```
PS0[D] = PS0[A] + PS0[B]
PS1[D] = PS1[A] + PS1[B]
```

3.4.2.3 PS_CMPO0 compare ordered high

3.4.2.4 PS_CMPO1 compare ordered low

3.4.2.5 PS_CMPU0 compare unordered high

3.4.2.6 PS_CMPU1 compare unordered low

```
"c" holds result of comparsion If (PS1[A] is NaN or PS1[B] is NaN) then c=0001b Else if (PS1[A] < PS1[B]) then c=1000b Else if (PS1[A] > PS1[B]) then c=0100b Else c=0010b Save result in D field of condition register (CR[D] = c). These four compare instructions looks same, because I omitted some unecessary FPSCR stuff.
```

3.4.2.7 PS_DIV divide

```
PSO[D] = PSO[A] / PSO[B]
```

$$PS1[D] = PS1[A] / PS1[B]$$

3.4.2.8 PS_MERGE00 merge high

```
PSO[D] = PSO[A]
```

PS1[D] = PS0[B]

3.4.2.9 PS_MERGE01 merge direct

```
PSO[D] = PSO[A]
```

PS1[D] = PS1[B]

3.4.2.10 PS_MERGE10 merge swapped

```
PS0[D] = PS1[A]
```

PS1[D] = PS0[B]

3.4.2.11 PS_MERGE11 merge low

```
PS0[D] = PS1[A]
```

PS1[D] = PS1[B]

3.4.2.12 PS_MR move register

```
PSO[D] = PSO[B]
```

PS1[D] = PS1[B]

$\textbf{3.4.2.13} \quad \textbf{PS_NABS} \quad \text{negate absolute value}$

```
Set bit 0 of PSO[B] and copy result to PSO[D]
```

Set bit 0 of PS1[B] and copy result to PS1[D]

3.4.2.14 PS_NEG negate

Invert bit 0 of PS0[B] and copy result to PS0[D]

Invert bit 0 of PS1[B] and copy result to PS1[D]

3.4.2.15 PS_RES reciprocal estimate

```
PSO[D] = 1 / PSO[B]
```

PS1[D] = 1 / PS1[B]

3.4.2.16 PS_RSQRTE reciprocal square root estimate

```
PSO[D] = 1 / SQRT(PSO[B])
```

PS1[D] = 1 / SQRT(PS1[B])

3.4.2.17 PS_SUB subtract

```
PSO[D] = PSO[A] - PSO[B]
```

$$PS1[D] = PS1[A] - PS1[B]$$

3.4.2.18 PS_MADD multiply-add

```
PSO[D] = PSO[A] * PSO[C] + PSO[B]
```

$$PS1[D] = PS1[A] * PS1[C] + PS1[B]$$

3.4.2.19 PS_MADDS0 multiply-add scalar high

```
PSO[D] = PSO[A] * PSO[C] + PSO[B]
```

$$PS1[D] = PS1[A] * PS0[C] + PS1[B]$$

3.4.2.20 PS_MADDS1 multiply-add scalar low

$$PSO[D] = PSO[A] * PS1[C] + PSO[B]$$

$$PS1[D] = PS1[A] * PS1[C] + PS1[B]$$

3.4.2.21 PS_MSUB multiply-subtract

$$PSO[D] = PSO[A] * PSO[C] - PSO[B]$$

$$PS1[D] = PS1[A] * PS1[C] - PS1[B]$$

3.4.2.22 PS_MUL multiply

```
PSO[D] = PSO[A] + PSO[C]
```

$$PS1[D] = PS1[A] + PS1[C]$$

3.4.2.23 PS_MULS0 multiply scalar high

```
PSO[D] = PSO[A] + PSO[C]
```

$$PS1[D] = PS1[A] + PS0[C]$$

3.4.2.24 PS_MULS1 multiply scalar low

```
PSO[D] = PSO[A] + PSI[C]
```

$$PS1[D] = PS1[A] + PS1[C]$$

3.4.2.25 PS_NMADD negative multiply-add

$$PSO[D] = - (PSO[A] * PSO[C] + PSO[B])$$

$$PS1[D] = - (PS1[A] * PS1[C] + PS1[B])$$

3.4.2.26 PS_NMSUB negative multiply-subtract

$$PSO[D] = - (PSO[A] * PSO[C] - PSO[B])$$

$$PS1[D] = - (PS1[A] * PS1[C] - PS1[B])$$

3.4.2.27 PS_SEL select

```
If (PS0[A] >= 0) then PS0[D] = PS0[C] else PS0[D] = PS0[B]
If (PS1[A] >= 0) then PS1[D] = PS1[C] else PS1[D] = PS1[B]
```

3.4.2.28 PS_SUM0 vector sum high

```
PS0[D] = PS0[A] + PS1[B]
PS1[D] = PS1[C]
```

3.4.2.29 PS_SUM1 vector sum low

PS0[D] = PS0[C] PS1[D] = PS0[A] + PS1[B]

3.4.3 Load and Store Instructions

Mnemonic	Opcode	Description
psq_lx	000100 DDDDD AAAAA BBBBB WIII 000110 0	Paired Singles Quantized Load indexed
psq_lux	000100 DDDDD AAAAA BBBBB WIII 100110 0	Paired Singles Quantized Load with Update indexed
psq_stx	000100 SSSSS AAAAA BBBBB WIII 000111 0	Paired Singles Quantized Store indexed
psq_stux	000100 SSSSS AAAAA BBBBB WIII 100111 0	Paired Singles Quantized Store with Update indexed

Mnemonic	Opcode	Description
psq_l	111000 DDDDD AAAAA WIII ddddddddddd	Paired Singles Quantized Load
psq_lu	111001 DDDDD AAAAA WIII ddddddddddd	Paired Singles Quantized Load with Update
psq_st	111100 SSSSS AAAAA WIII ddddddddddd	Paired Singles Quantized Store
psq_stu	111101 SSSSS AAAAA WIII dddddddddddd	Paired Singles Quantized Store with Update

- **3.4.3.1** psq_lx Paired Singles Quantized Load indexed
- **3.4.3.2** psq_lux Paired Singles Quantized Load with Update indexed
- **3.4.3.3** psq_stx Paired Singles Quantized Store indexed
- 3.4.3.4 psq_stux Paired Singles Quantized Store with Update indexed
- **3.4.3.5** psq_l Paired Singles Quantized Load
- 3.4.3.6 psq_lu Paired Singles Quantized Load with Update
- **3.4.3.7** psq_st Paired Singles Quantized Store
- **3.4.3.8** psq_stu Paired Singles Quantized Store with Update

3.4.4 modified floating point instructions

In paired single mode (HID2[PSE] = 1), all the double-precision floating point instructions are still valid, and execute as in non-paired single mode. All single-precision floating-point instructions (fadds, fsubs, fmuls, fdivs, fmadds, fmsubs, fnmsubs, fres, frsp) switch their meaning and operate on the ps0 operand.

Mnemonic	Opcode	Description
fadds		
fsubs		
fmuls		
fdivs		
fmadds		
fmsubs		
fnmadds		
fnmsubs		
fres		
frsp		
fsel		
fmr		

3.4.4.1	fadds
J.T.T.1	iauus

3.4.4.2 fsubs

3.4.4.3 fmuls

3.4.4.4 fdivs

3.4.4.5 fmadds

3.4.4.6 fmsubs

3.4.4.7 fnmadds

3.4.4.8 fnmsubs

3.4.4.9 fres

3.4.4.10 frsp

3.4.4.11 fsel

3.4.4.12 fmr

3.5 Programming Tips and additional information

3.5.1 Machine State Register

to do

3.5.2 Caches

to do

3.5.3 branch unit

to flush branch unit's dynamic prediction logic, you must sequentially execute 3 branches

b label1
label1: b label2
label2: b label3
label3:

4 Memory Map

4.1 Overview

start	end	size	description
0x00000000	0x017fffff	24MB	Physical address of the RAM
0x80000000	0x817fffff	24MB	Logical address of the RAM, cached
0xC0000000	0xC17fffff	24MB	Logical address of the RAM, not cached
0xc8000000		2MB	Embedded Framebuffer (EFB)
0xCC000000			Hardware registers
0xCC000000			CP - Command Processor
0xCC001000			PE - Pixel Engine
0xCC002000			VI - Video Interface
0xCC003000			PI - Processor Interface (Interrupt Interface)
0xCC004000			MI - Memory Interface
0xCC005000			AI - Audio Interface
0xCC006000			DI - DVD Interface
0xCC006400			SI - Serial Interface
0xCC006800			EXI - External Interface
0xCC006C00			Streaming Interface
0xCC008000			GX FIFO (Graphic display lists)
0xe0000000	0xe0003fff	16k	L2 Cache
0xfff00000		1MB	IPL (mapped here at bootup)

4.2 RAM usage

Variables that are marked as B are changed by bootrom or IPL. Variables marked as A are changed lately in apploader when a game is booting. Variables, which are marked as O are changed after an OSInit call. Remember that the IPL also has a hard-linked Dolphin OS inside, so those variables that are marked as O are also changed in the IPL.

4.2.1 Dolphin-OS globals

In PowerPC architectures the lower 256 bytes of main memory are reserved for internal OS use. This map describes all known OS low memory variables. Dolphin OS accesses low memory as 0x80000000 + offset (cached).

4.2.1.1 Boot Info

4.2.1.1.1 DVD Disc ID

start	size		description
0x80000000	0x04	В	Gamecode
0x80000004	0x02	В	Company
0x80000006	0x01	В	Disk ID
0x80000007	0x01	В	Version
0x80000008	0x01	В	Streaming
			0 audio streaming off
			1 audio streaming on
0x80000009	0x01	В	StreamBufSize
0x8000000a	0x0f		padding zeros

start	size		description			
0x8000001c		Α	DVD magic word			
			0xc2339f3d	Nintendo Game Disc		
0x80000020	4	Α	Magic word (ho	ow did the console boot?)		
			value	description		
			0x0D15EA5E	normal boot		
			0xE5207C22	booted from jtag		
0x80000024	4	Α	Version (usually	y set to 1 by apploader)		
0x80000028	4	В	physical Memor	ry Size		
			0x01800000	24MB on retail console		
0x8000002C	4	В	Console type			
			value	Description		
			0x00000001	Retail1		
			0x00000002	HW2 production board		
			0x00000003	The latest production board		
			0x0000004	Reserved		
			0x1XXXXXXX	Devkits		
			0x10000000	MAC emulator		
			0x10000001	PC Emulator		
			0x10000002	'Arthur'		
			0x10000003	'Minnow'		
			0x10000004	1st Devkit HW		
			0x10000005	2nd Devkit HW		
			0x10000006	latest Devkit HW		
			0x10000007	Reserved		
			0x2XXXXXXX	TDEV-kits		
			0x20000005	HW2 TDEV system		
			0x20000006	The latest TDEV system		
			0x20000007	Reserved		
0x80000030	4	О	ArenaLo (==0x			
0x80000034	4	О	ArenaHi (==0x			
0x80000038	4		FST Location in ram (==0x817fe8c0)			
0x8000003C	4		FST Max Length (==0x00000024)			

4.2.1.1.2 system Info

4.2.1.2 Debugger info

start	size		description
0x80000040	4	A	flag for "debugger present" (used byOSIsDebuggerPresent)
0x80000044	4	A	Debugger Exception mask Bitmap, set to 0 at sdk lib start
0x80000048	4	A	Exception hook destination (physical address)
0x8000004c	4	Α	Temp for LR, Return from exception address (to return from hook)
0x80000050	16		padding zeros

4.2.1.3 Debugger Hook .>80000060 38 a0 00 40 li r5,0x40 r5=0x40 .>80000064 7c 68 02 a6 mflr r3 r3=lr .>80000068 90 65 00 0c stw r3,0x0c(r5) .>8000006c 80 65 00 08 lwz r3,0x08(r5) .>80000070 64 63 80 00 oris r3,r3,0x8000 .>80000074 7c 68 03 a6 mtlr r3 lr=r3

.>80000078 38 60 00 30 li r3,0x30 .>8000007c 7c 60 01 24 mtmsr r3 .>80000080 4e 80 00 20 blr

msr=0x30

jump (lr)

4.2.1.4 Dolphin OS Globals

start	end	size		description		
0x80000084	0x800000bf			padding zeros		
0x800000c0		4	О	Current OS context (physical address)		
0x800000C4		4	О	Previous OS interrupt mask		
0x800000C8		4	О	current OS interrupt mask		
0x800000CC				TV Mode		
				value description		
				0 ntsc		
				1 pal		
				2 debug		
				3 debug pal		
				4 mpal		
				5 pal 60		
0x800000d0			В	ARAM size (internal+expansion) in bytes. set by ARAM driver, usually 16mb.		
0x800000D4			О	current OS Context (logical address)		
0x800000D8			О	default OS thread (logical address)		
0x800000Dc			О	active Thread queue, head thread (logical address)		
0x800000e0			О	active Thread queue, tail thread (logical address)		
0x800000e4			О	Current OS thread		
0x800000e8			A	Debug monitor size (in bytes)		
0x800000ec			A	Debug monitor location (usually at the top of main memory)		
0x800000F0			A	Console Simulated Memory Size, 0x01800000 (usually same as physical memor		
0x800000F4			A	DVD BI2 location in main memory (size of BI2 is 0x2000 bytes)		
0x800000F8				Bus Clock Speed, 162 MHz (=0x09a7ec80, 162000000)		
0x800000FC				CPU Clock Speed, 486 MHz (=0x1cf7c580, 486000000)		

4.2.2 Exception Handlers

start	end	size	description
0x80000100			System Reset Interrupt
0x80000200			Machine Check Interrupt
0x80000300			DSI Interrupt
0x80000400			ISI Interrupt
0x80000500			External Interrupt
0x80000600			Alignment Interrupt
0x80000700			Program Interrupt
0x80000800			FP unavailable Interrupt
0x80000900			Decrementer Interrupt
0x80000C00			System Call Interrupt
0x80000d00			Trace Interrupt
0x80000f00			Performance Monitor Interrupt
0x80001300			IABR Interrupt
0x80001400			reserved
0x80001700			Thermal Interrupt
0x80001800	0x80002fff		unused/reserved (*)

(*) note: psoload v2 uses this area to stay resident in memory, it is unused by Dolphin-OS

4.2.3 Dolphin-OS globals

start	end	size		Description		
0x80003000				exception handler vectors (from sdk libs & ipl)		
0x8000303c		4		padding/unused		
0x80003040				external inter	rrupt handler v	vectors (from sdk libs & ipl)
0x800030a4				padding/unus	sed	
0x800030c0		4		?		
0x800030c4		4		?		
0x800030c8		4		First Module	Header Point	er in Module Queue
0x800030cc		4		Last Module	Header Point	er in Module Queue
0x800030d0		4		Module Strin	ng Table Point	er
0x800030d4		4	Α			t/data sections), in bytes (*1)
0x800030d8		4	В	OS system time (set, when console is powered up)		
0x800030dc		4		?		
0x800030E0		4		? (6=production pads ?)		
0x800030e4		2		?		
0x800030e6		1		?		
0x800030e7		1		?		
0x800030e8		1	О	set by OsInit() (debugger stuff?)		
0x800030e9		1	О	set by OsInit() (debugger stuff?)		
0x800030ea		2		?		
0x800030ec		4		?		
0x800030F0		2		?		
0x800030F2		1		Boot status		
					escription	
					first boot	
					eady booted	
0x800030F3		1		?		
0x800030F4		4		?		
0x800030F8		4		?		
0x800030Fc		4		?		

(*1) If FST on DVD is placed after DOL, then BB2 FSTLength is added to this value.

4.2.4 User Memory

4.2.4.1 user program area

start	end	size	description
0x80003100			Start of code (usually)
0x80003140			Entry point (early SDK v1.0 applications)
0x81200000			Load Address of the Apploader
0x81300000			Load Address of Bootrom/IPL

note: of course the entrypoint of an application can be anything, those listed here are just some typical examples. Retail game start dol-files are usually located below the apploader.

4.2.4.2 stack area

start	end	size	description
			Bottom of Stack
			Top of Stack

4.2.4.3 heap area

start	end	size		description
?			О	ArenaLo - Bottom of Heap
0x817fe8c0			О	ArenaHi - Top of Heap

note: the address of ArenaHi is not a constant, but should be set to the bottom of the FST which is read from the DVD so its size depends on the application. the value given here is just an example.

4.2.4.4 'high memory'

start	end	size		description
0x817fe8c0		24	О	FST (used by Dolphin-OS)
0x817fffff				Memory Top

5 Hardware Registers

5.1 CP - Command Processor

Registerblock	Ba	se	Siz	e of Registerblock	common access size
0xcc0000	00			0x80	2
0xCC000000	2	R	/W	SR - Status Register	r

15	8	7	0

bit(s)	description
5-15	unused/reserved
4	BP (breakpoint?) interrupt
3	GP is idle for commands (1: idle)
2	GP is idle for reading (1: idle)
1	gx fifo underflow (ptr <lo th="" watermark)<=""></lo>
0	gx fifo overflow (ptr>hi watermark)

0xCC000002	2	R/W	CR - Control Register
------------	---	-----	-----------------------

15	8	7	0
		bl	.mig

bit(s)		description
6-15		unused/reserved
5	b	bp enable
4	1	gp link enable (enable for linking of cp/pe FIFO)
3		FIFO underflow irq enable (?)
2	m	FIFO overflow irq enable? / cp irq (clear to acknowledge)?
1	i	cp irq enable (?) (write 1 to clear bp irq?)
0	g	gp FIFO read enable

0xCC000004 2 W Clear Register

bit(s)	description
2-15	unused/reserved
1	write 1 to clear FIFO underflow
0	write 1 to clear FIFO overflow

0xCC00000E	2	R/W	token register

	0xCC000010	2	R/W	bounding box - left
--	------------	---	-----	---------------------

0xCC000012	2	R/W	bounding box - right

0xCC000014	2	R/W	bounding box - top

0xCC000016	2	R/W	bounding box - bottom
------------	---	-----	-----------------------

2	R/W	cp FIFO base lo
2	R/W	cp FIFO base hi
2	R/W	cp FIFO end lo
2	R/W	cp FIFO end hi
2	R/W	cp FIFO high watermark lo
2	R/W	cp FIFO high watermark hi
2	R/W	cp FIFO low watermark lo
2	R/W	cp FIFO low watermark hi
	2 2 2 2	2 R/W

the low and high watermark control the assertion of the CP interrupt

0xCC000030	2	R/W	cp FIFO read/write distance lo
0xCC000032	2	R/W	cp FIFO read/write distance hi
0xCC000034	2	R/W	cp FIFO write pointer lo
0xCC000036	2	R/W	cp FIFO write pointer hi
0xCC000038	2	R/W	cp FIFO read pointer lo
0xCC00003a	2	R/W	cp FIFO read pointer hi
0xCC00003c	2	R/W	cp FIFO bp lo
0xCC00003e	2	R/W	cp FIFO bp hi

5.1.1 Token register

You can insert this dirty marker, at the end of command list, by this way :

```
*(u32 *)GXFIFO = 0x4800XXXX
*(u32 *)GXFIFO = 0x4700XXXX
```

Where XXXX is the token value. When command processor reaches this stage, it writes XXXX into PE token register (see above), and then raise "PE TOKEN" interrupt. Thus you can monitor the completion of your drawing tasks.

note: its probably a good idea to send a BP 'drawing complete' command (0x45000002) before the in-

sertion of the token.

5.2 PE - Pixel Engine

Registerblock Base			Size of Registerblock			common access size
0xcc0010	2001000			0x100		2
0001000	2	DΛ	17	7 configuration		

0xcc001000	2	R/W	Z configuration
------------	---	-----	-----------------

15	8	7	0

bit(s)	description	
4	Z update enable	
1-3	function	
0	z-comperator enable	

0xcc001002	2	R/W	Alpha configuration

15	8	7	0

bit(s)	description
12-15	blend operator (?)
11	substractive / additive toggle (?)
8-10	source
5-7	destination
4	alpha update enable
3	color update enable
2	dither enable (?)
1	arithmetic blending enable (?)
0	boolean blending enable (?)

0xcc001004 2 R/W destination alpha
--

15	8	7	0

bit(s)	description
8	enable
0-7	alpha

0xcc001006	2.	R/W	Alpha Mode

15	8	7	0

bit(s)	description
8-15	mode
0-7	threshold

0xcc001008	2	R/W	Alpha Read (?)
------------	---	-----	----------------

15	8	7	0

bit(s)	description
	mode
2	?

0xcc00100a 2 R/W Interrupt Status Register
--

15	8	7	0

bit(s)	description
3	PE Finish (set to acknowledge)
2	PE Token (set to acknowledge)
1	PE Finish enable (?)
0	PE Token enable (?)

0xcc00100e	2	R/W	PE Token?
------------	---	-----	-----------

15	8	7	0
tttt	tttt	tttt	tttt

bit(s)		description	
0-15	t	PE Token (asserted from last PE Token Interrupt)	

5.3 VI - Video Interface

Registerblock	Bas	e S	Size of Registerblock	common access size
0xcc0020	00		0x100	4
0~~~~000	2	D/V	W VTP Vertical Tim	ing Pagister

0xCC002000	2	R/W	VTR - Vertical Timing Register
------------	---	-----	--------------------------------

l	15	8	7	0
	00aa	aaaa	aaaa	eeee

bit(s)		description
4-13	a	ACV - Active Video (in full Lines) ? other source says halflines
0-3	e	EQU - Equalization pulse in half lines

pal50/pal60/ntsc: 0x11F5, 0x0F06, 0x0F06

The value in ACV is double buffered

0xCC0	02002	2	R/W	DC	R - Display Configuration Register
15	8	7		0	
0000	qq00	11	.tt d	ire	

bit(s)		description
	p	FMT - Current Video Format
		0 NTSC
		1 PAL
		2 MPAL
		3 Debug
	1	LE1 - Enables Display Latch 1
		0 Off
		1 On for 1 field
		2 On for 2 fields
		3 Always On
	t	LE0 - Enables Display Latch 0
		0 Off
		1 On for 1 field
		2 On for 2 fields
		3 Always On
	d	DLR - Selects 3D Display Mode
	i	NIN - Interlace Selector
		0 Interlaced
		1 Non-Interlaced, top field drawn at field rate and bottom field is not displayed
	r	RST - Reset - Clears all data requests and puts VI into its idle state.
	e	ENB - Enable - Enables video timing generation and data request.

pal50/pal60/ntsc: 0x0101, 0x0001, 0x0001

l	0xCC002004	4	R/W	HTR0 - Horizontal Timing 0

31	24	23	16	15	8	7	0
Osss	SSSS	0eee	eeee	0000	w000	WWWW	WWWW

bit(s)		description
	S	HCS - Horizontal Sync Start to Color Burst Start
	e	HCE - Horizontal Sync Start to Color Burst End
	W	HLW - Halfline Width (W*16 = Width (720))

pal50/pal60/ntsc: 0x4B6A01B0, 0x476901AD, 0x476901AD

53

ı	0xCC002008	4	R/W	HTR1 - Horizontal Timing 1

31	24	23	16	15	8	7	0
0000	Osss	SSSS	ssse	eeee	eeee	еммм	WWWW

bit(s)		description
	s	HBS - Half line to horizontal blanking start
	e	HBE - Horizontal Sync Start to horizontal blank end
	w	HSY - Horizontal Sync Width

pal50/pal60/ntsc: 0x02F85640, 0x02EA5140, 0x02EA5140

Setting bit 0 seems to blackout the screen. (Similar to ViBlack?)

0xCC00200C	4	R/W	VTO - Odd Field Vertical Timing Register

31	24	23	16	15	8	7	0
	ss	SSSS	SSSS		rr	rrrr	rrrr

bit(s)		description
16-25	S	PSB - Post blanking in half lines
0-9	r	PRB - Pre-blanking in half lines

pal50/pal60/ntsc: 0x00010023, 0x00030018, 0x00030018

This register sets up the pre-blanking and post-blanking interval of odd fields, PRB and PSB are double-buffered.

31	24	23	16	15	8	7	0
	ss	SSSS	SSSS		rr	rrrr	rrrr

	bit(s)		description
	16-25	S	PSB - post-blanking in halflines
Γ	0-9	r	PRB - pre-blanking in halflines

pal50/pal60/ntsc: 0x00000024, 0x00020019, 0x00020019

This register sets up the pre-blanking and post-blanking intervals of even fields. PRB and PSB are double-buffered.

54

	0xCC002014	4	R/W	BBEI - Odd Field Burst Blanking Interval Register
--	------------	---	-----	---

31	24	23	16	15	8	7	0

bit(s)	description
21-31	BE3 - Field 3 start to burst blanking end in halflines
16-20	BS3 - Field 3 start to burst blanking start in halflines
5-15	BE1 - Field 1 start to burst blanking end in halflines
0-4	BS1 - Field 1 start to burst blanking start in halflines

pal50/pal60/ntsc: 0x4D2B4D6D, 0x410C410C, 0x410C410C

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description
21-31	BE4 - Field 4 start to burst blanking end in halflines
16-20	BS4 - Field 4 start to burst blanking start in halflines
5-15	BE2 - Field 2 start to burst blanking end in halflines
0-4	BS2 - Field 2 start to burst blanking start in halflines

pal50/pal60/ntsc: 0x4D8A4D4C, 0x40ED40ED, 0x40ED40ED

31	24	23	16	15	8	7	0
ууу?	ZZZZ	aaaa	aaaa	aaaa	aaax	XXXX	XXXX

bit(s)		description
29-31	у	always zero (maybe some write only control register stuff?, setting bit 31 clears bits 31-28 (?))
28		page offset bit (*1)
24-27	Z	XOF - Horizontal Offset of the left-most pixel within the first word of the fetched picture.
9-23	a	FBB - bit 23 - bit 9 of XFB Address (*2)
0-8	X	unused (?)

pal50/pal60/ntsc: 0x00435A4E, 0x00435A4E, 0x00435A4E

This register specifies the display origin of the top field of a picture in 2D mode or for the left picture in 3D mode (*1) when this bit is set, the framebuffer address is calculated as (address>>5)

(*2) if bit 28 is cleared, highest possible Address: 0x80fffe00 (set register to 0x00fffe00) (aligned to 9bit)

	0xCC002020	4	R/W	TFBR - Top Field Base Register (R) (Only valid in 3D Mode)
ľ		<u> </u>		

31	24	23	16	15	8	7	0
0000	0000	ffff	ffff	ffff	fff0	0000	0000

bit(s)		description
	f	FBB - External Memory Address of frame buffer

pal50/pal60/ntsc: 0x00000000, 0x00000000, 0x00000000

This register specifies the base address of the top field for the right picture in 3D mode.

0xCC002024 | 4 | R/W | BFBL - Bottom Field Base Register (L) (External Framebuffer Half 2)

31	24	23	16	15	8	7	0
УУУУ	УУУУ	aaaa	aaaa	aaaa	aaax	XXXX	XXXX

bit(s)		description
	у	always zero (maybe some write-only control register stuff?)
28		page offset bit (*1)
	a	FBB - bit 23 - bit 9 of XFB Address
	X	unused (?)

pal50/pal60/ntsc: 0x00435A4E, 0x00435A4E, 0x00435A4E

This register specifies the display origin of the bottom field of a picture in 2D mode or for the left picture in 3D mode

(*1) when this bit is set, the framebuffer address is calculated as (address>5)

BFBR - Bottom Field Base Register (R) (Only valid in 3D Mode) 0xCC002028 R/W

31	24	23	16	15	8	7	0
0000	0000	ffff	ffff	ffff	fff0	0000	0000

bit(s)		description
	f	FBB - External Memory Address of frame buffer

pal50/pal60/ntsc: 0x00000000, 0x00000000, 0x00000000

specifies the base address of the bottom field for the right picture in 3D mode.

0xCC00202C 2 R DPV - current vertical Position

ĺ	15	8	7	0
	0000	0vvv	VVVV	VVVV

bit(s)		description
	V	VCT - current vertical Position of Raster beam

pal50/pal60/ntsc: 0x013C, 0x0005, 0x0000

0xCC00202E		2	R	DPH -	current horizontal Position (?)
15	8	7		0	
0000	0hhh	hh	hh	hhhh	

ĺ	bit(s)		description
ĺ		h	HCT - current horizontal Position of Raster beam (?)

pal50/pal60/ntsc: 0x0144, 0x0176, 0x0000

The Horizontal Count is in pixels and runs from 1 to # pixels per line. It is reset to 1 at the beginning of every line.

The Vertical Count is in lines (on a frame basis) and runs from 1 to # lines per frame. It is 1 at the beginning of pre-equalization. This is a frame line count. So for example: for NTSC vcount=264 is the first (full) line in the second field and vcount=525 is the last line in the frame (fields being numbered 1-4). For non-interlaced modes vcount is on a field-by-field basis (for NTSC vcount ranges from 1-263).

This counting scheme applies the Display Position, Display Interrupt, and Display Latch registers.

0xCC002030	4	R/W	DI0 - Display Interrupt 0
			_

31	24	23	16	15	8	7	0
i00e	00vv	VVVV	VVVV	0000	00hh	hhhh	hhhh

bit(s)		description
31	i	INT - Interrupt Status (1=Active) (Write to clear)
28	e	ENB - Interrupt Enable Bit
16-25	v	VCT - Vertical Position
0-9	h	HCT - Horizontal Position

pal50/pal60/ntsc: 0x113901B1, 0x110701AE, 0x110701AE

There are a total of four display interrupt registers (0-3). They are used to generate interrupts to the main processor at different positions within a field. Each register has a separate enable bit. The interrupt is cleared by writing a zero to the status flag (INT).

0xCC002	2034	4	R/W	DI1 - Display Interrupt 1
---------	------	---	-----	---------------------------

pal50/pal60/ntsc: 0x10010001, 0x10010001, 0x10010001

Refer to Display Interrupt 0

0xCC002038 R/W DI2 - Display Interrupt 2

pal50/pal60/ntsc: 0x00010001, 0x00010001, 0x00010001

Refer to Display Interrupt 0

pal50/pal60/ntsc: 0x00010001, 0x00010001, 0x00010001

Refer to Display Interrupt 0

0xCC002040	4	R/W	DL0 - Display Latch Register 0
------------	---	-----	--------------------------------

bit(s)	Description
31	TRG - Trigger Flag
16-26	VCT - Vertical Count
0-10	HCT - Horizontal Count

pal50/pal60/ntsc: 0x0000, 0x0000, 0x0000

The Display Latch Register 0 latches the value of the Display Position Register at the rising edge of the gt0 signal. The trigger flag is set if a gun trigger is detected. Writing a zero to the register clears the trigger flag.

pal50/pal60/ntsc: 0x0000, 0x0000, 0x0000

See the description of Display Latch Register 0. This register is latched on the rising edge of the gt1 signal.

0xCC002048	2	R/W	HSW - Scaling Width Register

15	8	7	0

	bit(s)	description
ĺ	0-9	SRCWIDTH - Horizontal Stepping size

pal50/pal60/ntsc: 0x2850, 0x2850, 0x2850

This register is the number of source pixels to be scaled. This is only used when the Horizontal Scaler is enabled. For example, if the image is to be scaled from 320x240 to 640x240, 320 would be written into this register.

0xCC00204a	2	R/W	HSR - Horizontal Scaling Register
------------	---	-----	-----------------------------------

15	8	7	0
000e	000v	VVVV	VVVV

bit(s)		description
12	e	HS_EN - Enable Horizontal Scaling
0-8	v	STP - Horizontal stepping size (U1.8 Scaler Value) (0x160 Works for 320)

pal50/pal60/ntsc: 0x0100, 0x0100, 0x0100

This register sets up the step size of the horizontal stepper.

ARDWARE REGISTERS

58

0xC	C0020)4C	4	R/W	FCT0 - Filt			er Coefficient Table 0 (AA stuff)
31	24	23	16	15	8	7	0	

bit(s)	description
20-29	T2 - Tap2
10-19	T1 - Tap1
0-9	T0 - Tap0

pal50/pal60/ntsc: 0x1AE771F0, 0x1AE771F0, 0x1AE771F0

sets up part of the low-pass filter. Taps 0 to 9 are in the range (0.0, 2.0)

0xcc002050	4	R/W	FCT1 - Filter Coefficient Table 1 (AA stuff)

31	24	23	16	15	8	7	0

bit(s)	description
20-29	T5 - Tap5
10-19	T4 - Tap4
0-9	T3 - Tap3

pal50/pal60/ntsc: 0x0DB4A574, 0x0DB4A574, 0x0DB4A574

0xcc002054	4	R/W	FCT2 - Filter Coefficient Table 2 (AA stuff)

31	24	23	16	15	8	7	0

bit(s)	description
20-29	T8 - Tap8
10-19	T7 - Tap7
0-9	T6 - Tap6

pal50/pal60/ntsc: 0x00C1188E, 0x00C1188E, 0x00C1188E

sets up part of the low-pass filter

0xcc002058 | 4 | R/W | FCT3 - Filter Coefficient Table 3 (AA stuff)

59

31	24	23	16	15	8	7	0

bit(s)	description
24-31	T12 - Tap12
16-23	T11 - Tap11
8-15	T10 - Tap10
0-7	T9 - Tap9

 $pal50/pal60/ntsc:\ 0xC4C0CBE2,\ 0xC4C0CBE2,\ 0xC4C0CBE2$

sets up part of the low-pass filter. Taps 9 to tap 24 are in the Rage (-0.125, 0.125)

31	24	23	16	15	8	7	0

bit(s)	description
24-31	T16 - Tap16
16-23	T15 - Tap15
8-15	T14 - Tap14
0-7	T13 - Tap13

pal50/pal60/ntsc: 0xFCECDECF, 0xFCECDECF, 0xFCECDECF

0xcc002060 | 4 | R/W | FCT5 - Filter Coefficient Table 5 (AA stuff)

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24-31	T20 - Tap20
16-23	T19 - Tap19
8-15	T18 - Tap18
0-7	T17 - Tap17

 $pal50/pal60/ntsc:\ 0x13130F08,\ 0x13130F08,\ 0x13130F08$

60

0xcc002064 4 R/W	FCT6 - Filter Coefficient Table 6 (AA stuff)
----------------------	--

31	24	23	16	15	8	7	0

bit(s)	description
24-31	T24 - Hardwired to zero
16-23	T23 - Tap23
8-15	T22 - Tap22
0-7	T21 - Tap21

 $pal50/pal60/ntsc:\ 0x00080C0F,\ 0x00080C0F,\ 0x00080C0F$

sets up part of the low-pass filter

0xcc002068	4	R/W	? ((AA stuff)

pal50/pal60/ntsc: 0x00FF0000, 0x00FF0000, 0x00FF0000

0xCC00206C	2	R/W	VICLK - VI Clock Select Register

15	8	7	0
0000	0000	0000	000s

bit(s)		desc	description		
		0	27 MHz video CLK		
	8	1	54 MHz video CLK (used in Progressive Mode)		

pal50/pal60/ntsc: 0x0000, 0x0000, 0x0000

ſ	0xCC00206e	2	R/W	VISEL - VI I	DTV	Status Register

15	8	7	0

bit(s)	description
2	VISEL - don't care

pal50/pal60/ntsc: 0x0000, 0x0000, 0x0000

this register allows software to read the status of two i/o pins

0xCC002070	2	R/W	?

Holds 0x280, but has no effect on change (maybe for Progressive ?)

pal50/pal60/ntsc: 0x0280, 0x0280, 0x0280

15	8	7	0

ĺ	bit(s)	description	
ĺ	15	BRDR_EN - Border Enable	
ĺ	0-9	HBE656 - Border Horizontal Blank End	

pal50/pal60/ntsc: 0x0000, 0x0000, 0x0000

This register (in conjunction with the border HBS) sets up a black border around the actual active pixels in debug mode. This was done in order to accommodate certain encoders that only support 720 active pixels. The border HBE and HBS can be programmed for 720 active pixels while the regular HBE and HBS can be programmed to the actual active width. This allows the frame buffer to be of any width without having to manually set up a border in memory. These registers will only take effect if enabled and in debug mode.

0xcc002074 2 r/w HBS - Border HBS

15	8	7	0

bit(s)	description
0-9)	HBS656 - Border Horizontal Blank start

pal50/pal60/ntsc: 0x0000, 0x0000, 0x0000

0xcc002076 2 ?/? ? (unused?)

pal50/pal60/ntsc: 0x00FF, 0x00FF, 0x00FF

0xcc002078 4 ?/? ? (unused?)

pal50/pal60/ntsc: 0x00FF00FF, 0x00FF00FF, 0x00FF00FF

0xcc00207c 4 ?/? ? (unused?)

pal50/pal60/ntsc: 0x00FF00FF 0x00FF00FF, 0x00FF00FF

5.3.1 Video Modes

Mode	TV Norm / Region	Framerate	Columns	Lines
NTSC	ntsc (usa, japan)	60Hz	640	480
PAL	pal (europe)	50Hz	640	574
DEBUG				
DEBUG PAL				
MPAL	pal (brazil)	60Hz	640	480
PAL60	pal	60Hz	640	480

note: other modes may be possible using VGA output, although its unlikely.

5.4 PI - Processor Interface

Regist	terblock	Ba	se	Size of	Registe	rblock	common access size			
0x	cc0030	00			0x100	4				
0xCC0	03000	4	r	INTSR - interrupt cause						
2.1	0.4			1.0	1.5	0	7	0		
31	24	23	i	16	15	8	1	- 0		
				r						

bit			Description
17-31			unused/reserved
16	r	RSWST	Reset Switch State (1 when pressed)
14-15			unused/reserved
13		HSP	High Speed Port
12		DEBUG	External Debugger
11		CP	Command FIFO
10		PE FINISH	Frame is Ready
9		PE TOKEN	Token Assertion in Command List
8		VI	Video Interface
7		MEM	Memory Interface
6		DSP	DSP
5		AI	Streaming
4		EXI	EXI
3		SI	Serial
2		DI	DVD
1		RSW	Reset Switch
0		ERROR	GP runtime error

0xCC0	03004	4	r/w	INT	nask			
31	24	23		16	15	8	7	0
			• •					

bit		Description
13	HSP	High Speed Port
12	DEBUG	External Debugger
11	CP	Command FIFO
10	PE FINISH	Frame is Ready
9	PE TOKEN	Token Assertion in Command List
8	VI	Video Interface
7	MEM	Memory Interface
6	DSP	DSP
5	AI	Streaming
4	EXI	EXI
3	SI	Serial
2	DI	DVD
1	RSW	Reset Switch
0	ERROR	GP runtime error

0xCC00300c	4	r/w	FIFO Base Start
------------	---	-----	-----------------

0xCC003010	4	?/?	FIFO Base End?
0xCC003014	4	?/?	PI (cpu) FIFO current Write Pointer?
0xCC003018	4	?/?	?
	•		
0xCC00301c	4	?/?	?
0xCC003020	4	?/?	?
0xCC003024	4	?/?	Reset?

Writing anything here seems to cause a complete reset.

console type (2: hw2)

0xCC0	0302c	4	?/?	?					
31	24	23	3	16)	15	8	7	0
hit(s)	De	escri	ntion						

5.4.1 Operation

28-31

5.4.1.1 FIFO/Write Gather Pipe when CPU writes a byte to 0xcc008000, it is written to mem[writeptr], and writeptr is increased automatically.

0xcc008000 is the write gather pipe, a way for the CPU to blast sequences of things of various sizes to memory without having to keep track of the write pointer and wrapping manually. the gp then reads what the CPU has written to memory. It is used for Display Lists. it will disconnect the GP from the writegatherpipe (cc000002 & 0x10 = 0), and change the write ptr to where it wants to write a display list.. then use ordinary GX commands to build it. there's a Call Displaylist GX command. so it will store render commands for rendering a certain object (for example) in a display list in memory, then send the CallDL with the address to the list instead of sending all the vertices over the FIFO.

5.4.1.2 Interrupts Each interrupt has one or more "source" devices. It means that some kind of device may generate a couple of different interrupts, represented by a single bit in interrupt registers. To "enable" interrupt, set bit in mask register. To ignore all interrupts write 0 to interrupt mask register. Raising of any interrupt will set corresponding bit in interrupt cause register. Interrupt cause register resets to 0, when read (i.e. you must read it to clear pending interrupts).

Interrupt mask register isn't controlled by hardware logic. Note that masking of interrupt in INTMR doesn't disable it at all. It is only causing masked interrupt to be ignored in the software interrupt handler. You must clear corresponding "source" device registers, to completely disable interrupt.

```
lis r3,0
lis r9,0xCC00
sth r3, 0x2000(r9)
li r4, 3
stw r4, 0x3024(r9)
stw r3, 0x3024(r9)
nop
loop__:
b loop__
```

5.5 MI - Memory Interface

Protection can be enabled only for pages (page size is 1024 bytes), and you can specify only 4 protected regions of memory. External interrupt will be raised, if CPU try to wrong access in protected region. Because it's allowed to enable protection for 4 regions only, there are a total of 4 possible interrupts which are called MEM_0, MEM_1, MEM_2 and MEM_3.

0xcc004000 0x80 4 0xCC004000 4 r/w Protected Region No1	Registerblock Base	Size of Registerblock	common access size
0xCC004000 4 r/w Protected Region No1	0xcc004000	0x80	4
	0xCC004000 4	Protected Region No	1
0xCC004004 4 r/w Protected Region No2	0xCC004004 4	Protected Region No	2
0xCC004008 4 r/w Protected Region No3	0xCC004008 4	Protected Region No	3
0xCC00400c 4 r/w Protected Region No4	0xCC00400c 4	Protected Region No	4

31	24	23	16	15	8	7	0
1111	1111	1111	1111	hhhh	hhhh	hhhh	hhhh

bit(s)		Description		
16-31	1	Page Address Lo		
0-15	h	Page Address Hi		

note: the page address can be calculated as (physical_address>>10)

0xCC004010	2	r/w	type of the protection, 4*2 bits
------------	---	-----	----------------------------------

15	8	7	0
		3322	1100

bit(s)		Des	Description			
		unus	unused/reserved			
6	3	Cha	Channel 3			
		0	0 access denied			
		1	1 read only (break on write)			
		2	2 write only (break on read)			
		3	read / write (no protection, full access)			
4	2	Cha	Channel 2 (see Channel 3)			
2	1	Cha	Channel 1 (see Channel 3)			
0	0	Cha	nnel 0 (see Channel 3)			

0xCC00401c 2 ?/w MI interrupt mask
--

15	8	7	0
		m	3210

bit(s)		Description
4	m	mask all MI interrupts (1 - enable)
3	3	mask MEM3 interrupt (1 - enable)
2	2	mask MEM2 interrupt (1 - enable)
1	1	mask MEM1 interrupt (1 - enable)
0	0	mask MEM0 interrupt (1 - enable)

0xCC00401e 2 r/w inte

15	8	7	0
		m	3210

bit(s)		Description		
4	m	all MI interrupts		
3	3	MEM3 interrupt		
		read 0 irq has not been requested		irq has not been requested
			1 irq has been requested	
		write	write 0 no effect	
			1	clear pending irq assertion
2	2	MEM2	inter	rupt
		read	0	irq has not been requested
			1 irq has been requested	
		write	write 0 no effect	
			1 clear pending irq assertion	
1	1	MEM1 interrupt		
		read 0 irq has not been requested		
		1 irq has been requested		
		write	rite 0 no effect	
			1 clear pending irq assertion	
0	0	MEM0 interrupt		
		read	read 0 irq has not been requested	
			1	irq has been requested
		write	0	no effect
			1	clear pending irq assertion

0xCC004020	2	?/?	?
------------	---	-----	---

15	8	7	0
			m.

bit(s)		Description
1	1	? (set when MI interrupt has been asserted)
0	0	?

note: assume to be zero, after init, and should be cleared by interrupt handler.

0xCC004022	2	r/?	ADDRLO - address which failed protection rules
------------	---	-----	--

	15	8	7	0
ſ				

bit(s)	Description
5-15	bit 5-bit 15 of address
0-4	zero

	0xCC004024	2	r/?	ADDRHI - address, which failed protection rules
--	------------	---	-----	---

15	8	7	0

bit(s)	Description	
14-15	zero	
0-13	bit 16-bit 29 of address	

RHI
RIO
ILC
RHI
RLO

note: writing anything to the timer register resets it to zero

0xCC00405a 2	2 r/?	?
----------------	---------	---

	. XXX	xxxx	XXXX
15	8	7	0

bit(s)	Description
11-15	unused?

5.6 DSP - Digital Signal Processor Interface

At the heart of the GCN audio hardware is a custom digital signal processor (DSP) which is largely dedicated to pitch modulation and the mixing of voices and effects data. The DSP is augmented by a large quantity of auxiliary RAM (ARAM) which may be used to store audio samples. The GCN audio hardware features a custom digital signal processor (DSP) which has the following characteristics:

- ⊳ 81MHz instruction clock.
- ▶ 16-bit data words and addressing.
- ▷ 8KB (4Kword) Data RAM.
- ▷ 4KB (2Kword) Data ROM.
- > 8KB (4Kword) Instruction RAM.
- ⊳ 8KB (4Kword) Instruction ROM.

- ▷ Cached memory interface to ARAM.
- > DMA interface to main memory.
- ▷ "Mailbox" registers for communicating with the CPU.

Register block Base			Size of Register block	common access size
0xCC005000			0x200 bytes	16bit words
0xCC005000 2 r/v		r/w	DSP Mailbox High (to	DSP)
0xCC005002	2	r/w	DSP Mailbox Low (to	DSP)

bit31 of DSP Mailbox shows mail delivery status. (it will be cleared when the transfer is done) to send mail just write data, high word first, with bit31 set.

	0xCC005004	2	r	CPU Mailbox High (from DSP)
ĺ	0xCC005006	2	r	CPU Mailbox Low (from DSP)

bit31 of CPU Mailbox shows mail delivery status.

15	8	7	0

bit(s)	Description							
11	Reset DSP (?)							
10	Reset DSF (!)							
9	DSP DMA Int Status							
8	DSPINTMSK - DSP interrupt mask (*1)							
7	DSPINT DSP Interrupt mask (*1)							
/								
	T T							
	1 morrape is active							
	T Clear Interrupt							
5	ARINTMSK - ARAM interupt mask (*2)							
5	ARINT -							
	read 0 no interrupts							
	1 interrupt is active							
	write 0 no effect							
	1 clear interupt							
4	AIDINTMASK - AI interrupt mask (*3)							
3	AIDINT							
	read 0 no interrupts							
	1 interrupt is active							
	write 0 no effect							
	1 clear interrupt							
2	HALT - Halt DSP (?)							
	read 0							
	1							
	write 0 unhalt DSP							
	1 halt DSP (stop task execution)							
1	PIINT - DSP Interrupt Assertion (?)							
	read 0							
	1							
	write 0							
	1 assert PI DSP interrupt							
0	RES - Reset DSP (?)							
	read 0							
	1							
	write 0							
	1 reset DSP							

- (*1) disables only PI interrupt, doesnt effect assertion of DSPINT.
- (*2) disables only PI interrupt, doesnt effect assertion of ARINT. (*3) disables only PI interrupt, doesnt effect assertion of AIDINT.

l	0xCC005012	2	?/?	AR_SIZE
---	------------	---	-----	---------

0xCC005016	2	?/?	AR_MODE
------------	---	-----	---------

0xCC00501a	2	?/?	AR REFRESH

0xCC005020 2 ?/? AR DMA MMADDR	0xCC005020	2	?/?	AR DMA MMADDR	Н
--------------------------------------	------------	---	-----	---------------	---

I	0xCC005022	2	?/?	AR DMA MMADDR L

0xCC005024	2	?/?	AR_DMA_ARADDR_H
------------	---	-----	-----------------

0xCC005026	2	?/?	AR_DMA_ARADDR_L	_

0xCC005028	2	7/7	AR	DMA	CNT	Н

	bit(s)	description
Ì	15	type of transfer (0: write to aram 1: read from aram)
Ì	0-14	high bits of transfer length

0xCC00502a	2	?/?	AR_DMA_CNT_L

0xCC005030	2	2/w	DMA Start address (High)

Start of Audio Data

0xCC005032	2	?/w	DMA Start address (Low)

Start of Audio Data

0xCC005036	2	?/w	DMA Control/DMA length (Length of Audio Data)

15	8	7	0
axxx	XXXX	XXXX	XXXX

ı	bit(s)		Description
		a	0=stop sample 1=play sample
ĺ		X	length/32 (max len is 0x000fffe0)

0xCC00503a 2 r/? 1	DMA Bytes left
--------------------------	----------------

Counts down to zero showing how any bytes are left

5.6.1 internal DSP Registers

Registerblock Base		ock Base Size of Registerblock		common access size	
0xffc9		9		2	
0xFFC9 2 r/w			DSCR - DSP dma Contro	l Register	

15	8	7	0

bit(s)	description						
3-15	unused/reserved						
2	DSP DMA busy						
	read 0						
	1 Block length counter not yet zero, DMA is still busy						
	write 0 no effect?						
	1 no effect ?						
1	DSP source/destination (DMA involved DSP memory)						
	0 DSP data memory						
	1 DSP instruction memory						
0	transfer direction						
	0 from main memory to DSP memory						
	1 from DSP memory to main memory						

0xFFCB	2	r/w	DSBL - DSp dma Block Length
--------	---	-----	-----------------------------

15	8	7	0

bit(s)	description
2-15	block length - This register is used to specify DSP DMA transfer length from bit 15 to bit 2
0-1	r: 2 bit of its LSBs - The transfer length is a multiple of 4 bytes

0xFFCD	2	r/w	DSPA - DSp dma dsP memory Address High
--------	---	-----	--

15	8	7	0

 	description
1-15	DSP memory address - This register is used to specify DSP memory starting/current address from bit 15 to bit 1
0	r: 1 bit of its LSBs - The DSP memory address should be located at 2 word boundary

0xFFCE	2	r/w	DSMAH - DSp dma Main memory Address High
15 8	7	0	

bit(s)	description
10-15	r: 6 bits of its MSBs - This register is used to specify DSP DMA main memory starting/current address from bit
0-9	main memory address high word - This register is used to specify DSP DMA main memory starting/current add

0xFFCF	2	r/w	DSMAL - DSp dma Main memory Address Low

15	8	7	0

bit(s)	description
2-15	main memory address - This register is used to specify DSP DMA main memory starting/current address from b
0-1	r: 2 bits of its LSBs - The main memory address of this DMA should be located at 4 byte boundary

0xFFD4	2	r/w	ACSAH - Accelerator aram Starting Address High

15	8	7	0

bit(s)	description
11-15	unused/reserved
0-10	wtarting address high-word - Bit 26 to bit 16 of ARAM starting address

0xFFD5	2 r/w	0xFFD5	ACSAL - Accelerator aram Starting Address Low
--------	-------	--------	---

15	8	7	0

bit(s)	description
0-15	Starting address low-word - Bit 15 to bit 0 of ARAM starting address

1	OxFFD6	2.	w	ACEAH - Accelerator aram Ending Address High

15	8	7	0

bit(s)	description
15-11	unused/reserved
0-10	ending address high-word - Bit 26 to bit 16 of ARAM ending address

0 x	FFD7	2	W	ACEAL - Accelerator aram Ending Address Low
		•	•	
15	8	7	0	

15	8	7	0

ĺ	bit(s)	description]
	0-15	ending address low-word - Bit 15 to bit 0 of ARAM ending address]

0xFFD8	2	r/w	ACCAH - Accelerator aram Current Address High
--------	---	-----	---

15	8	7	0

bit(s)	description				
15	dire	direction			
	0	accelerator read ARAM			
	1	accelerator write ARAM			
11-14	unused/reserved				
0-10	current address high-word - Bit 26 to bit 16 of ARAM current address				

0xFFD9	2	r/w	ACCAL - Accelerator aram Current Address Low

15	8	7	0

bit(s)	description
0-15	Bit 15 to Bit 0 of ARAM current address

	0xFFEF	2	r/w	AMDM - ARAM-Dma request Mask
--	--------	---	-----	------------------------------

15	8	7	0

bit(s)	description	
1-15	unused/reserved	
0	0 DMA request ARAM is unmask	ed
U	1 DMA request ARAM is masked	

5.6.2 Operation

5.6.2.1 play raw audio sample

- ⊳ load DMA Start Address
- > setup DMA Control/DMA length

5.6.2.2 transfer from/to ARAM

 $\,\rhd\,$ set main memory address in AR_DMA_MMADDR_H and AR_DMA_MMADDR_L

- ▷ set length and transfer type in AR_DMA_CNT_H and AR_DMA_CNT_L

5.6.2.3 reset DSP

⊳ set bit0 and bit11 of AI DSP Control Register

5.6.2.4 Boot DSP Task

⊳ send mail to DSP: 0x80F3A001, ram_mmem_addr

⊳ send mail to DSP: 0x80F3C002, ram_addr

⊳ send mail to DSP: 0x80F3A002, ram_length

⊳ send mail to DSP: 0x80F3B002, aram_mmem_addr (==0 ?)

⊳ send mail to DSP: 0x80F3D001, dsp_init_vector

5.7 DI - DVD Interface

Register block Base	Size of Register block	common access size
0xCC006000	0x40	4

0xCC006000 4 r/v	v DISR - DI Status Register
------------------	-----------------------------

31	24	23	16	15	8	7	0

bit(s)	description							
7-31	reserved							
6	BRKINT - Break Complete Interrupt Status (*1)							
	read 0 Interrupt has not been requested							
	1 Interrupt has been requested							
	write 0 no effect							
	1 clear Interrupt							
5	BRKINTMASK - Break Complete Interrupt Mask. 0:masked, 1:enabled (*2)							
4	TCINT - Transfer Complete Interrupt Status (*3)							
	read 0 Interrupt has not been requested							
	1 Interrupt has been requested							
	write 0 no effect							
	1 clear Interrupt							
3	TCINTMASK - Transfer Complete Interrupt Mask. 0:masked, 1:enabled (*4)							
2	DEINT - Device Error Interrupt Status (*5)							
	read 0 Interrupt has not been requested							
	1 Interrupt has been requested							
	write 0 no effect							
	1 clear Interrupt							
1	DEINTMASK - Device Error Interrupt Mask. 0:masked, 1:enabled (*6)							
0	BRK - DI Break (*7)							
	read 0 break not requested or break complete							
	1 break requested and pending							
	write 0 no effect							
	1 request break							

- (*1) On read this bit indicates the current status of the break complete interrupt. This interrupt is asserted when a Break cycle has completed (break acknowledge received from mass storage access device). When a '1' is written to this register, the interrupt is cleared.
- (*2) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of DISR[BRKINT]
- (*3) On read this bit indicates the current status of the transfer complete interrupt. The Transfer Complete interrupt is asserted under the following conditions: a DMA mode transfer has completed (DMA finished) or an Immediate mode transfer has completed (transfer to/from DIIMMBUF has completed). When a '1' is written to this register, the interrupt is cleared. The assertion of TCIT is delayed until the DIDSTRBb (low) in order to guarantee the error interrupt occurs before transfer complete interrupt. If DIERRb is asserted during the current transaction, the transaction will be halted and TCINT will not be asserted.
- (*4) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of DISR[TCINT]
- (*5) On read this bit indicates the current status of the mass storage access device error interrupt. To clear this interrupt, two actions must occur. When a '1' is written to this register, the internal interrupt is cleared. To reset the DIERRb signal, a command must be issued to the external DI device. If error occurs during the command packet, the drive has to delay the error assertion until the completion of the 12 bytes command transfer. In immediate mode, if error occurs during the data packet, the error assertion has to be delayed until the completion of the 4 bytes data transfer. In DMA mode, it has to be delayed until the completion of any 32 bytes data transfer.
- (*6) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the

assertion of DISR[DEINT]

(*7) When a '1' is written to this bit, the DI controller interrupts the current command and sends a break signal to the mass storage access device. The break signal interrupts the current command on the mass storage access device. After the break sequence is complete (see TCINT), a new command may be sent to the mass storage access device. This bit is cleared after the break command is complete. Note that DI controller will delay the break signal assertion if it is in the middle of the command transfer. Hence break can only occur during the data transfer or when it is idle.

0xCC0	06004	4	r/w	DIC	VR - DI	Cover F	Register	(status2)
31	24	23		16	15	8	7	0
		٠.						.smc

bit(s)		Descrip	tion		
2	s	CVRIN	T - C		
		read	0	cover interrupt has not been requested	
			1	cover interrupt has been requested	
		write	0	no effect	
			1	clear cover interrupt	
1	m	CVRIN	1: enabled (*2)		
0	С	CVR - S	State	of the DICOVER signal. 0: cover closed	, 1: cover opened

(*1) On read this bit indicates the current status of the Mass Storage Device Cover interrupt. When a '1' is written to this register, the internal interrupt is cleared. The Mass Storage Device Cover Interrupt is asserted when the status of the DICOVER signal changes (e.g., when the cover is opened or closed). (*2) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of DISR[CVRINT].

	0xCC0	06008	4	r/w	DIC	MDBUF	F0 - DI C	Comman	d Buffer	. 0
	31	24	23		16	15	8	7	0	
Ì	cccc	cccc	11	11 :	1111	2222	2222	2222	2222	

bit(s)		Description
24-31	С	command
16-23	1	subcommand 1
0-15	2	subcommand 2

0xCC00600c	4	r/w	DICMDBUF1 - DI Command Buffer 1 (offset in 32 bit words)
------------	---	-----	--

0xCC006010	4	r/w	DICMDBUF2 - DI Command Buffer 2 (source length)

0xCC006014 4 r/w DIMAR - DMA Memory Address Register
--

31	24	23	16	15	8	7	0

bit(s)	description
26-31	reserved/unused
5-25	DIMAR - Address of source/destination buffer in main Memory
0-4	always zero (Address must be 32 byte aligned)

0xCC006018	4	r/w	DILENGTH - DI DMA Transfer Length Register
------------	---	-----	--

31	24	23	16	15	8	7	0

bit(s)	description
26-31	reserved/unused
5-25	DILENGTH - length of DMA data transfer in bytes (*1)
0-4	always zero (transfer length must be 32 byte aligned)

(*1) If a DMA command is interrupted by a break cycle, this register indicates the amount of data that was left to transfer before the DMA command was interrupted. If the length equals zero, it is a special case with command transfer only.

31	24	23	16	15	8	7	0
							.mbe

bit(s)		Description
2	m	RW - access mode, 0:read, 1:write
1	b	DMA - 0: immediate mode, 1: DMA mode (*1)
0	e	TSTART - transfer start. write 1: start transfer, read 1: transfer pending (*2)

- (*1) The only mass storage device packet command which can use immediate mode is the 'Register Access' command. When in immediate mode, the DIMAR and DILENGTH registers are ignored.
- (*2) When read this bit represents the current command status. This bit is also cleared after the break completion and after DIERRb is asserted.

0xCC006020	4	r/w	DIIMMBUF - DI immediate data buffer (error code ?)

31	24	23	16	15	8	7	0

bit(s)	description
24-31	REGVAL0 - data of register address+0
16-23	REGVAL1 - data of register address+1
8-15	REGVAL2 - data of register address+2
0-7	REGVAL3 - data of register address+3

0xCC006024	4	r	DICFG - DI Configuration Register

31	24	23	16	15	8	7	0

bit(s)	description
8-31	reserved/unused
0-7	CONFIG - during reset this register latches DIDD bus (only bit 0 used)

5.7.1 Drive Commands

DICMDBUF0	DICMDBUF0 DICMDBUF1	DICMDBUF2 DIMAR	DIMAR	DILENGTH	DILENGTH DIIMMBUF	DICR	Description
0x12000000	0x0000000x0	0x00000020	ret: Drive-Info	0x00000020	1	DMA read	Inquiry
0xa80000000	Data-Position>>2	Data-Length	ret: Sector-Data Data-Length	Data-Length	1	DMA read read Sector	read Sector
0xa8000040	0x0000000x0	0x00000020	ret: Disc-ID	0x00000020	1	DMA read	DMA read read Disc ID/Init Drive
0xa8000080	i	i	i	ż	i	¿	i
0xa80000C0	i	i	i	ż	i	¿	i
0xab000000	Position>>2	ı	ı	ı	ı	imm (read)	seek
0xe00000000	1	1	ı	ı	ret: Error-Code	imm read	request error Status
0xe1??0000	Stream-Position>>2	Stream-Length	ı	ı	1	imm read	play Audio Stream (?)
0xe2??0000	1		ı	ı	ret: Status (?)	imm read	request Audio Status
0xe3000000	1		ı	ı	ı	imm (read) stop Motor	stop Motor
0xe4000000	1		ı	ı	1	imm (read)	imm (read) DVD Audio disable
0xe4010000	-	_	-	ı	-	imm (read)	imm (read) DVD Audio enable

5.7.2 Drive Debug Commands

	DICMDBUFI	BUF1 DICMDBUF2 DIMAR DILENGTH DIIMMBUF	DIMAR	DILENGTH		DICR	Description
0xfe00????	i	i	į	i	3	i	i
0xfe010000	offset	0x00010000		ı	ret: 32bit value imm (read)	imm (read)	read memory
0xfe010100	offset	0x00010000		ı	32bit value	imm (write)	write memory
0xfe018000	offset	0xff0000000		ı	ret: 32bit value imm (read)	imm (read)	read cache
0xfe018100	offset	0xff0000000		ı	32bit value	imm (write)	write cache
0xfe100000	<u>ئ</u>	i		ı	ı	imm (read)	i
0xfe110000 (*)	ı	1		ı	ı	imm (read)	stop drive
0xfe110100 (*)	ı	ı		ı	ı	imm (read)	start drive
0xfe114000 (*)		1	1	-	-	imm (read)	accept copy
0xfe118000 (*)	-	1	,	1	1	imm (read)	do disc-check
0xfe120000	24bit address	0x66756e63	1	ı	ı	imm (read)	jsr to address 'func'
0xff004456	0x442d4741	0x4d450300	1	ı	ı	imm (read)	unlock 2 'DVD-GAME'
0xff014d41	0x54534849	0x5441024f	1	1	1	imm (read)	imm (read) unlock 1 'MATSHITA'

^(*) commands can be ORed to perform several actions at once

5.7.3 Operation

5.7.3.1 Drive Info (Inquiry)

5.7.3.1.1 Structure of the Drive Info Data

Description	size	end	start
revision level	0x02	0x0001	0x0000
device code	0x02	0x0003	0x0002
release date	0x04	0x0007	0x0004
padding zeros	0x18	0x001F	0x0008

5.7.3.2 Read Disc ID / Init Disc

5.7.3.3 Read Sector

5.7.3.4 Seek

5.7.3.5 Request Error

31	24	23	16	15	8	7	0
aaaa	aaaa	nnnn	nnnn	nnnn	nnnn	nnnn	nnnn

bit(s)		descrip	tion	
		0x00	ok	
		0x01	lid	open
	a	0x02	no o	disc/disc changed
	a	0x03	no o	disc
		0x04		tor off
		0x05	disc	e not initialized/disc id not read
		0x000	000	ok
		0x020	400	Motor stopped
		0x020	401	Disk ID not read
		0x023	A00	Medium not present / Cover opened
		0x030	200	No Seek complete
		0x031	100	UnRecoverd read error
		0x040	800	Transfer protocol error
	n	0x052	000	Invalid command operation code
	"	0x052	001	Audio Buffer not set
		0x052	100	Logical block address out of range
		0x052	400	Invalid Field in command packet
		0x052	401	Invalid audio command
		0x052	402	Configuration out of permitted period
		0x056	300	End of user area encountered on this track
		0x062	800	Medium may have changed
		0x0B5	A01	Operator medium removal request

5.7.3.5.1 Error Codes

5.7.3.7 Request Audio Status

5.7.3.8 Stop Motor

5.7.3.9 DVD Audio Disable

5.7.3.10 DVD Audio Enable

- Command/Subcommand/Padding <- E4010000
 </p>
- ⊳ Action <- 1
- ▷ ACK (???)
- Status2 <- Status2
 </p>
- ▷ INIT (???)
- ⊳ Status1 <- 2Ah
- Status 2 <- 0
 </p>

5.7.3.11 Write Mem debug command Note: This command is not really a single command but two commands in sequence.

This command writes 'length' bytes to the specified address 'address' in the DVD drive addressable memory. 'length' is specified in bytes and must be in the range 1 to 12. If more data needs to be written, several commands need to be issued. 'address' is a 24 bit value, but a 32 bit value can be safely used. 'length' is a 16 bit value.

- write the constant 0xfe010100 to DICMDBUF0 (0xCC006008)
- ⊳ write 'length' to the upper 16 bits of DICMDBUF2 (0xcc006010) and clear the lower 16 bits.
- ⊳ start immediate read transfer: write 1 (TSTART) to DICR (0xcc00601c)
- wait until transfer is complete, poll bit 0 (lowest order bit) of DICR (0xcc00601c), it will be cleared on end of transfer
- write the data (up to 'length' bytes) to 0xcc00600c (write the first byte at 0xcc00600c, the second
 at 0xcc00600d, and so on)
- ⊳ start immediate read transfer: write 1 (TSTART) to DICR (0xcc00601c)
- wait until transfer is complete, poll bit 0 (lowest order bit) of DICR (0xcc00601C), it will be cleared
 on end of transfer

5.7.4 DVD-ROM Subsystem

- → Matsushita MN103S13BGA Optical Disk Controller
- → Matsushita MN102H60GFA MicroComputer

5.7.4.1 Memory Map

start	end	size	description
0x00008000		4kb	internal (cpu) ram
0x00080000		128kb	firmware rom (*)
0x00400000			internal (controller) ram

(*) note: reading the firmware at its real location is prevented by the debug commands (imm buffer will not be changed at all). however you can read its contents from the memory mirrors, ie 0x000a0000-.

5.8 SI - Serial Interface

Register bloc	k Ba	ıse	Size of Register block	common access size	
0xCC0064	00		0x100	4	
0xCC006400	4	r/w	SICOOUTBUF - SI C	hannel 0 Output Buffer	(Joy-channel 1 Command)
0xCC00640c	4	r/w	SIC1OUTBUF - SI C	hannel 1 Output Buffer	(Joy-channel 2 Command)
0xCC006418	4	r/w	SIC2OUTBUF - SI C	hannel 2 Output Buffer	(Joy-channel 3 Command)
0xCC006424	4	r/w	SIC3OUTBUF - SI C	hannel 3 Output Buffer	(Joy-channel 4 Command)

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24-31	unused/reserved
16-23	CMD - (*1)
8-15	OUTPUT0 - (*2)
0-7	OUTPUT1 - (*3)

This register is double buffered, so main processor writes to the SIC0OUTBUF will not interfere with the serial interface output transfer. Internally, a second buffer is used to hold the output data to be transferred across the serial interface. To check if SIC0OUTBUF has been transferred to the second buffer, main processor polls the SISR[WRST0] register. When SICOOUTBUF is transferred, SISR[WRST0] is cleared.

- (*1) This byte is the opcode for the command sent to the controller during each command/response packet. This is the first data byte sent from the SI I/F to the game controller in the command/response packet.
- (*2) This is the first data byte of the command packet. It is the second data byte sent from the SI I/F to the game controller in the command/response packet.
- (*3) This is the second data byte of the command packet. It is the third data byte sent from the SI I/F to the game controller in the command/response packet.

0xCC006404	4	r	Joy-channel 1 Buttons 1
0xCC006410	4	r	SIC1INBUFH - SI Channel 1 Input Buffer High (Joy-channel 2 Buttons 1)
0xCC00641c	4	r	Joy-channel 3 Buttons 1
0xCC006428	4	r	Joy-channel 4 Buttons 1

ĺ	31	24	23	16	15	8	7	0
	s	yxba	LR	udrl	XXXX	XXXX	уууу	УУУУ

bit(s)	Description					
31	ERRSTAT - Error Status (*1)					
	0 no error on last transfer					
	1 error on last transfer					
30	ERRLATCH - Error Latch (*2)					
	0 no error latched					
	1 error latched (check SISR)					
24-29	bit 0-5 of input byte 0 (bit 6 and 7 are assumed to be 0)					
16-23	input byte 1					
8-15	input byte 2					
0-7	input byte 3					

- (*1) This bit represents the current error status for the last SI polling transfer on this channel. This register is updated after each polling transfer on this channel.
- (*2) This bit is an error status summary of the SISR error bits for this channel. If an error has occurred on a past SI transfer (polling or Com transfer), this bit will be set. To determine the exact error, read the SISR register. This bit is actually an 'or' of the latched error status bits for this channel in the SISR. The bit is cleared by clearing the appropriate error status bits latched in the SISR. The no response error indicates that a controller is not present on this channel.

	0xCC006408	4	r/w	Joy-channel 1 Buttons 2	
	0xCC006414	4	r/w	Joy-channel 2 Buttons 2	
	0xCC006420	4	r/w	Joy-channel 3 Buttons 2	
Ì	0xCC00642c	4	r S	SIC3INBUFL - SI Channel	3 Input Buffer Low (Joy-channel 4 Buttons 2)

31	24	23	16	15	8	7	0
XXXX	XXXX	уууу	УУУУ	1111	1111	rrrr	rrrr

bit(s)		Description
24-31	X	input byte 4
16-23	у	input byte 5
8-15	1	input byte 6
0-7	r	input byte 7

SIC0INBUFH and SIC0INBUFL are double buffered to prevent inconsistent data reads due to main processor conflicting with incoming serial interface data. To insure data read from SIC0INBUFH and SIC0INFUBL are consistent, a locking mechanism prevents the double buffer from copying new data to these registers. Once SIC0INBUFH is read, both SIC0INBUFH and SIC0INBUFL are 'locked' until SIC0INBUFL is read. While the buffers are 'locked', new data is not copied into the buffers. When SIC0INBUFL is read, the buffers become unlocked again.

31	24	23	16	15	8	7	0
		????	.???		?.	eeee	

bit(s)		description						
26-31		unused/reserved						
16-25		X - 7 X lines register (*1)						
8-15		Y - y times register (*2)						
4-7	e	EN - controller port enable (1 bit per port, 1: enabled) (*3)						
0-3		VBCPY - Vblank copy output channel (1 bit per port) (*4)						
		0 copy SICOUTBUF to output buffer after writing						
		1 copy SICOUTBUF to output buffer only on vblank						

- (*1) 7 X lines register: determines the number of horizontal video lines between polling (the polling interval). The polling begins at vsync. 7 is the minimum setting (determined by the time required to complete a single polling of the controller). The maximum setting depends on the current video mode (number of lines per vsync) and the SIPOLL[Y] register. This register takes affect after vsync.
- (*2) This register determines the number of times the SI controllers are polled in a single frame. This register takes affect after vsync.
- (*3) Enable polling of channel. When the channel is enabled, polling begins at the next vblank. When the channel is disabled, polling is stopped immediately after the current transaction. The status of this bit does not affect communication RAM transfers on this channel.
- (*4) Normally main processor writes to the SICOOUTBUF register are copied immediately to the channel 0 output buffer if a transfer is not currently in progress. When this bit is asserted, main processor writes to channel 0's SICOOUTBUF will only be copied to the outbuffer on vblank. This is used to control the timing of commands to 3D LCD shutter glasses connected to the VI.

	0xCC006434	4	r/w	SICOMCSR - SI Communication Control Status Register (command)
--	------------	---	-----	---

31	24	23	16	15	8	7	0
r?	?ccs	. mmm	mmmm	.nnn	nnnn	eb	?

bit(s)		description							
31	r	TCINT - Transfer Complete Interrupt Status							
		read 0 transfer complete interrupt not requested							
		1 transfer complete interrupt has been requested							
		write 0 no effect							
		1 clear transfer complete interrupt							
30		TCINTMSK - Transfer Complete Interrupt Mask (*1)							
		0 interrupt masked							
		1 interrupt enabled							
29		COMERR - Communication Error							
		0 ok							
		1 error (see SiSr for the cause)							
28		RDSTINT - Read Status Interrupt Status (*2)							
		read 0 Transfer Complete Interrupt not requested							
		1 Transfer Complete Interrupt has been requested							
		write 0							
		1							
27		RDSTINTMSK - Read Status interrupt Mask (*3)							
		0 masked							
		1 enabled							
25-26	с	Channel Number (?)							
24	S	Channel Enable (?)							
23		unused/reserved							
16-22	m	OUTLNGTH - Communication Channel Output Length (*4)							
15		unused/reserved							
8-14	n	INLNGTH - Communication Channel Input Length (*4)							
7	e	Command Enable (?)							
6	b	callback enable							
		bit Description							
		0 no callback							
		1 callback enabled							
1-2		CHANNEL - (*5)							
		00 Channel 1							
		01 Channel 2							
		10 Channel 3							
		11 Channel 4							
0		TSTART - Transfer Start (*6)							
		read 0 Command Complete							
		1 Command Pending							
		write 0 Do not start command							
		1 Start command							

^(*1) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of SICOMCSR[TCINT]

^(*2) On read this bit indicates the current status of the Read Status interrupt. The interrupt is set whenever SISR[RDSTn] bits are set. The interrupt is cleared when all of the RdSt bits in the SISR are cleared by

reading from the Si Channel Input Buffers. This interrupt can be used to indicate that a polling transfer has completed and new data is captured in the input registers

- (*3) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of SICOMCSR[RDSTINT]
- (*4) Minimum transfer is 1 byte. A value of 0 will transfer 128 bytes. These bits should not be modified while SICOM transfer is in progress.
- (*5) These bits should not be modified while SICOM transfer is in progress.
- (*6) When a '1' is written to this register, the current communication transfer is executed. The transfer begins immediately after the current transaction on this channel has completed. When read this bit represents the current transfer status. Once a communication transfer has been executed, polling will resume at the next vblank if the channel's SIPOLL[ENn] bit is set.

When programming the SICOMCSR after a SICOM transfers has already started (e.g., SICOMCSR[TSTART] is set), the software should read the current value first, then and/or in the proper data and then write the new data back. The software should not modify any of the transfer parameters (OUTLNGTH, INLNGTH, CHANNEL) until the current transfer is complete. This is done to prevent a SICOM transfer already in progress from being disturbed. When writing the data back, the software should not set the TSTART bit again unless the current transfer is complete and another transfer is required.

0xCC006438	4	r/w	SISR - SI Status Register (channel select & status2)
------------	---	-----	--

31	24	23	16	15	8	7	0
r???	aaaa	????	bbbb	????	cccc	????	dddd

bit(s)		description							
31	r	WR - W	rite	SICnOUTBUF Register (*1)					
		read	0	buffer copied					
			1	buffer not copied					
		write	0	no effect					
			1	copy all buffers					
30		reserved							
29		RDST0 - Read Status SIC0OINBUF Register (*2)							
		0 Ne	ew d	ata available, not read by main processor					
		1 No	o nev	w data available, already read by main processor					
28		WRST0	WRST0 - Write Status SICOOUTBUF Register (*3)						
		0 Bu	0 Buffer copied						
		1 Bu	ıffer	not copied					
27		NOREP	1 - 0	No Response Error Channel 0 (*4)					
		read	0	No Response Error not asserted					
			1	No Response Error asserted					
		write	0	No effect					
			1	Clear No Response Error					
26		COLL0	- Co	ollision Error Channel 0 (*5)					
		read	0	Collision Error not asserted					
			1	Collision Error asserted					
		write	0	No effect					
			1	Clear Collision Error					
25		OVRUN	10 - 0	Over Run Error Channel 0 (*6)					
		read	0	Over Run Error not asserted					
			1	Over Run Error asserted					
		write	0	No effect					
			1	Clear Over Run Error					
24		UNRUN - Under Run Error Channel 0 (*7)							
		read	0	Under Run not asserted					
			1	Under Run asserted					
		write	0	No effect					
			1	Clear Under Run Error					
22-23		reserved							
16-21	b	Joy-char							
14-15		reserved							
8-13	c	Joy-cha							
6-7		reserved							
0-5	d	Joy-cha	nnel	3 bits					

- (*1) Write SICnOUTBUF Register: This register controls and indicates whether the SICnOUTBUFs have been copied to the double buffered output buffers. This bit is cleared after the buffers have been copied. (*2) This register indicates whether the SIC0INBUFs have been captured new data and whether the data has
- (*2) This register indicates whether the SIC0INBUFs have been captured new data and whether the data has already been read by the main processor (read indicated by main processor read of SIC01NBUF[ERRSTAT, ERRLATCH, INPUT0, INPUT1)]
- (*3) This register indicates whether the SIC0OUTBUFs have been copied to the double buffered output

buffers. This bit is cleared after the buffers have been copied.

- (*4) This register indicates that a previous transfer resulted in no response from the controller. This can also be used to detect whether a controller is connected. If no controller is connected, this bit will be set. Once set this bit remains set until it is cleared by the main processor. To clear this bit write '1' to this register.
- (*5) This register indicates data collision between controller and main unit. Once set this bit remains set until it is cleared by the main processor. To clear this bit write '1' to this register.
- (*6) This register indicates that the main unit has received more data than expected. Once set this bit remains set until it is cleared by the main processor. To clear this bit write '1' to this register.
- (*7) This register indicates that the main unit has received less data than expected. Once set this bit remain set until it is cleared by the main processor. To clear this bit write '1' to this register.

0xcc00643c			4	F	R/W	SII	EXII	LK -	SI EXI Clock Lock
31	24	23	16	5	15	8	7	0	

bit(s)	description						
31	LOCK - prevents CPU from setting EXI clock to 32MHz						
	0 32MHz EXI clock setting permitted						
	1 32MHz EXI clock setting not permitted						
0-30	unused/reserved (always zero)						

Г	0xCC006480	0x80	r/w	SI i/o buffer (access by word)

5.8.1 Operation

5.8.1.1 Serial Send Buffer

- ▷ select channel: unset all bits in 0xcc006438 that are not corresponding to your channel and leave the others untouched.
- ▷ Put output data into SI buffer (128 bytes maximum), word by word.
- ⊳ Send command: fill in 'c','m','n' and 'b' bits of 0xcc006434 accordingly, and set bits 's' and 'e'. leave other bits untouched.

5.8.1.2 Serial Get Result

5.9 EXI - External Interface

Upper memory (0xCC000000 and above) can't keep enough data for extra-large arrays, it's limited up to 0xFFFF bytes (suppose to be). EXI was designed to remove this limitation. EXI is used for access to big, unmapped areas of HW memory (such as bootrom or SRAM). This is the main task of EXI. Put another way, EXI can be used for providing access to slow, serial devices, such as memory cards. EXI is a complex of different devices, mapped to a single bus. The EXI bus is divided on 3 channels. Each channel has 3 unique devices. Each device is defined by its ID, and has its own address space.

EXI can be accessed in immediate mode, or via DMA channel. Each EXI device can generate up to 3 interrupts. They are called EXI, TC and EXT:

EXI	Device EXI Interrupt
TC	Transfer Completed (any mode)
EXT	Device Attached / Device Detached

Each EXI channel have its own register set, 5 32bit Registers each.

Register block Base	Size of Register block	common access size
0xCC006800	0x40	4

	0xCC006800	4	EXIOCSR - EXI Channel 0 Parameter Register (Status?)
	0xCC006814	4	EXI1CSR - EXI Channel 1 Parameter Register
ĺ	0xCC006828	4	EXI2CSR - EXI Channel 2 Parameter Register

31	24	23	16	15	8	7	0

bit(s)		Description							
14-31		unused							
13		ROMDIS - (EXIO only) 1: rom de-scramble logic disabled (*1)							
12	d	EXT - Device Connected Bit (R) 1 if a device is connected on the specific channel							
11	Х	EXTINT - External Insertion Interrupt Status (R): check to poll EXT interrupt (or to detect device detach)							
		read 0 External Insertion Interrupt has not been requested							
		1 External Insertion Interrupt has been requested							
		write 0 No effect							
		1 Clear External Insertion Interrupt							
10	m	EXTINTMASK - EXT Interrupt Mask (1 - enable, 0 - disable) (*5)							
7-9	210	CS - devices selected on this channel, each bit selecting one device. (*)							
4-6	f	CLK - used frequency (0-5)							
		000 1MHz							
		001 2MHz							
		010 4MHz							
		011 8MHz							
		100 16MHz							
		101 32MHz							
		110 reserved							
		111 reserved							
3	t	TCINT - Transfer Complete Interrupt Status							
		read 0 Transfer Complete Interrupt has not been requested							
		1 Transfer Complete Interrupt has been requested							
		write 0 No effect							
		1 Clear Transfer Complete Interrupt							
2	m	TCINTMASK - Transfer complete interrupt mask (1 - enable, 0 - disable) (*2)							
1	e	EXTINT - Interrupt Status (*6)							
		read 0 EXI Interrupt has not been requested							
		1 EXI Interrupt has been requested							
		write 0 No effect							
		1 Clear EXI Interrupt							
0	m	EXTINTMASK - EXI interrupt mask (1 - enable, 0 - disable)							

(*)Only one of these three bits can be set to signify which device number has been selected on a specific channel.

- (*6) This bit indicates the current status of the EXI0 interrupt. The interrupt is cleared by accessing the expansion device and clearing the interrupt on the device itself and cleared locally when a '1' is written to this register. This interrupt input is edge triggered.
- (*1) This bit disables access to the IPL Mask ROM attached to CS1. Once this bit is enabled, it can only be disabled again by global reset. The ROM de-scramble logic will become disabled and any reads to the memory mapped ROM area will return all 0.When de-scrambler is enabled all EXIO data will be de-scrambled, so only the IPL ROM may be accessed through EXIO until ROMDIS is set to '1'. (this is usually done by the Bootstrap, see Boot process details)
- (*2) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of TCINT

- (*3) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of EXIINT
- (*5) Interrupt masking prevents the interrupt from being sent to the main processor, but does not affect the assertion of EXICPR[EXTINT]
- (*4) This interrupt indicates than an external EXI device has been removed from channel 1. To check whether the device has been inserted or removed, check the EXICPR[EXT] bit. When this bit is set, the channel's expansion EXI interface outputs go to high.

0xCC006804	4	r/w	EXIOMAR - EXI Channel 0 DMA Start Address
0xCC006818	4	r/w	EXI1MAR - EXI Channel 1 DMA Start Address
0xCC00682c	4	r/w	EXI2MAR - EXI Channel 2 DMA Start Address

31	24	23	16	15	8	7	0
	dd	dddd	dddd	dddd	dddd	ddd.	

Physical Startaddress for DMA transfer. Must be aligned to 32 byte boundary .

(*) The memory address is the destination address when EXICR[RW] is set to 'read' and is the source address when set to 'write'.

0xCC006808	4	r/w	EXIOLENGTH - EXI Channel 0 DMA Transfer Length				
0xCC00681c	4	E	XI Channel 1 DMA Transfer Length				
0xCC006830	4	E	XI Channel 2 DMA Transfer Length				

31	24	23	16	15	8	7	0
	dd	dddd	dddd	dddd	dddd	ddd.	

Size of DMA transfer data in bytes. bits 0-4 are always zero (which means the size is 32 byte aligned)

			EXIOCR - EXI Channel 0 Control Register
			EXI1CR - EXI Channel 1 Control Register
0xCC006834	4	r/w	EXI2CR - EXI Channel 2 Control Register

	31	24	23	16	15	8	7	0
ſ							11	ttme

bit(s)		Description						
6-31		unused						
4-5	1	TLEN - (data length-1) for immediate mode						
		00 1 byte						
		01 2 bytes						
		10 3 bytes						
		11 4 bytes						
2-3	t	RW - transfer type						
		00 read						
		01 write						
		10 read and write, invalid for DMA						
		11 undefined						
1	m	DMA - transfer mode (0 - immediate, 1 - DMA)						
0	e	TSTART - set, to start transfer. will be cleared after transfer completed.						

0xCC006810	4	r/w	EXIODATA - EXI Channel 0 Immediate Data
0xCC006824	4	r/w	EXI1DATA - EXI Channel 1 Immediate Data
0xCC006838	4	r/w	EXI2DATA - EXI Channel 2 Immediate Data

31	24	23	16	15	8	7	0
dddd							

Data for read / write immediate operations (up to 4 bytes long).

The EXICPR must be configured to assert one of the devices CS, before the read or write operation can be performed. The actual read/write operation is triggered by the EXI0CR[TSTART] register and EXI0CR[DMA] set to '0'. Data is sent with MSB (bit 31) first.

5.9.1 Operation

5.9.1.1 Initializing the EXI Bus

- ▷ clear all EXIs status registers (set to 0)
- > eventually initialize interrupt callbacks.

If you want to use DMA with EXI, you need your own properly installed EXI interrupt handlers. There is no need in callbacks and interrupts, if you are using EXI in immediate mode (just mask all TCs, to prevent unhandled interrupts).

5.9.1.2 Selecting a Specific EXI Device on an EXI Channel

- > set selected device number and frequency ('210' and f fields in status register)

5.9.1.3 Deselecting EXI Devices on an EXI Channel

5.9.1.4 Performing an IMM Operation on a EXI Device

5.9.1.4.1 IMM Read

- ⊳ setup EXI Control Register (bit4-5:data length-1, bit2: 0 for read, bit1: 0 for immediate, bit1: 1 to start transfer)
- > wait until transfer has been completed (until bit 0 in EXI Control Register has been cleared)
- ▷ get data from EXI IMM Data Register (up to 4 bytes)

5.9.1.4.2 IMM Write

- > write data to EXI IMM Data Register (up to 4 bytes)
- ⊳ wait until transfer has been completed (until bit 0 in EXI Control Register has been cleared)

5.9.1.5 Performing a DMA Operation on a EXI Device

5.9.1.5.1 DMA Read

- ⊳ setup EXI Control Register (bit4-5:data length-1, bit2: 0 for read, bit1: 1 for DMA, bit1: 1 to start transfer)
- > wait until transfer has been completed (until bit 0 in EXI Control Register has been cleared)

5.9.1.5.2 DMA Write

- ⊳ wait until transfer has been completed (until bit 0 in EXI Control Register has been cleared)
- **5.9.1.6** Wait for EXI transfer completed To detect the end of a transfer on a specific channel either setup a 'transfer completed' callback (only works with DMA transfer) or periodically check bit 0 of the EXI Control Register (until cleared).

5.10 AI - Audio Streaming Interface

Registerblock Base	Size of Registerblock	common access size	
0xcc006c00	0x20	4	

0xCC006C00 r/w			4	AIC	R - Au	dio Interfa	ace C	ontrol Regi	ster
31	24	23		16	15	8	7	0	

bit(s)	Description							
7-31	reserved/unused							
6	DSP Sample Rate							
	0 48 kHz sample rate							
	1 32 kHz sample rate							
5	SCRESET Sample Counter Reset: When a '1' is written to this bit the AISLRCNT register is reset to 0							
4	AIINTVLD Audio Interface Interrupt Valid.							
	This bit controls whether AIINT is affected by the AIIT register matching AISLRCNT. Once set, AIINT will ho							
	0 Match affects AIINT							
	1 AIINT hold last value.							
3	AIINT Audio Interface Interrupt Status and clear. (*3)							
	r 0 Audio Interface Interrupt has not been requested							
	1 Audio Interface Interrupt has been requested.							
	w 0 No effect							
	1 Clear Audio Interface interrupt							
2	AIINTMSK Audio interface Interrupt Mask							
	0 interrupt masked							
	1 Interrupt enabled							
1	AFR: Auxiliary Frequency Register (*1)							
	0 48 kHz sample rate							
	1 32 kHz sample rate							
0	PSTAT: Playing Status							
	0 Stop or Pause streaming audio (AISLR clock disabled)							
	1 Play streaming audio (AISLR clock enabled)							

(*3)

On read this bit indicates the current status of the audio interface interrupt. When a '1' is written to this register, the interrupt is cleared. This interrupt indicates that the AIIT register matches the AISLRCNT. This bit asserts regardless of the setting of AICR[AIMSK]. (*1)

Controls the sample rate of the streaming audio data. When set to 32 kHz sample rate, the SRC will convert the streaming audio data to 48 kHz. This bit should only be changed when Streaming Audio is stopped (AICR[PSTAT] set to 0). (*0)

This bit enables the AISLR clock which controls the playing/stopping of audio streaming. When this bit is 1 AISLRCNT register will increment for every stereo pair of samples output.

0xCC006C04	r/w	4	AIVR - Audio Interface Volume Register

31	24	23	16	15	8	7	0
				rrrr	rrrr	1111	1111

bit(s)		description
16-31		unused/reserved
8-15	r	AVRR - Volume Right Channel (0x00 is muted,0xff is max)
0-7	1	AVRL - Volume Right Channel (0x00 is muted,0xff is max)

0xCC006C08 r 4 AISCNT - Audio Interface Sample Counter

Audio interface Sample Counter: This register counts the number of AIS stereo samples that have been output. It is enabled by AICR[PSTAT]. It can be cleared by the AICR[SCRESET] register.

ſ	0xCC006C0C	r/w	4	AIIT - Audio Interface Interrupt Timing
---	------------	-----	---	---

This register indicates the stereo sample count to issue an audio interface interrupt to the main processor. The interrupt is issued when the value of the AISLRCNT register matches the content of this register.

5.11 GX FIFO (Graphic display lists)

GP have mapped 32-byte FIFO buffer, at 0xCC008000, which is controlled by write gather pipe (WPAR). when FIFO is filled (or overloaded by 32-bytes), WPAR performs burst transaction of primitive data to GP command FIFO. WPAR API also keeps watching for wrapping it on 32-buffer. You can think, that data is always looped and flows like in circle.

Registerblock Base	Size of Registerblock	common access size	
0xcc008000	4	any	

To access FIFO, you should just write data of any size to 0xCC008000, WPAR will control circularity and gathering automatically. By "data of any size" are assumed command types, vertices, vertex attributes etc stuff. All commands and primitive data are sending through mapped GP FIFO. GP task is only to draw primitives in embedded frame buffer, and then send it to XFB, for VI rendering. All render rules are stored in VI. GP can only change some copy rules, using pixel engine setup.

GP primitives also can be drawn, using Display List. In that case, GP FIFO takes only "CALL_DL" command with pointer to list data, and then GP command FIFO sequentially parsing primitive data from the main memory. Primitives can contains both direct and indexed vertexes as well. In first case, vertex attributes are sent directly using GP FIFO, in the other case the CPU sends only the pointer to vertex attribute data which is located in main memory.

5.11.1 internal BP registers

Registerblock Base	Size of Registerblock	common access size
0x00	0x100	4 (1+3)

Register	Description
0x00	GEN_MODE
0x01	display copy filter
0x02	display copy filter
0x03	display copy filter
0x04	display copy filter
0x05	?
0x06	IND_MTXA0
0x07	IND_MTXB0
0x08	IND_MTXC0
0x09	IND_MTXA1
0x0a	IND_MTXB1
0x0b	IND MTXC1
0x0c	IND_MTXA2
0x0d	IND MTXB2
0x0e	IND MTXC2
0x0f	IND IMASK
0x10	IND_CMD0 - tev indirect 0
0x11	IND CMD1 - tev indirect 1
0x12	IND_CMD2 - tev indirect 2
0x13	IND_CMD3 - tev indirect 3
0x14	IND CMD4 - tev indirect 4
0x15	IND_CMD5 - tev indirect 5
0x16	IND_CMD6 - tev indirect 6
0x17	IND CMD7 - tev indirect 7
0x18	IND_CMD8 - tev indirect 8
0x19	IND_CMD9 - tev indirect 9
0x1a	IND CMDA - tev indirect 10
0x1b	IND_CMDB - tev indirect 11
0x1c	IND_CMDC - tev indirect 12
0x1d	IND_CMDD - tev indirect 13
0x1e	IND_CMDE - tev indirect 14
0x1f	IND_CMDF - tev indirect 15
0x20	scissor x0,y0 (0x20156156)
0x21	scissor x1,y1 (0x213d5335)
0x22	SU_LPSIZE - field mode line width - point width
0x23	SU Counter (?) (0x23000000)
0x24	RAS Counter (?) (0x24000000)
0x25	RAS1_SS0 - ind tex coord scale 0
0x26	RAS1_SS1 - ind tex coord scale 1
0x27	RAS1_IREF
0x28	RAS1_TREF0 - tev order 0
0x29	RAS1_TREF1 - tev order 1
0x2a	RAS1_TREF2 - tev order 2
0x2b	RAS1_TREF3 - tev order 3
0x2c	RAS1_TREF4 - tev order 4
0x2d	RAS1_TREF5 - tev order 5
0x2e	RAS1_TREF6 - tev order 6
0x2f	RAS1 TREF7 - tev order 7

Register	Description
0x30	SU_SSIZE0 - texture offset 0 (Texture Size X, Y ?)
0x31	SU_TSIZE0 -
0x32	SU_SSIZE1 - texture offset 1
0x33	SU_TSIZE1 -
0x34	SU SSIZE2 - texture offset 2
0x35	SU TSIZE2 -
0x36	SU SSIZE3 - texture offset 3
0x37	SU TSIZE3 -
0x38	SU SSIZE4 - texture offset 4
0x39	SU TSIZE4 -
0x3a	SU SSIZE5 - texture offset 5
0x3b	SU TSIZE5 -
0x3c	SU SSIZE6 - texture offset 6
0x3d	SU TSIZE6 -
0x3e	SU SSIZE7 - texture offset 7
0x3f	SU TSIZE7 -
0x40	PE ZMODE set z mode
0x40	PE_CMODE0 dithering / blend mode/color_update/alpha_update/set_dither
0x42	PE CMODE1 destination alpha
0x42	PE_CONTROL comp z location z_comp_loc(0x43000040)pixel_fmt(0x43000041)
0x13	field mask (0x44000003)
0x45	PE_DONE - draw done (end of list marker) ?
0x46	some clock ? (0x46000000 (((162000000/500)/4224) 0x0200))
0x47	PE_TOKEN token B (16 bit)
0x47	PE_TOKEN_INT token A (16 bit)
0x49	EFB source rectangle top left
0x4a	EFB source rectangle width, height-1
0x4b	XFB target address
0x4c	?
0x4d	stride ?
0x4e	DispCopyYScale
0x4e	PE copy clear AR - set clear alpha and red components
0x41 0x50	PE copy clear GB - green and blue
0x50	PE copy clear Z - 24-bit Z value
0x51	pe copy execute?
0x52	copy filter
0x53	copy filter
0x54 0x55	bounding box (0x550003ff)
0x55	bounding box (0x550003ff) bounding box (0x560003ff)
0x50	?
0x57	? (0x5800000f)
0x56	scissor-box offset (0x5902acab)
0x59 0x5a	?
0x5a 0x5b	?
	?
0x5c	?
0x5d	?
0x5e	?

Register	Description
0x60	?
0x61	?
0x62	?
0x63	?
0x64	TX_LOADTLUT0
0x65	TX_LOADTLUT1
0x66	?
0x67	metric ? (0x67000000)
0x68	field mode
0x69	some clock ? (0x69000000 ((((162000000/500)>>11)&0x00ffffff)) 0x0400)
0x6a	?
0x6b	?
0x6c	?
0x6d	?
0x6e	?
0x6f	?
0x70	?
0x71	?
0x72	?
0x73	?
0x74	?
0x75	?
0x76	?
0x77	?
0x78	?
0x79	?
0x7a	?
0x7b	?
0x7c	?
0x7d	?
0x7e	?
0x7f	?
0x80	TX_SETMODE0_I0 - 0x90 for linear
0x81	TX_SETMODE0_I1
0x82	TX_SETMODE0_I2
0x83	TX_SETMODE0_I3
0x84	TX_SETMODE1_I0
0x85	TX_SETMODE1_I1
0x86	TX_SETMODE1_I2
0x87	TX_SETMODE1_I3
0x88	TX_SETIMAGE0_I0 - texture size ?
0x89	TX_SETIMAGE0_I1
0x8a	TX_SETIMAGE0_I2
0x8b	TX_SETIMAGE0_I3
0x8c	TX_SETIMAGE1_I0
0x8d	TX_SETIMAGE1_I1
0x8e	TX_SETIMAGE1_I2
0x8f	TX_SETIMAGE1_I3

Register	Description
0x90	TX_SETIMAGE2_I0
0x91	TX_SETIMAGE2_I1
0x92	TX_SETIMAGE2_I2
0x93	TX_SETIMAGE2_I3
0x94	TX_SETIMAGE3_I0 - Texture Pointer
0x95	TX_SETIMAGE3_I1
0x96	TX_SETIMAGE3_I2
0x97	TX_SETIMAGE3_I3
0x98	TX_LOADTLUT0
0x99	TX_LOADTLUT1
0x9a	TX_LOADTLUT2
0x9b	TX_LOADTLUT3
0x9c	?
0x9d	?
0x9e	?
0x9f	?
0xa0	TX_SETMODE0_I4
0xa1	TX_SETMODE0_I5
0xa2	TX_SETMODE0_I6
0xa3	TX_SETMODE0_I7
0xa4	TX_SETMODE1_I4
0xa5	TX_SETMODE1_I5
0xa6	TX_SETMODE1_I6
0xa7	TX_SETMODE1_I7
0xa8	TX_SETIMAGE0_I4
0xa9	TX_SETIMAGE0_I5
0xaa	TX_SETIMAGE0_I6
0xab	TX_SETIMAGE0_I7
0xac	TX_SETIMAGE1_I4
0xad	TX_SETIMAGE1_I5
0xae	TX_SETIMAGE1_I6
0xaf	TX_SETIMAGE1_I7
0xb0	TX_SETIMAGE2_I4
0xb1	TX_SETIMAGE2_I5
0xb2	TX_SETIMAGE2_I6
0xb3	TX_SETIMAGE2_I7
0xb4	TX_SETIMAGE3_I4
0xb5	TX_SETIMAGE3_I5
0xb6	TX_SETIMAGE3_I6
0xb7	TX_SETIMAGE3_I7
0xb8	TX_SETTLUT_I4
0xb9	TX_SETTLUT_I5
0xba	TX_SETTLUT_I6
0xbb	TX_SETTLUT_I7
0xbc	?
0xbd	?
0xbe	?
0xbf	4

Register	Description
0xc0	TEV_COLOR_ENV_0 - tev op 0
0xc1	TEV_ALPHA_ENV_0 - tev op 1
0xc2	TEV_COLOR_ENV_1 -
0xc3	TEV_ALPHA_ENV_1
0xc4	TEV_COLOR_ENV_2 -
0xc5	TEV_ALPHA_ENV_2
0xc6	TEV_COLOR_ENV_3 -
0xc7	TEV_ALPHA_ENV_3
0xc8	TEV_COLOR_ENV_4 -
0xc9	TEV_ALPHA_ENV_4
0xca	TEV_COLOR_ENV_5 -
0xcb	TEV_ALPHA_ENV_5
0xcc	TEV_COLOR_ENV_6 -
0xcd	TEV_ALPHA_ENV_6
0xce	TEV_COLOR_ENV_7 -
0xcf	TEV_ALPHA_ENV_7
0xd0	TEV_COLOR_ENV_8 -
0xd1	TEV_ALPHA_ENV_8
0xd2	TEV_COLOR_ENV_9 -
0xd3	TEV_ALPHA_ENV_9
0xd4	TEV_COLOR_ENV_A -
0xd5	TEV_ALPHA_ENV_A
0xd6	TEV_COLOR_ENV_B -
0xd7	TEV_ALPHA_ENV_B
0xd8	TEV_COLOR_ENV_C -
0xd9	TEV_ALPHA_ENV_C
0xda	TEV_COLOR_ENV_D -
0xdb	TEV_ALPHA_ENV_D
0xdc	TEV_COLOR_ENV_E -
0xdd	TEV_ALPHA_ENV_E
0xde	TEV_COLOR_ENV_F -
0xdf	TEV_ALPHA_ENV_F
0xe0	TEV_REGISTERL_0
0xe1	TEV_REGISTERH_0
0xe2	TEV_REGISTERL_1
0xe3	TEV_REGISTERH_1
0xe4	TEV_REGISTERL_2
0xe5	TEV_REGISTERH_2
0xe6	TEV_REGISTERL_3
0xe7	TEV_REGISTERH_3
0xe8	Fog Range (0xe8000156)
0xe9	?
0xea	?
0xeb	?
0xec	? (guessed: tev_range_adj_c)
0xed	? (guessed: tev_range_adj_k)
0xee	TEV_FOG_PARAM_0 (0xee03ce38)
0xef	TEV_FOG_PARAM_1 (0xef471c82)

Register	Description			
0xf0	TEV_FOG_PARAM_2 (0xf0000002)			
0xf1	TEV_FOG_PARAM_3 (0xf1000000)			
0xf2	TEV_FOG_COLOR (0xf2000000)			
0xf3	TEV_ALPHAFUNC - alpha compare (0xf33f0000)			
0xf4	TEV_Z_ENV_0 - z texture 0			
0xf5	TEV_Z_ENV_1 - z texture 1			
0xf6	TEV_KSEL_0 - Tev Swap Mode Table 0 (0xf6018064)			
0xf7	TEV_KSEL_1 - Tev Swap Mode Table 1 (0xf701806e)			
0xf8	TEV_KSEL_2 - Tev Swap Mode Table 2 (0xf8018060)			
0xf9	TEV_KSEL_3 - Tev Swap Mode Table 3 (0xf901806c)			
0xfa	TEV_KSEL_4 - Tev Swap Mode Table 4 (0xfa018065)			
0xfb	TEV_KSEL_5 - Tev Swap Mode Table 5 (0xfb01806d)			
0xfc	TEV_KSEL_6 - Tev Swap Mode Table 6 (0xfc01806a)			
0xfd	TEV_KSEL_7 - Tev Swap Mode Table 7 (0xfd01806e)			
0xfe	SS_MASK - BP Mask Register			
0xff	?			
0x00 4	w GEN_MODE			

31	24	23	16	15	8	7	0

bit(s)	description			
24	RID			
19	ZFREEZE			
16	NBMP - Number of Bumpmaps			
14-15	REJECT_EN - Culling Mode			
	0 none 1 negative 2 positive 3 all			
10	NTEV			
9	MS_EN			
4	NCOL - Number of Colors			
0	NTEX - Number of Texture Coords			

0x01	4	W	display copy filter
0x02	4	W	display copy filter
0x03	4	W	display copy filter
0x04	4	W	display copy filter
0x05	4	W	?

0x06	4	W	IND_MTXA0
0x09	4	W	IND_MTXA1
0x0c	4	W	IND_MTXA2

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
22	S
11	MB
0	MA

	0x07	4	W	IND_MTXB0
	0x0a	4	W	IND_MTXB1
ĺ	0x0d	4	W	IND_MTXB2

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
22	S
11	MD
0	MC

ı	000	1	T	IND MTVCO
	0x08	4	W	IND_MTXC0
	0x0b	4	w	IND MTXC1
IJ				
	0x0e	4	W	IND MTXC2

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
22	S
11	MF
0	ME

0x0f	4	W	IND IMASK

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
0	IMASK

0x10	4	W	IND_CMD0
------	---	---	----------

0x11	4	W	IND_CMD1		
0x12	4	W	IND_CMD2		
0x13	4	W	IND_CMD3		
0x14	4	W	IND_CMD4		
0x15	4	W	IND_CMD5		
0x16	4	W	IND_CMD6		
0x17	4	W	IND_CMD7		
0x18	4	W	IND_CMD8		
0x19	4	W	IND_CMD9		
0x1a	4	W	IND_CMDA		
0x1b	4	W	IND_CMDB		
0x1c	4	W	IND_CMDC		
0x1d	4	w	IND_CMDD		
0x1e	4	W	IND_CMDE		
0x1f	4	W	IND_CMDF		

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
21-23	PAD0 - padding zeros
20	FB - addprev
19	LB - utclod
16-18	TW - Wrap T
	0 ITW_OFF
	1 ITW_256
	2 ITW_128
	3 ITW_64
	4 ITW_32
	5 ITW_16
	6 ITW_0
	7
13-15	SW - Wrap S
	0 ITW_OFF
	1 ITW_256
	2 ITW_128
	3 ITW_64
	4 ITW_32
	5 ITW_16
	6 ITW_0
	7
9-12	M - Matrix ID
	0 ITM_OFF
	1 ITM_0
	2 ITM_1
	3 ITM_2
	5 ITM_S0
	6 ITM_S1
	7 ITM_S2
	9 ITM_T0
	10 ITM_T1
	11 ITM_T2
7-8	BS - Alpha Selection
	0 ITBA_OFF
	1 ITBA_S
	2 ITBA_T
	3 ITBA_U
4-6	BIAS
	0 ITB_NONE
	1 ITB_S
	2 ITB_T
	3 ITB_ST
	4 ITB_U
	5 ITB_SU
	6 ITB_TU
	7 ITB_STU
2-3	FMT - Format
	0 ITF_8
	1 ITF_5
	2 ITF_4
	3 ITF_3
0-1	BT - Indirect Tex Stage ID (0-3)

0x20	4	w	SU_SCIS0 - Scissorbox Top Left Corner
------	---	---	---------------------------------------

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
12	X0 - Scissorbox X0 offset + 342
0	Y0 - Scissorbox Y0 offset + 342

0x21	4	W	SU_SCIS1 - Scissorbox Bottom Right Corner

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24	RID
12	X1 - Scissorbox X1 offset + 342
0	Y1 - Scissorbox Y1 offset + 342

0x22	4	W	SU_LPSIZE
------	---	---	-----------

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
23	PAD0
22	LINEASPECT
19	PTOFF
	0 to 0
	1 to 16th
	2 to 8th
	3 to 4th
	4 to half
	5 to 1
16	LTOFF
	0 to 0
	1 to 16th
	2 to 8th
	3 to 4th
	4 to half
	5 to 1
8	PSIZE
0	LSIZE

	0x23	4	W	SU Counter?	
--	------	---	---	-------------	--

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
12	TS1 - Ind. Tex Stage 1
8	SS1 - Ind. Tex Stage 1
4	TS0 - Ind. Tex Stage 0
0	SS0 - Ind. Tex Stage 0

ſ	0x26	4	W	RAS1_SS - ind tex coord scale 1
---	------	---	---	---------------------------------

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
12	TS1 - Ind. Tex Stage 3
8	SS1 - Ind. Tex Stage 3
4	TS0 - Ind. Tex Stage 2
0	SS0 - Ind. Tex Stage 2

|--|

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
21	BC3 - Ind. Tex Stage 3 NTexCoord
18	BI3 - Ind. Tex Stage 3 NTexMap
15	BC2 - Ind. Tex Stage 2 NTexCoord
12	BI2 - Ind. Tex Stage 2 NTexMap
9	BC1 - Ind. Tex Stage 1 NTexCoord
6	BI1 - Ind. Tex Stage 1 NTexMap
3	BC0 - Ind. Tex Stage 0 NTexCoord
0	BIO - Ind. Tex Stage 0 NTexMap

0x28	4	W	RAS1_TREF0
0x29	4	W	RAS1_TREF1
0x2a	4	W	RAS1_TREF2
0x2b	4	W	RAS1_TREF3
0x2c	4	W	RAS1_TREF4
0x2d	4	W	RAS1_TREF5
0x2e	4	W	RAS1_TREF6
0x2f	4	W	RAS1_TREF7

31	24	23	16	15	8	7	0

bit(s)	description				
24	RID				
22	PAD1				
19-21	CC1 - Ind. Tex Stage 1 Channel ID				
	0 Color0				
	1 Color1				
	2 Alpha0				
	3 Alpha1				
	4 Color0A0				
	5 Color1A1				
	6 ColorZero				
	7 Bump				
18	TE1 - Ind. Tex Stage 1 TexMap enable				
15	TC1 - Ind. Tex Stage 1 TexCoord				
12	TI1 - Ind. Tex Stage 1 TexMap				
10	PAD0				
7	CC0 - Ind. Tex Stage 0 Color ID				
6	TE0 - Ind. Tex Stage 0 TexMap enable				
3	TC0 - Ind. Tex Stage 0 TexCoord				
0	TI0 - Ind. Tex Stage 0 TexMap				

0x30	4	W	SU_SSIZE0
0x32	4	W	SU_SSIZE1
0x34	4	W	SU_SSIZE2
0x36	4	W	SU_SSIZE3
0x38	4	W	SU_SSIZE4
0x3a	4	W	SU_SSIZE5
0x3c	4	W	SU_SSIZE6
0x3e	4	W	SU_SSIZE7

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
19	PF - texcoord offset for points enable
18	LF - texcoord offset for lines enable
17	WS - s-cylindrical texcoord wrapping enable
16	BS - s-range bias enable
0	SSIZE - s-scale value -1 (U16)

0x31	4	W	SU_TSIZE0
0x33	4	W	SU_TSIZE1
0x35	4	W	SU_TSIZE2
0x37	4	W	SU_TSIZE3
0x39	4	W	SU_TSIZE4
0x3b	4	W	SU_TSIZE5
0x3d	4	W	SU_TSIZE6
0x3f	4	W	SU_TSIZE7

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
17	WT - t-cylindrical texcoord wrapping enable
16	BT - t-range bias enable
0	TSIZE - t-scale value -1 (U16)

0x40	4	W	PE_ZMODE

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description					
24	RID					
4	MA	SK - Update e	nable			
1	FUN	NC - Z-Buffer	Compare Function			
	0	NEVER				
	1 LESS					
	2 EQUAL					
	3 LEQUAL					
	4 GREATER					
	5 NEQUAL					
	6 GEQUAL					
	7 ALWAYS					
0	ENA	ABLE - Z-Buff	er enable			

0x41	4	W	PE_CMODE0
------	---	---	-----------

ſ	31	24	23	16	15	8	7	0
ſ								

bit(s)	description			
24	RID			
12	LOGICOP			
	0 CLEAR			
	1 AND			
	2 REVAND			
	3 COPY			
	4 INVAND			
	5 NOOP			
	6 XOR			
	7 OR			
	8 NOR			
	9 EQUIV			
	10 INV			
	11 REVOR			
	12 INVCOPY			
	13 INVOR			
	14 NAND			
	15 SET			
11	BLENDOP			
8	SFACTOR			
5	DFACTOR			
4	ALPHA_MASK			
3	COLOR_MASK			
2	DITHER_ENABLE			
1	LOGICOP_ENABLE			
0	BLEND_ENABLE			

0x42	4	W	PE_CMODE1
------	---	---	-----------

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24	RID
8	CONSTANT_ALPHA_ENABLE
0	CONSTANT_ALPHA

0x43 4 w	PE_CONTROL
----------------------------	------------

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description			
24	RID			
7-23	unused?			
6	Z Comp Loc (1: before tex)			
3-5	Z Format			
	0 linear			
	1 near			
	2 mid			
	3 far			
0-2	Pixel Format			
	0 RGB8_Z24			
	1 RGBA6_Z24			
	2 RGB565_Z16			
	3 Z24			
	4 Y8			
	5 U8			
	6 V8			
	7 YUV420			

0x44 4 w	field mask?
----------------------------	-------------

31	24	23	16	15	8	7	0

bit(s)	description
24	RID

0x45 4 w PE_DONE - draw do	ne
----------------------------	----

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description
24	RID
1	1=end of list
0	?

0x46	4	W	? (some clock?)
------	---	---	-----------------

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
9	? (must be 1)
0	((162000000/500)/4224)

0x47	4	W	PE_TOKEN

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
0	Token

0x48 4	W	PE	TOKEN	INT
--------	---	----	-------	-----

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24	RID
0	

0×49	4	w	EFB Address Top Left

31	24	23	16	15	8	7	0

bit(s)	description
10	Y coordinate
0	X coordinate

0x4a 4 w EFB Address Width, Height-1	
--	--

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
10	Height-1
0	Width

ſ	0x4b	4	W	XFB Address
---	------	---	---	-------------

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
0	physical XFB Address >> 5

0x4c | 4 | w | ?

0x4d 4 w stride?

0x4e | 4 | w | DispCopyYScale

31	24	23	16	15	8	7	0

bit(s)	Description
24	RID
0	YSCALE - ((u32)(256.0/YSCALEIN))&0x1ff

0x4f | 4 | w | PE copy clear AR - set clear alpha and red components

31	24	23	16	15	8	7	0

bit(s)	Description
24	RID
8	A
0	R

0x50 | 4 | w | PE copy clear GB - green and blue

31	24	23	16	15	8	7	0

bit(s)	Description
24	RID
8	G
0	В

0x51	4	w	PE copy clear Z - 24-bit Z value
------	---	---	----------------------------------

31	24	23	16	15	8	7	0

bit(s)	Description
24	RID
0-23	Z - 24bit Z-Value

0x52 4 w	pe copy execute?
-----------------	------------------

31	24	23	16	15	8	7	0

bit(s)	Description
24	RID
14	execute ? (1: to XFB 0: to texture ?!)
12-13	Frame 2 Field Mode
11	clear (1: clear EFB)
10	1: (256-(u32)(256.0/YSCALEIN)) > 0
9	?
7-8	disp copy gamma
4	target (XFB) pixel format
1	clamp
0	clamp

	0x53	4	W	copy filter
--	------	---	---	-------------

0x54 4 w copy filter

0x55 4 w bounding box

0x56 4 w bounding box

0x57 | 4 | w | ?

0x58 4 w ?

0×59	4	W/	Scissorbox Offset

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
10	YO - ((Scissorbox Y offset + 342)>>1)
0	XO - ((Scissorbox X offset + 342) >> 1)

note: regs 0x5a-0x63 are left out (all unknown)

0x64 4 w TX_LOADTLUT0

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24-	rid
21-	pad0
0-	tlut base

0x65 4 w	TX_LOADTLUT1
----------	--------------

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24-	rid
21-	pad0
10-	count
0	tmem offset

0x66	4	W	
------	---	---	--

0x67	4	W	metric ?

0x68	4	W	field mode
------	---	---	------------

0x69	4	W	?
------	---	---	---

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
10	? (must be 1)
0	((162000000/500)>>11)

note: regs 0x6a-0x7f are left out (all unknown)

0x80	4	W	TX_SETMODE0_I0 - Texture lookup and filtering mode
0x81	4	W	TX_SETMODE0_I1 - Texture lookup and filtering mode
0x82	4	W	TX_SETMODE0_I2 - Texture lookup and filtering mode
0x83	4	W	TX_SETMODE0_I3 - Texture lookup and filtering mode
0xa0	4	W	TX_SETMODE0_I4 - Texture lookup and filtering mode
0xa1	4	W	TX_SETMODE0_I5 - Texture lookup and filtering mode
0xa2	4	W	TX_SETMODE0_I6 - Texture lookup and filtering mode
0xa3	4	W	TX_SETMODE0_I7 - Texture lookup and filtering mode

31	24	23	16	15	8	7	0

bit(s)	description						
24	RID						
21	LODCLAMP / BIASCLAMP						
	0 off						
	1 on						
19	MAXANISO						
	0 1						
	1 2 (requires edge LOD)						
	2 4 (requires edge LOD)						
	3 unused/reserved						
9	LODBIAS (s2.5)						
8	DIAGLOAD						
	0 edge LOD						
	1 diagonal LOD						
5	MIN FILTER						
	0 near						
	1 near mip near						
	2 near mip lin						
	3 unused/reserved						
	4 linear						
	5 lin mip near						
	6 lin mip lin						
	7 unused/reserved						
4	MAG FILTER						
	0 near						
	1 linear						
2	WRAP T						
	0 clamp						
	1 repeat (*)						
	2 mirror (*)						
	3 unused/reserved						
0	WRAP S (same as WRAP T)						

^(*) requires the texture size to be a power of two. (wrapping is implemented by a logical AND (SIZE-1))

0x84	4	W	TX_SETMODE1_I0 - LOD Info
0x85	4	W	TX_SETMODE1_I1 - LOD Info
0x86	4	W	TX_SETMODE1_I2 - LOD Info
0x87	4	W	TX_SETMODE1_I3 - LOD Info
0xa4	4	W	TX_SETMODE1_I4 - LOD Info
0xa5	4	W	TX_SETMODE1_I5 - LOD Info
0xa6	4	W	TX_SETMODE1_I6 - LOD Info
0xa7	4	W	TX_SETMODE1_I7 - LOD Info

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description
24	RID
8	MAX LOD (U4.4)
0	MIN LOD (U4.4)

0x88	4	W	SETIMAGE0_I0 - Texture width, height, format
0x89	4	W	SETIMAGE0_I1 - Texture width, height, format
0x8a	4	W	SETIMAGE0_I2 - Texture width, height, format
0x8b	4	W	SETIMAGE0_I3 - Texture width, height, format
0xa8	4	W	SETIMAGE0_I4 - Texture width, height, format
0xa9	4	W	SETIMAGE0_I5 - Texture width, height, format
0xaa	4	W	SETIMAGE0_I6 - Texture width, height, format
0xab	4	W	SETIMAGE0_I7 - Texture width, height, format

31	24	23	16	15	8	7	0

bit(s)	desci	ription					
24-	rid						
20-	forma	at					
	0	I4					
	1	I8					
	2	IA4					
	3	IA8					
	4	RGB565					
	5	5 RGB5A3					
	6	6 RGBA8					
	7	unused/reserved					
	8	C4					
	9	C8					
	10	C14X2					
	11	unused/reserved					
	12	unused/reserved					
	13	unused/reserved					
	14	CMP					
	15	unused/reserved					
10-	heigh	it - 1					
0-	width	n - 1					

0x8c	4	W	TX_SETIMAGE1_I0 - even LOD address in TMEM
0x8d	4	W	TX_SETIMAGE1_I1 - even LOD address in TMEM
0x8e	4	W	TX_SETIMAGE1_I2 - even LOD address in TMEM
0x8f	4	W	TX_SETIMAGE1_I3 - even LOD address in TMEM
0xac	4	W	TX_SETIMAGE1_I4 - even LOD address in TMEM
0xad	4	W	TX_SETIMAGE1_I5 - even LOD address in TMEM
0xae	4	W	TX_SETIMAGE1_I6 - even LOD address in TMEM
0xaf	4	W	TX_SETIMAGE1_I7 - even LOD address in TMEM

31	24	23	16	15	8	7	0

bit(s)	description							
24	RID							
21	IMAGE_TYPE							
	0 cached							
	1 preloaded							
18	CACHE_HEIGHT							
	0 unused/reserved							
	1 unused/reserved							
	2 unused/reserved							
	3 32kb							
	4 128kb							
	5 512kb							
	6 unused/reserved							
	7 unused/reserved							
15	CACHE_WIDTH (must be equal to CACHE_HEIGHT)							
0	TMEM_OFFSET (address in TMEM >> 5)							

0x90	4	W	TX_SETIMAGE2_I0 - odd LOD address in TMEM
0x91	4	W	TX_SETIMAGE2_I1 - odd LOD address in TMEM
0x92	4	W	TX_SETIMAGE2_I2 - odd LOD address in TMEM
0x93	4	W	TX_SETIMAGE2_I3 - odd LOD address in TMEM
0xb0	4	W	TX_SETIMAGE2_I4 - odd LOD address in TMEM
0xb1	4	W	TX_SETIMAGE2_I5 - odd LOD address in TMEM
0xb2	4	W	TX_SETIMAGE2_I6 - odd LOD address in TMEM
0xb3	4	W	TX_SETIMAGE2_I7 - odd LOD address in TMEM

31	24	23	16	15	8	7	0

bit(s)	description					
24	RID					
18	CACHE_HEIGHT					
	0 none (if odd LOD is unused)					
	1 unused/reserved					
	2 unused/reserved					
	3 32kb					
	4 128kb					
	5 512kb					
	6 unused/reserved					
	7 unused/reserved					
15	CACHE_WIDTH (must be equal to CACHE_HEIGTH)					
0	TMEM_OFFSET - (address in TMEM >> 5)					

0x94	4	W	TX_SETIMAGE3_I0 - Address of Texture in main memory
0x95	4	W	TX_SETIMAGE3_I1 - Address of Texture in main memory
0x96	4	W	TX_SETIMAGE3_I2 - Address of Texture in main memory
0x97	4	W	TX_SETIMAGE3_I3 - Address of Texture in main memory
0xb4	4	W	TX_SETIMAGE3_I4 - Address of Texture in main memory
0xb5	4	W	TX_SETIMAGE3_I5 - Address of Texture in main memory
0xb6	4	W	TX_SETIMAGE3_I6 - Address of Texture in main memory
0xb7	4	W	TX_SETIMAGE3_I7 - Address of Texture in main memory

31	24	23	16	15	8	7	0

	bit(s)	description
	24	RID
ĺ	0	IMAGE_BASE (physical address >> 5)

0x98	4	W	TX_SETTLUT_0
0x99	4	W	TX_SETTLUT_1
0x9a	4	W	TX_SETTLUT_2
0x9b	4	W	TX_SETTLUT_3
0xb8	4	W	TX_SETTLUT_4
0xb9	4	W	TX_SETTLUT_5
0xba	4	W	TX_SETTLUT_6
0xbb	4	W	TX_SETTLUT_7

31	24	23	16	15	8	7	0

bit(s)	description						
24	RID						
10	FORMAT						
	0 IA8						
	1 RGB565						
	2 RGB5A3						
	3 reserved/unused						
0	TMEM_OFFSET (offset of TLUT from start of TMEM high bank >> 5)						

|--|

0x9d	4	w	?

4	W	TEV_COLOR_ENV_0
4	W	TEV_COLOR_ENV_1
4	W	TEV_COLOR_ENV_2
4	W	TEV_COLOR_ENV_3
4	W	TEV_COLOR_ENV_4
4	W	TEV_COLOR_ENV_5
4	W	TEV_COLOR_ENV_6
4	W	TEV_COLOR_ENV_7
4	W	TEV_COLOR_ENV_8
4	W	TEV_COLOR_ENV_9
4	W	TEV_COLOR_ENV_A
4	W	TEV_COLOR_ENV_B
4	W	TEV_COLOR_ENV_C
4	W	TEV_COLOR_ENV_D
4	W	TEV_COLOR_ENV_E
4	W	TEV_COLOR_ENV_F
	4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	4 w 4 w 4 w 4 w 4 w 4 w 4 w 4 w 4 w 4 w

ſ	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24	RID
22	DEST
20	SHIFT
19	CLAMP
18	SUB
16	BIAS
12	SELA
8	SELB
4	SELC
0	SELD

SELA - SELD Format:

0x0	CC_CPREV
0x1	CC_APREV
0x2	CC_C0
0x3	CC_A0
0x4	CC_C1
0x5	CC_A1
0x6	CC_C2
0x7	CC_A2
0x8	CC_TEXC
0x9	CC_TEXA
0xA	CC_RASC
0xB	CC_RASA
0xC	CC_ONE
0xD	CC_HALF
0xE	CC_KONST
0xF	CC_ZERO

7 0
_1
_2
′_3
_4
′_5
′_6
7_7
7_8
7_9
_A
_B
_C
_D
_E
_F

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24	RID
22	DEST
20	SHIFT
19	CLAMP
18	SUB
16	BIAS
13	SELA
10	SELB
7	SELC
4	SELD
2	TSWAP
0	RSWAP

SELA - SELD Format:

0	CA_APREV
1	CA_A0
2	CA_A1
3	CA_A2
4	CA_TEXA
5	CA_RASA
6	CA_KONST
7	CA ZERO

0xe0	4	w	TEV_REGISTERL_0
0xe2	4	W	TEV_REGISTERL_1
0xe4	4	W	TEV_REGISTERL_2
0xe6	4	W	TEV_REGISTERL_3

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description				
24	RID				
23	TYPE				
	0 Color (?)				
	1 Constant (?)				
12	A				
0	R				

0xe1	4	W	TEV_REGISTERH_0
0xe3	4	W	TEV_REGISTERH_1
0xe5	4	W	TEV_REGISTERH_2
0xe7	4	W	TEV_REGISTERH_3

31	24	23	16	15	8	7	0

bit(s)	description			
24	RID			
23	TYPE			
	0 Color (?)			
	1 Constant (?)			
12	G			
0	В			

0x88	4	W	Fog Range

0x89	4	W	

5 HARDWARE REGISTERS 122

0xec (guessed)					w	t	ev_r	ange	e_adj_	c
31	24	23	16	1	5	3	7	0		

bit(s)	description								
24	RID								
10	CENTER - Screen X Center for range Adjustment								
0	ENB - Range-Adjustment enable								
	0 TEV_ENB_DISABLE								
	1 TEV_ENB_ENABLE								

	0xed	(gı	ıesse	d)	4	w	t	ev_r	ange	e_adj	_k
П	2.1	\circ	1 00	1 0	1 -	- /	^		^		

	31	24	23	16	15	8	7	0
Ì								

bit(s)	description
24	RID
0-11	r2k (u4.8) - specifies the range adjustment function

range adjustment = sqr((x*x)+(k*k))/k

0xee | 4 | w | TEV_FOG_PARAM_0 - "a" parameter of the screen to eye space conversion function

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
19	A_SIGN_SHIFT
11	A_EXPN
0	A_MANT (signed 11e8)

0xef | 4 | w | TEV_FOG_PARAM_1 - the "b" parameter of the z screen to eye space conversion function

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
0	B_MAG (unsigned 0.24)

0xf0	4	W	TEV_FOG_PA			PAR	AM_	2 - amount to pre-shift screen z
31	24	23	16	15	8	7	0	

bit(s)	description	i
24	RID	ì
0-4	B_SHF - equivalent to the value of "b" parameter's exponent + 1	1

The Z-Screen to Eyespace conversion is defined as:

$$Ze = A / (B_MAG - (Zs >> B_SHF))$$

0xf1	4	W	TEV_FOG_PARAM_3 - fog type

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
21-23	FSEL
	0 FSEL_OFF; No fog
	1 reserved
	2 FSEL_LIN; linear Fog
	3 reserved
	4 FSEL_EXP; Exponential Fog
	5 FSEL_EX2; Exponential Squared Fog
	6 FSEL_BXP; Backward Exp Fog
	7 FSEL_BX2 Backward Exp Squared Fog
20	PROJ
	0 PERSP; Perspective projection
	1 ORTHO; Orthographic projection
19	C_SIGN (*)
11	C_EXPN (*)
0-10	C_MANT (*)

(*) Specifies the amount to subtract from eye-space Z after range adjustment.

0xf2	4	W	TEV_FOG_COLOR - Value of Fog Color

31	24	23	16	15	8	7	0

bit(s)	description
24	RID
16	R
8	G
0	В

()xf3	4	W	TEV_	_ALPHAFUNC
---	------	---	---	------	------------

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description				
24	RID				
22	LOGIC				
	0	AND			
	1	OR			
	2	XOR			
	3	XNOR			
19	OP1				
16	OP0				
8	A1				
0	A0				

Γ	0xf4	4	W	TEV	\mathbb{Z}	ENV	0
---	------	---	---	-----	--------------	-----	---

31	24	23	16	15	8	7	0

bit(s)	description
24	RID -
0-23	ZOFF/BIAS -

0xf5	4	w	TEV	\mathbf{Z}	ENV	1

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	desc	cription	
24	RID		
2-3	OP		
	0	disable	
	1	add	
	2	replace	
	3	unused/reserved	
0-1	TYF	PE/FORMAT	
	0	u8	
	1	u16	
	2	u24	
	3	unused/reserved	

0xf6	4	W	TEV_KSEL_0
0xf7	4	W	TEV_KSEL_1
0xf8	4	W	TEV_KSEL_2
0xf9	4	W	TEV_KSEL_3
0xfa	4	W	TEV_KSEL_4
0xfb	4	W	TEV_KSEL_5
0xfc	4	W	TEV_KSEL_6
0xfd	4	W	TEV_KSEL_7

	31	24	23	16	15	8	7	0
Ī								

bit(s)	description
24	RID
19	KASEL1
14	KCSEL1
9	KASEL0
4	KCSEL0
2	XGA
0	XRB

KCSEL - tev const color sel

0	1
1	7_8
2	3_4
3	5_8
4	1_2
5	3_8
6	1_4
7	1_8
8	
9	
10	
11	
12	K 0
13	K1
14	K2
15	K3
16	K0_R
17	K1_R
18	K2_R
19	K3_R
20	K0_G
21	K1_G
22	K2_G
23	K3_G
24	K0_B
25	K1_B
26	K2_B
27	K3_B
28	$K0_A$
29	K1_A
30	K2_A
31	K3_A

KASEL - tev const alpha sel

0	1
1	7_8
2	7_8 3_4
2 3 4 5	5_8
4	1_2
	3_8
6	1_4
7	1_8
8	
9	
10	
11	
12	
13	
14	
15	
16	K0_R
17	K1_R
18	K2_R
19	K3_R
20	K0_G
21	K1_G
22	K2_G
23	K3_G
24	K0_B
25	K1_B
26	K2_B
27	K3_B
28	K0_A
29	K1_A
30	K1_A K2_A K3_A
31	

0xfe	4	W	SS_MASK - BP Mask Register

31	24	23	16	15	8	7	0
****	****						

bit(s)		description
24	*	RID
0-23		MASK (*)

(*) This Register can be used to limit to which bits of BP registers is actually written to. the mask is only valid for the next BP command, and will reset itself.

0xff	4	W	?
------	---	---	---

5.11.2 internal CP Registers

Registerblock Base	Size of Registerblock	common access size	
0x20	0xa0	4	

0770	0000 4
Register	description
0x20	?
0x30	MATINDEX_A - Texture Matrix Index 0-3
0x40	MATINDEX_B - Texture Matrix Index 4-7
0x50	VCD_LO - Vertex Descriptor (VCD) low, format 0
0x51	VCD_LO - Vertex Descriptor (VCD) low, format 1
0x52	VCD_LO - Vertex Descriptor (VCD) low, format 2
0x53	VCD_LO - Vertex Descriptor (VCD) low, format 3
0x54	VCD_LO - Vertex Descriptor (VCD) low, format 4
0x55	VCD_LO - Vertex Descriptor (VCD) low, format 5
0x56	VCD_LO - Vertex Descriptor (VCD) low, format 6
0x57	VCD_LO - Vertex Descriptor (VCD) low, format 7
0x60	VCD_HI - Vertex Descriptor (VCD) high, format 0
0x61	VCD_HI - Vertex Descriptor (VCD) high, format 1
0x62	VCD_HI - Vertex Descriptor (VCD) high, format 2
0x63	VCD_HI - Vertex Descriptor (VCD) high, format 3
0x64	VCD_HI - Vertex Descriptor (VCD) high, format 4
0x65	VCD_HI - Vertex Descriptor (VCD) high, format 5
0x66	VCD_HI - Vertex Descriptor (VCD) high, format 6
0x67	VCD_HI - Vertex Descriptor (VCD) high, format 7
0x70	VAT_A - Vertex Attribute Table (VAT) group 0, format 0
0x71	VAT_A - Vertex Attribute Table (VAT) group 0, format 1
0x72	VAT_A - Vertex Attribute Table (VAT) group 0, format 2
0x73	VAT_A - Vertex Attribute Table (VAT) group 0, format 3
0x74	VAT_A - Vertex Attribute Table (VAT) group 0, format 4
0x75	VAT_A - Vertex Attribute Table (VAT) group 0, format 5
0x76	VAT_A - Vertex Attribute Table (VAT) group 0, format 6
0x77	VAT_A - Vertex Attribute Table (VAT) group 0, format 7
08x0	VAT_B - Vertex Attribute Table (VAT) group 1, format 0
0x81	VAT_B - Vertex Attribute Table (VAT) group 1, format 1
0x82	VAT_B - Vertex Attribute Table (VAT) group 1, format 2
0x83	VAT_B - Vertex Attribute Table (VAT) group 1, format 3
0x84	VAT_B - Vertex Attribute Table (VAT) group 1, format 4
0x85	VAT_B - Vertex Attribute Table (VAT) group 1, format 5
0x86	VAT_B - Vertex Attribute Table (VAT) group 1, format 6
0x87	VAT_B - Vertex Attribute Table (VAT) group 1, format 7
0x90	VAT_C - Vertex Attribute Table (VAT) group 2, format 0
0x91	VAT_C - Vertex Attribute Table (VAT) group 2, format 1
0x92	VAT_C - Vertex Attribute Table (VAT) group 2, format 2
0x93	VAT_C - Vertex Attribute Table (VAT) group 2, format 3
0x94	VAT_C - Vertex Attribute Table (VAT) group 2, format 4
0x95	VAT_C - Vertex Attribute Table (VAT) group 2, format 5
0x96	VAT_C - Vertex Attribute Table (VAT) group 2, format 6
0x97	VAT_C - Vertex Attribute Table (VAT) group 2, format 7

Register	description
0xA0	ARRAY_BASE - vertices ptr
0xa1	ARRAY_BASE - normals ptr
0xa2	ARRAY_BASE - color 0 ptr
0xa3	ARRAY_BASE - color 1 ptr
0xa4	ARRAY_BASE - texture 0 coordinate ptr
0xa5	ARRAY_BASE - texture 1 coordinate ptr
0xa6	ARRAY_BASE - texture 2 coordinate ptr
0xa7	ARRAY_BASE - texture 3 coordinate ptr
0xa8	ARRAY_BASE - texture 4 coordinate ptr
0xa9	ARRAY_BASE - texture 5 coordinate ptr
0xaa	ARRAY_BASE - texture 6 coordinate ptr
0xab	ARRAY_BASE - texture 7 coordinate ptr
0xac	ARRAY_BASE - IndexRegA - general purpose array 0 ptr
0xad	ARRAY_BASE - IndexRegB - general purpose array 1 ptr
0xae	ARRAY_BASE - IndexRegC - general purpose array 2 ptr
0xaf	ARRAY_BASE - IndexRegD - general purpose array 3 ptr
0xB0	ARRAY_STRIDE - size of vertices
0xb1	ARRAY_STRIDE - size of normals
0xb2	ARRAY_STRIDE - size of colors 0
0xb3	ARRAY_STRIDE - size of colors 1
0xb4	ARRAY_STRIDE - size of texture 0 coordinates
0xb5	ARRAY_STRIDE - size of texture 1 coordinates
0xb6	ARRAY_STRIDE - size of texture 2 coordinates
0xb7	ARRAY_STRIDE - size of texture 3 coordinates
0xb8	ARRAY_STRIDE - size of texture 4 coordinates
0xb9	ARRAY_STRIDE - size of texture 5 coordinates
0xba	ARRAY_STRIDE - size of texture 6 coordinates
0xbb	ARRAY_STRIDE - size of texture 7 coordinates
0xbc	ARRAY_STRIDE - IndexRegA - general purpose array 0 stride
0xbd	ARRAY_STRIDE - IndexRegB - general purpose array 1 stride
0xbe	ARRAY_STRIDE - IndexRegC - general purpose array 2 stride
0xbf	ARRAY_STRIDE - IndexRegD - general purpose array 3 stride
0x20 4	w ?

UX3U 4 W MATIDX_REG_A

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24	TEX3IDX - Index for Texture 3 matrix
18	TEX2IDX - Index for Texture 2 matrix
12	TEX1IDX - Index for Texture 1 matrix
6	TEXOIDX - Index for Texture 0 matrix
0	POSIDX - Index for Position/Normal matrix

0x40 4 w	MATIDX_REG_B
----------	--------------

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description
18	TEX7IDX - Index for Texture 7 matrix
12	TEX6IDX - Index for Texture 6 matrix
6	TEX5IDX - Index for Texture 5 matrix
0	TEX4IDX - Index for Texture 4 matrix

0x50	4	R/W	VCD_LO - Vertex Descriptor low Format 0
0x51	4	R/W	VCD_LO - Vertex Descriptor low Format 1
0x52	4	R/W	VCD_LO - Vertex Descriptor low Format 2
0x53	4	R/W	VCD_LO - Vertex Descriptor low Format 3
0x54	4	R/W	VCD_LO - Vertex Descriptor low Format 4
0x55	4	R/W	VCD_LO - Vertex Descriptor low Format 5
0x56	4	R/W	VCD_LO - Vertex Descriptor low Format 6
0x57	4	R/W	VCD_LO - Vertex Descriptor low Format 7

	31	24	23	16	15	8	7	0
Ì								

bit(s)	description
17-31	unused
15-16	COL1 - Color1 (Specular)
13-14	COLO - ColorO (Diffused)
11-12	NRM - Normal or Normal/Binormal/Tangent
9-10	POS - Position
8	T7MIDX
7	T6MIDX
6	T5MIDX
5	T4MIDX
4	T3MIDX
3	T2MIDX
2	T1MIDX
1	TOMIDX - Texture Coordinate O Matrix Index
0	PMIDX - Position/Normal Matrix Index (*1)

^(*1) position and normal matrices are stored in 2 seperate areas of internal XF memory, but there is a one to one correspondence between normal and position index. If index 'A' is used for the position, then index 'A' needs to be used for the normal as well.

0x60	4	R/W	VCD_HI - Vertex Descriptor high Format 0
0x61	4	R/W	VCD_HI - Vertex Descriptor high Format 1
0x62	4	R/W	VCD_HI - Vertex Descriptor high Format 2
0x63	4	R/W	VCD_HI - Vertex Descriptor high Format 3
0x64	4	R/W	VCD_HI - Vertex Descriptor high Format 4
0x65	4	R/W	VCD_HI - Vertex Descriptor high Format 5
0x66	4	R/W	VCD_HI - Vertex Descriptor high Format 6
0x67	4	R/W	VCD_HI - Vertex Descriptor high Format 7

31	24	23	16	15	8	7	0
							tt

bit(s)		description
16-		unused
14-15		TEX7 - texture coordinate 7
12-13		TEX6 - texture coordinate 6
10-11		TEX5 - texture coordinate 5
8-9		TEX4 - texture coordinate 4
6-7		TEX3 - texture coordinate 3
4-5		TEX2 - texture coordinate 2
2-3		TEX1 - texture coordinate 1
0-1	t	TEX0 - texture coordinate 0

vertex descriptor data

value	Vertex/Color	Pos/Tex Matrix Index
0	no data present	no data present
1	direct	direct
2	i8 - indirect/8 bit index	n/a
3	i16 - indirect/16 bit index	n/a

0x70	4	W	CP_VAT_REG_A - Format	0
0x71	4	W	CP_VAT_REG_A - Format	1
0x72	4	W	CP_VAT_REG_A - Format	2
0x73	4	W	CP_VAT_REG_A - Format	3
0x74	4	W	CP_VAT_REG_A - Format	4
0x75	4	W	CP_VAT_REG_A - Format	5
0x76	4	W	CP_VAT_REG_A - Format	6
0x77	4	W	CP_VAT_REG_A - Format	7

31	24	23	16	15	8	7	0

bit(s)	description					
31	NORMALINDEX3 (*1)					
	0 single index per normal					
	1 triple-index per nine-normal					
30	BYTEDEQUANT (should always be 1)					
	0 shift does not apply to u8/s8 components					
	1 shift applies to u8/s8 components					
25	TEXOSHFT					
22	TEX0FMT					
21	TEXOCNT					
18	COL1FMT (Specular)					
17	COL1CNT (Specular)					
14	COLOFMT (Diffused)					
13	COLOCNT (Diffused)					
10	NRMFMT					
9	NRMCNT					
4	POSSHFT					
1	POSFMT					
0	POSCNT					

^(*1) when nine-normals are selected in indirect mode, input will be treated as three staggered indices (one per triple biased by components size), into normal table (note: first index internally biased by 0, second by 1, third by 2)

0x80	4	W	CP_VAT_REG_B - Format	0
0x81	4	W	CP_VAT_REG_B - Format	1
0x82	4	W	CP_VAT_REG_B - Format	2
0x83	4	W	CP_VAT_REG_B - Format	3
0x84	4	W	CP_VAT_REG_B - Format	4
0x85	4	W	CP_VAT_REG_B - Format	5
0x86	4	W	CP_VAT_REG_B - Format	6
0x87	4	W	CP_VAT_REG_B - Format	7

31	24	23	16	15	8	7	0

bit(s)	description
31	VCACHE_ENHANCE (must always be 1)
28	TEX4FMT
27	TEX4CNT
22	TEX3SHFT
19	TEX3FMT
18	TEX3CNT
13	TEX2SHFT
10	TEX2FMT
9	TEX2CNT
4	TEX1SHFT
1	TEX1FMT
0	TEX1CNT

0x90	4	W	CP_VAT_REG_C - Format	0
0x91	4	W	CP_VAT_REG_C - Format	1
0x92	4	W	CP_VAT_REG_C - Format	2
0x93	4	W	CP_VAT_REG_C - Format	3
0x94	4	W	CP_VAT_REG_C - Format	4
0x95	4	w	CP_VAT_REG_C - Format	5
0x96	4	W	CP_VAT_REG_C - Format	6
0x97	4	w	CP_VAT_REG_C - Format	7

	31	24	23	16	15	8	7	0
1								

bit(s)	description
27	TEX7SHFT
24	TEX7FMT
23	TEX7CNT
18	TEX6SHFT
15	TEX6FMT
14	TEX6CNT
9	TEX5SHFT
6	TEX5FMT
5	TEX5CNT
0	TEX4SHFT

Vertex Attribute Data Formats

CompCount

value	coords	normals	tex coords	colors
0	two (x,y)	three	one (s)	three (r,g,b)
1	three (x,y,z)	nine	two (s,t)	four (r,g,b,a)

CompSize

value	coords	normals	colors
0	u8	n/a	16 bit rgb565
1	s8	s8	24 bit rgb888
2	u16	n/a	32 bit rgb888x
3	s16	s16	16 bit rgba4444
4	f32	f32	24 bit rgba6666
5	n/a	n/a	32 bit rgba8888
6	unused	unused	unused
7	unused	unused	unused

Shift

coords	normals	colors
location of decimal point	n/a (byte: 6, short: 14)	n/a

This shift applies to all \$s16/u16\$ components, and all \$s8/s8\$ components when ByteDequant is asserted.

0xA0	4	w	ARRAY_BASE
0xA1	4	w	ARRAY_BASE
0xA2	4	w	ARRAY_BASE
0xA3	4	w	ARRAY_BASE
0xA4	4	w	ARRAY_BASE
0xA5	4	W	ARRAY_BASE
0xA6	4	W	ARRAY_BASE
0xA7	4	w	ARRAY_BASE
0xA8	4	w	ARRAY_BASE
0xA9	4	w	ARRAY_BASE
0xAA	4	w	ARRAY_BASE
0xAB	4	w	ARRAY_BASE
0xAC	4	w	ARRAY_BASE
0xAD	4	w	ARRAY_BASE
0xAE	4	w	ARRAY_BASE
0xAF	4	w	ARRAY_BASE

ſ	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
26-	unused
0-25	array base addres in main memory

0xB0	4	W	ARRAY_STRIDE
0xB1	4	W	ARRAY_STRIDE
0xB2	4	W	ARRAY_STRIDE
0xB3	4	W	ARRAY_STRIDE
0xB4	4	W	ARRAY_STRIDE
0xB5	4	W	ARRAY_STRIDE
0xB6	4	W	ARRAY_STRIDE
0xB7	4	W	ARRAY_STRIDE
0xB8	4	W	ARRAY_STRIDE
0xB9	4	W	ARRAY_STRIDE
0xBa	4	W	ARRAY_STRIDE
0xBb	4	W	ARRAY_STRIDE
0xBc	4	W	ARRAY_STRIDE
0xBd	4	W	ARRAY_STRIDE
0xBe	4	W	ARRAY_STRIDE
0xBf	4	W	ARRAY_STRIDE

ſ	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
8-	unused
0-7	array stride

5.11.3 internal XF Memory

Every register in the transform unit is mapped to a unique 32b address. All addresses are available to the xform register load command (command 0x30).

The first block is formed by the matrix memory. Its address range is 0 to 1 k, but only 256 entries are used. This memory is organized in a 64 entry by four 32b words. Each word has a unique address and is a single precision floating point number. For block writes, the addresses auto increment. The memory is implemented in less than 4-32b rams, then it is possible that the memory writes to this block will require a minimum write size larger than 1 word.

start	end	size	description
0x0000		32	Matrix Ram word 0
0x0001	0x00ff		Matrix Ram word (n)
0x0100	0x03ff	0x300	not used

```
0 - position matrix (4*3)
0xF0 - (texture?) transform matrix (4*3)
```

The second block of memory is the normal matrix memory. It is organized as 32 rows of 3 words. Each word has a unique address and is a single precision floating point number. Also, each word written is 32b, but only the 20 most significant bits are kept. For simplicity, the minimum granularity of writes will be 3 words:

	start	end	size	description
	0x0400	0x0402	20	Normal Ram words 0,1,2
	0x0403	0x045f		Normal Ram word (n)
ĺ	0x0460	0x05ff		not used

0x400 - normal transform matrix (3*3)

The third block of memory holds the dual texture transform matrices. The format is identical to the first block of matrix memory. There are also 64 rows of 4 words for these matrices. These matrices can only be used for the dual transform of regular textures:

	start	end	size	description
	0x0500		32	Matrix Ram word 0
ĺ	0x0501	0x05ff		Matrix Ram word (n)

0x5F4 - dual texture transform matrix (4*3)

The fourth block of memory is the light memory. This holds all the lighting information (light vectors, light parameters, etc.). Both global state and ambient state are stored in this memory. Each word written is 32b, but only the 20 most significant bits are kept. Each row is 3 words wide. Minimum word write size is 3 words.

start	end	size	description
0x0600			reserved
0x0601			reserved
0x0602			reserved
0x0603		32 bit	Light0 - RGBA
0x0604		20 bit	Light0A0 - cos atten. A-0
0x0605		20 bit	Light0A1 - cos atten. A-1
0x0606		20 bit	Light0A2 - cos atten. A-2
0x0607		20 bit	Light0K0 - dist atten. A-0
0x0608		20 bit	Light0K1 - dist atten. A-1
0x0609		20 bit	Light0K2 - dist atten. A-2
0x060a		20 bit	Light0Lpx - x light pos, or inf ldir x
0x060b		20 bit	Light0Lpy - y light pos, or inf ldir y
0x060c		20 bit	Light0Lpz - z light pos, or inf ldir z
0x060d		20 bit	Light0Dx/Hx - light dir x, or 1/2 angle x
0x060e		20 bit	Light0Dy/Hy - light dir y, or 1/2 angle y
0x060f		20 bit	Light0Dz/Hz - light dir z, or 1/2 angle z
0x0610	0x067f		Light(n)data - see Light0 data
0x0680	0x07ff		not used

5.11.4 internal XF Registers

Registerblock Base	Size of Registerblock	common access size
0x1000	0x54	4

Register	description
0x1000	Error (=0x3f)
0x1001	Diagnostics
0x1002	State0 - Internal State Register 0
0x1003	State1 - Internal State Register 1
0x1004	Xf_clock - Enables Power Saving Mode
0x1005	ClipDisable - clip mode (=0)
0x1006	Perf0 - Performance monitor selects (=0)
0x1007	Perf1 - Xform target performance register
0x1008	InVertexSpec - INVTXSPEC - (=0x01)
0x1009	NumColors - NUMCOLORS - (=0x00)
0x100a	Ambient0 - chan Ambient color 0 (=0x00)
0x100b	Ambient1- chan Ambient color 1 (=0x00)
0x100c	Material0 - chan Material ID 0 (=0xffffffff)
0x100d	Material1 - chan Material ID 1 (=0xffffffff)
0x100e	COLOROCNTRL (=0x0401)
0x100f	COLOR1CNTRL (=0x0401)
0x1010	ALPHA0CNTRL (=0x0401)
0x1011	ALPHA1CNTRL (=0x0401)
0x1012	DualTexTrans - (=0x01)
0x1013	?
0x1014	?
0x1015	?
0x1016	?
0x1017	?
0x1018	MatrixIndex0 - MATINDEX A
0x1019	MatrixIndex1 - MATINDEX B
0x101a	ScaleX - Viewport Scale X
0x101b	ScaleY - Viewport Scale Y
0x101c	Scale Z - Viewport Scale Z
0x101d	OffsetX - Viewport Offset X
0x101e	OffsetY - Viewport Offset Y
0x101f	OffsetZ - Viewport Offset Z
0x1020	ProjectionA - A parameter in projection equations
0x1021	ProjectionB - B parameter in projection equations
0x1022	ProjectionC - C parameter in projection equations
0x1023	ProjectionD - D parameter in projection equations
0x1024	ProjectionE - E parameter in projection equations
0x1025	ProjectionF - F parameter in projection equations
0x1026	ProjectOrtho
Register	description

Register	description
0x103f	NUMTEX - Number of active Textures
0x1040	TEX0
0x1041	TEX1
0x1042	TEX2
0x1043	TEX3
0x1044	TEX4
0x1045	TEX5
0x1046	TEX6
0x1047	TEX7

Register		des	cription	l
0x1050		DU	ALTEX	0
0x1051		DU	ALTEX	1
0x1052		DU	ALTEX	2
0x1053		DU	ALTEX	3
0x1054		DU	ALTEX	4
0x1055		DU	ALTEX	5
0x1056		DU	ALTEX	6
0x1057		DU	ALTEX	7
0x1000	4	W	Error	

0x1001	4	W	Diagnostics
--------	---	---	-------------

	0x1002	4	W	State 0 - Internal State Register 0
--	--------	---	---	-------------------------------------

0x1003 4 v	N	State 1 - Internal State Register 1
------------	---	-------------------------------------

0×1004	4	w	Xf	clock
UVIUUI		vv	2 X I	CIOCK

	31	24	23	16	15	8	7	0
ĺ								

	bit(s)		desc	cription	
ĺ	0		0	no power saving when idle	
ı	0	$0 \mid 1 \mid 1$	enable Power saving when idle		

0x1005	4	W	ClipDisable

31	24	23	16	15	8	7	0

bit(s)	description
2	when set, disable cpoly clipping acceleration (default==0)
1	when set, disable trivial rejection (default==0)
0	when set, disable clipping detection (default==0)

0x1006	4	W	Perf0 - Performance monitor selects
--------	---	---	-------------------------------------

0x1007 4 w Perf1 - Xform target performance Registe

ſ	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
0-6	Xform internal target performance (Cycles per Vertex)

0x1008	4	W	INVTXSPEC
--------	---	---	-----------

31	24	23	16	15	8	7	0

bit(s)	description					
4-7	HOST	Г_Т	EXTURES - number of host supplied	texture coordinates		
	0		no host supplied textures			
	1		1 host supplied texture pair (S0, T0))		
	2-	8	2-8 host supplied texturepairs			
	9-1	5	reserved/unused			
2-3	HOST	Γ_N	ORMAL - host supplied normal			
	0	no	host supplied normal			
	1	ho	ost supplied normal			
	2	ho	ost supplied normal and binormals			
0-1	HOST_COLORS - host supplied color0 usage					
	0	no	host supplied color information			
	1	ho	ost supplied color 0			
	2	ho	ost supplied color 0 and color 1			

	31	24	23	16	15	8	7	0
ĺ								

value	description
0	No colors
1	One color - Xform supplies 1 color (host supplied or computed)
2	Two colors - Xform supplies 2 colors (host supplied or computed)

Selects the number of output colors

0x100a | 4 | w | XF_AMBIENTO - Ambient color O specifications

31	24	23	16	15	8	7	0

bit(s)	description
24	RED
16	GREEN
8	BLUE
0	ALPHA

5 HARDWARE REGISTERS

0x100b | 4 | w | XF_AMBIENT1 - Ambient color 1 specifications

140

31	24	23	16	15	8	7	0

bit(s)	description
24	RED
16	GREEN
8	BLUE
0	ALPHA

0x100c | 4 | w | XF_MATERIALO - global color0 material specification

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description
24	RED
16	GREEN
8	BLUE
0	ALPHA

0x100d | 4 | w | XF_MATERIAL1 - global color1 material specification

ı	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description
24	RED
16	GREEN
8	BLUE
0	ALPHA

0x100e 4 w	COLOR0CNTRL
----------------	-------------

31	24	23	16	15	8	7	0

bit(s)	description				
14	LIGHT7 - Light 7 is source				
	0 Do not use Light				
	1 Use light				
13	LIGHT6 - Light6 is source				
	0 Do not use Light				
	1 Use light				
12	LIGHT5 - Light5 is source				
	0 Do not use Light				
	1 Use light				
11	LIGHT4 - Light4 is source				
	0 Do not use Light				
	1 Use light				
10	ATTENSELECT - Attenuation Select function				
	0 Select specular (N.H) attenuation				
	1 Select diffuse spotlight (L.Ldir) attenuation				
9	ATTENENABLE - Attenuation Enable function				
	0 Select 1.0				
	1 Select Attenuation fraction				
7-8	DIFFUSEATTEN - Diffuse Attenuation function				
	00 Select 1.0				
	01 Select N.L, signed				
	10 Select N.L clamped to [0,1.0]				
	11				
6	AMBIENT_SRC - Ambient source				
	0 Use register Ambient0 register				
	1 Use CP supplied vertex color 0				
5	LIGHT3 - Light3 is source				
	0 Do not use light				
	1 Use light				
4	LIGHT2 - Light2 is source				
	0 Do not use light				
	1 Use light				
3	LIGHT1 - Light1 is source				
	0 Do not use light				
	1 Use light				
2	LIGHTO - LightO is source				
	0 Do not use light				
	1 Use light				
1	LIGHTFUNC - Color0 Light Function				
	0 Use 1.0				
	1 Use Illum0				
0	MATERIAL_SRC - Color0 Material source				
	0 Use register (Material 0)				
	1 Use CP supplied Vertex color 0				

0x100f	4	W	COLOR1CNTRL
--------	---	---	-------------

31	24	23	16	15	8	7	0

bit(s)	description						
14	LIGHT7 - Light 7 is source						
	0 Do not use Light						
	1 Use light						
13	LIGHT6 - Light6 is source						
	0 Do not use Light						
	1 Use light						
12	LIGHT5 - Light5 is source						
	0 Do not use Light						
	1 Use light						
11	LIGHT4 - Light4 is source						
	0 Do not use Light						
	1 Use light						
10	ATTENSELECT - Attenuation Select function						
	0 Select specular (N.H) attenuation						
	1 Select diffuse spotlight (L.Ldir) attenuation						
9	ATTENENABLE - Attenuation Enable function						
	0 Select 1.0						
	1 Select Attenuation fraction						
7-8	DIFFUSEATTEN - Diffuse Attenuation function						
	00 Select 1.0						
	01 Select N.L, signed						
	10 Select N.L clamped to [0,1.0]						
	11						
6	AMBIENT_SRC - Ambient source						
	0 Use register Ambient1 register						
_	1 Use CP supplied vertex color 1						
5	LIGHT3 - Light3 is source						
	0 Do not use light						
4	1 Use light						
4	LIGHT2 - Light2 is source 0 Do not use light						
3	1 Use light LIGHT1 - Light1 is source						
3	0 Do not use light						
2	1 Use light LIGHTO - LightO is source						
2	0 Do not use light						
	1 Use light						
1	LIGHTFUNC - Color1 Light Function						
1	0 Use 1.0						
	1 Use Illum1						
0	MATERIAL_SRC - Color1 Material source						
- 	0 Use register (Material 1)						
	1 Use CP supplied Vertex color 1						
	1 Ose Cr supplied vertex color 1						

0x1010 4 w	ALPHA0CNTRL
----------------	-------------

	31	24	23	16	15	8	7	0
Γ								

bit(s)	description						
14	LIGHT7 - Light 7 alpha is source						
	0 Do not use Light						
	1 Use light						
13	LIGHT6 - Light6 alpha is source						
	0 Do not use Light						
	1 Use light						
12	LIGHT5 - Light5 alpha is source						
	0 Do not use Light						
	1 Use light						
11	LIGHT4 - Light4 alpha is source						
	0 Do not use Light						
	1 Use light						
10	ATTENSELECT - Attenuation Select function						
	0 Select specular (N.H) attenuation						
	1 Select diffuse spotlight (L.Ldir) attenuation						
9	ATTENENABLE - Attenuation Enable function						
	0 Select 1.0						
	1 Select Attenuation fraction						
7-8	DIFFUSEATTEN - Diffuse Attenuation function						
	00 Select 1.0						
	01 Select N.L, signed						
	10 Select N.L clamped to [0,1.0]						
	11						
6	AMBIENT_SRC - Ambient source						
	0 Use register Ambient0 alpha register						
_	1 Use CP supplied vertex color 0 alpha						
5	LIGHT3 - Light3 alpha is source						
	0 Do not use light						
4	1 Use light						
4	LIGHT2 - Light2 alpha is source 0 Do not use light						
	1 Use light						
3	LIGHT1 - Light1 alpha is source						
3	0 Do not use light						
	1 Use light						
2	LIGHT0 - Light0 alpha is source						
2	0 Do not use light						
	1 Use light						
1	LIGHTFUNC - ColorO alpha Light Function						
-	0 Use 1.0						
	1 Use Illum0						
0	MATERIAL_SRC - Color0 alpha Material source						
-	0 Use register (Material 0 alpha)						
	1 Use CP supplied Vertex color 0 alpha						
	1 Ose Ci supplied vertex color o alpha						

0x1011	4	W	ALPHA1CNTRL
--------	---	---	-------------

	31	24	23	16	15	8	7	0
Γ								

bit(s)	description						
14	LIGHT7 - Light 7 alpha is source						
	0 Do not use Light						
	1 Use light						
13	LIGHT6 - Light6 alpha is source						
	0 Do not use Light						
	1 Use light						
12	LIGHT5 - Light5 alpha is source						
	0 Do not use Light						
	1 Use light						
11	LIGHT4 - Light4 alpha is source						
	0 Do not use Light						
	1 Use light						
10	ATTENSELECT - Attenuation Select function						
	0 Select specular (N.H) attenuation						
	1 Select diffuse spotlight (L.Ldir) attenuation						
9	ATTENENABLE - Attenuation Enable function						
	0 Select 1.0						
	1 Select Attenuation fraction						
7-8	DIFFUSEATTEN - Diffuse Attenuation function						
	00 Select 1.0						
	01 Select N.L, signed						
	10 Select N.L clamped to [0,2.0]						
	11						
6	AMBIENT_SRC - Ambient source						
	0 Use register Ambient1 alpha register						
_	1 Use CP supplied vertex color 1 alpha						
5	LIGHT3 - Light3 alpha is source						
	0 Do not use light						
4	1 Use light						
4	LIGHT2 - Light2 alpha is source 0 Do not use light						
	1 Use light						
3	LIGHT1 - Light1 alpha is source						
3	0 Do not use light						
2	1 Use light IGHT0 - Light0 alpha is source						
2	0 Do not use light						
	1 Use light						
1	LIGHTFUNC - ColorO alpha Light Function						
-	0 Use 1.0						
	1 Use Illum0						
0	MATERIAL_SRC - Color0 alpha Material source						
	0 Use register (Material 0 alpha)						
	1 Use CP supplied Vertex color 0 alpha						
	1 Osc C1 supplied vertex color o alpha						

0x1012 4 w DualTexTrans	ıs
-------------------------	----

31	24	23	16	15	8	7	0

bit(s)	desc	cription
0	0	disable dual texture transform feature
	1	enable dual transform for all texture coordinates

0x1013 | 4 | w | ?

0x1014 | 4 | w | ?

0x1015 | 4 | w | ?

0x1016 | 4 | w | ?

0x1017 | 4 | w | ?

0x1018 4 w MatrixIndex0

	31	24	23	16	15	8	7	0
ſ								

bit(s)	description
24-29	Tex3 matrix index
23-18	Tex2 matrix index
12-17	Tex1 matrix index
6-11	Tex0 matrix index
0-5	Geometry matrix index

0x1019 4 w MatrixIndex1

31	24	23	16	15	8	7	0

bit(s)	description
18-23	Tex7 matrix index
12-17	Tex6 matrix index
6-11	Tex5 matrix index
0-5	Tex4 matrix index

0x101A	4	W	Viewport
0x101B	4	W	Viewport
0x101C	4	W	Viewport
0x101D	4	W	Viewport
0x101E	4	W	Viewport
0x101F	4	W	Viewport

Viewport Matrix

		description
0x101A	f32	wd / 2
0x101B	f32	-ht / 2
0x101C	f32	ZMAX * (farZ - nearZ)
0x101D	f32	xOrig + wd / 2 + 342
0x101E	f32	yOrig + ht / 2 + 342
0x101F	f32	ZMAX * farZ

ZMAX is 16777215.0 (maximum 24-bit Z buffer value, or 'infinite')

0 1000	1		Desired Medi
0x1020	4	W	Projection Matrix
0x1021	4	W	Projection Matrix
0x1022	4	W	Projection Matrix
0x1023	4	W	Projection Matrix
0x1024	4	W	Projection Matrix
0x1025	4	W	Projection Matrix

Projection Matrix

		orthogonal	perspective
0x1020	f32	2.0 / (r - 1)	(1.0f / tanf(fovy * 0.5F)) / aspect
0x1021	f32	-(r+l) / (r-l)	0
0x1022	f32	2.0 / (t-b)	(1.0f / tanf(fovy * 0.5F))
0x1023	f32	-(t+b)/(t-b)	0
0x1024	f32	-1.0/(f-n)	-n * 1.0f / (f-n)
0x1025	f32	-(f)/(f-n)	-(f*n) * 1.0f / (f-n)

0x1026 4 w ProjectOrtho

31	24	23	16	15	8	7	0

bit(s)	description

If set selects orthographic otherwise non-orthographic (Zh or 1.0 select)

note: regs 0x1027-0x103e skipped (all unknown)

0.2	k103f	4	W	NUMTEX - Number of active Textures
-----	-------	---	---	------------------------------------

0x1040	4	W	TEX0
0x1041	4	W	TEX1
0x1042	4	W	TEX2
0x1043	4	W	TEX3
0x1044	4	W	TEX4
0x1045	4	W	TEX5
0x1046	4	W	TEX6
0x1047	4	W	TEX7

31	24	23	16	15	8	7	0

bit(s)	description					
15-17	EMBOSS_LIGHT - Bump mapping source light (*1)					
12-14	EMBOSS_SOURCE - bump mapping source texture (*2)					
7-11	SOURCE_ROW - regular texture source row (*3)					
	0 GEOM_INROW -					
	1 NORMAL_INROW -					
	2 COLORS_INROW -					
	3 BINORMAL_T_INROW -					
	4 BINORMAL_B_INROW -					
	5 TEX0_INROW -					
	6 TEX1_INROW -					
	7 TEX2_INROW -					
	8 TEX3_INROW -					
	9 TEX4_INROW -					
	a TEX5_INROW -					
	b TEX6_INROW -					
	c TEX7_INROW -					
	d					
	e					
	f					
4-6	TEXGEN_TYPE					
	0 REGULAR - Regular transformation (transform incoming data)					
	1 EMBOSS_MAP - texgen bump mapping					
	2 COLOR_STRGBC0 - Color texgen: (s,t)=(r,g:b) (g and b are concatenated), color 0					
2	3 COLOR_STRGBC1 - Color texgen: (s,t)=(r,g:b) (g and b are concatenated), color 1					
3 2	reserved/unused					
2	INPUT_FORM - format of source input data for regular textures					
	0 AB11 - (A, B, 1.0, 1.0) (used for regular texture source) 1 ABC1 - (A, B, C, 1.0) (used for geometry or normal source)					
1						
1	PROJECTION					
	0 ST - (s,t): texmul is 2x4					
	1 STQ - (s,t,q): texmul is 3x4					
0	reseved/unused					

^(*1) n: use light #n for bump map direction source (10 to 17)

^(*2) n: use regular transformed tex(n) for bump mapping source

^(*3) Specifies location of incoming textures in vertex (row specific) (i.e.: geometry is row0, normal is row1, etc...) for regular transformations

note: regs 0x1048-104f skipped (all unknown)

0x1050	4	W	DUALTEX0
0x1051	4	W	DUALTEX1
0x1052	4	W	DUALTEX2
0x1053	4	W	DUALTEX3

	31	24	23	16	15	8	7	0
ĺ								

bit(s)	description
8	NORMAL_ENABLE - specifies if texture coordinate should be normalized before send transform.
6-7	unused
0-5	DUALMTX - base row of the dual transform matrix for regular texture coordinate0 (63 max, simelar to 0x1018/0x1

5.11.5 GP packet description

The first thing in a GP Packet is the command type (8 bit). Next follows actual primitive data. It may vary on each opcode type.

0

5.11.5.1 Command Type

0000	OVV	VV	
bit(s)		de	escription
	О	О	pcode
	37	V	ertev Attribute Table Index (VAT)

opcode	Description
0x00	NOP - No Operation
0x08	Load CP REG
0x10	Load XF REG
0x20	Load INDX A
0x28	Load INDX B
0x30	Load INDX C
0x38	Load INDX D
0x40	CALL DL - Call Displaylist
0x48	Invalidate Vertex Cache
0x61	Load BP REG (SU_ByPassCmd)
0x80	QUADS - Draw Quads (*)
0x90	TRIANGLES - Draw Triangles (*)
0x98	TRIANGLESTRIP - Draw Triangle Strip (*)
0xA0	TRIANGLEFAN - Draw Triangle Fan (*)
0xA8	LINES - Draw Lines (*)
0xB0	LINESTRIP - Draw Line Strip (*)
0xB8	POINTS - Draw Points (*)

5.11.5.1.1 opcodes

(*) all draw opcodes must be Or-ed with used VAT index (0...7)

5.11.5.2 Drawing Commands

8 bits	16 bits	n
opcode	number of vertices	vertex data

Vertex data may be in one of many formats. The VCD tells wether data for a component exists (and if yes, if it is direct or indexed) and the VAT tells the actual format of the respective component. Each individual component may or may not exist, but the order is fixed as follows:

- 1. PNMTXIDX Position/Normal Matrix Index
- 2. TEX0MTXIDX Texture 0 Matrix Index
- 3. TEX1MTXIDX Texture 1 Matrix Index
- 4. TEX2MTXIDX Texture 2 Matrix Index
- 5. TEX3MTXIDX Texture 3 Matrix Index
- 6. TEX4MTXIDX Texture 4 Matrix Index
- 7. TEX5MTXIDX Texture 5 Matrix Index
- 8. TEX6MTXIDX Texture 6 Matrix Index
- 9. TEX7MTXIDX Texture 7 Matrix Index
- 10. POS Position Vector
- 11. NRM Normal or NBT Binormal vector (T, B)
- 12. CLR0 Color0 (Diffused)
- 13. CLR1 Color1 (Specular)
- 14. TEX0 Texture 0 data
- 15. TEX1 Texture 1 data
- 16. TEX2 Texture 2 data
- 17. TEX3 Texture 3 data
- 18. TEX4 Texture 4 data
- 19. TEX5 Texture 5 data
- 20. TEX6 Texture 6 data
- 21. TEX7 Texture 7 data

Notice that the Position/Normal and Texture Matrix Indices are different from the other data in that they are 8 bit and must always be sent as direct data.

- **5.11.5.2.1 Quads** draws a series of non planar quads, using v0,v1,v2,v3 then v4,v5,v6,v7 and so on. (the quad is actually drawn using 2 triangles so the 4 vertices do not have to be coplanar). The minimum number of vertices is 4.
- **5.11.5.2.2 Triangles** draws a series of triangles, from v0,v1,v2 then v3,v4,v5 and so on. The number of vertices should be a multiple of 3

5.11.5.2.3 Trianglestrip draws a series of triangles, from v0,v1,v2 then v1,v3,v2, then v2,v3,v4 amd so on. The number of vertices must be at least 3.

5.11.5.2.4 TriangleFan draws a series of triangles, from v0,v1,v2 then v0,v2,v3 and so on. The number of vertices must be at least 3.

5.11.5.2.5 Lines draws a series of unconnected lines, from v0 to v1, then from v2 to v3 and so on. The number of vertices should be a multiple of 2

5.11.5.2.6 Linestrip draws a series of connected lines, from v0 to v1, then from v1 to v2 and so on. If n vertices are drawn, n-1 lines are drawn

5.11.5.2.7 Points draws a Point at each of the n vertices

5.11.5.3 NOP - No Operation Use it to pad primitive data to 32-byte boundaries and to terminate a display list.

5.11.5.4 CALL DL - Call Display List used to call one display list from another.

L	8 bits							
	7	0						
	0100	0000						
	opcode:	== 0x40						
				32	bits			
	31	24	23	16	15	8	7	0
	0000	000.						
	list address							
				32	bits			
	31	24	23	16	15	8	7	0
	0000	000.						
	list size in bytes (32 bit words?)							

5.11.5.5 Invalidate Vertex Cache

8 bits
opcode == 0x48

5.11.5.6 BP command (Bypass Raster State Registers)

ſ	8 bits	8 bits	24 bits	
	opcode == 0x61	reg. addr.	reg. value	

5.11.5.7 CP command (Command Processor Registers)

8 bits	8 bits	32 bits	
opcode == 0x08	reg. addr.	reg. value	

5 HARDWARE REGISTERS

151

5.11.5.8 XF command (Transform Unit Registers)

8 bits	16 bits	16 bits	32 bits * length
opcode == 0x10	length - 1	1st addr.	reg. value(s)

note: "length" is limited to 16.

5.11.5.9 Indexed XF command

8 bits	16 bits	4 bits	12 bits
opcode	index value	length-1	1st address

note: "length" is limited to 16.

There are 4 different XF index units, which are typically used as follows: A: pos. mtx's B: nrm. mtx's C: tex. mtx's D: light obj's.

6 Exception and Interrupt Processing

6.1 Hardware Exception Sources

Handler Start	Exception
0x80000100	System Reset Interrupt
0x80000200	Machine Check Interrupt
0x80000300	DSI Interrupt
0x80000400	ISI Interrupt
0x80000500	External Interrupt
0x80000600	Alignment Interrupt
0x80000700	Program Interrupt
0x80000800	FP unavailable Interrupt
0x80000900	Decrementer Interrupt
0x80000C00	System Call Interrupt
0x80000d00	Trace Interrupt
0x80000f00	Performance Monitor Interrupt
0x80001300	IABR Interrupt
0x80001700	Thermal Interrupt

6.1.1 System Reset Interrupt

Triggered at a system reset

6.1.2 Machine Check Interrupt

6.1.3 DSI Interrupt

Triggered if an attempt to store or read data from/to an illegal address was made

6.1.4 ISI Interrupt

Triggered if an attempt to fetch an instruction from an illegal address was made.

6.1.5 External Interrupt

14 sources, triggered by external chips (you may look at it as the traditional IRQ).

6.1.5.1 Setup

- ⊳ set corresponding bit(s) in PI Interrupt Mask Register (0xcc003004)
- > enable external Interrupts in the Machine State Register

6.1.5.2 Handling

- □ acknowledge by setting corresponding bits in PI Interrupt Cause Register (0xcc003000)
- > handle different interrupt sources

bit		Description
13	HSP	High Speed Port
12	DEBUG	External Debugger
11	CP	Command FIFO
10	PE FINISH	Frame is Ready
9	PE TOKEN	Token Assertion in Command List
8	VI	Video Interface
7	MEM	Memory Interface
6	DSP	DSP
5	AI	Audio Streaming
4	EXI	EXI
3	SI	Serial
2	DI	DVD
1	RSW	Reset Switch
0	ERROR	GP runtime error

6.1.6 Alignment Interrupt

6.1.7 Program Interrupt

Triggered if the instruction that was about to execute is invalid.

6.1.8 FP unavailable Interrupt

6.1.9 Decrementer Interrupt

Triggered by an underflow of the decrementer register.

6.1.10 System Call Interrupt

Triggered when the PowerPC instruction 'sc' is executed.

6.1.11 Trace Interrupt

6.1.12 Performance Monitor Interrupt

6.1.13 IABR Interrupt

6.1.14 Thermal Interrupt

6.2 External Interrupt Sources

6.2.1 HSP - High Speed Port

3 Sources

6.2.1.1 TX Mailbox Interrupt

6.2.1.2 RX Mailbox Interrupt

6.2.1.3 ID Interrupt

6.2.2 Debug

1 Source

6.2.3 CP - Command Processor

2 Sources (read/write pointer watermark over- and underflow) check bit 0 and bit 1 of 0xcc000000

6.2.3.1 FIFO underflow

6.2.3.1.1 setup

- ⊳ setup CP FIFO low watermark
- ⊳ set bit 1 of CP interrupt status register (0xcc000002) to enable

6.2.3.1.2 handling

▷ clear bit 3 of CP interrupt status register (0xcc000002) to acknowledge

6.2.3.2 FIFO overflow

6.2.3.2.1 setup

- ⊳ set bit 0 of CP interrupt status register (0xcc000002) to enable

6.2.3.2.2 handling

▷ clear bit 2 of CP interrupt status register (0xcc000002) to acknowledge

6.2.4 PE - Pixel Engine Finished

1 Source (Frame finished)

6.2.4.1 setup

6.2.4.2 handling

⊳ set bit 3 in PE Interrupt status register (0xcc001000a) to acknowledge the interrupt

6.2.5 PE - Pixel Engine Token

1 Source (Token in GP Command List)

6.2.5.1 setup

6.2.5.2 handling

- ⊳ check PE Token Register (0xCC00000E) for the token that triggered the interrupt.
- ⊳ set bit 2 in PE Interrupt status register (0xcc001000a) to acknowledge the interrupt

6.2.6 VI - Video Interface

4 Sources, check (0xcc002030) (0xcc002034) (0xcc002038) (0xcc00203c) for flags

6.2.6.1 Setup

- > setup desired position of the interrupt
- ⊳ set enable bit in Display Interrupt Register (0xcc002030) (0xcc002034) (0xcc002038) (0xcc00203c)

6.2.6.2 Handling

▷ clear Status bit in Display Interrupt Register (0xcc002030) (0xcc002034) (0xcc002038) (0xcc00203c) to acknowledge the interrupt.

6.2.7 Memory Interface

4 sources (4 regions of memory can be protected independently)

6.2.7.1 protection fault

6.2.7.1.1 Setup

6.2.7.1.2 Handling

- > read status bits from (0xcc00401e) to check what region triggered the protection fault
- ⊳ set status bits in (0xCC00401e) to acknowledge the interrupt
- ⊳ read the address that triggered the protection fault from (0xcc004022) and (0xcc004024)

6.2.8 DSP Interface

3 Sources, check (0xcc00500a) for flags

6.2.8.1 Audio DMA finished asserted when audio DMA transfer has been completed.

6.2.8.1.1 Setup

6.2.8.1.2 Handling

⊳ set bit 3 of DSP Control Register (0xcc00500a) to acknowledge the interrupt.

6.2.8.2 ARAM transfer complete asserted when a transfer from/to auxiliary ram has been completed.

6.2.8.3 DSP

6.2.9 Audio Streaming Interface

1 Source, check (0xcc006c00) for flag. asserted based on the disk streaming sample counter.

6.2.10 EXI

3 Sources each EXI Channel (TCINT, EXTINT, EXIIRQ), making 9 total, check (0xcc006800) (0xcc006814) (0xcc006828) for flags.

6.2.10.1 DMA Transfer finished (TCINT channel 0, channel 1)

6.2.10.2 Ethernet Adapter (EXIIRQ channel 2)

6.2.10.2.1 setup

6.2.10.2.2 handling

- be check command register 3 (irq status) for the exact source (MX chip, killing irq,cmd error, challenge/response request, challange/response status)
- ⊳ if from MX chip, check register 8 and 9 for the exact cause

6.2.10.3 Memory Card removed (EXTINT channel 0, channel 1)

6.2.10.3.1 setup

6.2.10.3.2 handling

> To check whether the device has been inserted or removed, check the EXICPR[EXT] bit.

6.2.11 Serial Interface

6.2.12 DVD Interface

4 Sources (Break Complete, DMA finished, Device Error, Cover state changed), check (0xcc006000)(0xcc006004) for flags.

6.2.12.1 Break Complete

6.2.12.2 DMA finished

6.2.12.3 Device Error

6.2.12.4 Cover State changed

6.2.13 Reset Button

1 Source (Reset Button pressed)

6.2.13.1 setup

> no further setup required

6.2.13.2 handling

> nothing special required, its however recommended to clear the PI Interrupt Mask to avoid multiple interrupts.

6.2.14 Error

1 Source (GP runtime error)

7 VIDEO PROCESSING 158

7 Video Processing


7.1 Used VI terms

ightharpoonup XFB - external Framebuffer

The external framebuffer resides in main memory and can be directly displayed by the video processor.

- 7.2 init VI
- 7.2.1 Videomodes
- 7.3 render to XFB
- 7.4 vertical retrace
- 7.5 set XFB Address

8 3D Graphics Processing



8.1 basic operations

8.1.1 load BP Register

⊳ write byte 0x61 to GXFIFO

8.1.2 load CP Register

- ⊳ write byte 0x08 to GXFIFO

8.1.3 load XF Register

- ⊳ write byte 0x10 to GXFIFO
- ⊳ write 0x0000 (16 bit) to GXFIFO
- ⊳ write addr (16 bit) to GXFIFO

8.1.4 load XF Register Indexed

- ⊳ write byte 0x10 to GXFIFO
- ⊳ write n-1 (16 bit) to GXFIFO
- ⊳ write addr (16 bit) to GXFIFO

8.2 example processing loop

```
gx_init();
while(running)
{
gx_begin();
drawframe();
gx_end();
waitvsync();
}
gx_close();
```

8.2.1 init GX

8.2.1.1 setup the fifos

- ⊳ fifo start/end must be 32 byte aligned
- by typical size for the hi watermark is fifo size 16kb

8.2.1.2 enable gx command processing while (mfwpar () & 1);

PI[3] = 0x100000;

PI[4] = 0x110000;

PI[5] = 0x100000;

mtwpar(0xC008000); // GXFIFO physical address

mtspr(920, mfspr(920) | 0x40000000);

- **8.2.1.3 send setup frame** after setting up and enabling gx command processing it is recommended to send a first initial 'frame' to setup the various internal registers to useful values.
- **8.2.1.3.1 Videomodes** remember that depending on the videomode some things must be setup differently (such as the scissor, viewport, ...)
- 8.2.2 begin frame
- 8.2.3 draw frame
- 8.2.4 end frame

 - □ copy EFB to XFB
 - be terminate the list by writing 32 zeroes
 be terminate the list by writing 32 zeroes
 considerable the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing 32 zeroes.
 The second terminate the list by writing term

8.2.4.1 copy EFB to XFB #define XY(x, y) (((y) << 10) | (x))

GX_LOAD_BP_REG(0x4000001f); // set z mode

GX_LOAD_BP_REG(0x410004bc); // set color mode 0

GX_LOAD_BP_REG(0x49000000 | XY(0, 0)); // set source top left

GX_LOAD_BP_REG(0x4a000000 | XY(639, 479)); // set source bottom right

GX_LOAD_BP_REG(0x4d000028); // stride? (0x1280>>5) ... 640*2; 320*YuYv

 $GX_LOAD_BP_REG(0x4b000000 | (0xC00000 >> 5)); // xfb target address$

GX_LOAD_BP_REG(PE_COPY_CLEAR_AR | 0x0000);

 $GX_LOAD_BP_REG(PE_COPY_CLEAR_GB \mid 0x0000);$

GX_LOAD_BP_REG(PE_COPY_CLEAR_Z | 0xFFFFFF);

GX_LOAD_BP_REG(0x52004803); // do it (efb copy execution command?)

8.2.4.2 copy EFB to Texture simelar to copying EFB to XFB, setup BP registers 0x4a,0x4d,0x4b and then (0x52000003| (format < < 4))

8.2.5 close GX

9 Joy-Bus Devices

9.1 ID and Device List

The device ID can be read by sending the SI Command 0x00, and then reading 3 bytes from the respective device. The response-data looks like this:

first comes a 16bit device id:

ID	Device
0x0500	? N64 Controller
0x0001	? N64 Microphone
0x0002	? N64 Keyboard
0x0200	? N64 Mouse
0x0004	GBA
0x0800	GBA (n/a)
0x0900	GC Standard Controller
0xe960	? GC Wavebird Receiver
0xe9a0	? GC Wavebird
0xa800	? GC Wavebird
0xebb0	? GC Wavebird
0x0820	GC Keyboard
0x0800	? GC Steering Wheel
0x0900	DKongas (same as std Controller)
?	Resident Evil4 Chainsaw

bit(s)	description
15	wireless (1: wireless Controller)
14	wireless receive (0: not wireless 1: wireless)
13	Rumble Motor (0: available 1: not available)
12	Type of Controller (always 0 ?)
11	Type of Controller (0: N64 1: Dolphin)
10	wireless type (0:IF 1:RF)
9	wireless state (0: variable 1: fixed)
8	0: non standard Controller 1: Dolphin Standard Controller
7	
6	
5	wireless origin (0:invalid 1:valid)
4	wireless fix id (0:not fixed 1:fixed)
3	wireless type - 0:normal 1: non-controller (?)
2	wireless type - 0:normal 1: lite controller
1	wireless type -
0	wireless type -

the device id is followed by 8 status bits:

bit(s)	description
7	?
6	?
5	?
4	?
3	? rumble motor running
2	?
1	?
0	?

9.2 standard Controller

9.2.1 Init

⊳ enable all controllers in 0xcc006430

⊳ set Joy-channel 1-4 Command Register to 0x00400300

 \triangleright wait until bit 31 of 0xCC006434 is 0, then set it to 1

Command Word

0x00400000 - enable polling

0x00000300 - ?

0x00000100 - ?

0x00000001 - enable rumble motor

Commands:

0x00 - get id+status

0x40 - ?

0x41 - get origins

0x42 - calibrate?

9.2.2 Read Controller Status

 $\, \rhd \,$ simply read all Joy-channel registers and extract the info you want

first input word

bit(s)		Description
31		ERRSTAT - (assumed 0)
30		ERRLATCH - (assumed 0)
29		unused (?)
28	s	Start Button
27	У	Y Button
26	X	X Button
25	b	B Button
24	a	A Button
23		unused (?)
22	L	L Trigger
21	R	R Trigger
20		Z Trigger
19	u	D-Pad Up
18	d	D-Pad Down
17	r	D-Pad Right
16	1	D-Pad Left
8-15	х	Analog Stick X (8bit unsigned, ~32128~224)
0-7	у	Analog Stick Y (8bit unsigned, ~32128~224)

second input word

bit(s)		Description
24-31	X	Analog C Stick X (8bit unsigned, ~32128~224)
16-23	у	Analog C Stick Y (8bit unsigned, ~32128~224)
8-15	1	L Trigger Analog (8bit unsigned, ~32~224)
0-7	r	R Trigger Analog (8bit unsigned, ~32~224)

9.2.3 rumble Motor On

(volatile unsigned long)0xCC006400 = 0x00400001;

9.2.4 rumble Motor Off

(volatile unsigned long)0xCC006400 = 0x00400000;

9.3 Keyboard

9.3.1 Types

9.3.1.1 ASCII Official Nintendo/SEGA keyboard for the GameCube. It has 80 keys plus an Fn key, some of the keys have Japanese labelings. It has an LShift and an RShift key, but only a single Ctrl and Alt key. The Fn key is internal to the keyboard. It makes the keyboard send different scancodes if it is pressed, and an Fn keypress alone cannot be detected.

^{*(}volatile unsigned long*)0xCC006438 = 0x80000000;

^{*(}volatile unsigned long*)0xCC006438 = 0x80000000;

9.3.1.2 Datel A British IBM PS/2 keyboard that ships with an adapter.

9.3.1.3 Tototek Adapter Converts the IBM PS/2 protocol to the GameCube SI protocol and also converts the PS/2 scancodes into GameCube scancodes. The keys that have Japanese labelings on the ASCII keyboard get mapped to keys like PrintScreen and Pause.

- ▷ 0-9 and Enter send the scancodes of their counterparts on the alphanumeric part of the keyboard, regardless of the status of NumLock, so the Numpad cannot be used as cursor keys.
- ▶ The key right of LShift on non-US keyboards sends no scancode.
- ▷ The Pause/SysReq key only sends the keycode of 0x37 once, even if it's pressed down continuously.
- ▷ Numpad-* sends 0x37, the same as Pause/SysReq, but this one continues sending it.
- ▷ All combinations of Pause/SysReq with other keys are possible, except for these: LStrg or LStrg together with Pause/SysReq doesn't send anything. This would have been SysReq.
- ➤ The adapter easily gets confused by two keys for which it produces the same GameCube scancodes:
 If you hold down LStrg and press RStrg, the LStrg scancode will disappear even though LStrg is srill pressed down. The same is true for Ctrl and Alt.

9.3.2 Scancodes

	. 0	.1	. 2	.3	. 4	. 5	. 6	. 7
0.							Home	End
1.	A	В	С	D	Е	F	G	Н
2.	Q	R	S	Т	U	V	W	X
3.	7	8	9	0	()	=+	PrntScrn	Pause/SysReq
	NP 7	NP 8	NP 9	NP 0	NP -		NP/	NP *
4.	F1	F2	F3	F4	F5	F6	F7	F8
5.	Backspace	Tab		CapsLock	LShift (*54)		LCtrl (*56)	LAlt (*57)
6.		Enter						
		NP Enter						
	. 8	. 9	. A	.B	.C	.D	.E	. F
0.	PgUp	PgDn	ScrollLock					
1.	I	J	K	L	M	N	O	P
2.	Y	Z	1	2	3	4	5	6
			NP 1	NP 2	NP 3	NP 4	NP 5	NP 6
3.	[{	;:	"]}	,<	.>	/?	\1
		NP + (*39)				NP.		
4.	F9	F10	F11	F!2	ESC	Ins	Del	'~
5.	LWin	space	RWin	Menu	Left	Down	Up	Right
6.								
			NumLock (*6a)					

- (*39) Tototek adapter: makes only sence for japenese ASCII labeling
- (*54) Tototek adapter sends this code for LShift and RShift
- (*56) Tototek adapter sends this code for LCtrl and RCtrl
- (*57) Tototek adapter sends this code for LAlt and RAlt
- (*6a) Tototek adapter: undefined for GameCube

9.3.3 Init

⊳ enable controller in 0xcc006430

ightharpoonup set Joy-channel Command Register to 0x00540000

⊳ clear SI i/o buffer

⊳ wait until bit 31 of 0xCC006434 is 0, then set it to 1

Command Word

0x00540000 - enable polling

9.3.4 Read Keyboard

first input word

bit(s)	Description
31	ERRSTAT - (assumed 0)
30	ERRLATCH - (assumed 0)
24-29	?
16-23	?
8-15	?
0-7	?

second input word

bit(s)	Description
24-31	key1
16-23	key2
8-15	key3
0-7	?

9.4 **GBA**

to do

9.5 Wavebird

to do

9.6 steering wheel

to do

9.7 DKongas

These work exactly like the standard controllers from the programmers point of view, and they even have the same ID.

9.7.1 Read Controller Status

first input word

bit(s)		Description
31		ERRSTAT - (assumed 0)
30		ERRLATCH - (assumed 0)
29		unused (?)
28	s	Start Button
27	У	left Konga, top/left (Y Button)
26	х	right Konga, top/left (X Button)
25	b	left Konga, bottom/right (B Button)
24	a	right Konga, bottom/right (A Button)
23		unused (?)
22	L	unused (L Trigger)
21	R	unused ? (R Trigger)
20		unused (Z Trigger)
19	u	unused (D-Pad Up)
18	d	unused (D-Pad Down)
17	r	unused (D-Pad Right)
16	1	unused (D-Pad Left)
8-15	Х	unused (Analog Stick X)
0-7	у	unused (Analog Stick Y)

second input word

bit(s)		Description
24-31	X	unused (Analog C Stick X)
16-23	у	unused (Analog C Stick Y)
8-15	1	unused (L Trigger Analog)
0-7	r	Microphone (R Trigger Analog) (8bit unsigned, ~16?)

9.8 Resident Evil4 Chainsaw

to do

10 EXI Devices

10.1 EXI Channel and Device List

The following table shows the GameCube devices which use the EXI bus and their channel and device numbers, the EXI frequency commonly used with them and their virtual offset in EXI mapping.

channel	device	freq	offset	Description
0	0	4		Memory Card (Slot A)
0	1	3	0x00000000	Mask ROM
0	1	3	0x20000000	Real-Time Clock (RTC)
0	1	3	0x20000100	SRAM
0	1		0x20010000	UART
1	0	4		Memory Card (Slot B)
2	0			AD16 (trace step)
0	2			Serial Port 1
0	2	5		Ethernet Adapter (SP1)

Note: The Real-Time Clock (RTC), SRAM, and Mask ROM are actually one device mapped to different address offsets. The SRAM should only be accessed by the IPL and contains non-volatile system data. The Mask ROM contains the IPL itself (encrypted) and the system font data.

10.2 Retrieving the ID of an EXI Device

To retrieve the ID of an EXI Device, an EXI IMM write operation must be used to send the ID command (0x0000) and an EXI IMM read operation should follow it to read the actual 4 byte ID.

ID	Device
0x00000004	Memory Card 59
0x00000008	Memory Card 123
0x00000010	Memory Card 251
0x00000020	Memory Card 507
0x00000040	Memory Card 1019
0x00000080	Memory Card 2043
0x01010000	USB Adapter
0x01020000	NPDP GDEV
0x05070000	IS Viewer
0x04120000	AD16
0x03010000	Marlin (?)
0x02020000	Modem
0x04020200	Ethernet Adapter

10.3 Mask ROM

Mask ROM also referred as bootrom or IPL. Total size of bootrom is 2 MB.

10.3.1 Memory Map (Europe/PAL)

Start	End	Size	Description
0x00000000	0x000000ff	0x00000100	Copyright message (*1)
0x00000100	0x001aeee8	0x001aede8	BIOS data (*2)
0x001AFF00	0x001FA0E0	0x0004D000	'Yay0' - ROM Fonts #1 (SJIS)
			0x61 bytes of 0xFF, 0x62, followed by zeros until 0x1FCF00
0x001FCF00	0x001FF474	0x00003000	'Yay0' - ROM Fonts #2 (ANSI)
0x001FF474	0x001FFEF0		filled with 0x00
0x001FFF00		0x001FFFFF	filled with 0xff

^{(*1) &}quot;(C) 1999-2001 Nintendo. All rights reserved.(C) 1999 ArtX Inc. All rights reserved.PAL Revision 1.0 " and zeros up to 0x100.

10.3.2 Memory Map (USA/NTSC)

Start	End	Size	Description
0x00000000	0x0015ee40	0x0015ee40	BIOS data (*1)
0x001AFF00		0x0004D000	ROM Fonts #1 (SJIS)
0x001FCF00		0x00003000	ROM Fonts #2 (ANSI)
0x001FFF00		0x001FFFFF	filled with 0x00

^(*1) encrypted by an XOR cyphertext which is generated by a yet unknown algorithm (probably not a single LFSR)

note: all unused space is filled with 0x00, no pieces with 0xFF.

10.3.3 Memory Map (Japenese/NTSC)

10.3.4 Memory Map (Japenese/NTSC - Panasonic Q)

10.3.5 Font Encoding

The 'Yay0' data is compressed similar to the Zelda 64 'Yaz0' compression. Besides the Raw Font data it also contains some information about the Font.

10.3.6 Font Layout

10.3.6.1 SJIS Font (ROM Font #1)

10.3.6.2 ANSI Font (ROM Font #2) The ANSI Font is a 512x512 Pixel Texture in I4 Format. It consists of 21 colums and 11 rows of characters which are in a 24x24 pixel grid.

^(*2) encrypted by an XOR cyphertext which is generated by a yet unknown algorithm (probably not a single LFSR)

	!	,	#	\$	%	&	ť	()	*	+	,	-		/	0	1	2	3	4
5	6	7	8	9	:	;	<	=	>	?	@	A	В	С	D	Е	F	G	Н	I
J	K	L	M	N	О	P	Q	R	S	Т	U	V	W	X	Y	Z	[\]	٨
	,	a	b	С	d	e	f	g	h	i	j	k	1	m	n	О	p	q	r	S
t	u	V	W	X	y	Z														

10.3.7 Operation

10.3.7.1 read

⊳ IMM write 32 bit: (offset<<6)
</p>

▷ DMA read X bytes

max offset is 2*1024*1024, max block len is?

10.4 RTC (Real-Time Clock)

Real-Time Clock (RTC) is 32-bit value, counting time intervals in seconds. To get the real time (seconds since January 1st, 2000 12am) add the counter bias saved in SRAM.

10.4.1 Operation

10.4.1.1 read

 \triangleright IMM write 32 : 0x20000000 | (0<<6) (RTC offset)

▷ IMM read 32-bit RTC value

Since it is uncertain if the hardware prevents fragmented reads of the time interval (eg byte 1 from tick n and byte 2-4 from tick n+1) it is recommended to repeatedly retrieve the value until there is no difference between two consecutive reads.

10.4.1.2 write

- ▷ IMM write 32 : 0xA0000000 (== 0x20000000 | 0x80000000 (write flag) | (0<<6) (RTC offset))

10.5 SRAM

SRAM is battery backed memory, used for saving some non volatile settings. Size of SRAM is 64 bytes.

10.5.1 Memory Map

offset	end	size	Description							
0x00		2	Checksu	Checksum 1						
0x02		2	Checksu	Checksum 2						
0x04		4	ead 0							
0x08		4	ead 1	ead 1						
0x0c		4				to get actual time)				
0x10		1	display o	offset H (signed	value, -	3232)				
0x11		1	ntd							
0x12		1	language							
			value Description							
			0	english						
			1	german						
			2	french						
			3	spanish italian						
			4							
			5 dutch							
0x13		1	flags							
			bit(s)	Descriptio	n					
			7	? (=0)						
			6	? (=0)						
			5	? (=1)						
			4	? (=0)						
			3	? (=1)						
			2	0: mono 1:	stereo					
			1	? (=0)						
			0	? (=0)						
0x14		2*12	Flash ID							
0x2c		4		Keyboard ID						
0x30		4*2	wireless							
0x38		1		last DVD Errorcode						
0x39		1	padding/unused/reserved							
0x3a		2*2		Flash ID checksum						
0x3e		2	padding/	unused/reserve	d					

10.5.2 Operation

10.5.2.1 read

- ightharpoonup IMM write 32 : 0x20000100 (== 0x20000000 | (8 << 6) (SRAM offset))
- ⊳ DMA read 64 bytes.

10.5.2.2 write

- $> IMM \ write \ 32:0xa0000100 \ (==0x200000000 \ | \ 0x800000000 \ (write \ flag) \ | \ (8 << 6) \ (SRAM \ offset))$
- $\, \rhd \,$ use sequential IMM writes

10.5.3 Checksums

the SRAM data is protected against corruption by a simple additive checksum which is calculated like this:

```
void checksums (unsigned short *buf, unsigned short *c1, unsigned short *c2)
{
  int i;
  *c1 = 0; *c2 = 0;
  for (i = 0;i<4;++i)
{
  *c1 += buf[0x06 + i];
  *c2 += (buf[0x06 + i] ^ 0xFFFF);
}
}</pre>
```

10.6 AD16

AD16 is on channel 2, as device 0. Probably its used for debugging purposes. AD16 is the 32-bit register, keeping bootrom "trace-step".

10.6.1 Operation

10.6.1.1 init

► IMM write: 0x0000

▷ IMM read 32 bit ID and check it for error (it should be 0x04120000)

10.6.1.2 write

► IMM write: 0xa0

▷ IMM write 32-bit value (trace-step)

10.6.1.3 read

▶ IMM write : 0xa2

⊳ IMM read 32-bit AD16 register value

10.6.2 Trace-Step Values

10.6.2.1 BS

0x01000000	AD16 Inited, cache lines 320, 340,360, 380, 3a0 prefetched	
0x02000000	cache line 0x3e0 prefetched	
0x03000000	rest of cachelines prefetched	
0x04000000	ramtest passed	
0x05000000	ramtest error	
0x06000000	ramtest error	

10.6.2.2 BS2

0x00000800	System Init
0x00000900	DVD Init
0x00000a00	Card Init
0x00000b00	video init
0x00000c00	final before menu

10.7 Memory Cards

Product	Blocks	Mega bits	Mega bytes	Vendor	
Memory Card 59	64	4	0.5	Nintendo	
Action Replay memory card	64	4	0.5	Datel	
Memory Card '4 Mega'	64	4	0.5	3rd Party	WINBOND 512K*8 CN
Memory Card 123	128	8	1	Nintendo (*)	
Memory Card '8 Mega'	128	8	1	3rd Party	
Memory Card 251	256	16	2	Nintendo	
Memory Card 507	512	32	4	Nintendo (*)	
Memory Card 1019	1024	64	8	Nintendo	
Memory Card '64 Mega'	1024	64	8	3rd Party	
USB Memory Adaptor 64M / 1019 blocks	1024	64	8	EMS	
Memory Card 2043	2048	128	16	Nintendo (*)	

^(*) never seen those, appearently supported but never manufactured.

as you can see the products are named in reference to their *useable* capacity in blocks or total size in mega bits. The theoretical maximum size for a memory card is 128 mega bits (16 mega bytes, 2048 blocks).

10.7.1 Commands

Command	len	indata	len	outdata	len	Description
0x8500	2	-	_	ID	2	get ID
0x8300	2	-	_	Status	1	get Card Status
0x89	1	-	_	-	-	clear Card Status
0x52	1	offset, 0x00000000	8	Block Data	<=0x200	read Block
0xf40000	3	-	_	-	-	erase Card
0xf1	1	Sector	2	-	-	erase Sector
0xf2	1	Block offset	4	Block Data	<=0x80	write Block

10.7.2 Operation

10.7.2.1 unlocking original memory cards (those manufactured by nintendo) need to be 'unlocked' before they can be accessed. this is appearently done by a small dsp program.

to do

10.7.2.2 get ID

- ⊳ IMM write 0x85,00
- ⊳ IMM read 2 bytes ID

10.7.2.2.1 Card IDs

10.7.2.3 get Status

- ⊳ IMM write 0x83,00
- ⊳ IMM read 1 byte Status

10.7.2.3.1 Status Bits

х		r
bit(s)		description
7	X	1: erase in Progress (?)
0	r	1: Card ready (?)

0

10.7.2.4 clear Status

⊳ IMM write 0x89

10.7.2.5 read Block

⊳ select

⊳ IMM write: 0x52

 \triangleright IMM write: (offset >> 17), (offset >> 9), (offset >> 7) & 3, offset & 0x7F

max offset is 16*1024*1024, max block len is 512 bytes.

10.7.2.6 erase Card

- ⊳ select

10.7.2.7 erase Sector

- \triangleright select
- ▷ IMM write 0xf1
- \triangleright IMM write (sector >> 17) & 0x7F, (sector >> 9) & 0xFF
- > wait until bit 7 of card status is cleared

10.7.2.8 write Block

- ▷ select
- ▷ IMM write 0xf2
- \triangleright IMM write (offset >> 17) & 0x3F, (offset >> 9) & 0xFF, (offset >> 7) & 3, offset & 0x7F
- ⊳ write 0x80 bytes

10.8 Ethernet Adapter

The Macronix chip found in the ethernet adapter (mx98730ec) seems to be a reenginered version of the mx98726 or mx98728 (or the ec type respectively).

10.8.1 registers

Registerblock Base	Size of Registerblock	common access size
0x00	0x1000	1

These are the actual Chip Registers which match with the descriptions in MXs documents.

	0x00	1	r/w	NCRA - Network Control Register A (0x08 ?)
--	------	---	-----	--

7	0
????	?ep?

bit(s)		descrip	description					
7		INTCL	INTCLK - must be 0 for normal operation.					
6		INTMO	INTMODE - Interrupt Mode: Set for the active high interrupt, reset for the active low interrupt case.					
5		LB1 - I	LB1 - Loopback mode					
4		LB0	LB0					
		LB1	LB1 LB0 description					
		0 0 Mode0 - Normal mode						
		0	1	Mode1 - internal FIFO Loopback				
		1	0	Mode2 - internal NWAY Loopback				
	1 1 Mode3 - internal PMD Loopback							
3		SR - St	SR - Start Receive : Enable the MAC to receive packets. Default is disabled.					
2	e	ST1 - Start Transmit Command/Status						
1	p	ST0	STO					
0		RESET	` - Softv	vare reset.				

bit 1 and bit 2 will get cleared after a packet has been sent

0x01	1	r/w	NCRB - Network Control Register (0x11, 0x12?)
------	---	-----	---

7 0

bit(s)	description
6-7	RXINTC - Recieve Interrupt Counter
5	HBD - Heart Beat Check Disable
4	AB - "pass all broadcast frames"
3	PB - "pass bad frames"
2	PM - "pass all multicast"
1	CA - capture effect mode
0	PR - promiscuous mode

	0x02	1	r/w	GMAC Test Register A: TRA
--	------	---	-----	---------------------------

bit(s)	Description
7	SB - Start/Stop Back-off counter
6	FC - Forced Collision
5	RWD - Receive Watchdog Disable
4	RWR - Recieve Watchdog Release
1-3	TMODE - Test Moder Select bits
0	TEST - Test mode enable

0x03	1	r/w	GMAC Test Register B : TRB

bit(s)	Description
7	BFSTATUS
6	BFS1
5	BKCNTLB
4	BFS0
3	COLCNTCB
2	RDNCNTSB
1	RDNCNTCB
0	FKD - Flaky Oscillator Disable

0x04	1 r/w	LTPS - Last	Transmitted Packet S	tatus (transm	it error code ?)
------	---------	-------------	----------------------	---------------	------------------

bit(s)	Description	
7	TERR - Transmit Error	
6	OWC - Out of Window Collision	
5	UF - TX FIFO Underflow	
4	CRSLOST - Carrier Sense Lost	
3	CC3 - Collision Count Bit 3	
2	CC2	
1	CC1	
0	CC0	

0x05	1	r/w	LRPS - Last Recieved Packet Status
------	---	-----	------------------------------------

bit(s)	Description
7	RERR - Recieve Error
6	RF - Runt Frame
5	MF - Multicast Frame address
4	RW - Recieve Watchdog
3	FO - FIFO Overrun
2	FAE - Frame Alignment Error
1	CRC - CRC error
0	BF - RX Packet Buffer Full Error

0x06	1	r/w	MPCL - Missed Packet Counter
------	---	-----	------------------------------

bit(s)	Description
0-7	MISSCNT - Miss Packet Counter LSB

ĺ	0x07	1	r/w	MPCL - Missed Packet Counter
---	------	---	-----	------------------------------

bit(s)	Description
0-7	MISSCNT - Miss Packet Counter MSB

0x08	1	r/w	IMR - Interrupt Mask Register (IRQ Mask)

bit(s)	Description	
7	RBFIM - RX Buffer Full Interrupt Mask	
6	BUSEIM - Bus Error Interrupt Mask	
5	FIFOEIM - FIFO Error Interrupt Mask	
4	TEIM - Transmit Error Interrupt Mask	
3	REIM - Receive Error Interrupt Mask	
2	TIM - Transmit Interrupt Mask	
1	1 RIM - Recieved Interrupt Mask	
0	FRAGIM - Fragment Counter Interrupt Mask	

	0x09	1	r/w	IR - Interrupt Register (irq status)	
--	------	---	-----	--------------------------------------	--

7	0
???t	esr?

bit(s)		description	
7		RBFI - RX Buffer Full Interrupt	
6		BUSEI - Bus Error Interrupt	
5		FIFOEI - FIFO Error Interrupt	
4	t	TEI - Transmit Error Interrupt (1: transmit error)	
3	e	REI - Recieve Error Interrupt (1: receive error ?)	
2	s	TI - Transmit OK Interrupt (1: packet sent ?)	
1	r	RI - Receive OK Interrupt (1: packet received ?)	
0		FRAGI - Fragment Counter Interrupt	

0x0a	2	r/w	BP - Boundary Page Pointer Register (0x0100 ?)	
------	---	-----	--	--

0x0c	2	r/w	TLBP - TX Low Boundary Page Pointer Register
0x0e	2	r/w	TWP - Transmit Buffer Write Page Pointer Register
0x10	2	?/?	unused/reserved
0x12	2	r/w	TRP - Transmit Buffer Read Page Pointer Register
0x14	2	r/w	RXINTT - Receive Interrupt Timer
0x16	2	r/w	RWP - Receive Buffer Write Page Pointer Register
0x18	2	r/w	RRP - Receive Buffer Read Page Pointer Register
0x1a	2	r/w	RHBP - RX High Boundary Page Pointer Register (0x0f00 ?)
0x1c	1	r/w	EEPROM Interface Register:

bit(s)	Description
6-7	unused/reserved
5	EELD -
4	EESEL -
3	EEDO - Serial Data Output from external EEPROM clock device
2	EEDI - Serial Data Input to external EEPROM clock device
1	EECK - Serial Clock output to external EEPROM clock device (< 1 MHz)
0	EECS - Chip Select output to external EEPROM clock device

0x1d	1	r/w	BICT - Bus Integrity Check Timer
------	---	-----	----------------------------------

0x1e	2	r/?	IORDP - IO Data Port Page Pointer Register	
------	---	-----	--	--

0x20	6	r/w	PAR0-PAR5 Network Address Filtering Registers - Physical (MAC) Address

0x26 | 8 | r/w | MAR0-PAR7 Network Address Filtering Registers - Hash Table Register

0x2e	1	r/w	ANALOG - '	Transceiver	Control Register
------	---	-----	------------	-------------	------------------

bit(s)	Description	
6-7	unused/reserved (must be 0)	
5	5 RST100 - Reset for NORMAL mode	
4	RSQ - Reduced SQuelch Enable	
3	PWD100 - Reset for NORMAL mode	
2	PWD10B - Set for NORMAL mode	
1	DS130 - Must be 1 for NORMAL mode with auto-compensation	
0	DS120 - Must be 1 for NORMAL mode with auto-compensation	

0x2f	1	r/w	DINTVAL - DMA Interval Timer
------	---	-----	------------------------------

179

0x30 1 r/w NWAYC - NWAY Configuration Register	0x30
--	------

bit(s)	Description
7	LTE - Link Test Enable
6	NTTEST - reserved
3-5	ANS - Autonegotiation Status
2	ANE - Autonegotiation Enable
1	PS100/10 - Port Select 100/10 Mbit
0	FD - Full Duplex Mode

ı	0x31	1	r/-	NWAYS - NWAY Status Register
---	------	---	-----	------------------------------

bit(s)	description
7	10TXH - NWAY 10 TX Half duplex Mode
6	10TXF - NWAY 10 TX Full duplex Mode
5	100TXH - NWAY 100 Half duplex Mode
4	100TXF - NWAY 100 TX Full duplex Mode
3	ANCLPT - Auto-negotiation Completion
2	LPNWAY - Link Partner NWAY Status
1	LS100 - Physical Link Status of 100Mbps TP
0	LS10 - Physical Link Status of 10 Mbps TP

0x32 | 1 | r/w | GCA - GMAC Configuration A Register (0x08 ?)

bit(s)	description
7	unused/reserved (must be 0)
6	TXFIFOCNTEN
5	AUTOPUB - Auto Page Update option
4	unused/reserved
3	ARXERRB - Accept RX packet with error
2	SLOWSRAM
1	PBW - Packet Buffer Data Width
0	BPSCRM - Bypass Scrambler

0x33 | 1 | r/w | GCB - GMAC Configuration B Register

bit(s)	description
4-7	unused/reserved
2-3	RTHD - Recieve FIFO Threshold
0-1	TTHD - Transmit FIFO Threshold

0x34	4	-/w	TWD - IO Mapped Data Port

0x38 2 -/-	unused/reserved
------------	-----------------

0x3a	1	r/w	Host Interface Protocol Register (0x08 ?)
		•	
7 0]		

bit(s)	description
2	DREQB - DREQB-pin status bit
1	STIORD/RRDYB - (no data available ?)
0	WRDYB - Write Packet Memory Ready Bar Status Indication

0x3b 1 r/-	LPC - Link Partner Link Code Register
------------	---------------------------------------

0x3d	1	r/w	MISC1 - MISC Control Register 1

0x40 | 4 | r/- | RRD - RX Burst Read Data Port

0x44 2 r/- ID1 - 'MX'

0x46 2 r/- ID2 - '0001'

0x48 | 4 | w | WRTXFIFOD - Write TX FIFO Data Port Register (output queue)

0x4c | 4 | r/- | IORD - IO Read Data Port Register

0x50 1 r/w MISC2 - MISC Control Register 2 (0x80 ?)

0x51 | 1 | ? | (?)

note: register 0x51 is not documented in mx98728 datasheet

0x52 2 r/- HRPKTCNT - Host Recieve Packet Counter

0x54 | 3 | r/w | FRAGCNT - Host DMA Fragment Counter

note: 0x56 is the last reg of a mx98726 and mx98728

0x5b ? ?/? (?)

0x5c ? ?/? (?)

0x36 = disconnect network

0x5e ? ?/? (0x01?)

		0x60	?	?/?	(0x00?)
--	--	------	---	-----	---------

0x100	0xf00	?/w	input queue (?)
-------	-------	-----	-----------------

- select for reading
- IMM read block

10.8.2 command-registers

Registerblock Base	Size of Registerblock	common access size
0x00	0x10	1

These Registers are related to the EXI Interface on the Ethernet-Adapter, not to the actual Ethernet Chip.

0x00	?	?/?	EXI id

- select register for reading
- IMM read 4 bytes (0x04,0x02,0x02,0x00)

bit(s)		description
7	r	irq from MX chip
6	?	'killing' irq (should not get this one)
5	?	command error
4	p	challange/response request
3	h	challange/response status

- select register for writing
- IMM write 0xd1,0x07 (16bit)

0x05 ? ?/?	? (0x4e ?)
------------	------------

0x08	?	?/?	Challenge
------	---	-----	-----------

- select for reading
- IMM read 4 bytes

0x09	?	?/?	Response
------	---	-----	----------

- select for writing
- IMM write 4 bytes

0x0a :	? ?/?	? ?
--------	---------	-----

- 1: challenge/response ok
- 2: challenge/response failed

10.8.3 Operation

10.8.3.1 selecting a register for reading

10.8.3.2 selecting a register for writing

10.8.3.3 selecting command-register for reading

> IMM write (register<<8) (16 bits)

10.8.3.4 selecting command-register for writing

ightharpoonup IMM write 0x4000 | (register<<8) (16 bits)

10.8.3.5 init

```
\triangleright write reg - 1 byte to 0x60, 0x00
\triangleright read reg - 1 byte from 0x0f(?)
\triangleright write reg - 1 byte to 0x00, 0x01
\triangleright write reg - 1 byte to 0x00, 0x00 (not necessary?)
\triangleright read reg - 1 byte from 0x01, 0x00
\triangleright read reg - 1 byte from 0x5b
\triangleright write reg - 1 byte to 0x5b, write back previously read value AND ~(1<<7)
\triangleright write reg - 1 byte to 0x5e, 0x01 (or same as 0x5b ?!)
⊳ write reg - 1 byte to 0x5c, write back previously read value OR 4
\triangleright write reg - 1 byte to 0x01, 0x11
\triangleright write reg - 1 byte to 0x50, 0x80 (?)
\triangleright write reg - 1 byte to 0x08, 0xff
\triangleright write reg - 1 byte to 0x09, 0xff
\triangleright write reg - 1 byte to 0x02, 0x00 (?)
\triangleright write reg - 1 byte to 0x00, 0x08
⊳ write reg - 2 bytes to 0x16, 0x0100 (recv buffer write ptr)
⊳ write reg - 2 bytes to 0x18, 0x0100 (recv buffer read ptr)
```

10.8.3.6 challenge/response calculation

```
u32 ETHChallResp(u32 val,u32 revid_0,u32 revid_eth_0,u32 revid_eth_1)
{
    u32 c0,c1,c2,c3;

    c0=(
        ((val&0xff000000)>>24) +
            ((val&0x00ff0000)>>16) * 0xc1 + 0x18 + revid_0)
        ^ ((val&0x000000ff) * ((val&0x0000ff00)>>8)) + 0x90)
        ) & 0xff;
```

10.8.3.7 send packet (outside interrupt)

```
\triangleright write reg - X bytes to 0x48, <senddata> (X must be >=0x3c!)
```

- \triangleright read reg 1 byte from 0x00, status?
- \triangleright write reg 1 byte to 0x00, 0x00
- \triangleright write reg 1 byte to 0x00, previously read status OR 0x04 (set bit3, ACK error?)
- ⊳ read reg 1 byte from 0x00, status ;do while (status AND 0x06)!=0 (wait until packet sent)

10.8.3.8 poll received packets (outside interrupt)

```
> read reg - 2 bytes from 0x16, write_ptr
```

- if write_ptr==read_ptr, no more packets are available
- \triangleright write reg 1 byte to 0x3a, 0x02
- ⊳ read reg 1 byte from 0x3a, if (value&2)!=0, no more data is available
- > read reg- 4 bytes from read_ptr, packet descriptor
- \triangleright read reg X bytes from 0x100+read_ptr, <data> (X must be >=0x3c!; wrap around to 0x100 if read_ptr=0xf00)
- \triangleright write reg 2 bytes to 0x18, first byte of packet descriptor, 0x00 (advance read pointer)
- \triangleright write reg 1 byte to 0x09, 0x02
- ⊳ write cmd 1 byte to 0x02, 0xf8 (ACK?)

10.8.3.9 received packet format first 4 bytes of a received packet contains a descriptor about the packet that has been received

			VVVV		XXXX	XXXX		
1	31	2.4	2.3	16	15	8	7	0

bit(s)		Description
20-23	у	length of received packet lo bits (shift 4 down)
8-15	X	length of received packet hi bits (shift 4 up and OR with lo bits)

length is inclusive the 4 byte descriptor!

10.9 UART

(note: the existance of an UART is highly speculative and was never proved for a fact) to do

10.10 SD Cards

SD cards support an SPI mode, which is essentially the same hardware protocol that official memory cards use. Notice the use of the word hardware, not software. SD cards uses the MMC command set for communication and data transfer, while Nintendo memory cards use a custom Macronix command set. This means that you should not waste your time trying to get standard GC programs to recognize the SD card as a normal memory card, because it will not work without specific code to access the SD card. Even if you make the raw sector data on the SD card the same as the Nintendo memory card, the low-level commands to access the sectors differ between the two. However, since the hardware bus and protocol are the same, an SD adapter can essentially be made with straight-through connections from the EXI bus to the SD card signals.

to do

10.11 Viper 'Modchip'

this is a 3rd-Party 'modchip' used to override the IPL with a custom program. todo

10.12 Ripper III GC 'Modchip'

todo

10.13 Qoob 'Modchip'

todo

10.14 NinjaMOD 'Modchip'

10.15 Mario Party Microphone

todo

11 HSP DEVICES 187

11 HSP Devices

HSP devices seem to be accessable through the ARAM interface with offsets beyond 16MB.

11.1 GB Player

to do

12 Memory Card Structure

12.1 Overview

one "block" on memcard equals 0x2000 bytes, the first 5 blocks are used for the filesystem (0xa000 bytes).

Offset	Size	Description
0x0000	0x2000	Header
0x2000	0x2000	Directory
0x4000	0x2000	Directory backup (*)
0x6000	0x2000	Block Allocation Map
0x8000	0x2000	Block Allocation Map backup (*)
0xa000		file(s) data

(*) If a change is to be made that will alter the Master File Table, such as moving or deleting a file, copying a file from another memory card, or creating a new save game file, the GameCube will first backup the Master File Table to this location. Presumably, if the operation fails for certain reasons, the GameCube will restore the Backup File Table to the Master File Table.

12.2 Header

Offset	Size	Description
0x0000		?
0x000c	8	time of format (OSTime value)
0x0014		unique card id (?)
0x0020	2	padding zeroes
0x0022	2	size of memcard in Mbits
0x0024	2	encoding (ASCII or japanese)
0x0026		unused (0xff)
0x01fa	2	update Counter (?, probably unused)
0x01fc	2	Checksum 1 (?)
0x01fe	2	Checksum 2 (?)
0x0200	0x1e00	unused (0xff)

12.3 Directory

Offset	Size	Description
0x0000		Directory Entries (max 127)
0x0ffa	2	update Counter
0x0ffc	2	Checksum 1
0x0ffe	2	Checksum 2

12.3.1 Directory Entries

offset	length	descript	tion				
0x00	0x04	Gameco	Gamecode				
0x04	0x02	Makerco	Makercode				
0x06	0x01	reserved	/unused (alv	vays 0xff, has	no effect)		
0x07	0x01	banner g	banner gfx format and icon animation (Image Key)				
		bit(s)	bit(s) description				
		2	2 Icon Animation 0: forward 1: ping-pong				
		1		ner 1: Banner			
		0	Banner Co	olor 0: RGB5	A3 1: CI8		
0x08	0x20	filename)				
0x28	0x04			odification in	seconds since 12am	, January 1st, 2000	
0x2c	0x04		ata offset				
0x30	0x02		format (2bi				
		bits	Description	1			
			no icon				
				hared color p	alette after the last fi	rame	
			RGB5A3				
		11 CI8 with a unique color palette after itself					
0x32	0x02	animation speed (2bits per icon) (*1)					
			Description	l			
			no icon				
			Icon lasts fo				
			Icon lasts fo				
			Icon lasts fo	r 12 frames			
0x34	0x01	file-pern					
			permission	Description			
			no move		be moved by the IPI		
			ю сору		be copied by the IPI		
		1	oublic	Can be read	l by any game		
0x35	0x01	1.0	unter (*2)				
0x36	0x02	block no of first block of file $(0 == offset 0)$					
0x38	0x02	file-length (number of blocks in file)					
0x3a	0x02			vays 0xffff, ha			
0x3c	0x04	Address	of the two c	comments wit	hin the file data (*3)		

- (*1) Clearly, the animation rate is unimportant when there is only one frame of icon data; nevertheless, a value for that one frame must still be set, or that one frame will not be shown. It is illegal to specify that a frame does not exist if it does; a value of 00 indicates that no frame exists, and should not be mistaken for meaning that this frame should not be shown. If you specify blank frames to slow the frame rate, these also cannot be 00.
- (*2) This byte contains an 8-bit integer that indicates how many times the file has been copied from one memory card to another.
- (*3) Each file has two 32 character strings which the IPL displays at the bottom of the memory card screen, next to the banner. The two strings (64 bytes) must fit within one block (8192 bytes), they are not allowed to cross sector boundaries.

- **12.3.1.1 Image Data** Image data consists of a banner image and an icon. The banner image is not required, dependant on the value of the Image Key. If the banner image is not present, the icon image is displayed where the banner image would be displayed (centered horizontally). The icon image is required, and immediately follows the banner if present. Otherwise, it is located at the start of the image data.
- **12.3.1.1.1 Banner Image** The banner size is 96*32 pixels, making 3072 pixels in total (= 0x0c00 bytes in 8bit, 0x1800 bytes in 16bit mode). If the Banner is in CI8 mode, the palette follows immediately after the banners pixel data.
- **12.3.1.1.2 Icon Image** Immediately following the banner (if present) is the Icon Image. This can have a variable number of frames (up to eight), each 32*32 pixels, making 1024 pixels per frame in total. (= 0x0400 bytes in 8bit, 0x0800 byte in 16bit mode). If the Icon is in CI8 mode, its palette either follows immediately after its pixel data or after the pixel data of all 8 icons, depending on the icon gfx format field.
- **12.3.1.1.3 Palettes** Palettes in the image data are in RGB5A3 pixel format, and are 0x100 entries large. (= 0x200 bytes)

12.4 Block Allocation Map

Offset	Size	Description
0x0000	2	Checksum 1
0x0002	2	Checksum 2
0x0004	2	update Counter
0x0006	2	free Blocks
0x0008	2	last allocated Block
0x000a	0x1ff8	Map of allocated Blocks

This is an array of 0x0ffc 16 bit values, each holding info about one allocated block on the memory card. (thus the maximum memcard size is limited to 2048 blocks (16 Megabytes, 128Mbit))

each 16 bit value at position X in the array has the following meaning:

value	Description
0x0000	block is not allocated (ie, free)
0xffff	last allocated block of a file
any other	allocated block, usually equals (x+1) (==next block of file)

scan through a file like this:

```
thisblock=firstblock;
do
{
    // process block
    // next block
    thisblock=((unsigned short*)0x6000)[thisblock];
}
```

```
while (thisblock!=0xffff);
note:
```

although this scheme could do it, i have never stumbled about a file yet that is NOT linear on the memcard anyway. from this point of view using this allocation map seems to be a bit stupid...more testing needed:)

12.5 Checksums

The Checksums for the Directory and Block Allocation Map are simple 16bit additive checksums (ie nothing fancy or particular safe) which can be easily calculated like this:

```
void checksums(unsigned short *buf, int num, unsigned short *c1, unsigned short *c2)
{
   int i;
   *c1 = 0;*c2 = 0;
   for (i = 0; i < num; ++i)
   {
      *c1 += buf[i];
      *c2 += (buf[i] ^ 0xffff);
   }
   if (*c1 == 0xffff)
   {
      *c1 = 0;
   }
   if (*c2 == 0xffff)
   {
      *c2 = 0;
   }
}</pre>
```

13 DVD STRUCTURE 192

13 DVD Structure

total capacity of disc data is 1,459,978,240 bytes (1.5 GB approx.). that's exactly 712880 DVD raw sectors (each 2048 bytes).

start	end	size	Description
0x00000000		0x0440	Disk header ("boot.bin")
0x00000440		0x2000	Disk header Information ("bi2.bin")
0x00002440		(0x2000 ?)	Apploader ("appldr.bin")
			FST ('fst.bin')

13.1 Disk header

start	end	size	Description
0x0000	0x0003	0x0004	Game Code
			1 Console ID
			2 Gamecode
			1 Country Code
0x0004	0x0005	0x0002	Maker Code
0x0006		0x0001	Disk ID
0x0007		0x0001	Version
0x0008		0x0001	Audio Streaming
0x0009		0x0001	Stream Buffer Size
0x000a	0x001b	0x0012	unused (zeros)
0x001c	0x001f	0x0004	DVD Magic Word (0xc2339f3d)
0x0020	0x03ff	0x03e0	Game Name
0x0400	0x0403	0x0004	offset of debug monitor (dh.bin) ?
0x0404	0x0407	0x0004	addr (?) to load debug monitor ?
0x0408	0x041f	0x0018	unused (zeros)
0x0420	0x0423	0x0004	offset of main executable DOL (bootfile)
0x0424	0x0427	0x0004	offset of the FST ("fst.bin")
0x0428	0x042B	0x0004	size of FST
0x042C	0x042F	0x0004	maximum size of FST (usually its same as FST size) (*)
0x0430	0x0433	0x0004	user position (?)
0x0434	0x0437	0x0004	user length (?)
0x0438	0x043b	0x0004	(?)
0x043c	0x043f	0x0004	unused (zeros)

^(*) multiple DVDs must use it, to properly reside all FSTs.

13.2 Disk header Information

this is loaded to the Address in 0x800000f4 when a disc is initialized by the IPL

193

offset	end	size	Description
0x0000		4	Debug-monitor Size
0x0004		4	Simulated Memory Size
0x0008		4	Argument offset
0x000c		4	Debug flag
0x0010		4	Track Location
0x0014		4	Track size
0x0018		4	Countrycode
0x001c		4	?

13.3 Apploader

offset	end	size	Description
0x0000	0x0009		Date (version) of the apploader in ASCII
0x000A	0x000F		padding (0)
0x0010	0x0013	4	Apploader entrypoint
0x0014	0x0017	4	size of the apploader (32 bit) (usually 0x2000)
0x0018	0x001b	4	trailer size
0x0020			Apploader code (loaded to 0x81200000 in RAM)

13.4 Format of the FST

start	end	size	Description
0x00	0x0c	0x0c	Root Directory Entry
0x0c		0x0c	more File- or Directory Entries
			String table

13.4.1 Format of a File Entry

start	end	size	Description	
0x00		1	flags; 0: file 1: directory	
0x01		3	filename, offset into string table	
0x04		4	file_offset or parent_offset (dir)	
0x08		4	file_length or num_entries (root) or next_offset (dir)	

14 general File Formats

14.1 BNR (Banner file format)

this is the format of the file 'opening.bnr' (file size: always 6.496 bytes) found in the root directory of every Gamecube disc. This file is the little image that is displayed in the cube menu when inserting a disc into the gamecube, when in menu mode.

start	end	size	Description
0x0000	0x0003	0x0004	Magic Word "BNR1" (US/JP) or 'BNR2' (EU)
0x0004	0x001f		padding zeroes
0x0020	0x181f	0x1800	Graphical Data (Pixel-format is RGB5A1)
0x1820	0x183f	0x0020	Gamename (*)
0x1840	0x185f	0x0020	Company/Developer (*)
0x1860	0x189f	0x0040	Full Game Title (*)
0x18a0	0x18df	0x0040	Company/Developer Full name, or description (*)
0x18e0	0x195f	0x0080	Game Description (*)

(*) All Text is all stored in either SHIFT-JIS or ASCII, depending on the region of the Game.

note: In the filesystem of european Games with multi-lingual text there may be several .bnr files (opening.bnr, openingUS.bnr, openingEU.bnr, openingJP.bnr). The opening.bnr is a BNR2 file, it is just like a regular BNR file, except that the metadata at the end repeats several times in different languages. 0x1820 through 0x1960 are the first, and it continues in blocks of 0x0140.

14.2 DOL (Gamecube Executable)

This is a custom GameCube program file format, which is directly booted by GameCubes' BIOS (to be exact, by the apploader on retail discs. a different apploader could well load a binary in whatever different format.).

start	end	size	description
0x0000	0x001B		Text[06] sections File Positions
0x001C	0x0047		Data[010] sections File Positions
0x0048	0x0063		Text[06] sections Mem Address
0x0064	0x008F		Data[010] sections Mem Address
0x0090	0x00AB		Text[06] sections Sizes
0x00AC	0x00D7		Data[010] sections Sizes
0x00D8		0x04	BSS Mem address
0x00DC		0x04	BSS Size
0x00E0		0x04	Entry Point
0x00e4		0x1c	unused
0x0100			Start of sections data (body)

14.3 ELF (Executable and linkable Format)

The ELF format is a standard, known format for debugging target specific code, etc. GCC targeted for the PPC 750 processor or even for the specialized Gekko processor has a final output of ELF format files. The exact GameCube ELF file format details are currently unknown, but they should be similar to the standard specification.

14.4 GCB (QOOB Flash Files)

start	end	size	description			
0x00	0x03	4	ID, indicates whats in the block			
			0x28432920	'(C) ' - qoob bios file		
			0x454c4600	'ELF\0' - ELF File		
			0x42494e00	(not yet) 'BIN\0'		
			0x444f4c00	(not yet) 'DOL\0'		
0x04	0xf7		description, will	l be shown in boot menu	(by the qoob bios)	
0xf8	0xfb	4	reserved			
0xfc	0xff	4	size of block			
0x100			data			

14.5 GCM (Gamecube Disc Image)

These files are always 1.4GB's exactly and each contains a complete binary image of a proprietary format GameCube DVD. This file format is used for the NR-Writer DVD writing software which writes special DVDs that can only be read by NR-Reader GameCubes. The GCM file format can probably be closely compared to the ISO file format for CDs in its purpose.

14.6 GCI (Gamecube Game Save)

Used by the EMS Memory Adapter.

64 byte header (equal to FST entry on memcard), followed by the file data (as on memory card)

14.7 GCP (Gamecube Memorycard Image)

Used by the EMS Memory Adapter.

this is a raw image of all blocks of a memory card.

14.8 TGC

a proprietary image format found on demo discs and eg the zelda n64 emu

note: there seem to be tgc files on european discs that follow a different layout (no header).

14.8.1 Header

start	end	size	description
0x0000	0x0003	0x0004	TGC-Magic (0xae0f38a2)
0x0004	0x0007	0x0004	? (=0x00000000)
0x0008	0x000b	0x0004	TGC-Header Size (=0x00008000)
0x000c	0x000f	0x0004	? (=0x00100000)
0x0010	0x0013	0x0004	Offset to FST inside embedded GCM
0x0014	0x0017	0x0004	FST Size
0x0018	0x001b	0x0004	max FST Size
0x001c	0x001f	0x0004	Offset to Boot-DOL inside embedded GCM
0x0020	0x0023	0x0004	Boot-DOL Size
0x0024	0x0027	0x0004	?
0x0028	0x002b	0x0004	?
0x002c	0x002f	0x0004	Offset to Banner inside embedded GCM?
0x0030	0x0033	0x0004	Banner Size ?
0x0034	0x0037	0x0004	?

14.8.2 embedded GCM

usually starts at offset 0×00008000 (after the TGC Header) and follows exactly the same layout as a GCM file, with the following exceptions:

- ▷ Boot-DOL offset, FST offset contain bogus data and must be substituted by the data found in the TGC header
- > offsets within the embedded GCM file must be calculated relative to the start of the embedded GCM (obviously)

14.9 VGC (Viper Flash Files)

start	end	size	description			
0x00	0x03	4	Viper Magic ('VIPR')			
0x04		1	Configuration Flags			
			bit(s) description			
			7 GC_FLASH_ACCESS - allows access to the flashrom			
			6 ?			
			5 ?			
			3 COMMAND_MODE - enables modchip command mode (requires extended mode)			
			2 EXTENDED_MODE - allows reading of original IPL			
			1 COBRA_ENCRYPTION - enables additional encryption mode			
			0 DISABLE_CHIP - disables the modchip			
0x05		1	Lid Sensor Status at Boot Time (*2)			
			0 LID_OPEN			
			1 LID_CLOSED			
			2 LID_PASSTHROUGH			
0x06	0x0f	10	padding (zeros)			
0x10	0x1f	16	BIOS Name in Ascii			
0x20			Encrypted (*1) BIOS, loaded to 0x81300000			

^(*1) encrypted with the IPL XOR-Stream

197

(*2) original docs state that the default value is 0xff, however actually using this value seems to cause problems.

198

15 Game File Formats

This Section contains information about files used in, or produced by the official SDK, and thus is primarily useful for those who are hacking retail games.

15.1 AFC (audio stream)

15.2 AST (audio stream)

like afc but with tags?

15.3 ARC (RARC Archive)

This file is an archive file and contains several other files.

15.3.1 Header

The file starts with an Rarc-Header:

start	end	size	description
		4	type - 'RARC'
		4	size, size of the file
		4	unknown
		4	dataStartOffset, where does the actual data start? You have to add 0x20 to this value.
		16	unknown
		4	numNodes
		8	unknown
		4	fileEntriesOffset
		4	unknown
		4	stringTableOffset, where is the string table stored? You have to add 0x20 to this value.
		8	unknown

15.3.2 Nodes

Next are RarcHeader.numNodes Node structures:

start	end	size	description
		4	type
		4	filenameOffset, directory name, offset into string table
		2	unknown
		2	numFileEntries, how many files belong to this node?
		4	firstFileEntryOffset

Each RARC file contains at least one Node, the 'ROOT' node. For each subdirectory in the archive, there's another Node (so each Node represents a directory). Each Node contains files and directories, represented by FileEntry structures:

15.3.3 File Entries

start	end	size	description	
		2	id, file id. If this is 0xFFFF, then this entry is a subdirectory link	
		2	unknown	
		2	unknown	
		2	filenameOffset, file/subdir name, offset into string table	
		4	dataOffset, offset to file data (for subdirs: index of Node representing the subdir)	
		4	dataSize, size of data	
		4	zero, seems to be always '0'	

To read the archive, you read the root node and its file entries. For each subdir in the root node's fileentries, you read the corresponding node and its file entries. For each file in the fileentries, you dump its data.

15.4 ARC (audio stuff)

if a .arc file doesnt start with 'RARC' it may contain audio data

15.5 ASN

audio related, contains strings

15.6 AW ("audio wave"?)

15.7 BAS ("audio script"?)

seems to have to do with audio (check mkdd file names...)

15.8 BCA

looks very similar to a .col file, only with some tags in it

15.9 BCK (animation of a .bmd skeleton)

15.10 BDL

same as .bmd

15.11 BFN (font)

images of characters + mapping from character code to corresponding image part

15.12 BIN (binary file)

scene.bin in sms contains scene layout

200

- 15.13 BLO (screen layout for dialog screens)
- 15.14 BMD (3d model with texture and skeleton)

15.15 BMG

messages, subtitles, ... (text)

15.16 BMP (window bitmap (!))

15.17 BMT

seems to contain a MAT3 block of a .bmd file

15.18 BCK ("Pack" file)

15.19 BRK

animation stuff? rotation keys?

15.20 BTI

Note: some .bti files are Yaz0-compressed (if the first 4 bytes are 'Yaz0'), if this is the case you have to uncompress them first.

A .bti file stores a single image, but can store several mipmaps. The file starts with a texture-header (which is used in the TEX! section of bmd/bdl and jpa files to store textures aswell):

15.20.1 Texture Header

start	end	size	description			
0x00		1	format			
			0 I4 (4 bit intensity, 8x8 tiles)			
			1 I8 (8 bit intensity, 8x4 tiles)			
			2 IA4 (4 bit intensity with 4 bit alpha, 8x4 tiles)			
			3 IA8 (8 bit intensity with 8 bit alpha, 4x4 tiles)			
			4 RGB565 (4x4 tiles)			
			5 RGB5A3 (*) (4x4 tiles)			
			6 RGBA8 (4x4 tiles in two cache lines - first is AR and second is GB)			
			8 CI4 (4 bit color index, 8x8 tiles)			
			9 CI8 (8 bit color index, 8x4 tiles)			
			10 CI14X2 (14 bit color index, 4x4 tiles)			
			14 CMP (S3TC compressed, 2x2 blocks of 4x4 tiles)			
0x01		1	unknown			
0x02	0x03	2	width			
0x04	0x05	2	height			
0x06	0x07	2	unknown			
0x08		1	unknown			
0x09		1	Palette Format			
			0 IA8			
			1 RGB565			
			2 RGB5A3 (*)			
0x0a	0x0b	2	Palette Entries - number of entries in the Palette			
0x0c	0x0f	4	Palette Offset - offset to Palette Data			
0x10	0x13	4	unknown			
0x14	0x15	2	unknown			
0x16	0x17	2	unknown			
0x18		1	mipmap count			
0x19		1	unknown			
0x1a	0x1b	2	unknown			
0x1c	0x1f	4	Data Offset - offset to image Data			

^(*) RGB5A3 is RGB5 if color value is negative and RGB4A3 otherwise.

Offsets are relative to the Texture Header (this is important in bmd/bdl files).

15.21 BTP

99% sure that this contains texture animation (NOT texture coordinate animation)

15.22 BTK

(curves??? kinematics??) translation keys? probably some material animation as well (texture coord anim?)

15.23 COL (collision triangles)

15.24 DZB

collision data?

202

15.25 H4M

a proprietary Movie Format found on some Gamecube Game DVDs. Probably related to the HVQ (Hirarchical Vector Quantization) format developed by Hudson.

15.26 JPA (particle data)

(TEX1 section contains .bti images)

15.27 JPC

collection of .jpa files ("Particle paCk"?)

15.28 MTH ('Mute thp?')

video format, has the same video frame format as thp, but headers are a bit different

15.29 PAD

recorded controller data?

15.30 PRM ('Parameters?')

15.31 REL (relocatable module)

some kind of .dll or similar, contains text and data sections and relocation info

15.32 SB

?, contains a stringtable

15.33 SZS (packed RARC Archive)

This is a Yaz0-compressed RARC archive

15.34 THP (video format)

.thp is a video format on the gamecube. The video frames are independent "quasi-jpegs", and if audio frames are present, they are in an adpcm format (described below).

15.34.1 Header data

The file starts with a thp header:

start	end	size	description			
0x00	0x03	4	Magic Bytes, 0x54485000 ('THP\0')			
0x04	0x07	4	Version			
			0x00010000 v1.0			
			0x00011000 v1.1			
0x08	0x0b	4	maxBufferSize - maximal buffer size needed for one complete frame (header + video + audio)			
0x0c	0x0f	4	maxAudioSamples - != 0 if sound is stored in file, maximal number of samples in one frame.			
0x10	0x13	4	FPS (float value)			
			0x41efc28f ~29; NTSC			
0x14	0x17	4	numFrames - number of frames in the thp file			
0x18	0x1b	4	firstFrameSize - size of first frame (header + video + audio)			
0x1c	0x1f	4	dataSize - size of all frames (not counting the thp header structures)			
0x20	0x23	4	componentDataOffset - ThpComponents stored here (see below)			
0x24	0x27	4	offsetsDataOffset - if != 0, offset to table with offsets of all frames?			
0x28	0x2b	4	firstFrameOffset - offset to first frame's data			
0x2c	0x2f	4	lastFrameOffset - offset to last frame's data			

15.34.2 Components structure

At ThpHeader.componentDataOffset, a ThpComponents structure is stored:

start	end	size	descrip	description				
0x00	0x03	4	numComponents - usually 1 or 2 (video or video + audio)					
0x04	0x13	16	componentTypes - each byte specifies the type of one component as follows:					
			0x00	video				
			0x01	audio				
			0xff	no component				

The first ThpComponents.numComponents entries of ThpComponents.componentTypes are valid. For each component, an information structure is stored after the ThpComponents struct.

15.34.3 VideoInfo Structure

Component type 0 is video, a ThpVideoInfo struct looks like this:

ĺ	start	end	size	description
	0x00	0x03	4	width
Ì	0x04	0x07	4	height
Ì	0x08	0x0b	4	unknown (only v1.1 files)

15.34.4 AudioInfo Structure

Component type 1 is audio (not always included), a ThpAudioInfo struct looks like this:

start	end	size	description
0x00	0x03	4	numChannels
0x04	0x07	4	frequency
0x08	0x0b	4	numSamples
0x0c	0x0f	4	numData (only for v1.1 files) - amount of audio blocks stored after each video block

15.34.5 Frame data

A frame is made up of a frame header followed by a video frame followed by ThpAudioInfo.numData audio frames (only if the video contains sound).

The frame header consists of 3 (or 4, if the video contains sound) 32bit values:

start	end	size	description			
0x00	0x03	4	tTotalSize - total size of NEXT frame (frame header, video and audio)			
0x04	0x07	4	prevTotalSize - total size of PREVIOUS frame			
0x08	0x0b	4	imageSize - size of image frame of THIS frame			
0x0c	0x0f	4	audioSize - size of one audio frame of THIS frame (only if the file contains audio)			

Directly after the frame header FrameHeader.imageSize bytes video information follow. Directly after the video information, ThpAudioInfo.numData audio frames follow, each Frameheader.audioSize bytes large (only if the file contains audio).

15.34.6 Video Frames

A video frame is more or less a jpeg image. A jpeg file is structured by several markers. A marker is a two-byte code, the first of the two bytes is 0xff. The jpeg standard states that if you want to store the value 0xff, you have to store it as 0xff 0x00 (else it would be confused with a marker). This is NOT the case in .thp files, the value 0xff is stored simply as 0xff in the image data. So if you want to use jpeglib to read the frame, you have to convert the thp "quasi-jpeg" to a real jpeg by converting 0xff values to 0xff 0x00 in the image data. You have to be careful that you don't convert the terminating End-Of-Image marker, though.

- search for Start-Of-Image marker (0xff 0xda)
- search for End-Of-Image marker (0xff 0xd9) (start search at end of buffer and search backwards!)
- convert each 0xff between image data start and image data end to 0xff 0x00
- the resulting buffer can be passed to jpeglib to let it decode the image for you

15.34.7 Audio Frames

An audio frame starts with a ThpAudioFrameHeader (total size is 80 bytes)

start	end	size	description		
0x00	0x03	4	channelSize - size of one channel in bytes (*1)		
0x04	0x07	4	numSamples - number of samples/channel		
0x08	0x27	32	able for first channel (*2)		
0x28	0x47	32	table for second channel (stored for one channel videos as well) (*2)		
0x48	0x49	2	signed value, channel1Prev1		
0x4a	0x4b	2	signed value, channel1Prev2		
0x4c	0x4d	2	signed value, channel2Prev1		
0x4e	0x4f	2	signed value, channel2Prev2		

(*1) audio frame size = sizeof(ThpAudioFrameHeader) + ThpAudioInfo.numChannels * ThpAudioFrameHeader.

(*2) tables stored as 16bit signed 5.11 fixed point numbers

Directly after the ThpAudioFrameHeader ThpAudioFrameHeader.channelSize bytes follow for the first channel, and if the video is stereo (ThpAudioInfo.numChannels = 2), that many bytes follow for the second channel.

The audio data is made up of small packets of 8 byte, each packet contains 14 samples. Some kind of adpcm coding is used. A sample is calculated like this:

newSample = previousSample*factor1 + sampleBeforePreviousSample*factor2 + (sampleData
* 2^exponent);

For each packet, the first byte stores factor1, factor2 and exponent:

```
u8 index = (firstByte >> 4) & 0x7; //highest bit of byte is ignored
u8 exponent = firstByte & 0xf;
float factor1 = ThpAudioFrameHeader.table[2*index]/pow(2.f, 11);
float factor2 = ThpAudioFrameHeader.table[2*index + 1]/pow(2.f, 11);
```

The following 7 bytes store 14 sampleData (each 4 bit, interpreted as a signed two's complement number).

15.35 TPL (Texture Palette)

Another custom GameCube file format that holds texture and texture palette data. Many textures can be stored in one TPL file format, and it is commonly used by the SDK to hold texture data for GameCube games.

note: appearently there are different formats of .TPL files, the following applies only to those with the magic 0x00,0x20,0xaf,0x30.

TPL Header

start	end	size	description		
0x0000	0x0003	4	Magic (0x00, 0x20, 0xAF, 0x30)		
0x0004	0x0007	4	ntextures - Number of Textures in File		
0x0008	0x000b	4	size of Header (always 0x0c in files with this structure)		

TPL Texture

After the header goes 'ntextures' times the TPLTexture structure:

	start	end	size	description		
ĺ			4	Texture Header Offset		
ĺ			4	Texture Palette Offset (0 if no palette)		

TPL Texture Header

For every texture at position 'Texture Header Offset' there is the TPL Texture Header:

start	end	size	description				
		2	height				
		2	vidth				
		4	format				
			0 I4 (4 bit intensity, 8x8 tiles)				
			1 I8 (8 bit intensity, 8x4 tiles)				
			2 IA4 (4 bit intensity with 4 bit alpha, 8x4 tiles)				
			3 IA8 (8 bit intensity with 8 bit alpha, 4x4 tiles)				
			4 RGB565 (4x4 tiles)				
			5 RGB5A3 (*) (4x4 tiles)				
			6 RGBA8 (4x4 tiles in two cache lines - first is AR and second is GB)				
			8 CI4 (4 bit color index, 8x8 tiles)				
			9 CI8 (8 bit color index, 8x4 tiles)				
			10 CI14X2 (14 bit color index, 4x4 tiles)				
			14 CMP (S3TC compressed, 2x2 blocks of 4x4 tiles)				
		4	offset to Texture Data				
		4	wrap s				
		4	wrap t				
		4	min filter				
		4	mag filter				
		4	lod bias (float value)				
		1	edge lod				
		1	min lod				
		1	max lod				
		1	unpacked				

TPL Palette Header

For every palette (not every texture has one) there is the TPL Palette Header:

start	end	size	description			
		2	nitems			
		1	unpacked			
		1	pad			
		4	format			
			0 IA8			
			1 RGB565			
			2 RGB5A3 (*)			
		4	offset to Palette Data			

 $(\mbox{*})$ RGB5A3 is RGB5 if color value is negative and RGB4A3 otherwise.

15.36 YMP (height map)

16 Compression Formats

16.1 Yay0

This format is used to store the fonts in the BIOS/IPL. It is compressed similar to the Zelda 64 'Yaz0' compression.

16.1.1 compression

start	end	size	description
0x0000		4	'Yay0' signature
0x0004		4	size of decoded data in bytes
0x0008		4	offset to link table
0x000c		4	offset to non-linked chunks and count modifiers table
0x0010			packed data (32 bit words)

The packed data is a bitstream (padded to a multiple of 32bits), with each bit having the following meaning:

0	linked chunk, copy block from the link table (offset 0x0008)
1	non linked chunk, copy next byte from non-linked chunks and count modifiers table (offset at 0x000c)

todo

16.1.2 de-compression Code

```
void Decode(void *s, void *d)
u32 i, j, k;
u32 p, q;
u32 cnt;
i = r21 = *(u32 *)(s + 4); // size of decoded data
j = r29 = *(u32 *)(s + 8); // link table
k = r23 = *(u32 *)(s + 12); // byte chunks and count modifiers
q = r31 = 0; // current offset in dest buffer
cnt = r28 = 0; // mask bit counter
p = r24 = 16; // current offset in mask table
// if all bits are done, get next mask
if(cnt == 0)
// read word from mask data block
r22 = *(u32 *)(s + p);
p += 4;
cnt = 32; // bit counter
// if next bit is set, chunk is non-linked
if(r22 & 0x80000000)
// get next byte
*(u8 *)(d + q) = *(u8 *)(s + k);
k++; q++;
```

```
// do copy, otherwise
else
// read 16-bit from link table
r26 = *(u16 *)(s + j);
j += 2;
// 'offset'
r25 = q - (r26 \& 0xfff);
// 'count'
r30 = r26 >> 12;
if(r30 == 0)
// get 'count' modifier
r5 = *(u8 *)(s + k);
k++;
r30 = r5 + 18;
else r30 += 2;
// do block copy
r5 = d + r25;
for(i=0; i<r30; i++)
*(u8 *)(d + q) = *(u8 *)(r5 - 1);
q++; r5++;
// next bit in mask
r22 <<= 1;
cnt--;
} while (q < i);
}
```

10.1.	3	Font	Data

start	end	size	description
0x0000		2	Font Type
0x0002		2	first Character in Font
0x0004		2	last Character in Font
0x0006		2	Character to use for substituting invalid Characters
0x0008		2	ascent Units
0x000a		2	descent Units
0x000c		2	width of widest Character
0x000e		2	leading Space
0x0010		2	Cell width
0x0012		2	Cell Height
0x0014		4	Texture Size
0x0018		2	Texture Format
0x001a		2	Texture Columns
0x001c		2	Texture Rows
0x001e		2	Texture Width
0x0020		2	Texture Height
0x0022		2	offset to Character-width Table
0x0024		4	offset to Tile-Data
0x0028		4	Tile-Data Size

16.2 Yaz0

Yaz0 compression is reportedly used in quite a few Nintendo datafiles. I have seen it in SuperMario Sunshine's .szs files for example, and I heard that it is used in Windwaker and Majoras Mask as well.

The first 16 bytes of a Yaz0-compressed data block are the data header. The first 4 bytes of the header are 'Y', 'a', 'z', '0', so you can easily see in your hex editor that there's a Yaz0 block waiting for you :-) The second 4 bytes are a single uint32 (big-endian of course) that tells you the size of the decompressed data, so you know how large your working buffer has to be. The next 8 bytes are always zero.

Next comes the actual compressed data. Yaz0 is some kind of RLE compression. You decode it as follows: First you read a "code" byte that tells you for the next 8 "read operations" what you have to do. Each bit of the "code" byte represents one "read operation" (from left to right, that is, 0x80 first, 0x01 last). If the bit is 1, copy one byte from the input buffer to the output buffer. Easy. If the bit is 0, things are a little bit more complicated, RLE compressed data is ahead. You have to read the next two bytes to decide how long your run is and what you should write to your output buffer.

15	8	7	0
a	b		

The upper nibble of the first byte (a) contains the information you need to determine how many bytes you're going to write to your output buffer for this "read operation". if a == 0, then you have to read a third byte from your input buffer, and add 0x12 to it. Otherwise, you simply add 2 to a. This is the number of bytes to write ("count") in this "read operation". byte2 and the lower nibble of byte1 (b) tell you from where to copy data to your output buffer: you move (dist = (b << 8)lbyte2 + 1) bytes back in your outputBuffer and copy "count" bytes from there to the end of the buffer. Note that count could be greater than dist which means that the copy source and copy destination might overlap.

16.2.1 de-compression Code

//src points to the yaz0 source data (to the "real" source data, not at the header!)
//dst points to a buffer uncompressedSize bytes large (you get uncompressedSize from

```
//the second 4 bytes in the Yaz0 header).
void decode(u8* src, u8* dst, int uncompressedSize)
int srcPlace = 0, dstPlace = 0; //current read/write positions
u32 validBitCount = 0; //number of valid bits left in "code" byte
u8 currCodeByte;
while(dstPlace < uncompressedSize)</pre>
//read new "code" byte if the current one is used up
if(validBitCount == 0)
currCodeByte = src[srcPlace];
++srcPlace;
validBitCount = 8;
if((currCodeByte & 0x80) != 0)
//straight copy
dst[dstPlace] = src[srcPlace];
dstPlace++;
srcPlace++;
else
//RLE part
u8 byte1 = src[srcPlace];
u8 byte2 = src[srcPlace + 1];
srcPlace += 2;
u32 dist = ((byte1 \& 0xF) << 8) | byte2;
u32 copySource = dstPlace - (dist + 1);
u32 numBytes = byte1 >> 4;
if(numBytes == 0)
numBytes = src[srcPlace] + 0x12;
srcPlace++;
else
numBytes += 2;
//copy run
for(int i = 0; i < numBytes; ++i)</pre>
dst[dstPlace] = dst[copySource];
copySource++;
dstPlace++;
}
//use next bit from "code" byte
currCodeByte <<= 1;</pre>
validBitCount-=1;
}
}
```

17 Graphic Formats

17.1 YCbYCr

This is the Format used for image data in the external framebuffer (XFB). It exploits the fact that the resolution of color on a PAL/NTSC screen is lower than the resolution of luminance (brightness), and thus stores only separate luminance info for each pixel and combines the color information of two pixels each, saving 2 bytes versus traditional RGB-per-pixel framebuffers. This means that in XFB you cant modify the color of a single pixel without affecting its neighbour. (you can however, seperatly modify its luminance/brightness). It also means that you can not accurately convert one single pixel into XFB framebuffer format, you will always have to convert two pixels at once.

To convert two pixels to YCbYCr, first average their RGB values

```
R = (R1+R2)/2

G = (G1+G2)/2

B = (B1+B2)/2
```

now calculate the luminance portion of each pixel

```
Y1 = (77/256)R1 + (150/256)G1 + (29/256)B1

Y2 = (77/256)R2 + (150/256)G2 + (29/256)B2
```

then calculate the combined color portion

```
Cb = -(44/256)R - (87/256)G + (131/256)B + 128

Cr = (131/256)R - (110/256)G - (21/256)B + 128
```

now a 32 bit value to be written to XFB (to a 32 bit aligned address of course) can be made up like this

31	24	23	16	15	8	7	0
1111	1111	bbbb	bbbb	2222	2222	rrrr	rrrr

bit(s)		description
24-31	1	Y1 - luminance Portion of first Pixel
16-23	b	Cb - combined color
8-15	2	Y2 - luminance Portion of first Pixel
0-7	r	Cr - combined color

converting a single pixel back to RGB looks like this

```
R = Y + 1.371 (Cr - 128)

G = Y - 0.698 (Cr - 128) - 0.336 (Cb - 128)

B = Y + 1.732 (Cb - 128)
```

- **17.2 I4** (4bit indexed)
- 17.3 IA4 (4bit indexed with alpha)
- **17.4 I8** (8bit indexed)
- 17.5 IA8 (8bit indexed with alpha)
- 17.6 CI4 (compressed 4bit indexed)
- 17.7 CIA4 (compressed 4bit indexed with alpha)
- 17.8 CI8 (compressed 8bit indexed)

Used for Icons and Banners on Memory Card. This Format uses a palette in RGB5A1 Format, the Pixel data is stored in 8x4 pixel tiles.

17.9 CIA8 (compressed 8bit indexed with alpha)

17.10 RGB4A3

Used for Icons and Banners on Memory Card. This Format uses no palette and is stored in 4x4 pixel tiles.

17.10.1 RGB4A3 Pixel Format

15	8	7	0
.ttt	rrrr	gggg	bbbb

bit(s)		description
15		unused (?)
12-14	t	transparency
8-11	r	red channel
4-7	g	green channel
0-3	b	blue channel

17.11 RGB5A1

Used for Icons and Banners on Memory Card. This Format uses no palette and is stored in 4x4 pixel tiles.

17.11.1 RGB5A1 Pixel Format

15	8	7	0
trrr	rrgg	gggb	bbbb

bit(s)		description
15	t	transparency
10-14	r	red channel
5-9	g	green channel
0-4	b	blue channel

17.12 RGB565

17.12.1 RGB565 Pixel Format

15	8	7	0
rrrr	rggg	gggb	bbbb

bit(s)		description
11-15	r	red channel
5-10	g	green channel
0-4	b	blue channel

17.13 RGBA8

17.13.1 RGBA8 Pixel Format

31	24	23	16	15	8	7	0
rrrr	rrrr	aaaa	aaaa	bbbb	bbbb	aaaa	aaaa

bit(s)		description
24-31	r	red channel
16-23	g	green channel
8-15	b	blue channel
0-7	a	alpha channel

17.14 S3TC

WARNING: this section is screwed! any advice/corrections/help/etcblabla welcomed! (thanx to **Aaron Kaluszka** for pointing this out)

S3TC is a compression method for textures, developed by S3 and licenced by Nintendo for the Gamecube (and also by Microsoft for DirectX 6.0). It basically gives you one more MIP level for free, with relatively small quality loss and a simple implementation in hardware. You basically store 2 colour values and then you have a few bits per pixel to interpolate between them. It works in blocks of 4x4 pixel.

There are 5 variants:

DXT1 allows one bit of alpha

DXT2/3 allows 4 bits of alpha

DXT4/5 stores 2 alpha values and has 3 bits to interpolate between them

The difference between DXT2/3 and 4/5 is, if colour values are pre-multiplied with alpha. The blending equation is normally $(c^*(1-a))+(t^*a)$, so with pre-multiplied alpha the texture contains (t^*a) in each colour channel and the blending becomes $(c^*(1-a)+t)$.

Each image is made up of tiles placed linearly from left to right then top to bottom.

Each tile is made up of 4 blocks

0.1

23

Each block is made up of 8 words. ăThese 8 words represent 16 pixels using S3TC compression.

RRRRGGG - GGGBBBBB - rrrrggg - gggbbbb - 00112233 - 44556677 - 8899UUVV- WWXXYYZZ

```
R = Color 0 Red
G = Color 0 Green
B = Color 0 Blue
r = Color 3 Red
g = Color 3 Green
b = Color 3 Blue
0 - 9, U - Z = Pixel color (2-bits each)
Colors 1 and 2 are interpolated from colors 0 and 3
```

The tiles are 32 bytes each. Depending on the image format the width and height of the tiles will differ. A 16bit format (ie RGB5 or RGB4A3) will have a 4x4 pixel tile since 4 * 4 * 2 bytes = 32. An 8bit format (ie Color Indexed) will have a 8x4 pixel tile since 8 * 4 * 1 byte = 32.

So a 32x32 image (like a memory card icon) that is in RGB5 format would be 8 tiles across and 8 tiles down.

17.14.1 CMPR

Like a usual texture, a CMPR-texture is divided on tiles, each 32-bytes to fit a texture cache line. Every tile is sub-tiled into four parts, in zigzag order :

0	1
2	3

The format of the sub-tiles is pretty simple, and looks like DXT1. First two base colors in RGB565, followed by 16 sub-tile texels. Every texel is 2-bit wide, to lookup from four colors: 00, 01, 10 and 11. First two are given already, and last two are interpolated from first ones, by the following rule:

```
    COLOR0 and COLOR1 are base colors.
```

```
▷ RGB0 <- unpack RGB565 COLOR0
```

- A0 = 255
- ⊳ RGB1 <- unpack RGB565 COLOR1
 </p>
- \triangleright A1 = 255

if COLOR0 > COLOR1

```
\triangleright RGB2 = (2 * RGB0 + RGB1) / 3
```

 \triangleright A2 = 255

A3 = 0

18 APPENDIX 216

18 Appendix

18.1 GCC Quick How To

18.1.1 compile ASM to object:

```
<DEVKITCUBE>/bin/powerpc-eabi-elf-as -c \
-I <DEVKITCUBE>/powerpc-eabi-elf/include -I <additional includes> \
testasm.s -o testasm.o
```

18.1.2 compile C to object:

```
<DEVKITCUBE>/bin/powerpc-eabi-elf-gcc -c \
-I <DEVKITCUBE>/powerpc-eabi-elf/include -I <additional includes> \
-nostdlib testc.c -o testc.o
```

18.1.3 compile C++ to object:

```
<DEVKITCUBE>/bin/powerpc-eabi-elf-g++ -c \
-I <DEVKITCUBE>/powerpc-eabi-elf/include -I <additional includes> \
-nostdlib -fno-exceptions testcpp.cpp -o testcpp.o
```

18.1.4 link objects

```
<DEVKITCUBE>/bin/powerpc-eabi-elf-ld -T ppc-ngcbin.x -o test.elf crt0.o \
<DEVKITCUBE>/lib/gcc-lib/powerpc-eabi-elf/3.3/crtbegin.o \
<DEVKITCUBE>/lib/gcc-lib/powerpc-eabi-elf/3.3/crtend.o \
testasm.o testc.o testcpp.o -lg -lstdc++ -lm -lc -lnosys
```

you only need to link against crtbegin.o/crtend.o if you are using c++, and you only need -lg,-lstdc++,-lc,-lm if you are actually using these libraries (of course:)). however if you do so, linking against -lnosys as well is essential.

18.1.5 remove unneeded sections (debug info etc) from object

```
<DEVKITCUBE>/bin/powerpc-eabi-elf-strip -s test.elf
```

18.1.6 convert object to plain binary

```
<DEVKITCUBE>/bin/powerpc-eabi-elf-objcopy -O binary test.elf test.bin
```

18.1.7 convert absolute address into filename/line number/function

```
compile with "-g" flag, then use
```

```
<DEVKITCUBE>/bin/powerpc-eabi-elf-addr2line -f -e test.elf 0x80003100
```

18.1.8 Building a Crosscompiler

configure options:

- --target=powerpc-eabi-elf
- --with-cpu=750
- --disable-threads
- --enable-languages=c
- --disable-shared
- --disable-nls
- --with-newlib

18.1.9 Linker Script

to do

18.1.10 Startup Code

to do

18.2 Boot Process Details

The IPL (Initial Program Loader), or Bootrom, is located inside one Macronix chip (near Flipper, U10) and connected to the EXI bus. When the Gamecube is powered on, bit 25 (IP) in the Machine State Register is set, which means the system exception vector offset is 0xfff00000. Then a small (about 0x0700 bytes) program called 'BS' will be mapped to 0xfff00100 (the hardware reset vector) and control will be returned to the Gamecube like after a normal reset, which means 'BS' will be started.

18.2.1 BS - Bootstrap 1

- ⊳ copies the Bootstrap 2 code (BS2) from Bootrom to 0x81300000
- ▷ disables the IPL decryption logic by clearing bit 17 of 0xcc006800
- > sets IP of Machine State Register so exception vectors are pointing to lower memory
- ⊳ jumps to BS2 code

18.2.2 BS2 - Bootstrap 2

BS2 is the Program that loads the game or shows the menus when the gamecube has been powered on without a game inserted. It was written in C, using official SDK libraries, probably earlier than 1.0. __start.c seems to be same as usual, except that there is no OSInit() call (old versions must call OSInit() in main, instead of __start).

note: this has been reversed from a PAL gamecube and looks different on a NTSC one.

18.2.2.1 short description of start() routine.

// 81300000

```
start:
    __init_registers() // set stack pointer and static bases (r2, r13)
    __init_hardware() // paired-singles and cache init
    __init_data() // clear bss ?
    . // here goes Debug Monitor stuff
    DBInit() // debug monitor init :)
    __init_user() // cpp init
    main() // that's actually, IPL (BS2) code
    jmp exit() // halt CPU
18.2.2.2 IPL main() reversing
// 813006D4
main()
    BS2Init();
    OSInit();
    AD16Init();
    AD16WriteReg(0x800);
    DVDInit();
    AD16WriteReg(0x900);
    CARDInit();
    AD16WriteReg(0xa00);
    0x81302104(); // SRAM, real-time clock (check ?)
    ___VIInit(0);
    VIInit();
    AD16WriteReg(0xb00);
    0x813004e4(); // setup performance. monitor
    0x8130222c(); // update time-base by SRAM clock
    0x813022c0(); // perform initial DVD actions and fall back into menu
    PADSetSpec(5); // sed PAD type ('spec') to 'production'
    PADInit();
    AD16WriteReg(0xc00);
```

BS2Menu(); // here goes intro and main menu... (BIG one!)

```
OSPanic(__FILE__, __LINE__, "BS2 ERROR >>> SHOULD NEVER REACH HERE");
}
float NaN;
// 8130045C
void BS2Init()
    // clear LoMem and OSMem
    memset(0x80000000, 0, 256);
    memset(0x80003000, 0, 256);
    BATInit();
    // set memory size to 24MB
    *0x80000028 = 0x01800000;
    // set console type to default retail 1
    *0x8000002c = 1;
    // upgrade retail
    *0x8000002c += *0xcc00302c >> 28;
    (u32) NaN = -1;
    FPUInit();
}
// 813003A0
void BATInit()
    __asm
    {
       isync
       li r4, 0
       mtspr DBAT2L, r4
        mtspr DBAT2U, r4
        mtspr DBAT3L, r4
       mtspr DBAT3U, r4
       mtspr IBAT1L, r4
        mtspr IBAT1U, r4
        mtspr IBAT2L, r4
        mtspr IBAT2U, r4
        mtspr IBAT3L, r4
        mtspr IBAT3U, r4
        isync
```

```
}
}
// 813003D8
void FPUInit()
    // FPU already initialized in __start(),
    // so just invalidate all FPRs.
    __asm
   {
   lfs f0, NaN
   fmr f1, f0
    fmr f2, f0
    fmr f3, f0
    . е
    . t
    . C
    fmr f31, f0
    }
}
// maybe later
0x81302104()
    __OSLockSram();
    __OSCheckSram();
    __OSGetRTC();
    OSTickToCalendarTime();
   memset();
   __OSUnlockSram();
    __OSSyncSram();
}
// maybe later
0x813004e4()
    OSDisableInterrupts();
    OSGetTick();
    OSGetTick();
    OSGetTick();
```

```
__div2i();
    __div2i();
    PPCMtpmc1();
    PPCMtmmcr0();
   OSGetTick();
    OSGetTick();
   PPCMtmmcr0();
   PPCMfpmc1();
    __div2i();
    __div2i();
    __div2i();
    OSRestoreInterrupts();
// maybe later
0x8130222c()
   __OSLockSram();
   __OSGetRTC();
    __OSSetTime();
   __OSUnlockSram();
static int BS2State = 0;
// just layer..
0x813022c0()
   BS2State = BS2Mach();
// 81300A70
// located in __FILE__ = "BS2Mach.c"
int BS2Mach()
    static int state = 0;
    BOOL level = OSDisableInterrupts();
    switch(state)
        case 0:
           [r13 - 0x7dc8] = 0x800030d4;
```

```
state = 1;
       case 1:
           __OSGetSystemTime();
... some checks
          if(fail) break;
           state = 2;
       // Install DVD cover callback
       case 2:
           if([r13 - 0x7da8] == 0)
                   r3 = [r13 - 0x7dc8]
                   [r3] = 0
                   [r13 - 0x7dc4] = 0
                   [r13 - 0x7dac] = 1
                   DVDLowSetResetCoverCallback(0);
                   DVDReset();
                   [r13 - 0x7da8] = 1
                   (s64)[r13 - 0x7d9c] = \_OSGetSystemTime();
               break;
           __OSGetSystemTime();
           if(fail) break;
           DVDLowSetResetCoverCallback(0x813007d8);
           DVDReset();
           state = 3;
       // Read Disk information (ID)
       case 3:
           DVDReadDiskID(0x8145e620 + 64, 0x80000000, 0x813007e4);
           state = 4;
       break;
       // Leave immediately ?
```

```
case 16:
           break;
        default:
            OSPanic(__FILE__, __LINE__, "BS2 ERROR >> UNKNOWN STATE");
    }
    OSRestoreInterrupts(level);
    return (DVDLowGetCoverStatus() == 1) ? 19 : step;
// 81301154
void BS2Menu()
   BS2InitAlloc();
static OSHeapHandler BS2Heap;
// 81307EA8
void BS2InitAlloc()
   u8 *arenaLo;
   u8 *arenaHi;
   u8 *arenaNew;
    arenaLo = OSGetArenaLo();
    arenaLo = (void *)OSRoundUp32B(arenaLo);
    arenaHi = OSGetArenaHi();
    arenaHi = (void *)OSRoundDown32B(arenaHi);
    arenaNew = OSInitAlloc(0x80800000, arenaHi, 2);
    OSSetArenaLo(arenaHi);
    BS2Heap = OSCreateHeap(arenaLo, arenaHi);
    OSSetCurrentHeap(BS2Heap);
    OSAddToHeap(BS2Heap, arenaNew, 0x81100000);
   BS2CheckAlloc();
}
// 81307F34
void BS2CheckAlloc()
   OSCheckHeap(BS2Heap);
// 81307F58
```

```
void *OSAlloc(long size)
{
    void *ptr;
    if((ptr = OSAlloc(size)) == 0)
    {
        OSPanic(?);
    }
    return ptr;
}
```

18.2.2.3 Map of IPL Library code

8.2.2.3 Map of IPL Library code				
Address	Name	Libray		
0x813014C8	DEMOInit (*)	DEMO		
0x81307F58	OSAlloc (*)	OS		
0x813327BC	PPCMtmmcr0			
0x813327C4	PPCMfpmc1			
0x813327CC	PPCMtpmc1			
0x81332814	OSInit	OS		
0x81332EF0	OSInitAlarm	OS		
0x81332F3C	OSCreateAlarm			
0x81333688	OSAllocFromHeap			
0x81333784	OSSetCurrentHeap			
0x81333794	OSInitAlloc			
0x81333804	OSCreateHeap			
0x81333870	OSAddToHeap			
0x813338D0	OSCheckHeap			
0x813344C0	OSGetStackPointer			
0x8133491C	OSReport			
0x8133499C	OSPanic			
0x81334AA4	PPCHalt			
0x81334D4C	EXIImm	EXI		
0x81335134	EXISync			
0x813353C8	EXIProbeReset			
0x8133570C	EXISelect			
0x81335838	EXIDeselect			
0x81335D6C	EXILock			
0x81335E60	EXIUnlock			
0x81335F54	AD16Init			
0x81336090	AD16WriteReg			
0x813361B0	OSDisableInterrupts			
0x813361C4	OSEnableInterrupts			
0x813361D8	OSRestoreInterrupts			
0x81336DD8	OSGetRTC			
0x813372B0	OSLockSram			
0x81337658	OSUnlockSram			
0x813376A0	OSSyncSram			
0x813376B0	_OSCheckSram			
0x81338504	OSInitThreadQueue			
0x8133939C	OSGetTick			
0x813393B8	OSSetTime			
0x8133943C	OSGetSystemTime			
0x8133963C	OSTicksToCalendarTime			
0x8133AC50	DVDLowGetCoverStatus	DVD		
0x8133AB18	DVDLowReset			
0x8133ABD4	DVDLowSetResetCoverCallback			
0x8133B5F0	DVDInit			
0x8133CD18	DVDReadDiskID			
0x8133D0EC	DVDReset			
0x8133DBE0	VIInit	VI		
0x8133DDC8	VIInit			
0x8133E6C0	VIConfigure			
0x8133F0B4	VIGetTvFormat			
07013310D4	, 13cti vi oimat	1		

Address	Name	Libray
0x8134052c	PADInit	PAD
0x8134092c	PADSetSpec	
0x81343114	CARDInit	
0x813480D4	GXInit	
0x81349148	GXInitFifoBase	
0x81349230	GXSetCPUFifo	
0x81349340	GXSetGPFifo	
0x813494B8	GXFifoInit	
0x8134B0AC	GXPEInit	
0x8135A178	div2i	gcc
0x8135A394	mod2i	gcc
0x8135B494	vprintf	stdlib

(*) these functions were slightly modified for the IPL.

18.2.3 Apploader

The Apploader provides functions to the bootrom that load the game (using bootrom read DVD functions). The bootrom calls the Init function, then the Main function in a loop, then the Closing function. At first, the BIOS calls the Apploader entrypoint with r3, r4, and r5 pointing to a free space for a 32 bit value.

```
// info based on Luigi Mansion appldr.bin file
// (built date is 17 Dec 2001).
// Apploader Entrypoint
// Input values :
// r3 = Address where to put the address of the Init function
// r4 = Address where to put the address of the Main Loading function
// r5 = Address where to put the address of the Closing function
// Return values :
// none
// file:[0010-0013] = 0x81200288 (apploader entrypoint)
void Entrypoint(r3, r4, r5)
{
    [r3] = 0x81200290 // Init
    [r4] = 0x81200580 // Main
    [r5] = 0x81200D50 // Close
}
// Init function
// Input values :
// ?
```

```
// Return values :
// none
void Init(void (*OSReport)(char *fmt, ...))
    // clear some important memory areas
    memset(OSAppLdr + 32, 0, 32);
    memset(&OSAppLdr.DolImage, 0, sizeof(DolImage));
    [+0x140] = 0
    OSAppLdr.pass = 0
    [+0x148] = 0
    OSAppLdr.OSReport = OSReport // save report callback
    OSAppLdr.OSReport("Apploader Initialized. $ Revision: 28 $\n");
    OSAppLdr.OSReport("This Apploader built %s %s\n", __DATE__, __TIME__);
// Main Loader function
//
// Input values :
// r3 = Address where to put the Memory destination of the disk read
// r4 = Address where to put the Size of the disk read
// r5 = Address where to put the Starting position of the disk read
//
// Return value:
// r3 = 0 if everything is already loaded
// = 1 (or !=0) if main function should be called again
//
// at 0x81200580
// helper functions (below)
u32 DOLSize(void);
// 0x812013E0 seems to be a big structure, like that :
struct OSAppLdr
    // untouched
    u32 SecondTimeForThePart;
    u8 [28]
    u8 [32] // "BB2" structure ?
    DolImage DolImage; // main DOL executable header
    // flags or something
```

```
u32 +0x140
    u32 pass; // 0...12
    u32 + 0x148
    // report routine itself is placed somewhere in bootrom
    void (*OSReport)(char *fmt, ...);
    // flags or something
    u32 +0x150
    u32 +0x154
    u32 +0x158
    u32 +0x15C
    u8 [32]
} OSAppLdr; // 0x174 total
int Main(r3, r4, r5)
    int pass = OSAppLdr.pass;
    if(pass <= 12)
        switch(pass)
            // read "BB2" structure (DVD offset at 0x0420)
            case 0:
            case 1:
                // "BB2" structure ?
                // 0420-0424 offset of main executable DOL
                // 0424-0427 offset of the FST
                // 0428-042B size of FST
                // 042C-042F maximum size of FST
                [r3] = OSAppLdr + 32
                [r4] = 32
                [r5] = 0x420
                OSAppLdr.pass = 2
                DCInvalidateRange([r3], [r4])
            break;
            // check "BB2" structure FST sizes
            case 2:
                FSTLength = [OSAppLdr + 32 + 8]
                FSTMaxLength = [OSAppLdr + 32 + 12]
```

```
if(FSTLength > FSTMaxLength)
        OSAppLdr.OSReport(
        "APPLOADER ERROR >>> FSTLength(%d) in BB2 is greater \
        than FSTMaxLength(%d)\n", FSTLength, FSTMaxLength);
        PPCHalt();
    [r3] = OSAppLdr + 0x160
    [r4] = 32
    [r5] = 0x440
    OSAppLdr.pass = 3
    DCInvalidateRange([r3], [r4])
break;
case 3:
    [0x800000E8] = [OSAppLdr + 0x160] // word
break;
case 4:
// load main DOL header (256 bytes)
case 5:
    [r3] = &OSAppLdr.DolImage
    [r4] = 256
    [r5] = [OSAppLdr + 32] // from BB2
    OSAppLdr.pass = 6
    DCInvalidateRange([r3], [r4])
break;
case 6:
    totalSize = DOLSize();
    maxSize = [[800000F4] + 0x28]; // PadSpec ?
    if((totalSize > maxSize) && maxSize)
    {
        OSAppLdr.OSReport(
        "APPLOADER ERROR >>> Total size of text/data sections \
        of the dol file are too big (%d(0x%08x) bytes). Currently \
        the limit is set as %d(0x\%08x) bytes\n", totalSize, maxSize);
        PPCHalt();
```

.

```
case 7:
            case 8:
            case 9:
            case 10:
            case 11:
            case 12:
                if(SecondTimeForThePart == TRUE)
                    OSAppLdr.OSReport(
                    "Failed assertion SecondTimeForThePart == TRUE");
                    PPCHalt();
            break;
            }
        return 1;
    }
   else
        return 0;
    }
// helper functions
// at 0x81200338
u32 DOLSize(void)
{
    DolImage *dol = &OSAppLdr.DolImage;
    u32 totalBytes = 0;
    int i;
    for(i=0; i<DOL_MAX_TEXT; i++)</pre>
        if(dol->textData[i])
        {
```

```
// aligned to 32 byte boundary
        totalBytes += (dol->textLen[i] + 31) & ~31;
        }
    }
    for(i=0; i<DOL_MAX_DATA; i++)</pre>
    {
       if(dol->dataData[i])
            // aligned to 32 byte boundary
            totalBytes += (dol->dataLen[i] + 31) & ~31;
        }
    }
    return totalBytes;
// Closing function
// Return value: r3 = entry point
// at 0x81200D50
u32 Close (void)
{
    \ensuremath{//} provide entrypoint of main DOL executable to IPL
    return OSAppLdr.DolImage.entry;
}
```

18.2.4 Main DOL executable

18.3 Game and Maker Codes

18.3.1 Gamecodes

offset	size	Descript	tion	
1	1	System I	D	
		value	id	Description
		0x47	G	Gamecube (standard value)
		0×44	_	used by Legend Of Zelda: Ocarina Of Time (Master Quest)
		UX44	D	Might be a indicator for emulated/ported/promotional titles.
		0x55	U	used by GBA-Player Boot CD
2-3	2	Game ID/serial Number		
4	1	Country/Region Code		
		value	id	Country
		0x45	E	USA/NTSC
		0x50	Р	Europe/PAL
		0x4a	J	Japan/NTSC
		0x55	U	used by the European version of The Legend Of Zelda: Ocarina Of Time (Master Quest)

18.3.2 Game Serial ID

Characters	Description		
3	System	ı ID 'DOL'	
4	Gamecode		
3	Country ID		
	ID	Country	
	USA	guess what :)	
	NOE	Nintendo of Europe	
	NOA	Nintendo of America	
	JPN	Japan	

for example

- ▷ DOL-GZLE-USA (Zelda)
- ightharpoonup DOL-GNHE-USA (NHL Hitz 20-20)
- DOL-GTEP-NOE (1080ř Avalanche)
- \triangleright DL-DOL-GFZJ-JPN (F-Zero GX)

18.3.3 Makercodes

The ID (2 Bytes ASCII) belongs to the publisher, not the developer. Hence, even though Rare developed Star Fox Adventures, and Retro Studios developed Metroid Prime, they both have the Vendor ID of Nintendo (01).

It is unknown how vendor IDs are allocated; However, all IDs thus far seem to be alphanumeric. If this is accurate, then as a result the maximum number of unique vendors is 1,296. Vendor IDs seem to be region-independent.

ID	Vendor
01	Nintendo
08	Capcom
41	Ubisoft
4F	Eidos
51	Acclaim
52	Activision
5D	Midway
5G	Hudson
64	Lucas Arts
69	Electronic Arts
6S	TDK Mediactive
8P	Sega
A4	Mirage Studios
AF	Namco
В2	Bandai
DA	Tomy
EM	Konami

18.4 Macronix Chip IDs

	MV ff	f + mm h n r e			
MX		ff t mm b p r s X', vendor id			
ff		ts, device family			
	17	auto focus controller			
		mask rom			
		spi serial flash memory			
		mtp eeprom			
	27	eeprom			
	28	flash memory			
	29	flash memory (single voltage)			
	53	memory card (smc)			
	67	flash memory			
	69	flash memory + sram (stacked chip)			
	88	digital camera/flat panel display controller			
	89	flat panel display controller			
	92	sound generator			
	93	single chip answering machine/digital recorder controller			
		isdn controller			
		network			
		bluetooth			
t		racter, device type			
	C	cmos			
	f	flash			
	1	low-voltage			
	W	2.2v			
	V	1.8v			
	u x	1.5v			
	VW	2.25v+srw			
mm		digits, mode/density			
111111	004				
	040	· · · · · · · · · · · · · · · · · · ·			
	400	-			
		100,000,000			
b	1 char	racter, bootblock type (rom only)			
		top			
	b 1	bottom			

	MX f	f t mm }	bprs	
p	1 cha	racter, package type		
	p	plastic dip		
	m		plastic sop	
	q		plastic plcc	
	t		tsop normal	
	d		qeramic dip	
	x8	0.8mm	ball pitch, bga, csp	
	X	csp		
r	1 cha		mperature range	
	c	commer		
	i	industr	rial	
	m	milita	nry	
S	1 cha	racter, sp	peed	
	45	45ns		
	55	55ns		
	70	70ns		
	85	85ns		
	90	90ns]	
	10	100ns]	
	12	120ns]	
	15	150ns]	
	20	200ns]	
	25	250ns		

18.5 chip simelarities

- > mx25L4001 (serial flash rom in nintendo memory card 59)
 - b datasheet was never available at Macronixă but take a look at their 3-volt SPI Flash ROMs (the MX25LXX02 series) for a general pinout withoutăthe Unknown pin 24.
- > mx25L4004 (serial flash rom in datel memory card)
 - ⊳ mx25L4004 4Mbit, 4Mx1 serial flash rom (datasheet was, but is no longer available at Macronix:/)
- > mx98730ec (eth controller in bba)
 - ⊳ mx98728ec single chip 10/100 base generic MAC interface
 - ⊳ (mx98726, mx98728)
- ⊳ Gekko
 - b ibm PowerPc750CXe

 b ibm PowerPc750CXe

 c ibm P
 - ▷ (PowerPc740, PowerPc750, PowerPc750CX)
- - ⊳ (big ???) mx92L832 32 poly phony sound generator
 - \triangleright (big ???) mx96037 16bit DSP Controller
 - ⊳ (mx93011a,...)

- > mx 8013108-M rtnc-dol 1r6022a1 (rtc/ipl)
- ▷ MoSys (MS3M23B-5 A) 12MB 1-T SRAM (main memory)
- ▷ NEC (D4891281G5 0125XU621) 16MB ARAM (auxiliary/dsp memory)

18.6 Easter Eggs

- ➤ To hear a different sound when the console boots hold the Z button down once you turn the console on and as the square bounces down you will hear the noises of kids.
- ⊳ Hold Z then about one second later hold A to hear another sound.
- ⊳ If you have 4 controllers (and 5 hands) this one will work: Before you turn the Gamecube on hold down Z on each controller, then turn the system on (with your 5th hand of course). You will be greeted by a ninja yell.
- ⊳ holding B on first controller, then powering on will let you switch a pal gamecube into 60Hz mode

18.7 Terms and Acronyms

⊳ AA

Antialiasing. Rendering method, that makes polygon edges seem less sharpen, combining colors of nearby pixels.

⊳ AD16

Mysterious EXI device.

> AI

Audio Interface. Hardware responsible for DMA playback of PCM buffer and DVD ADPCM streaming sound. AI hardware cannot mix sound channels or set channel volume for PCM DMA playback. These operations and more advanced sound effects are produced by DSP.

Small program on DVD to load main DOL executable.

> AR, ARAM

Auxiliary (Audio) Memory. 16 MB of slow (comapred to RAM) DRAM. Used for raw DSP sound data and as temporary space for textures. ARAM has DMA communication channel with main memory (RAM). Development boards has "ARAM Expansion" (additional 4, 16 or 32 MBs).

⊳ BAT

Block Address Translation, PPC MMU translation mechanism. There are DBAT and IBAT special-purpose registers for data and instruction address translation respectively.

⊳ BBA

Broad-Band Adapter, GC's 10BaseT Ethernet Adapter.

 \triangleright BS

Bootstrap Stage (from analogy with UNIX). Very first code, executed after GC hard reset.

⊳ BS2

Bootstrap Stage 2. Same as IPL.

⊳ CR

PPC Condition Register, stores result of integer comare operation, for conditional branch decision.

> CRT

C Run Time. C/C++ program environment (libraries and startup calls).

⊳ DOL

Gamecube application (custom executable file format).

▷ Dolphin

Early development work name of Gamecube.

▷ Dolphin OS

Gamecube OS. Single user, single process, multithreaded. Linked together with any GC application ("hard-linked"), as library.

▷ DSP

Digital Signal Processor. Used to produce advanced sound on GC. DSP is integrated with GP in Flipper chip and has its own ROM. Developed by Macronix.

⊳ DI, DVD

DVD hardware interface. GC DVD is actually microcontroller, based on MN-102 CPU with proprietary firmware ROM. DVD is protected by non-standard barcodes and data encryption, which is decrypted on-the-fly by DVD controller. GC DVD cannot be read on usual PC hardware. Whole GC DVD stuff is developed by Matsushita.

⊳ EFB

Embedded Framebuffer. 2MB of fast 1T-SRAM memory located inside Flipper. Used by GP's pixel engine to draw pixels. Later copied into XFB, for final TV-output.

⊳ EXI

Expansion Interface. Gamecube peripherial devices bus, sort of USB architecture. Developed by Macronix. Devices drived by EXI: memory cards, broad-band adapter, real-time clock, bootrom, SRAM.

▷ FIFO

First-In-First-Out buffer to send GP commands and create GP command lists.

⊳ Flipper

Gamecube Northbridge+Peripheral Hardware+Graphics Processor+Audio DSP.

⊳ FPR

Floating Point Register. Gekko has 32 64-bit FPRs, named f0-f31.

▷ FPSCR

Floating Point Status and Control Register.

\triangleright JTAG

Hardware debug interface to CPU. You can connect some wires to CPU pins, to overwhelm it. Gekko has full support of IEEE 1149-1a-1993 JTAG standard.

▷ GC, GCN, NGC

Nintendo Gamecube.

⊳ GCM

Gamecube Master Data (official term). GC DVD Image files.

Sekko

Gamecube CPU, PowerPC 750-derivative processor with FPU extensions, called "Paired Single".

⊳ GP, GX

Graphics Processor, the major part of Flipper chip. GP is fixed point state-machine. Developed by ArtX team.

⊳ GPR

General Purpose Register. Gekko has 32 32-bit GPRs, named r0-r31. r1 often used as stack pointer (sp).

\triangleright GX

Software library, developed by Nintendo and ArtX, to drive GP hardware. Has many crossways with OpenGL (but more advanced).

⊳ HW2

Common name of GC hardware. Number state for revision ("2" is production board).

▷ IPL

Initial Program Loader. Graphics shell, used to load game from DVD.

⊳ MC

Memory Card, EXI device.

\triangleright MI

Flipper memory interface, plays role of "Nothbridge".

⊳ MMU

PPC Memory Management Unit. Translates virtual address to physical. MMU has two translation mechanisms: block address translation and page table translation. Address translation for data access and instruction fetch is processed separately in DMMU and IMMU.

⊳ MSR

Machine State Register. CPU status and control register.

\triangleright MX

Macronix Ltd. chips index. GC has many hardware parts, developed by Macronix, like DSP, EXI and bootrom chip.

> PC

Program Counter. PowerPC architecture does not define such term, but everyone is using it anyway, instead "CIA" (Current Instruction Address).

⊳ PCM

Pulse Code Modulation, method commonly used in digital sound hardware. PCM sound parameters are: playback rate, bits per sample, sample format. GC AI can playback 32000/48000 Hz, 16-bit big-endian stereo samples via DMA.

\triangleright PI

Peripheral Interface. Set of hardware registers to control interrupts and hardware reset. There also "PI FIFO": hardware-driven FIFO buffer in RAM.

⊳ PM

PowerPC Performance Monitor. Set of PPC special purpose registers used for speed profiling of applications.

▷ PPC

IBM PowerPC Architecture.

▷ PTE

Page Table Entry. Page table record, used to translate virtual address to physical.

$\sim R \Delta M$

Main memory. GC has 24 MB of fast 1T-SRAM. Development boards has RAM extended up to 48 MB. Developed by MoSys.

⊳ ROM

Read-only memory. GC has following ROMs: 2 MB encrypted bootrom, 128 KB DVD firmware, 4 KB DSP DROM, 8 KB DSP IROM.

> RSW

"Reset Switch", same as reset button. Seems early development GC models were equipped by switch, insted programmable reset button.

\triangleright RTC

Real-time clock. EXI device, counting seconds since 00:00 AM 2000.

⊳ SDK

Software Development Kit. Full set of compilers, libraries and documentation for development on specified platform. Gamecube SDK contain development tools, like sound and texture convertors, and set of libraries for OS and hardware. Compiler is provided by Metrowerk's CodeWarrior. There also huge development board and paper documentation.

\triangleright SI

Serial Interface. Hardware responsible for communication with serial devices, such as GC controller and keyboard via serial I/O buffer.

▷ SPR

Special-purpose register. Set of registers, dedicated to operating system. Gekko has about 60 SPRs.

> SR

Segment Registers, used by MMU for virtual address translation.

\triangleright SRAM

Small amount of battery backuped memory for OS misc settings.

\triangleright TLB

PPC MMU Translation Lookaside Buffer, used to keep recently used page address translations. Gekko has 128 two-way set associative TLB for each MMU (DMMU and IMMU).

\triangleright VI

Video Interface. Hardware responsible for TV-out of framebuffer (XFB), and generating VBlank interrupt (actually can be configured to interrupt CPU at any beam location). Has support for lightgun, antialiasing of XFB by tap-filters and progressive video mode (480p).

\triangleright WBUF

Gekko Write Gather Buffer. Small cache for burst memory transactions. Used together with graphics FIFO to send GP commands.

\triangleright XFB

External Framebuffer, located in main memory. Used for final TV-out by VI.

19 REFERENCES 241

19 References

Description > U.S. Pat. 5,680,534 (Video game/video graphics program fabricating system and method with superimpose control)

- ▷ U.S. Pat. 6,411,301; 6,452,600; 6,466,218; 6,697,074 (Graphics system interface) GX Info
- □ U.S. Pat. 6,424,348; 6,456,290; 6,489,963 (Application program interface for a graphics system) GX Info
- ∪.S. Pat. 6,457,128 (Optical disk. An optical disk barcode forming method, an optical disk reproduction apparatus, a marking forming apparatus, a method of forming a laser marking on an optical disk, and a method of manufacturing an optical disk.)
- ▷ U.S. Pat. 6,591,019 (3D transformation matrix compression and decompression)
- ▷ U.S. Pat. 6,606,689 (Method and apparatus for pre-caching data in audio memory) ARAM Info
- ▷ U.S. Pat. 6,609,977 (External interfaces for a 3D graphics system) Lots of Register Info
- □ U.S. Pat. 6,636,214 (Method and apparatus for dynamically reconfiguring the order of hidden surface processing based on rendering mode) Some GX Stuff
- ▷ U.S. Pat. 6,639,595 (Achromatic lighting in a graphics system and method) Some GX Info
- U.S. Pat. 6,580,430 (Method and apparatus for providing improved fog effects in a graphics system)
 some GX Info
- ▷ U.S. Pat. 6,643,744 (Method and apparatus for pre-fetching audio data) Some ARAM Info
- ▷ U.S. Pat. 6,664,962 (Shadow mapping in a low cost graphics system) GX Info
- ▷ U.S. Pat. 6,707,458 (Method and apparatus for texture tiling in a graphics system) GX Info
- ▷ U.S. Pat. 6,681,296; 6,859,862 (Method and apparatus for software management of on-chip cache)
- ▷ U.S. Pat. 6,701,424 (Method and apparatus for efficient loading and storing of vectors)
- ▷ U.S. Pat. 6,717,577 (Vertex cache for 3D computer graphics)

19 REFERENCES 242

- ⊳ mx25L4004 Datasheet
- ▷ PowerPC 740/PowerPC 750 RISC Microprocessor User's Manual
- ▷ PowerPC 750CX/ 750CXe RISC Microprocessor User's Manual
- Standard ECMA-268 (80 mm DVD Read-Only Disk)
- > MN102H60G/60K/F60G/F60K LSI User Manual

19.1 Sources

- ▷ http://www.uspto.gov
- ▷ http://www.macronix.com
- ▷ http://www.ibm.com
- ▷ http://www.s3.com/s3tc (no more available)
- ▷ https://www.semicon.panasonic.co.jp

20 CREDITS 243

20 Credits

besides freely available datasheets and patents, this document was created based on information provided by the following people. if you think you are missing in this list, please keep me informed so i can add you

titanik/crazy nation	'Gamaguha Law laval Info' in C'7N 'Gamaguha Sauraa naak #1'
duke/napalm	'Gamecube Low-level Info' in CZN 'Gamecube Source pack #1' duke@napalm-x.com
uuke/napann	initial "gcinfo.txt"
	some invaluable information (you know who you are)
costis	costis@gbaemu.com, gcdev.com http://www.gcdev.com
Costis	hardware introduction text (posted on some websiteuhm:))
	gcspec.html
	additional info in sram checksum, video regs
org	kvzorganic@mail.ru
5	additional apploader info / apploader RE
	IPL RE, boot process details
	info on Gekko specific opcodes
	tons of other info (cheers mate)
torlus	
	gcc config
???	www.gc-nfo.com
	some file-format info
Crowtrobo	
	ctr-snd.txt
	memory card info
Azimer	http://www.apollo64.com
	some additional VI info
tmbinc	debugmo.de http://debugmo.de
	released some sources that helped to close the one or other gap
	driving force behind GX reversing
-1	IPL encryption reversing/IPL replacement info
shagkur	shagkur@gmx.net
Timothy Wilson	GX reversing, additional sources/infos theimp@iinet.net.au
Timothy Wilson	compiled some valuable info concerning memory cards
Authors of GClib	gclib.sf.net
Authors of Genb	cross-checking against the Source helped to make sure no bad errors sneaked in
GC-Linux Team	gc-linux.sf.net
GO Emux Teum	another valueable source for code that has been cross-checked against
Aaron Kaluszka	megabyte@kontek.net
- 242 922 2242	some image format info
Monk	monk@mad.scientist.com
	TPL Fileformat details
Steven Looman	steven@krx.nl
	keyboard scancodes, comments on adapters
thakis	http://www.amnoid.de/gc/
	lots of additional fileformat info, proofreading&spellchecking
Alexander Wold (micropal)	http://cube.iu.hio.no/~s104086/
	additional rtc/ipl pinout info

moreover, many thanks must go to everyone who helped making this document more consistant and error free by proofreading and pointing out mistakes, in particular tmbinc, org, hubb, Aaron Kaluszka,

20 CREDITS 244

Skywalker, Jihad, xor37h, costis, CrowTrobo, mist, ionic, Briii, Desktopman, Spike Grobstein, Steven Looman, Anders Montonen, Monk, Josiah "afnom" Burroughs, ScreamlCT, thakis ... (please check the changelog for details)