Common Public Radio Interface

eCPRI presentation

© 2017 Ericsson AB, Huawei Technologies Co. Ltd, NEC Corporation and Nokia.



Background 1/2

1. Operator view of CPRI features

Although CPRI has been the main Fronthaul interface standard, many operators started to question its suitability to high bandwidth 5G use cases.

Improvements to efficiency and link capacity utilization were requested.

Also advanced networking and OAM features of mainstream packet transport standards were requested.




Background 2/2

2. High risk of Fragmentation for FH Standardization

An increasing number of proposals for a new functional splits between the baseband and radio started to emerge.

Several standardization bodies announced activities to define new Fronthaul Interfaces.





Targets agreed for the new CPRI Specification:

- 1. Significant reduction of required bandwidth
- 2. More efficient utilization of available bandwidth
- 3. Enable evolution for radio processing and support of sophisticated coordination algorithms to guarantee best possible radio performance
- 4. Carefully select the functionalities of the radio unit in order to enable evolution by SW updates and long life span of the radio units
- 5. Utilize existing main stream technologies to minimize duplicated specification work
- 6. Encourage utilization of existing technologies for OAM and networking
- 7. Be first to the market, becoming the prevailing fronthaul standard and minimizing fronthaul standards fragmentation

eCPRI key Features:

- 1. ~10 fold reduction of required bandwidth
- 2. Required bandwidth can scale flexibly according to the user plane traffic
- 3. Functional split inside PHY layer enables support of sophisticated coordination algorithms
- 4. Split in PHY keeps most of the functionality in baseband enabling new feature introduction without changes in the radio equipment
- 5. Encourage utilization of Ethernet and IP , thus guaranteeing future evolution
- 6. Use Ethernet/IP technologies encouraged
- 7. eCPRI specification V1.0 published and openly available to download from www.cpri.info



CPRI reminder


What is CPRI?

- A digital interface standard to transport antenna samples between a Radio Equipment (RE) and a Radio Equipment Control (REC) performing the digital processing of these signals
- Antennas signals are interleaved in a TDM-like fashion supported by a Constant Bit Rate transport solution
- CPRI v7.0 bit rates range from 614 Mbit/s (Rate 1) up to 24330 Mbit/s (Rate 10)
- Mix of Radio Access Technologies is supported
- Provide time and synchronization information for the Radio Air Interface
- Originally specified for point-to-point topology
- Maximum latency assuming no intermediate nodes
- Multipoint topologies supported but networking management left to the application layer
- Interoperability limited to the low layers covered by the specification
- CPRI define how to exchange the radio signal data not the data content itself nor the associated management plane




CPRI reminder

CPRI Protocol Stack




CPRI reminder



eCPRI system architecture

- eCPRI is packet based fronthaul interface developed by CPRI forum
- Same level of interoperability as CPRI
- Ethernet/IP networking, synchronization and security relying on existing standards






eCPRI main characteristics

- eCPRI does not constrain the use of specific network- and data link-layer protocols to form the network
 - Any type of network can be used for eCPRI, provided eCPRI requirements are fulfilled.
 - "Requirements for the eCPRI Transport Network" aim to ensure that eCPRI systems can:
 - Use packet based transport network solutions
 - Comply with the requirements associated with the more stringent radio technologies features in terms of:
 - Timing and frequency accuracy
 - Bandwidth capacity,
 - ...
 - eCPRI also encourages the use of existing de-facto/de-jure standard protocols as much as possible where available
 - In case eCPRI User Plane over Ethernet directly, eCPRI messages shall be transmitted in standard Ethernet frames. The type field of the Ethernet frame shall contain the eCPRI Ethertype (AEFE₁₆)



eCPRI protocol stack over IP / Ethernet




eCPRI does not restrict the Transport Network to be Ethernet or IP based




eCPRI node functional decomposition

- eCPRI enables flexible functional decomposition while limiting the complexity of the eRE
- Split points located at the PHY level is one set of examples covered in the eCPRI specification





eCPRI functional decomposition



Common Public Radio Interface

eCPRI typical bandwidth estimations assumptions

- Throughput: 3/1.5 Gbps (DL/UL, end-user data rate, transport block from/to MAC)
- Air bandwidth: 100 MHz (5 * LTE20) -> 500 PRB
- Number of downlink MIMO-layers: 8
- Number of uplink MIMO-layers: 4 (with 2 diversity streams per uplink MIMO layer)
- MU-MIMO: No
- TTI length: 1 ms
- Digital beamforming where BF-coefficients calculation is performed in eREC.
- Rate matching assumptions: Code rate: ~0.80
- Modulation scheme (Downlink & Uplink): 256 QAM
- Number of antennas: 64
- Subcarrier spacing: 15 kHz
- IQ sampling frequency: 122.88 Msps (3.84*32)
- IQ-format: 30 bits per IQ-sample
- No IQ compression




eCPRI typical bandwidth estimations

	Split D		Split I _D		Split II _D		Split E
	User	Control	User	Control	User	Control	User
	Data		Data		Data		Data
	[Gbps]	[Gbps]	[Gbps]	[Gbps]	[Gbps]	[Gbps]	[Gbps]
eREC→ eRE	3 (assumption)	<< 1	< 4	< 10	~ 20	< 10	236
	Split D		Split I _U				Split E
eRE→ eREC	1.5 (assumption)	<< 1	~ 20	< 10			236




eCPRI Messages Common Header format

• 4 byte eCPRI common header followed by a variable length eCPRI payload




eCPRI Messages Common Header format



- "C" is the eCPRI messages concatenation indicator:
 - "C=0" indicates that the eCPRI message is the last one inside the eCPRI PDU
 - "C=1" indicates that another eCPRI message follows this one within the eCPRI PDU




eCPRI Messages Common Header format: concatenation indicator





eCPRI Messages Common Header format: concatenation indicator





eCPRI Message types

Message Type #	Name
0	IQ Data
1	Bit Sequence
2	Real-Time Control Data
3	Generic Data Transfer
4	Remote Memory Access
5	One-way Delay Measurement
6	Remote Reset
7	Event Indication
8 – 63	Reserved
64 – 255	Vendor Specific



eCPRI Message types for data transfer: #0, #1, #2 and #3

Message Type #0: IQ Data

To transfer time domain or frequency domain IQ samples between PHY processing elements split between eCPRI nodes

Message Type #1: Bit Sequence

To transfer user data in form of bit sequence between PHY processing elements split between eCPRI nodes

Message Type #2: Real-Time Control Data


To transfer vendor specific real-time control messages between PHY processing elements split between eCPRI nodes (eREC and eRE). This message type addresses the need to exchange various types of control information associated with user data (in form of IQ samples, bit sequence, etc.) between eCPRI nodes in real-time for control/configuration/measurement

Message Type #3: Generic Data Transfer

To transfer user plane data or related control between eCPRI nodes (eREC and eRE) providing extended data synchronization support for generic data transfers.




eCPRI User Plane message formats





Message Type #3: Generic Data Transfer sequence diagram example





eCPRI Message types for Remote Memory Access: #4

Message Type #4: Remote Memory Access


The message type 'Remote Memory Access' allows reading or writing from/to a specific memory address on the opposite eCPRI node. The service is symmetric i.e. any "side" of the interface can initiate the service.

The service is conceived in a generic way to handle different kinds of write and read access that depend on the hardware used in a specific implementation. It is up to the driver routines for an implementation to map a write/read request to its hardware implementation.

A read or write request/response sequence is an atomic procedure, i.e. a requester needs to wait for the response from the receiver before sending a new request to the same receiver. A write request without response is also defined, this procedure is a one-message procedure.




Message Type #4: Remote Memory Access





Message Type #4: Remote Memory Access sequence diagram example





eCPRI Message types for One-Way Delay Measurement: #5

Message Type #5: One-Way Delay Measurement


The message type 'One-Way delay measurement' is used for estimating the one-way delay between two eCPRI-ports in one direction. The one-way delay measurement can be performed without or with a Follow_Up message (1-Step and 2-Step versions). The decision of which version to use is vendor specific.

The service assumes that both nodes are time synchronized to a common time with an accuracy sufficient for the eCPRI service.

The usage of eCPRI message type 'One-Way delay measurement' regarding which node initiates a transmission, the frequency of measurements, response deadline, etc. is vendor specific.



eCPRI Message types for One-Way Delay Measurement: #5




Two compensation values are used to set the measurements reference points as suited for a specific implementation. The exact locations of the reference points are vendor specific.

The One-Way delay value is calculated according to following equation:


$$t_D = (t_2 - t_{CV2}) - (t_1 + t_{CV1})$$
CPRI
Common Public Radio Interface

Message Type #5: One-Way Delay Measurement






eCPRI Message Type #5: One-Way Delay Measurement sequence diagram example






eCPRI Message Type #5: One-Way Delay Measurement sequence diagram example




eCPRI Message types for Remote Reset: #6

Message Type #6: Remote Reset

This message type is used when one eCPRI node requests reset of another node. A "Remote Reset" request sent by an eREC triggers a reset of an eRE.







eCPRI Message types for Event Indication: #7

Message Type #7: Event Indication

The message type 'Event Indication' is used when either side of the protocol indicates to the other end that an event has occurred. An event is either a raised or ceased fault or a notification. Transient faults shall be indicated with a Notification.

Faults/Notifications sent on eCPRI level should be relevant to the eCPRI services.

One Event Indication can either contain one or more faults, or one or more notifications.


The Event/Fault Indication message could be sent from an eCPRI node at any time.

An eCPRI node is modelled as consisting of N Elements, a fault or notification is connected to 1 Element. The detailed mapping of a specific implementation of HW and SW to Elements and their associated faults/notification is vendor specific.

For consistency check a synchronization request procedure is defined.





Message Type #7: Event Indication





Message Type #7: Event Indication sequence diagram example







eCPRI C&M

Control and Management Service Access point

The C&M information will not be transmitted via the eCPRI specific protocol.

The details of this information flow are out of the scope of the eCPRI specification.

This information flow can use protocols (e.g. TCP) over the IP protocol but any other solution is not precluded.

The C&M information flow will be considered as non-time-critical and utilize a small part of the total bandwidth between eCPRI entities.

The majority of this information flow will be considered as background traffic, the rest is interactive traffic needed to keep control of the eCPRI node.

The eCPRI specification highlights some considerations regarding relative priorities of the different flows.



eCPRI Synchronization

Synchronization Service Access point

eCPRI nodes shall recover the synchronization and timing from a synchronization reference source, and the air interface of the eRE shall meet the 3GPP synchronization and timing requirements.

The synchronization information will not be transmitted via the eCPRI specific protocol.

The details of this information flow are out of the scope of the eCPRI specification.

This information flow can use protocols (e.g. SyncE, PTP) but any other solution is not precluded.


The synchronization information flow will be considered as time-critical and will utilize a small part of the total bandwidth between eCPRI nodes.



eCPRI Networking (1/2)

CPRI networking reminder

CPRI networking example






eCPRI Networking (2/2)

eCPRI networking principle

eCPRI networking example













CPRI Common Public Radio Interface