

Ecosystem infrastructure for smart and personalised inclusion and PROSPERITY for ALL stakeholders

ARE REST API

Project Acronym Prosperity4All
Grant Agreement number FP7-610510

Deliverable number Work conducted for D203.1, D202.1

Work package number WP203, WP202

Work package title **T203.3 Runtime Environment**

T202.5: Real-Time User Monitoring

Modules

Authors Marios Komodromos, Christos Mettouris

Status Final

Dissemination Level Public/Consortium

Number of Pages 13

Table of Contents

Executive Summary3

- 1 REST API4
 - 1.1 REST API Functions5
 - 1.2 Path parameter encoding Fehler! Textmarke nicht definiert.
 - 1.3 Event Types11
- 2 REST API Client libraries 13
 - 2.1 JavaScript Client library13
 - 2.2 Java Client library21

List of Tables

Table 2: Event TypesFehler! Textmarke nicht definiert.

Table 3: JavaScript Client FunctionsFehler! Textmarke nicht definiert.

Table 4: JSON objects20

Table 5: Java Client Functions Fehler! Textmarke nicht definiert.

List of Figures

No table of figures entries found.

Executive Summary

This document describes the usage of the ARE REST API developed by UCY in the context of Task 203.3 of WP203, T202.5 of WP202 Prosperity4All project.

1 REST API

To allow remote communication with the AsTeRICS Runtime Environment, the ARE REST API was developed. It allows manipulation of resources through a set of HTTP methods such as GET, POST, PUT and DELETE.

Apart from the regular REST functions, an event mechanism is provided (SSE). With this mechanism, ARE can broadcast messages to anyone who subscribes and inform when an event occurs.

The API uses HTTP status codes to declare an error in a call. Specifically, when an error occurs, the response will contain a 500 HTTP status code (Internal Server Error) with an ARE-produced error message inside the HTTP response body.

The table in the next page (table 1) describes these methods and provides the necessary information in order to call them.

1.1 REST API Functions

| HTTP Method | Resource | Parameters | Consumes | Produces | Description |
|----------------|---|-----------------------------|----------|----------|---|
| GET | /runtime/model | - | - | XML | Retrieves the currently deployed model in XML |
| PUT | /runtime/model | modellnXML (in body) | XML | TEXT | Deploys the model given as a parameter |
| PUT | /runtime/model/{filename} | filename | - | TEXT | Deploys the model contained in the given filename |
| PUT | /runtime/model/state/{state} | state | - | TEXT | Changes the state of the deployed model to STARTED, PAUSED, STOPPED |
| GET | /runtime/model/state | - | - | TEXT | Returns the state of the deployed model |
| GET | /runtime/model/name | - | - | TEXT | Returns the name (ID) of the deployed model |
| PUT | /runtime/model/autorun/ {filename} | filename | - | TEXT | Deploys and starts the model in the given filename |
| GET | /runtime/model/components /ids | - | - | JSON | Returns the component ids contained in the currently deployed model |
| GET | /runtime/model/components/ {componentId} | componentId | - | JSON | Returns all property keys of the specified runtime component |
| GET | /runtime/model/components/ {componentId}/{propertyKey} | componentId, propertyKey | - | TEXT | Returns the a property value of the runtime component |
| GET | /runtime/model/components/ | componentId, | - | JSON | Returns the |

| | {componentId}/{propertyKey}/dynamicproperty | propertyKey | | | value list of the |
|-----|---|--------------|--------------|-------|---------------------------------|
| | teemperentary (property ney); a yriaimoproperty | propertyncy | | | dynamic |
| | | | | | property |
| | | componentId, | | | Changes a |
| PUT | /runtime/model/components/ | propertyKey, | TEXT | TEXT | property value |
| '0' | {componentId}/{propertyKey} | value (in | 12/(1 | 12/(1 | of a runtime |
| | | body) | | | component |
| | | | | | Changes |
| | | | | | multiple property |
| | | | | | value(s) of a |
| PUT | /runtime/model/components/ | propertyMap | JSON | TEXT | runtime |
| | properties | (in body) | | | component(s) |
| | | | | | (propertyMap – |
| | | | | | see JSON |
| | | | | | objects) |
| | | | | | Returns the |
| GET | /runtime/model/components/ | componentId | - | JSON | input port ids of |
| | {componentId}/ports/input/ids | | | | the specified |
| | | | | | component Returns the |
| | /runtime/model/components/ | | | | output port ids |
| GET | {componentId}/ports/output/ids | componentId | - | JSON | of the specified |
| | | | | | component |
| | /runtime/model/components/ | componentId, | | | Returns the |
| GET | {componentId}/ports/{portId}/ | portId | - | TEXT | datatype of the |
| | datatype | portia | | | specified port |
| | | componentId, | | | Sends data to a |
| DUT | {componentId}/ports/{portId}/ | portld, | TEVT | TEVT | specific port of a component in |
| PUT | data | value (in | TEXT | TEXT | the running |
| | | body) | | | model |
| | | | | | Triggers an |
| DUT | | componentId, | | TEVE | event on the |
| PUT | {componentId}/events/{eventPortId} | eventPortId, | - | TEXT | given |
| | | | | | component/port |
| | | | | | Returns the |
| | runtime/model/component | _ | | | event channel |
| GET | /{componentId}/eventChannels | componentId | - | JSON | ids of the |
| | /ids | | | | specified |
| | | | | | component Returns the data |
| | runtime/model/component/ | | | | channel ids of |
| GET | {componentId}/dataChannels/ids | componentId | - | JSON | the specified |
| | , | | | | component |
| GET | runtime/model/channels/event | | | JSON | Returns the |
| GEI | /ids | - | - | JOON | event channel |

| | | | | | ids of the |
|--------|---|--------------------------------------|------|------|--|
| | | | | | current model |
| GET | runtime/model/channels/event /{channelld}/source | dataChannelId | - | JSON | Returns the source (channel edge – se JSON objects) of a specific event channel |
| GET | runtime/model/channels/event /{channelld}/target | dataChannelId | - | JSON | Returns the target (channel edge – see JSON objects) of a specific event channel |
| GET | runtime/model/channels/data /ids | - | - | JSON | Returns the data channel ids of the current model |
| GET | runtime/model/channels/data /{channelld}/source | dataChannelId | - | JSON | Returns the source (channel edge – se JSON objects) of a specific data channel |
| GET | runtime/model/channels/data /{channelld}/target | dataChannelId | - | JSON | Returns the target (channel edge – se JSON objects) of a specific data channel |
| GET | /storage/models/{filename} | filename | - | XML | Returns an xml representation of a model in a specific file |
| POST | /storage/models/{ filepath } | filepath, modelInXML (in body) | XML | TEXT | Stores a model in the given filepath |
| POST | /storage/data/{filepath} | filepath, data (in body) | TEXT | TEXT | Stores data to a given filepath in the ARE/data folder |
| DELETE | /storage/models/{filename} | filename | - | TEXT | Deletes the model with the given filename |
| GET | /storage/models/names | - | - | JSON | Retrieves the model names that are saved in |

| | | | | | the ARE repository |
|------|--|---|------|------|--|
| GET | /storage/components/ descriptors/xml | - | - | XML | Returns an xml string containing the descriptors of the created components with some modifications in order to be used by the webACS |
| GET | /storage/components/descriptors /json | - | - | JSON | Retrieves the exact content of the component descriptors contained in the ARE repository |
| POST | /storage/webapps/{webappName}/{filepath} | webappName, filepath, data (in body) | TEXT | TEXT | Stores data for a specific webapp. |
| GET | /storage/webapps/{webappName}/{filepath} | webappName, filepath | - | TEXT | Returns saved data for a webapp |
| GET | /restfunctions | - | - | JSON | Returns a list with all the available rest functions |
| GET | /runtime/deployment/listener | - | - | TEXT | Opens a persistent connection with ARE and listens for model deployment events (SSE). |
| GET | /runtime/model/state/listener | - | - | TEXT | Opens a persistent connection with ARE and listens for model state change events (SSE). |
| GET | /runtime/model/channels/event /listener | - | - | JSON | Opens a persistent connection with ARE and listens |

| | | | | I | |
|-----|-------------------------------------|------------------|------------------|------------------|--------------------|
| | | | | | for event |
| | | | | | channel |
| | | | | | transmissions |
| | | | | | (SSE). |
| | | | | | Opens a |
| | | | | | persistent |
| | | | | | connection with |
| | | | | | ARE and listens |
| | | channelld - JSON | | for data channel | |
| CET | /runtime/model/channels/data | | ICON | transmissions | |
| GET | {channelId}/listener | | (SSE). Mind that | | |
| | | | | | data channel |
| | | | | | subscriptions |
| | | | | | are initialized on |
| | | | | | every model |
| | | | | | deployment. |
| | | | | | Opens a |
| | | | | | persistent |
| | /www.time.e/wee.ele.l/ee.ee.ee.ee.e | | | | connection with |
| GET | /runtime/model/components/ | - | - | JSON | ARE and listens |
| | properties/listener | | | | for component |
| | | | | | property |
| | | | | | changes (SSE). |
| | | | | | |

Table 1: REST API

1.2 Path parameter encoding

As seen in table 1, there are some functions that expect parameters in the URI, the **path parameters**. It can be observed that the path parameters are part of the URI and are wrapped with curly brackets (for example, the "filename" in "/runtime/model/{filename}"). Caution: do not confuse **query parameters** with path parameters.

Before the function call, these parameters should be encoded based on the UTF-16 encoding table. Every character of the parameter should be replaced with the corresponding **decimal value** of the UTF-16 table, and every encoded character should be separated from the other characters with an un-encoded dash ("-") character.

For a better understanding check the example below:

REST function call:

| PUT | /runtime/model/{filename} | filename | - | TEXT | Deploys the model contained in the given filename |
|-----|---------------------------|----------|---|------|---|
|-----|---------------------------|----------|---|------|---|

Un-encoded URI: http://localhost:8081/runtime/model/foobar

Encoded URI: http://localhost:8081/runtime/model/102-111-111-98-97-114

1.3 Event Types

As said before, the API allows subscription to specific ARE event types. To consume SSE events, the client must be able to achieve communication using SSE technology. SSE library implementations are available for almost any well-known programming language (java, C#, JavaScript etc).

A subscription can be conducted per event type. Each event received by a client, will contain a message from a pre-defined set. The client should check this message in order to retrieve details regarding the event. The event types and their corresponding messages can be found in table 2.

| Event type | Event messages | Description |
|-------------------------------|--|--------------------------------------|
| model_changed | pre_deploy_event | Notifies the subscribers that a new |
| | post_deploy_event | model was deployed or is going to |
| | | be deployed |
| model_state_changed | pre_start_event | Notifies the subscribers that an |
| | post_start_event | event occurred, which has affected |
| | pre_stop_event | or is going to affect the runtime |
| | post_stop_event | model state |
| | pre_pause_event | |
| | post_pause_event | |
| | pre_resume_event | |
| | post_resume_event | |
| $event Channel_transmission$ | see JSON objects section | Notifies the subscribers that an ARE |
| | - EventChannel SSE | runtime model event was triggered |
| | | through a specific eventChannel |
| dataChannel_transmission | see JSON objects section | Notifies the subscribers that an ARE |
| | - DataChannel SSE | runtime model event was triggered |
| | | through a specific dataChannel |
| property_change | see JSON objects section | Notifies the subscribers that a |
| | – PropertyChange SSE | property value of a component has |
| | | been changed |

Table 2: Event Types

1.4 Port Datatypes

Every **component port** in an AsTeRICS model can transmit data of some specific type. A REST client is able to register a listener for a port and receive data being sent from this port. Below you can find the available port datatype and the corresponding string representations.

| Datatype type | Datatype string value |
|---------------|-----------------------|
| STRING | string |
| DOUBLE | double |
| INTEGER | integer |
| CHAR | char |
| BYTE | byte |
| BOOLEAN | boolean |
| UNKNOWN | unknown |

Table 3: Port datatypes

The port datatype can be obtained using this rest call

| GET | /runtime/model/components/ {componentId}/ports/{portId}/ datatype | componentid, portid | - | TEXT | Returns the datatype of the specified port |
|-----|---|---------------------|---|------|--|
|-----|---|---------------------|---|------|--|

and the expected return value is one of the fields in the "Datatype string value" column of Table 3.

2 REST API Client libraries

To enable easier REST API accessibility, communication libraries were created that simplify the whole procedure.

2.1 JavaScript Client library

To install the JavaScript library in a webpage these steps have to be followed:

- 1) Import the 'ARECommunicator.js' file in the html page.
- 2) Import 'JSmap.js' file in the html page.
- Import a script that provides jQuery functionality.
 (i.e. "http://ajax.googleapis.com/ajax/libs/jquery/1.7.1/jquery.min.js")

(For testing purposes, a simple implementation of a JavaScript client was created and it can be found here:

https://github.com/asterics/AsTeRICS/tree/master/ARE RestAPIlibraries/clientExample/client.html)

Before calling ARE functions, the baseURI has to be set. This is the URI where ARE runs at. For example:

```
setBaseURI("http://localhost:8081/rest/");
```

To call any REST function, we have to provide two callback functions: a successCallback and an errorCallback such as the example below

```
//downloadDeployedModel
function DDM() {
    downloadDeployedModel(DDM_successCallback, DDM_errorCallback);
}

function DDM_successCallback(data, HTTPstatus) {
    alert(data);
}

function DDM_errorCallback(HTTPstatus, AREerrorMessage) {
    alert(AREerrorMessage);
}
```

Furthermore, the 'subscribe' function is opening a persistent connection with ARE. Using an event mechanism based on Server Sent Events (SSE) specifications, it listens to the

connection for broadcasted messages. Additionally, the event type (Table 2) name must be provided, to specify what type of events to listen for. The concept still remains the same, as a success-Callback function and an error-Callback function must be provided. The unsubscribe function does not use any rest calls since it closes the connection from the browser's side.

In the next page, Table 4 describes each method provided by the library.

2.1.1 Java Script Library Functions

| Function Signature | Description |
|---|--|
| downloadDeployedModel(sCB1, eCB) | Retrieves the currently deployed model in |
| deministration (1992) | XML |
| uploadModel(sCB1, eCB, modelinXML) | Deploys the model given as a parameter |
| deployModelFromFile(sCB1, eCB, filename) | Deploys the model contained in the given |
| deploymodel form ne(3002) cos) mename, | filename |
| startModel(sCB1, eCB) | Changes the state of the deployed model to |
| stopModel(sCB1, eCB) | STARTED, PAUSED, STOPPED |
| pauseMolel(sCB1, eCB) | 3711(125) 1710325) 31311 25 |
| getModelState(sCB1, eCB) | Returns the state of the deployed model |
| getModelName(sCB1, eCB) | Returns the name (ID) of the deployed |
| gentiodentaine(sep2) ces) | model |
| autorun(CB1, eCB, filename) | Deploys and starts the model in the given |
| (3 , 22 , 2 , 2 , 2 , 2 , 2 , 2 , 2 , 2 , | filename |
| getRuntimeComponentIds(sCB1, eCB) | Retrieves all the component ids contained in |
| | the currently deployed model (as JSON |
| | array) |
| getRuntimeComponentPropertyKeys(sCB2, eCB, | Returns all property keys of the component |
| componentId) | with the given componentld in the currently |
| | deployed model (as JSON array) |
| getRuntimeComponentProperty(sCB1, eCB, | Retrieves a property value of a specific |
| componentId, propertyKey) | component, in the currently deployed |
| | model |
| setRuntimeComponentProperty(sCB1, eCB, | Changes a property value of a specific |
| componentId, propertyKey, value) | component, in the currently deployed |
| | model |
| setRuntimeComponentProperties(sCB1, eCB, | Changes multiple property values of a |
| propertyMap) | runtime component(s) (propertyMap – see |
| | JSON objects section) |
| getComponentInputPortIds(sCB1, eCB, componentId) | Returns the input port ids of the specified |
| | component |
| getComponentOutputPortIds(sCB1, eCB, componentId | Returns the output port ids of the specified |
| | component |
| getPortDatatype(sCB1, eCB, componentid, portid) | Returns the datatype of the specified port |
| sendDataToInputPort(sCB1, eCB, componentId, portId, | Sends data ("value") to a specific port of a |
| value) | component in the running model. Returns |
| | "success" or an error message. |
| triggerEvent(sCB1, eCB, componentId, eventPortId) | Triggers an event on the given |
| | component/port |
| getEventChannelsIds(sCB1, eCB) | Returns all the event channel ids of the |
| | current model (as JSON array) |
| getEventChannelSource(sCB1, eCB, channelId) *3 | Returns the source (channel edge object) of |
| | a specific event channel |
| getEventChannelTarget(sCB1, eCB, channelId) *3 | Returns the target (channel edge object) of |
| | a specific event channel |

| getComponentEventChannelsIds(sCB1, eCB, | Returns the event channel ids of the given |
|--|--|
| componentId) | component |
| getDataChannelsIds(sCB1, eCB) | Returns all the data channel ids of the |
| , , , | current model (as JSON array) |
| getDataChannelSource(sCB1, eCB, channelId) *3 | Returns the source (channel edge object) of |
| | a specific data channel |
| getDataChannelTarget(sCB1, eCB, channelId) *3 | Returns the target (channel edge object) of |
| | a specific data channel |
| getComponentDataChannelsIds(sCB1, eCB, | Returns the data channel ids of the given |
| componentId) | component |
| downloadModelFromFile(sCB1, eCB, filename) | Returns an xml representation of a model in |
| | a specific file |
| storeModel(sCB1, eCB, filename, modelinXML) | Stores a model in the given filename |
| storeData(sCB1, eCB, filepath, modelinXML) | Stores data to a given filepath in the |
| | ARE/data folder |
| storeWebappData(sCB1, eCB, webappId, filepath, | Stores data for a specific webapp to |
| data) | webapps/ <webappid>/data</webappid> |
| getWebappData(sCB1, eCB, webappId, filepath) | Gets saved data of a specific webapp |
| deleteModelFromFile(sCB1, eCB, filename) | Deletes the model with the given filename |
| listStoredModels(sCB2, eCB) | Retrieves the model names that are saved in |
| | the ARE repository (as JSON array) |
| getComponentDescriptorsAsXml(sCB2, eCB) | Returns an xml string containing the |
| | descriptors of the created components with |
| | some modifications in order to be used by |
| | the webACS |
| getComponentDescriptorsAsJSON(sCB2, eCB) *1 | Retrieves the exact content of the |
| | component descriptors contained in the ARE |
| | repository (as JSON array) |
| getRestFunctions(sCB2, eCB) *2 | Retrieves the information for all the |
| | available rest functions provided by the |
| | Restful API (as JSON array with Function |
| subscribe(sCB1, eCB, eventType) | objects) |
| subscribe(SCB1, eCB, eventrype) | Opens a persistent connection with ARE and listens for Server Sent Events. The |
| | 'eventType' parameter is a string and |
| | accepts the values defined in Table 2, 'Event |
| | Type' column. |
| unsubscribe(eventType) | Closes the connection for Server Sent |
| ansabsenbelevenerype, | Events. Returns true if the unsubscription |
| | was successful and false otherwise. The |
| | 'eventType' parameter is a string and |
| | accepts the values defined in Table 2, 'Event |
| | Type' column. |
| | Type column. |

- sCB1: successCallback(textData, HTTPstatus)
- sCB2: successCallback(array, HTTPstatus)
- eCB: errorCallback(HTTPstatus, AREerrorMessage)
- *1: Component object (see JSON objects section)
- *2: Function object (see JSON objects section)
- *3: Channel edge object (see JSON objects section)

Keep in mind

A browser limits the number of persistent connections to 4-6 (varies from browse to browser), so use your SSEs wisely!

2.1.2JSON OBJECTS

```
Object Name
                                              Example
                     "path": "/runtime/model",
 Function
                     "description": "Retrieves the currently deployed model in
                   XML",
                     "httpRequestType": "GET",
                     "bodyParameter": "",
                     "consumes": "",
                     "produces": "text/xml"
                   "canonicalName": "eu.asterics.component.processor....",
Component
                     "type":"PROCESSOR",
                     "id": "asterics. String Dispatcher",
                     "description": "Send text from chosen slot",
                     "singleton":false,
                     "inputPorts":[
                      {
                        "type":"INPUT",
                        "multiplicity":null,
                        "description": "Send the string from the slot defined by
                   the incoming value",
                        "portID": "slotDispatch",
                        "dataType":"INTEGER",
                        "propertyNames":null
                      }
                    ],
                     "outputPorts":[
                        "type":"OUTPUT",
                        "description": "Output text",
                        "portID":"output",
                        "dataType": "STRING",
                        "propertyNames":null
                      }
                    ],
                     "eventTriggererPorts":[
                    ],
                     "ports":[
                        "type":"INPUT",
```

```
"multiplicity":null,
                          "description": "Send the string from the slot defined by
                     the incoming value",
                          "portID": "slotDispatch",
                          "dataType":"INTEGER",
                          "propertyNames":null
                          "type":"OUTPUT",
                          "description": "Output text",
                          "portID":"output",
                          "dataType":"STRING",
                          "propertyNames":null
                        }
                       ],
                       "eventPorts":[
                          "id":"dispatchSlot1",
                          "description": "Send text from slot 1"
                        }
                       ],
                       "eventListenerPorts":[
                          "id": "dispatchSlot1",
                          "description": "Send text from slot 1"
                        }
                       ],
                       "propertyNames":[
                        "delay",
                        "slot1"
                      ]
 Channel edge
                       "component": "Timer.1",
                       "eventPort", "start"
 EventChannel
                     "channelId": "enterZone_start",
       SSE
                     "targetComponentId":"Timer.1"
DataChannel SSE
                     "channelld": "binding.11",
                     "data":"100.0"
PropertyChange
                     "newValue":"5",
       SSE
```

Table 5: JSON objects

2.2 Java Client library (currently not up-to-date)

Environment specs:

1) Recommended IDE: eclipse

2) Recommended Java version: 7

To import, test or modify the Java library in an IDE, follow these steps:

- 1) Create a simple java project in your IDE.
- 2) Navigate to the destination where the Java library is located and copy the 'lib' and 'models' folders to the root of your project.
- 3) Copy the contents of 'src' folder to the 'src' folder of your project.
- 4) Add all the jar files which are located inside 'lib' folder to your project build path.
- 5) Run 'JavaClient.java' class located inside the 'tester' package to test that everything works as expected.

To use the Java library in our own project, follow these steps:

- 1) Add 'ARECommunicator.jar' file to the build path of our project.
- 2) Add the jar files contained in the 'lib' folder to the build path of our project.

When installation is completed, the procedure of communicating with ARE is reduced to plain calls of Java methods of an object.

As with JavaScript library, the baseURI has to be set:

```
ARECommunicator areCommunicator = new ARECommunicator("http://localhost:8081/rest/");
```

and when this is done, you are able to call any method you desire:

```
areCommunicator.startModel();
```

Furthermore, the 'subscribe' function is opening a persistent connection with the ARE. Using an event mechanism based on Server Sent Events (SSE) specifications, it listens to the connection for broadcasted messages. Additionally, the eventType name must be provided, to specify what type of events to listen for. To achieve this functionality, the <u>Jersey SSE java library</u> was used.

In the next page, Table 5 describes each method provided by the library.

2.2.1 Java Library Methods

| Function Signature | Description |
|--|---|
| String downloadDeployedModel() | Retrieves the currently deployed model |
| | in XML |
| String uploadModel(String modelinXML) | Deploys the model given as a parameter |
| String deployModelFromFile(String filename) | Deploys the model contained in the |
| | given filename |
| String startModel() | Changes the state of the deployed |
| String stopModel() | model to STARTED, PAUSED, STOPPED |
| String pauseModel() | |
| String getModelState() | Retrieves the state of the deployed |
| | model |
| String getModelName() | Returns the name (ID) of the deployed |
| | model |
| String autorun(String filename) | Deploys and starts the model in the |
| | given filename |
| String[] getRuntimeComponentIds() | Retrieves all the components contained |
| | in the currently deployed model |
| String[] getRuntimeComponentPropertyKeys(String | Retrieves all property keys of the |
| componentId) | component with the given componentld |
| | in the currently deployed model |
| String getRuntimeComponentProperty(String | Retrieves property value of a specific |
| componentId, String propertyKey) | component, in the currently deployed |
| | model |
| String setRuntimeComponentProperty(String | Changes a property value of a specific |
| componentId, String propertyKey, String value) | component, in the currently deployed |
| | model |
| String sendDataToInputPort(String componentId, String | Sends data to a port of a component in |
| portId, String value) | the currently deployed model |
| String triggerEvent(String componentId, String | Triggers an event on the given |
| eventPortId) | component/port |
| String downloadModelFromFile(String filename) | Retrieves an xml representation of a |
| | model in a specific file |
| String storeModel(String filename, String modelinXML) | Stores a model in the given filename |
| String storeData(String filepath, String data) | Stores data to a given filepath in the ARE/data folder |
| String storeWebappData(String webappId, String filepath, | Stores webapp data to |
| String data) | ARE/web/webapps/ <webappid>/data</webappid> |
| String getWebappData(String webappId, String filepath) | Gets stored webapp data |
| String deleteModelFromFile(String filename) | Deletes the model with the given |
| | filename |
| String[] listStoredModels() | Retrieves a list with all the model that |
| | are saved in the ARE repository |
| String getComponentDescriptorsAsXml() | Returns an xml string containing the |
| | descriptors of the created components |
| | with some modifications in order to be |

| | used by the webACS |
|--|--|
| List <string> getComponentDescriptorsAsJSON()</string> | Retrieves the exact content of the |
| | component descriptors contained in the |
| | ARE repository (as JSON array) |
| ArrayList <restfunction> functions()</restfunction> | Retrieves a list with all the available rest |
| | functions |
| subscribe(String eventType) | Subscribes the IP that sent the request |
| | to the event mechanism |
| unsubscribe(String eventType) | Unsubscribes the IP that sent the |
| | request to the event mechanism |

Table 6: Java Client