
	EXPERIMENT No: 01
	SPECTRUM ANALYSER AND OBSERVE SPECTRUM
	AIM: To study spectoum Analyzer and observe the spectrum of sinusoidal signal and square wave.
	APPARATUS: Spectrum Analyzer (9kHz - 3 GHz) Function Generator
	THEORY: (1) A spectrum Analyzer is a laboratory instrument that displays signal amplitude (strength) as it varies by signal frequency. The frequency appears on the horizontal axis, and the amplitude is displayed on the vertical axis.
	(2) To the casual observer, a spectrum analyzer looks like an ascilloscope and, in fact, some lab instruments can function either as oscilloscopes or spectrum analyzer. A spectrum Analyzer can be used to determine whether or not a wireless transmitter is working according to federally defined standards for purity of emissions
	(3) Output signals at frequencies other than the intended communications frequency appear as vertical lines (pips) on the display. A spectrum Analyzer can also be used to determine, by direct observation, the bandwidth of a digital or Analog Signal.
	(4) A spectrum Analyzer interface is a device that can be connected to a wireless receiver or a personal computer to allow Yishah detection and analysis of electromagnetic signals over a defined band of frequencies.
rision	



FE	EATURES OF LAB INSTRUMENT (SP-830 (GWINSTEK):
	5 markers with delta marker & peak functions
	Sput windows with separate settings
V	6.4" TET color LCD, 640 X 480 XSOLUTION
	AC/DC/ battery - multi-mode power operator
1	Autoset
V	9 kHz - 3 Ghz frequency range
	Torong Cris
	FREQUENCY SELECTION AND THEIR SELECTION METHODS
(1) FREQUENCY:
	Friquency (Span: The friquency key, toghether with span key sets the friquency scale
	View Signal (Center & Span): Center and span method defines
	right bandwidth (span) to locate the signal.
	Catting transport light of the F
	Setting Frequency adjustment Step: Frequency adjustment step
	resolution for center, Start and Stop frequency
	and the same of th
	Panel Operation:
	V Prese browsom ken
	V Press Frequency key V Press F4 (step) Scroll nobe.
	VENTER the value using numerical and unit keys, arrowkeys &

	3
	(2) RANGE: 9 KHZ to 3 GHZ
	(3) Set Center Frequency:
	Panel Operation:
	Prece bequercy key
	prese F1 (center)
	Enter the value using humerical and unit keys, arrow keys and scroll nobe.
	(4) Set Frequency Span:
	Panel operation:
	Press Span key pross F1 (Span)
	Enter the Value using numerical and unit keys
	arrow keys and scroll nobe.
	(5) View Signal (Start & Stop)
	VStart and stop method defines the beginning and end of
	Arrow keys and small knobe resolution: 1/10 of span.
	Arrow keys and small knohe zwoluhon: 1/10 of span.
	(6)
	(6) Set Start Frequency
	Panel Operation:
	Press F2 (start)
	and scroll note
SION	

	(7) Set Stop Frequency:
	Panel Operation:
	Press Fraguency key
	pros F3 (stop)
	Enter the value using numerical and unit keys arrow keys
	and scroll nobe.
	(8) Full or Zero Span:
	Full or zero span setting set the spant to extreme values
	: 3 GHZ (FWI) or O KHZ (Zero) - They provide faster
	ways to view signals in certain signals such as in
	time demains (0 span) for viewing modulation or in
	tull span for viewing signals with unknown frequencies.
	(9) Display full Brequency Span
	Pany operation
	V Press the span key
	Press F2 (Sull span)
	Range: 3 GHz (fixed)
	Full span also sets there parameters to fixed valuel
	V Center broquency: 1.5 attz
	Start briquency: 0 KHZ
	Stop Enguency: 3 GHZ
	(10) Zero Spon Display Panel Operations
	Viero spon display can be obtained by pressing F3 Key
	Start frequency & Stop frequency remains Same as center frequency
	Note: Last span sotting can be occalled by F4 key
SION	

Amp	LITUDE SELECTION AND SETTING METHODS
(1) AMPLITUDE	
Amplitud	te key sets vertical attribute of the display, including
the us	per limit (xeforence level), vertical range (amputude
VINICAL	unit and compensation for external gain or scale
	(external offset)
27	
(2) Set Virtice	
Vertical	display scale is defined by reference amplitude,
ampli)	ude ronge, measurement unit and external gain/loss.
(3) Set refor	ence amplifiede
1 the	reference level defines the amplitude at the top of
	displayed range.
Panel	operations:
V Pr	us amplitude key
V Pm	es E1 (reference lovel)
√ En	ter the value using numerical and unit keys, arrow
	ow keys, and scroll knob, scroll knob resolution: vertical
All	scale.
Range:	
dAn	- 110 to + 20 dBm, 0.1 dBm resolution
	nV: -63-1 to 66.99 dBmV, 0.01 dB resolution
	1 V: -3.01 to 120.99 dBUV, 0.01 dB xcsolution.
ON	

(4) Select amplitude Scale Pand Operation. Pres Ampulude key
Pres F2 (Scale dB/DIV) Repeatedly to select the scale Range: 10, 5, 2, 1 dB/Div Panel operation. Press Amplitude key Press F3 (Units) School and pross the unit from FJ (dBm), F21 dBm) and F3 (dBuV) Press FG (return) to go back to previous menu. dBm = -110 to +20 dBm, 0.1 dBm resolution dBmV = -63.1 to 66.99 dBmV, 0.01 dB resolution dB uV = -3.01 to 126.99 dB 0.01 dB resolution Set external offset level (5) Background External offset compensated the amplitude gain or loce caused by on external hetwork or devices. Pand operation : 1. Press Amplitude key 2. Prest F4 (external gain) 3. Enter the value using numerical and unit keys, arrow keye and scroll knob VISION

Range
Range: -20 dB to +20 dB, 0.1 dB resolution
Transitude iron appears at the bottom of the display when the external effect changes. To check whether Spectrum analyzer working proper generate Auxiliary signal frest system key, press auxiliary signal scheck on option from side given menu, following signal with generate Tr generate 10 MHz sypal with 10 dB amputtude.