Tuning Android for low RAM

when 1 GiB is too much



License



These slides are available under a Creative Commons Attribution-ShareAlike 3.0 license. You can read the full text of the license here http://creativecommons.org/licenses/by-sa/3.0/legalcode You are free to

- copy, distribute, display, and perform the work
- make derivative works
- make commercial use of the work

Under the following conditions

- Attribution: you must give the original author credit
- Share Alike: if you alter, transform, or build upon this work, you may distribute
 the resulting work only under a license identical to this one (i.e. include this
 page exactly as it is)
- For any reuse or distribution, you must make clear to others the license terms of this work

About Chris Simmonds



- Consultant and trainer
- Working with embedded Linux since 1999
- Android since 2009
- Speaker at many conferences and workshops

"Looking after the Inner Penguin" blog at http://2net.co.uk/



https://uk.linkedin.com/in/chrisdsimmonds/



https://google.com/+chrissimmonds

Overview

- Project Svelte
- How much RAM do you need?
- Tuning Android
 - Reducing memory pressure from the Dalvik heap
 - Optimising the JIT cache
- Tuning the kernel
 - Kernel Samepage Merging (KSM)
 - Compressed swap area

The problem

- Android devices need memory for
 - Operating system
 - Background services
 - Video buffers
 - Applications
- Since Gingerbread minimum RAM has gone beyond 512 MiB
- Especially since Jelly Bean 4.1 "project Butter" which improved graphics performance by adding more buffers. But display buffers are getting larger...

Project Svelte

- Kit Kat 4.4 introduced "project Svelte": Android on devices with 512 MiB RAM
- · Project Svelte consists of
 - Various memory-saving changes to Android framework
 - Tuning knobs for Android
 - Validated techniques for tuning Linux
 - Improved memory diagnostics
- See source.android.com/devices/low-ram.html
- Note: In many cases there is a tradeoff between reducing memory use and increasing CPU load (and therefore increasing power requirements)


How much RAM am I using?

- Tricky question!
- Some (most) is used by processes: apps and system daemons
 - But note that processes share a lot of read-only data
- Some is cached
 - But caches can be dropped, so cached memory is usually regarded as "free"
- Some is allocated by the kernel and not owned by any process
- Some is used for the code and data segments of the kernel and kernel modules

Memory metrics for processes

- For each Linux process we can measure
 - Vss = virtual set size: pages mapped by this process
 - Rss = resident set size: pages mapped to real memory
 - Uss = unique set size: pages of memory not shared with any other process
 - Pss = proportional set size: pages shared with other processes, divided by the number of processes sharing
- · Perhaps a diagram would help...

Memory metrics




$$Vss = A + B + C$$

$$Rss = A + B$$

$$Uss = A$$

Pss = A + B/n where n is the number of processes sharing

How to calculate Pss



$$Pss(1) = 2 + 3/3 + 2/2 = 4$$

 $Pss(2) = 2 + 3/3 + 2/2 = 4$
 $Pss(3) = 2 + 3/3 = 3$
 $Sum(Pss) = 11 = total of pages in use$

Tools: procrank

Part of the Android tool set for a long time: ranks processes by Pss (default), type $_{\tt procrank}$ -h for more options

Example (edited):

```
# procrank
 PID
            Vss
                    Rss
                              Pss
                                       Uss
                                            cmdline
 3351
       1058776K
               163952K
                          141197K
                                  139596K
                                            com.google.earth
 2616 943156K
               116020K
                         93360K
                                  91724K
                                            com. android. vending
 539
      990756K 112504K 91393K 89808K
                                            com.android.systemui
 4657
      995760K 105964K
                                            com.rovio.angrybirds
                          77829K
                                    70776K
        31904K
                  7676K
                            6038K
                                     5900K
                                            /system/bin/surfaceflinger
 119
                                            /system/bin/mediaserver
 122
         27468K
                  3788K
                            3045K
                                     2964K
 120
       865084K
                 24308K
                            2263K
                                      860K
                                           zygote
. . .
                          717098K
                                   669272K
                                            TOTAI.
RAM: 1124832K total, 105528K free, 3808K buffers, 136624K cached,
 656K shmem, 23656K slab
```

Tools: procmem

Another tried and tested tool: shows Vss, Rss, etc for each mapping of a single process Example (edited):

# procme	m 119							
Vss	Rss	Pss	Uss	ShCl	ShDi	PrCl	PrDi	Name
4K	OK	OK	OK	OK	OK	OK	OK	
1012K	4 K	4 K	4K	OK	OK	4 K	OK	[stack:944]
512K	512K	512K	51 2K	OK	OK	36K	476K	/dev/mali0
512K	512K	512K	51 2K	OK	OK	OK	51 2K	/dev/mali0
516K	12K	12K	1 2K	OK	OK	12K	OK	[anon:libc_malloc]
512K	512K	512K	51 2K	OK	OK	224K	288K	/dev/mali0
512K	512K	512K	51 2K	OK	OK	32K	480K	/dev/mali0
516K	12K	12K	1 2K	OK	OK	12K	OK	[anon:libc_malloc]
2680K	2668K	2668K	2668K	OK	OK	2668K	0K	[heap]
132K	20K	20K	20K	OK	OK	20K	OK	[stack]
0K	OK	OK	OK	OK	OK	0 K	0K	[vectors]
31904K	7676K	6039K	5900K	1760K	16K	4144K	1760K	TOTAL

The Android application life cycle

- Activity Manager grades applications by how many components (activities and services) are being used
- Sets a per-process measure called oom_adj
- oom_adj values are from -16 (important process) to 15 (unimportant process)
- As memory pressure increases, the kernel low memory killer starts killing processes starting with the highest oom_adj

Values for oom_adj

From frameworks/base/services/java/com/android/server/am/ProcessList.java

State	oom_adj	Type of process
System	-16	daemons and system services
Persistent	-12	persistent apps, e.g. telephony
Foreground	0	contains the foreground activity
Visible	1	contains activities that are visible
Perceptible	2	e.g. background music playback
Service	5	contains an application service
Home	6	contains the home application
Previous	7	the previous foreground application
B Services	8	"old and decrepit services"
Cached	915	all activities and services de-
		stroyed

lowmemory killer thresholds

- Thresholds calculated according to screen size and total memory
- Example (from Nexus 10)

oom_adj	Threshold (KiB)
-16	49152
-12	49152
0	49152
1	61440
2	73728
3	86016
4	98304
5	98304
6	98304
7	98304
8	98304
9	98304
15	122880

Tools: meminfo

dumpsys meminfo takes the oom_adj value into account:

```
# dumps vs meminfo
Applications Memory Usage (kB):
Uptime: 5156998 Realtime: 70066043
Total PSS by process:
   141263 kB: com.google.earth (pid 3351 / activities)
    93354 kB: com.android.vending (pid 2616 / activities)
    92554 kB: com.android.systemui (pid 539)
Total PSS by 00M adjustment:
    19794 kB: Native
                6031 kB: surfaceflinger (pid 119)
   36427 kB: System
               36427 kB: system (pid 444)
  101001 kB: Persistent
               92554 kB: com.android.systemui (pid 539)
   362721 kB: Cached
              141263 kB: com.google.earth (pid 3351 / activities)
Total RAM: 1124832 kB
Free RAM: 633617 kB (362721 cached pss + 138452 cached + 132444 free)
Used RAM: 352407 kB (323895 used pss + 4304 buffers + 656 shmem + 23552 slab)
Lost RAM: 138808 kB
  Tuning: 192 (large 512), oom 122880 kB, restore limit 40960 kB (high-end-gfx)
```

Tools: meminfo

- In Kit Kat, dumpsys meminfo has been augmented to make the use of memory more clear
- Processes with oom_adj >= 9 (CACHED_APP_MIN_ADJ)
 can be killed without the user noticing
- So Free RAM includes apps that can be discarded ("cached pss") and system buffers ("cached")

Tools: procstats

- procstats adds history to the measurement by integrating Pss over time
- Use to identify persisten memory hogs
- Typically shows up apps with long-running background services
- procstats has a nice graphical interface, and can be run from the command line

procstats

Settings -> Developer options -> Process Stats



- Bar is a summary of memory pressure: green=good, yellow=OK, red=bad
- · For each app, shows
 - % of time it was running
 - a blue bar which is (average Pss * runtime)

procstats

Zoom in on second app:



- Contains a service FlightUpdateService
- Has been running 100% of the time
- · Is taking 33 MiB

procstats command-line

- The raw data is avaiable through system service procstats
- Dump the data using

The memory numbers are minPss-avgPss-maxPss / minUss-avgUss-maxUss

Tuning Android for low RAM

What are the options?

- · Tune Activity manager
- Tune Dalvik
- Tune Apps

Tuning Android for low RAM

- Kit Kat has a global tuning parameter for low RAM ro.config.low_ram
- If set to true:
 - Optimise allocations in Dalvik heap
 - Saves memory by reducing use of the GPU
 - New API ActivityManager.isLowRamDevice() returns true which apps can use as a hint that they should reduce memory usage: some Google apps are reportedly coded to make this check
- Reduces the Dalvik total PSS by 10 15% on devices with large bitmaps (such as Nexus 7 or 10)

Optimising Dalvik JIT

- JIT cache defaults to 1.5 MiB per app (on ARMv7a)
- If set too low will send the JIT into a thrashing mode
- For the really low-memory devices disable JIT by setting cache size to zero

PRODUCT_PROPERTY_OVERRIDES += dalvik.vm.jit.codecachesize=0

Wallpaper

- Ensure the default wallpaper setup on launcher is not live wallpaper
- Do not pre-install any live wallpapers

Tuning Linux for low RAM

What are the options?

- KSM
- Swap to compressed RAM
- Tune ION carveout

Linux memory reclaim

- Background reclaim is done by the kswap daemon
 - Started when free memory drops below a threshold:
 2MB on a 2GB device and 636KB on a 512MB
 - Aims to keep some memory free by flushing dirty pages to disk (or invoking the low memory killer)
- Direct reclaim happens when a process tries to allocate memory and there are no free pages
 - blocks the calling thread while pages are freed
- Direct reclaim is bad because it can freeze the UI thread, leading to a poor UX

extra_free_kbytes

- Default kswapd threshold is rather low for Android devices
- /proc/sys/vm/extra_free_kbytes is a tuneable added by Google to Linux 3.4 to modify the kswapd threshold
- If set to 0 (default), Activity Manager will adjust it to 3 x screen buffer
- Can be configured in platform config.xml frameworks/base/core/res/res/values/config.xml
 - config_extraFreeKbytesAbsolute overrides the default chosen by Activity Manager: -1 keeps the default
 - config_extraFreeKbytesAdjust added (subtracted if negative) from the value chosen by Activity Manager

Kernel Samepage Merging (KSM)

- KSM is a kernel thread (ksmd) that runs in the background and compares pages in memory that have been marked MADV_MERGEABLE by user-space
- If two pages are found to be the same, it merges them back to a single copy-on-write page
- Balancing reduced memory usage vs more processing (greater power demand)
- Benefit depends on workload

KSM controls

- Build kernel with config_ksm=y (Linux 2.6.32 or later)
- Controlled by these files in /sys/kernel/mm/ksm

File	default	Description
run	0	Start ksmd thread if non-zero
sleep_millisecs	500	ms between scans
pages_to_scan	100	pages per scan

 Typically you add lines to your init.[name].rc to set up KSM

Does KSM work?

Also in /sys/kernel/mm/ksm

File	Description
full_scans	how many times all mergeable areas have been
	scanned
pages_shared	how many shared pages are being used
pages_sharing	how many more sites are sharing them i.e. how
	much saved
pages_unshared	how many pages unique but repeatedly checked
	for merging
pages_volatile	how many pages changing too fast to be placed
	in a tree

• And, at the end of dumpsys meminfo:

```
# dumpsys meminfo
...
KSM: 33992 kB saved from shared 4216 kB
234796 kB unshared; 532028 kB volatile
```

Compressed swap area

- Use a compressed RAM swap area, zram, for swap
- Unused dirty pages can be swapped out and compressed
- Compression ratios in the 30-50% range are usually observed
- Once again, you are balancing reduced memory usage vs more processing (greater power demand)

Compressed swap area

Add to kernel config

```
CONFIG_SWAP
CONFIG_CGROUP_MEM_RES_CTLR
CONFIG_CGROUP_MEM_RES_CTLR_SWAP
CONFIG_ZRAM
```

Add to fstab:

```
/dev/block/zram0 none swap defaults
zramsize=<size in bytes>,swapprio=<swap partition priority>
```

Contiguous memory buffers

- Some simple peripherals require contiguous memory
- Typically, a region on memory is reserved using CMA
- ... and allocated using an ION carveout heap
- ... so it makes sense to review and minimise the use of such heaps

· Questions?