

# The **OpenVX™** Installable Client Driver Loader Extension

Version 1.0 (Provisional)

Document Revision: 76df2d2

Khronos Vision Working Group

Editor: Radhakrishna Giduthuri Editor: Xin Wang

Copyright ©2016 The Khronos Group Inc.

Copyright ©2016 The Khronos Group Inc. All Rights Reserved.

This specification is protected by copyright laws and contains material proprietary to the Khronos Group, Inc. It or any components may not be reproduced, republished, distributed, transmitted, displayed, broadcast, or otherwise exploited in any manner without the express prior written permission of the Khronos Group. You may use this specification for implementing the functionality therein, without altering or removing any trademark, copyright or other notice from the specification, but the receipt or possession of this specification does not convey any rights to reproduce, disclose, or distribute its contents, or to manufacture, use, or sell anything that it may describe, in whole or in part. Khronos Group grants express permission to any current Promoter, Contributor or Adopter member of Khronos to copy and redistribute UNMODIFIED versions of this specification in any fashion, provided that NO CHARGE is made for the specification and the latest available update of the specification for any version of the API is used whenever possible. Such distributed specification may be reformatted AS LONG AS the contents of the specification are not changed in any way. The specification may be incorporated into a product that is sold as long as such product includes significant independent work developed by the seller. A link to the current version of this specification on the Khronos Group website should be included whenever possible with specification distributions.

Khronos Group makes no, and expressly disclaims any, representations or warranties, express or implied, regarding this specification, including, without limitation, any implied warranties of merchantability or fitness for a particular purpose or non-infringement of any intellectual property. Khronos Group makes no, and expressly disclaims any, warranties, express or implied, regarding the correctness, accuracy, completeness, timeliness, and reliability of the specification. Under no circumstances will the Khronos Group, or any of its Promoters, Contributors or Members or their respective partners, officers, directors, employees, agents or representatives be liable for any damages, whether direct, indirect, special or consequential damages for lost revenues, lost profits, or otherwise, arising from or in connection with these materials. SAMPLE CODE and EXAMPLES, as identified herein, are expressly depicted herein with a "grey" watermark and are included for illustrative purposes only and are expressly outside of the Scope as defined in Attachment A - Khronos Group Intellectual Property (IP) Rights Policy of the Khronos Group Membership Agreement. A Member or Promoter Member shall have no obligation to grant any licenses under any Necessary Patent Claims covering SAMPLE CODE and EXAMPLES.

## **Contents**

1 The OpenVX Installable Client Driver Loader Extension				
1.1	Overview			
1.2	Dependencies			
1.3	External Interface			
1.4	Inferring Vendor ICD Calls from Arguments			
1.5	5 Vendor Enumerations on Linux			
1.6				
1.7	Vendor Enumerations on Windows			
1.8	ICD Compatible Khronos Sample Implementation			
1.9	Sample Implementation of ICD Loader			
1.10	Updates to ICD Loader source code			
	Contributors			
Mod	ule Documentation			
2.1	OpenVX ICD Loader API			
	2.1.1 Detailed Description			
	2.1.2 Function Documentation			
	vxCreateContextFromPlatform			
	vxlcdGetPlatforms			
	vxQueryPlatform			
	1.1 1.2 1.3 1.4 1.5 1.6 1.7 1.8 1.9 1.10 1.11			

### **Chapter 1**

# The OpenVX Installable Client Driver Loader Extension

### 1.1 Overview

The vx\_khr\_icd extension defines a simple mechanism through which the Khronos installable client driver loader (IC-D Loader) may expose multiple separate vendor installable client drivers (Vendor ICDs) for OpenVX. An application written against the ICD Loader will be able to access all vx\_platform exposed by all vendor implementations with the ICD Loader acting as a demultiplexer.

### 1.2 Dependencies

OpenVX 1.0.1 or later

### 1.3 External Interface

The ICD Loader interface can be accessed by application using:

```
#include <VX/vx_khr_icd.h>
```

The VX/vx\_khr\_icd.h includes definition of a new object vx\_platform and new functions vxlcdGetPlatforms, vx-QueryPlatform, vxCreateContextFromPlatform. An ICD compatible vendor implementation is required to implement the function vxCreateContextFromPlatform. And the implementation of vxlcdGetPlatforms, vxQueryPlatform, and struct \_vx\_platform will be part of ICD Loader source. See OpenVX ICD Loader API for further details.

### 1.4 Inferring Vendor ICD Calls from Arguments

At every OpenVX function call, the ICD Loader infers the Vendor ICD function to call from the ICD compatible object that is passed as the first argument. All OpenVX objects are said to be ICD compatible if the struct \_vx\_reference contains a placeholder for vx\_platform as it's first field, as shown below:

```
struct .vx.reference {
    struct .vx.platform * platform;
    // ... remainder of internal data
};
```

The structure \_vx\_platform has a function pointer dispatch table which is used to make direct calls to a particular vendor implementation. All objects created from ICD compatible objects must be ICD compatible.

Functions which do not take ICD compatible object or a pointer to ICD compatible object as it's first argument needs to be implemented by ICD Loader. The OpenVX functions that are required for an implementation in ICD Loader source are:

The ICD Loader's vxCreateContext implementation is required to pick the default platform and to call the vendor specific implementation of vxCreateContextFromPlatform.

The ICD Loader's vxHint implementation is required to check the OpenVX version of the vendor implementation and handle function signature changes between OpenVX 1.0.1 and OpenVX 1.1.

### 1.5 Vendor Enumerations on Linux

To enumerate vendor ICDs on Linux, the ICD Loader scans the files under /etc/OpenVX/vendors. For each file in this path, the ICD Loader opens the file as a text file. The expected format for the file is a single line of text which specifies the Vendor ICD's library. If the Vendor ICD comes with a separate library for immediate mode functions (V-XU), the expected format for the file is a single line of text with OpenVX and VXU libraries separated by semi-colon(;) in that order

The ICD Loader will attempt to open that file as a shared object using dlopen(). Note that the library specified may be an absolute path or just a file name.

#### **EXAMPLE**

```
If the following file exists
/etc/OpenVX/vendors/VendorA.icd
and contains the text
libopenvx.so;libvxu.so
then the ICD Loader will load the libraries "libopenvx.so" and "libvxu.so"
```

### 1.6 Vendor Enumerations on Android

To enumerate vendor ICDs on Android, the ICD Loader scans the files under /system/vendor/Khronos/OpenV-X/vendors/. For each file in this path, the ICD Loader opens the file as a text file. The expected format for the file is a single line of text which specifies the Vendor ICD's library. If the Vendor ICD comes with a separate library for immediate mode functions (VXU), the expected format for the file is a single line of text with OpenVX and VXU libraries separated by semi-colon(;) in that order.

The ICD Loader will attempt to open that file as a shared object using dlopen(). Note that the library specified may be an absolute path or just a file name.

#### **EXAMPLE**

```
If the following file exists
/system/vendor/Khronos/OpenVX/vendors/VendorA.icd
and contains the text
libopenvx.so
then the ICD Loader will load the library "libopenvx.so"
```

### 1.7 Vendor Enumerations on Windows

To enumerate Vendor ICDs on Windows, the ICD Loader scans the values in the registry key HKEY\_LOCAL\_M-ACHINE. For each value in this key which has DWORD data set to 0, the ICD Loader opens the dynamic link library specified by the name of the value using LoadLibraryA. If the Vendor ICD comes with a separate library for immediate mode functions (VXU), the expected format for the name of the value is a single line of text with OpenVX and VXU libraries separated by semi-colon(;) in that order.

### **EXAMPLE**

```
If the registry contains the following value [HKEY_LOCAL_MACHINE\SOFTWARE\Khronos\OpenVX\Vendors] "c:\vendor_a\openvx.dll;c:\vendor_a\\vxu.dll"=dword:00000000 then the ICD will open the libraries "c:\vendor_a\openvx.dll" and "c:\vendor_a\vxu.dll"
```

### 1.8 ICD Compatible Khronos Sample Implementation

To make the sample implementation compatible with ICD implementation, the following two changes are required:

```
    Add "struct _vx_platform * platform;" as first field to "struct _vx_reference"
    Every derived reference should copy "platform" from it's parent:
        add "ref->platform = context ? context->base.platform : NULL;" statement to vxInitReference()
    Create a new vxCreateContextFromPlatform() which initializes context->base.platform with the function argument and performs same functionality as vxCreateContext().
```

### 1.9 Sample Implementation of ICD Loader

An implementation of ICD Loader is available in vx\_khr\_icd folder of sample implementation tree. Use cmake to build ICD Loader library to a static library with the name "openvx". Applications that use ICD Loader library can use any ICD compatible vendor implementation picked during run-time.

### Example: Build and Run Conformance Tests using ICD Loader

```
# Build ICD Loader sample implementation from vx_khr_icd folder
% pushd <path-to-sample-implementation-trunk>
 export OPENVX_DIR=$PWD
 popd
% mkdir -p build/vx_khr_icd
% cd build/vx_khr_icd
% cmake $OPENVX_DIR/vx_khr_icd
% make
% export VX_KHR_ICD_LIB=$PWD
# Build OpenVX Conformance Tests using ICD Loader
% mkdir -p build/conformance_tests
% cd build/conformance_tests
% cmake -DOPENVX_INCLUDES=$OPENVX_DIR/include \
        -DOPENVX_LIBRARIES=$VX_KHR_ICD_LIB/libopenvx.a\;pthread\;dl\;m \
        $OPENVX_DIR/conformance_tests
% make
# Run Conformance Tests
# Note: use of sample implementation requires LD_LIBRARY_PATH to be set properly
% export VX_TEST_DATA_PATH=$OPENVX_DIR/conformance_tests/test_data
% <build binary path>/vx_test_conformance
```

### 1.10 Updates to ICD Loader source code

The sample implementation tree has a python script vx\_khr\_icd/vx\_khr\_icd.py to update ICD Loader source code from OpenVX header files in include/VX folder.

### 1.11 Contributors

• Radhakrishna Giduthuri (radha.giduthuri@amd.com)

### **Chapter 2**

### **Module Documentation**

### 2.1 OpenVX ICD Loader API

The OpenVX Installable Client Driver (ICD) Loader API.

### **Typedefs**

typedef struct \_vx\_platform \* vx\_platform
 Platform handle of an implementation.

### **Functions**

- vx\_context vxCreateContextFromPlatform (vx\_platform platform)
  - Creates a vx\_context from a vx\_platform.
- vx\_status vxlcdGetPlatforms (vx\_size capacity, vx\_platform platform[], vx\_size \*pNumItems)

Queries list of available platforms.

vx\_status vxQueryPlatform (vx\_platform platform, vx\_enum attribute, void \*ptr, vx\_size size)

Queries the platform for some specific information.

### 2.1.1 Detailed Description

The OpenVX Installable Client Driver (ICD) Loader API. The vx\_khr\_icd extension provides a mechanism for vendors to implement Installable Client Driver (ICD) for OpenVX. The OpenVX ICD Loader API provides a mechanism for applications to access these vendor implementations.

### 2.1.2 Function Documentation

### vx\_context vxCreateContextFromPlatform ( vx\_platform platform )

Creates a vx\_context from a vx\_platform.

This creates a top-level object context for OpenVX from a platform handle.

#### Returns

The reference to the implementation context  $vx\_context$ . Any possible errors preventing a successful creation should be checked using vxGetStatus.

vx\_status vxlcdGetPlatforms ( vx\_size capacity, vx\_platform platform[], vx\_size \* pNumltems )

Queries list of available platforms.

### **Parameters**

in	capacity	Maximum number of items that platform[] can hold.
out	platform[]	List of platform handles.
out	pNumItems	Number of platform handles returned.

### Returns

A  $vx\_status\_e$  enumeration.

### Return values

VX_SUCCESS	No errors.
VX_FAILURE	If no platforms are found.

### vx\_status vxQueryPlatform ( vx\_platform platform, vx\_enum attribute, void \* ptr, vx\_size size )

Queries the platform for some specific information.

### **Parameters**

in	platform	The platform handle.
in	attribute	The attribute to query. Use one of the following: VX_CONTEXT_VENDOR_ID,
		VX_CONTEXT_VERSION, VX_CONTEXT_EXTENSIONS_SIZE, VX_CONT-
		EXT_EXTENSIONS.
out	ptr	The location at which to store the resulting value.
in	size	The size in bytes of the container to which <i>ptr</i> points.

### Returns

A  $vx\_status\_e$  enumeration.

### Return values

VX_SUCCESS	No errors.
VX_ERROR_INVALID_REF-	If the platform is not a vx_platform.
ERENCE	
VX_ERROR_INVALID_PAR-	If any of the other parameters are incorrect.
AMETERS	
VX_ERROR_NOT_SUPPO-	If the attribute is not supported on this implementation.
RTED	

## Index

```
OpenVX ICD Loader API, 5
vxCreateContextFromPlatform, 5
vxlcdGetPlatforms, 5
vxQueryPlatform, 6

vxCreateContextFromPlatform
OpenVX ICD Loader API, 5
vxlcdGetPlatforms
OpenVX ICD Loader API, 5
vxQueryPlatform
OpenVX ICD Loader API, 6
```