



# Chip Scale Atomic Clocks Sources

Technology comparison

---

Tommaso Bocchietti

March 27, 2024

University of Waterloo

# Agenda

1. Key Parameters
2. Technology comparison
3. Conclusion

## Recap from "Working principles"

General idea: leverage the intrinsic stability of atomic transitions to discipline an oscillating circuit based on a vibrating quartz crystal.





Figure 1: Chip Scale Atomic Clock scheme.

## Key Parameters

---

# Stability and Accuracy

The second, symbol  $s$ , is the SI unit of time. It is defined by taking the fixed numerical value of the  $Cs$  frequency  $\Delta\nu_{Cs}$ , the unperturbed ground-state hyperfine transition frequency of the  $^{133}Cs$  atom, to be 9.192.631.770 when expressed in the unit Hz, which is equal to  $s^{-1}$ .




# Short term stability (Allan deviation $\sigma_y(\tau)$ )

Allan deviation is a measure of the stability of a frequency standard.

$$y(t) = \frac{f(t) - f_0}{f_0}$$

$$\sigma_y(\tau) = \sqrt{\frac{1}{2M} \sum_{i=2}^M (\bar{y}(\tau)_i - \bar{y}(\tau)_{i-1})^2}$$



It captures the frequency **Fast Noise (mainly caused by the Local Oscillator (LO))** & the Slow Drift (next slide)

---

<sup>0</sup>σ<sub>y</sub>(τ = 1s) = 3 × 10<sup>-9</sup> is equivalent to an instability in frequency between two observations 1 second apart with a (RMS) value of 3 × 10<sup>-9</sup>. For a 10MHz clock, this would be equivalent to 30mHz RMS movement.

# Short term stability (Allan deviation $\sigma_y(\tau)$ )

Allan deviation is a measure of the stability of a frequency standard.

$$y(t) = \frac{f(t) - f_0}{f_0}$$

$$\sigma_y(\tau) = \sqrt{\frac{1}{2M} \sum_{i=2}^M (\bar{y}(\tau)_i - \bar{y}(\tau)_{i-1})^2}$$




Figure 2: CBT, Rb, OCXO, TCXO

It captures the frequency **Fast Noise (mainly caused by the Local Oscillator (LO))** & the Slow Drift (next slide)

---

${}^0\sigma_y(\tau = 1s) = 3 \times 10^{-9}$  is equivalent to an instability in frequency between two observations 1 second apart with a (RMS) value of  $3 \times 10^{-9}$ . For a 10MHz clock, this would be equivalent to 30mHz RMS movement.

## Medium term stability (Allan deviation $\sigma_y(\tau)$ )

After the flicker floor, the **Slow Drift** became the dominant noise source and Allan deviation can be expressed as:

$$\sigma_y(\tau) = \frac{1}{Q \times SNR} \tau^{-1/2}, \text{ where } \begin{cases} Q & \text{Line quality} \\ SNR & \text{Signal-to-noise ratio} \end{cases} \quad = \frac{\nu_0}{\Delta\nu} = \frac{P_{signal}}{P_{noise}} \quad (1)$$




Figure 3:  $\nu_0$  and  $\Delta\nu$ .





Figure 4:  $P_{signal}$  and  $P_{noise}$ .

**MODR**-based: lower  $Q$  but higher  $SNR$ .

**CPT**-based: higher  $Q$  but lower  $SNR$ .

## Long term stability (Drift)

Drift is a measure of the long term stability of the clock which is caused by variation in the atomic reference frequency due to aging and environmental factors.




<sup>0</sup>MJD: Modified Julian Dates, are a count of days since November 17, 1858.

## **Technology comparison**

---

# ADEV@1s vs. Size

Empirical correlation<sup>1</sup>:  $\sigma_y(\tau = 1) = 6.85 \times 10^{-10} + \text{volume}^{-0.64}$




## Legend

- CSAC = Microsemi SA.45s CSAC
- TCSAC = Teledyne CSAC (preliminary)
- CPT = Chengdu Spaceon CPT
- NAC = Accubeat Rb NAC1
- IQRB1 = IQD IQRB-1
- Ch Rb = Chengdu Spaceon XHTF1031
- MAC = Microsemi SA.35m
- SA22 = Microsemi SA.22c
- PRS = SRS PRS10
- LP = Spectratime low profile Rb
- AR133A = Accubeat AR133A Rb
- miniRAFS = Spectratime miniRAFS
- IQRB2 = IQD IQRB-2
- 5669 = FEI FE-5660 Rb
- F5725 = SRS F5725
- RAFS = Excelitas space RAFS
- iRAFS = Spectratime iSpace RAFS
- CsIII = Microsemi CBT 4310B CsIII
- FEI RAFS = FEI RAFS
- 5071A = Microsemi 5071A CBT
- OPC = Chengdu Spaceon TA1000 OPC
- c-Rb = Spectradynamics cold Rb c-Rb
- PHM = T4Science pHMaser 1008
- mu = Muquans cold-atom MuClock (preliminary)
- MHM = Microsemi MHM 2010 H Maser
- Vremya = Vremya VCH-1003M H Maser
- T4 = T4Science iMaser-3000 H Maser

<sup>1</sup>Volume is expressed in [cm<sup>3</sup>].

# ADEV@1s vs. SWaP (Size, Weight and Power)

Similar correlation as before<sup>1</sup>:  $\sigma_y(\tau = 1) = 1.15 \times 10^{-10} + \text{SWaP}^{-0.27}$



<sup>1</sup>SWaP is expressed in  $[cm^3 \times kg \times W]$ .

## Cost vs. Performance (qualitative)

Similar to what we have seen before, the cost of an atomic clock is proportional to its performance.

Technology	Units/year	Unit price (Range in \$)	Worldwide sales (\$/year)	ADEV (1 s)
Quartz crystals	$5 \times 10^9$	[0.1; 2000]	5B	Low to medium
CSACs	12000	[2000; 6000]	15M	Medium to high
Rubidium cells	30000	[1000; 10000]	150M	High
Caesium beam	500	[40000; 100000]	40M	Very high
Hydrogen masers	20	> 100000	4M	The best

**Table 1:** All data must be taken as indicative.

For a CSAC, the cost is mainly driven by the packaging and assembly of the physics package.

## Conclusion

---

## Choice the right technology

The performance of an atomic clock can be evaluated (simplistically) as:

$$\text{Better performance} \Leftrightarrow \text{Higher SWaP \& Cost} \quad (2)$$

Both **MODR**-based<sup>1</sup> and **CPT**-based<sup>2</sup> have comparable performance, but different SWaP and cost:

- **CSAC (MODR)**: cheaper, but larger and more power hungry.
- **CSAC (CPT)**: more expensive, but smaller and more power efficient.

The right balance between performance, size, power consumption and cost depends on the specific application.

---

<sup>1</sup>Microwave Optical Double-Resonance

<sup>2</sup>Coherent Population Trapping

**Extra slides**

## Commercial CSACs

Manufacturer/Model	Country	ADEV (1 s)	Power (W)	Size (cm <sup>3</sup> )
Jackson Labs CSAC GPSDO	US	1E-10	1,4	85
Seiko Epson A06860LAN	JP	3E-11	3,0	75
Precision Test Systems RFS2	UK	3E-11	6,0	65
Quartziock EI O-MRX	UK	5E-11	6,0	65
Microsemi MAC SA.3Xm	US	3E-11	5,0	50
Orolia Spectratime mRO-50	CH/FR	4E-11	0,5	50
Chengdu Spaceon XHTF1031	China	5E-11	6,0	50
Microsemi MAC SA.5X	US	3E-11	6,3	47
Accubeat NAC1	Israel	2E-10	1,2	32
IQD ICPT-1	UK	9E-11	1,7	25
Chengdu Spaceon XHTF1040	China	3E-10	1,6	24
Teledyne TCSAC	US	3E-10	0,2	23
Microsemi SA45.s	US	3E-10	0,1	17
Chengdu Spaceon XHTF1045	China	3E-10	0,3	17

<sup>0</sup>Data ordered by size.

# Commercial atomic clocks

Vendor	Product	Type	ADEV (1 s)	$\mathcal{L}$ (10 Hz)	Aging (month)	Retrace	Tmin (°C)	Tmax (°C)	Tempco	Power (W)	Weight (kg)	Size (cm <sup>3</sup> )
Muquans	MuC10ck	cold Rb	3,00E-13	-151						200,00	135,000	682000
T4Science	iMaser-3000	Maser	6,00E-14	-136	6,00E-15					100,00	100,000	436800
Microsemi	MHM 2020	Maser	8,00E-14	-138	9,00E-15					75,00	246,000	374072
Vremya	VCH-1003M	Maser	6,00E-14	-135	9,00E-15					100,00	100,000	305525
T4Science	pHMaser	PHM	5,00E-13	-130	6,00E-14					90,00	33,000	49820
Chengdu Spaceon	TA1000	OPC	1,20E-11	-125						100,00	40,000	48266
Spectradynamics	c-Rb	cold Rb	5,00E-13	-138						75,00	30,500	39806
Microsemi	5071A	CBT	5,00E-12	-130			0	55		50,00	30,000	29700
Oscilloquartz	OSA 3235B Cs	CBT	1,20E-11	-120						60,00	15,000	23021
Microsemi	cslll 4310B	CBT	1,20E-11	-130			0	50		30,00	13,500	16544
FEI	FEI RAFS	Space Rb	6,00E-13	-138	9,00E-13	5,00E-12	-4	25		39,00	7,500	4902
Spectratime	iSpace RAFS	Space Rb	3,00E-12	-120	8,30E-12		-5	10		35,00	3,400	3224
Excelitas	RAFS	space Rb	2,00E-12	-105	3,00E-12	5,00E-12	-20	45		39,00	6,350	1645
FEI	FE-5669	Rb	6,00E-12	-140	1,00E-11	2,00E-11	-20	60	5,00E-11	20,00	1,690	669
Microchip	XPRO (low drift)	Rb	1,00E-11	-90	1,00E-11	3,00E-11	-25	70	6,00E-10	13,00	0,500	455
Spectratime	miniRAFS	Rb	1,00E-11	-84	3,00E-11		-15	55		10,00	0,450	388
IQD	IQRB-2	Rb	2,00E-12	-138	4,00E-11	2,00E-11				6,00	0,220	230
Spectratime	LP Rb	Rb	1,00E-11	-100	3,00E-11	5,00E-11	-25	55	2,00E-10	10,00	0,290	216
SRS	PRS10	Rb	2,00E-11	-130	5,00E-11	5,00E-11	-20	65	2,00E-10	14,40	0,600	155
Accubeat	AR133A	Rb	5,00E-12	-116	1,00E-11	5,00E-11	-20	65	1,00E-10	8,25	0,295	146
IQD	IQRB-1	Rb	5,00E-11	-95	5,00E-11	2,00E-11	0	50	5,00E-10	6,00	0,105	66
Chengdu Spaceon	XHTF1031 Rb	CPT	5,00E-11	-95	5,00E-11		-30	65	2,00E-10	6,00	0,200	65
Spectratime	mRO-50 (EAS)	CSAC	4,00E-11	-76	1,50E-10	1,00E-10	-10	65	4,00E-10	0,36	0,075	50
Microsemi	SA55 MAC	CPT	3,00E-11	-87	5,00E-11	5,00E-11	-10	75	5,00E-11	6,30	0,100	46
Accubeat	NAC	CSAC	2,00E-10	-86	3,00E-10		-20	65	2,00E-09	1,20	0,075	32
Chengdu Spaceon	CPT	CSAC	2,00E-10	-90	9,00E-10	5,00E-11	-45	70	5,00E-10	1,60	0,045	24
Teledyne	TCSAC	CSAC	3,00E-10	-85	3,00E-10	3,00E-10	-10	60	1,00E-09	0,18	0,042	23
Microsemi	SA45.s	CSAC	3,00E-10	-70	9,00E-10	5,00E-10	-10	70	1,00E-09	0,12	0,035	17
Microsemi	SA65	CSAC	3,00E-10	-64	9,00E-10	5,00E-10	-40	80	3,00E-10	0,12	0,035	16

<sup>0</sup>Data ordered by size.

## References i

-  P. Banerjee and D. Matsakis.  
**Frequency Stability, pages 79–108.**  
Springer Nature Switzerland, Cham, 2023.
-  BIMP.  
**Si base unit: second (s).**  
[https://www.bipm.org/en/si-base-units/second.](https://www.bipm.org/en/si-base-units/second)
-  J. H. David R. Scherer, Bonnie L. Schmittberger.  
**Current and future atomic clocks - roadmap and applications.**  
[https://www.gps.gov/cgsic/meetings/2019/.](https://www.gps.gov/cgsic/meetings/2019/)
-  S. Knappe.  
**Emerging Topics MEMS Atomic Clocks.**  
Elsevier (Netherlands), Nov 2007.

## References ii

-  B. L. S. Marlow and D. R. Scherer.  
**A review of commercial and emerging atomic frequency standards.**  
*IEEE Transactions on Ultrasonics, Ferroelectrics, and Frequency Control*,  
68(6):2007–2022, 2021.
-  Microchip.  
**Microchip technology inc. (website).**  
<https://www.microsemi.com/>.
-  NIST.  
**Time and frequency from a to z.**  
<https://www.nist.gov/pml/time-and-frequency-division/popular-links/time-frequency-z>.
-  M. Travagnin.  
**Chip-scale atomic clocks: Physics, technologies, and applications.**  
(KJ-NA-30790-EN-N (online)), 2021.

**Questions?**

**Thank you!**



# Chip Scale Atomic Clocks Sources

## Applications

---

Tommaso Bocchietti

March 27, 2024

University of Waterloo

# Agenda

1. Global Navigation Satellite Systems (GNSS)
2. Ocean Bottom Seismic (OBS)
3. Military field
4. Conclusion

## Recap from "Technology comparison"

The *absolute best* CSACs doesn't exist.

In general, performance of the clock are proportional to its SWaP (Size Weight and Power) and cost.

The choice of the clock depends on the application requirements.

# **Global Navigation Satellite Systems (GNSS)**


---

# Trilateration in GNSS networks

System of equations involved in trilateration ( **$\delta t$  is the receiver clock delay**):

$$\Delta d_i = c \cdot (\Delta t_i + \delta t) = \sqrt{(x_r - x_i)^2 + (y_r - y_i)^2 + (z_r - z_i)^2}, \quad i = 1, 2, 3, 4$$

$\underbrace{x_r, y_r, z_r, \delta t}_{\text{4 Unknowns requires 4 satellites}}$



**Final position strongly depends on  $\delta t$ .**

---

<sup>0</sup>In the equation above,  $c$  is the speed of light which is approximately  $3 \times 10^8$  m/s.

# Role of CSAC

Better holdover capabilities → eliminate the need for the 4<sup>th</sup> satellite after the first clock calibration.

More accurate timing → more precise trilateration and indeed a more accurate position.





Figure 1: TCXO, CSAC

## **Ocean Bottom Seismic (OBS)**

---

# Seismic Methods & Oil Exploration

Seismic or acoustic methods measure the travel times of the reflected or refracted waves detected by a series of geophones and are able to estimate the location and depth of the targets.



**Figure 2:** Seismic method applied from Earth's surface.


A precise timestamp is required to measure the travel time of the waves.

Seismic methods are used for oil exploration since they can estimate the location and depth of the oil reservoirs.

## Role of CSAC

Small short & medium drifts → no GNSS required for nodes synchronization.

Low battery consumption → long-lasting measurements campaigns (weeks or months).



**Figure 3:** Thanks to CSAC, mapping is now done by placing the geophones on the ocean floor and not on the surface, obtaining more accurate results.

## Military field

---

# IED (Improvised Explosive Devices) Jammers

IED Jammers are devices that prevent the detonation of IEDs by blocking the radio signals used to trigger them.

A single jammer can cover a limited area, so multiple jammers are used to cover a larger area. In order to work together, **the network must be tightly synchronized.**



# SAASM (Selective Availability Anti-Spoofing Module)



SAASM is a module that provides decryption and encryption capabilities to GPS receivers.

The use of a CSAC reduce the time needed to acquire the signal and allows the **use of longer GPS codes (encrypted P(Y) code)** that are less susceptible to jamming and spoofing.

## Conclusion

---

## Applications of CSACs

CSACs find applications in sectors that require **high precision timing** sources, **network synchronization** without GNSS, **low power** consumption and **portable devices**.


The relative high cost of CSACs (2000\$ - 6000\$) is still a barrier to their widespread adoption in large-scale market or consumer products.

**Extra slides**

# 5G networks

5G networks require highly accurate timing sources for synchronization (max shift in the order of  $100\text{ns/day}$ ).


In case of failure of the primary source, CSAC holdover capabilities can be used to maintain synchronization at base stations.



# Space experiments

Space versions of CSACs are being developed for scientific missions and data collection.

SPATIUM (Space Precision Atomic-clock Timing Utility Mission) is a mission with the objective to model the ionosphere TEC (Total Electron Content) based on multipoint measurements formed by a constellation of small satellites.



## References i

-  K. Aheieva, R. Rahmatullah, R. Ninagawa, I. O. Adebolu, H. Masui, T. Yamauchi, S. Kim, M. Cho, C. L. Chow, M. S. Tse, and K. H. H. Li. **Cubesat mission for ionosphere mapping and weather forecasting using chip-scale atomic clock.** In *2017 Progress in Electromagnetics Research Symposium - Fall (PIERS - FALL)*, pages 761–766, 2017.
-  GISGeography. **How gps receivers work - trilateration vs triangulation.** <https://gisgeography.com/trilateration-triangulation-gps/>.
-  C. Jiang, S. Chen, Y. Chen, and Y. Bo. **Research on a chip scale atomic clock driven gnss/sins deeply coupled navigation system for augmented performance.** *IET Radar, Sonar & Navigation*, 13(2):326–331, 2019.

## References ii

-  F. I. John Smythe.  
**A nodal approach.**  
https://www.hartenergy.com/ep/exclusives/nodal-approach-176191.
-  J. Keller.  
**Northrop to build electronic warfare (ew) rf jammers to protect warfighters from improvised explosives.**  
https://www.militaryaerospace.com/rf-analog/article/14196810/electronic-warfare-ew-rf-jammers-improvised-explosives.
-  Microchip.  
**Microchip technology inc. (website).**  
https://www.microsemi.com/.
-  PEOIEWS.  
**Dagr.**  
https://www.flickr.com/photos/69349609@N02/6326407470.

## References iii



P. Shine.

### **Seismic methods.**

<https://petroshine.com/seismic-methods>.

**Questions?**

**Thank you!**