

This square resistor that is on the outside of the board area is done so
to keep the footprint but reduce the copper area required.
If populated it should be flipped 180.
Orientation doesn't matter for this resistor.
It shouldn't need to have that whole area soldered onto the board.
If necessary a heatsink could be added.
If necessary kaptop tape could be added for insulation.

Sheet:
File: rp2040_v0.kicad_pcb

Title: Enos Flight Computer Rev 0

Size: USLetter	Date: 2023-02-23	**Rev: 0**
KiCad E.D.A. kicad (6.0.10)		Id: 1/1



Sheet:		
File: rp2040_v0.kicad_pcb		
Title: Enos Flight Computer Rev 0		
Size: USLetter	Date: 2023-02-23	**Rev: 0**
KiCad E.D.A. kicad (6.0.10)		Id: 1/1



Sheet:		
File: rp2040_v0.kicad_pcb		
Title: Enos Flight Computer Rev 0		
Size: USLetter	Date: 2023-02-23	**Rev: 0**
KiCad E.D.A. kicad (6.0.10)		Id: 1/1



Sheet:		
File: rp2040_v0.kicad_pcb		
Title: Enos Flight Computer Rev 0		
Size: USLetter	Date: 2023-02-23	**Rev: 0**
KiCad E.D.A. kicad (6.0.10)		Id: 1/1