SOUTHGATE TERMINAL

Port Operations Security Documentation

ADDITION TO: Technical Containment Guide.docx

INSERT LOCATION: Add as new section after existing containment procedures SECTION TITLE: CCTV Blackout Response SOP

CCTV Blackout Response SOP

Purpose

This procedure provides immediate and extended response protocols for CCTV system failures, ensuring continued safe operations during surveillance loss. Use when camera feeds go black, show static, or display frozen images.

When to Use

- Individual camera blackouts affecting critical zones
- Multiple camera failures across sectors
- · Complete CCTV system failure
- · Intermittent camera feed disruptions
- CCTV failures coinciding with other system issues

Immediate Response (First 5 minutes)

Step	1: Scope Assessment
1.	Identify Affected Areas
	Document specific cameras/zones affected Map coverage gaps for operational areas Identify critical safety zones without coverage
2.	System Status Check
	Verify CCTV control room system status Check network connectivity to camera feeds Review recent system configuration changes
3.	Safety Evaluation
	Assess crane operations in blind zones Evaluate container movement safety Check personnel working in affected areas

Step 2: Immediate Safety Measures (Next 5 minutes)					
	1.	Personnel Deployment			
		Station manual spotters at affected critical zones Deploy safety personnel to blind spots Establish radio contact with all spotters			
	2.	Operations Adjustment			
		Slow down operations in affected areas Implement buddy system for crane operations Increase communication frequency			
	3.	Communication Alert			
		Alert all crane operators to CCTV loss Notify operations team of coverage gaps Establish direct radio protocols			
SI	nor	:-Term Response (5-30 minutes)			
Εı	nha	nced Manual Procedures			
	1.	Spotter Network Establishment			
		Assign dedicated spotters to each blind zone Establish clear radio communication protocols Create backup spotter rotation schedule			
	2.	Modified Operating Procedures			
		Reduce crane movement speed in blind zones Require verbal confirmation for all container moves Implement double-check system for safety clearances			
	3.	Alternative Monitoring			
		Use handheld radios for constant communication Deploy temporary mobile cameras if available Increase frequency of safety walks			
Cı	os	s-System Impact Assessment			
	1.	Network Correlation Check			
		Verify if CCTV loss correlates with network issues Check if other systems affected simultaneously Document timing relationships			
	2.	AIS Correlation Check			
		Compare CCTV blackout timing with AIS anomalies			

		Assess if vessels are visible but not tracking Note any cross-system pattern implications					
E	kter	nded Response (30+ minutes)					
Sustained Operations Protocol							
	1.	Workforce Adjustments					
		Rotate spotter personnel to prevent fatigue Brief all personnel on modified safety procedures Monitor crew stress and confidence levels					
	2.	Operational Capacity Assessment					
		Calculate safe operational capacity without CCTV Determine if operations should be reduced or halted Document capacity limitations for planning					
	3.	Alternative Solutions					
		Deploy temporary surveillance equipment Consider external security personnel Evaluate mobile camera options					

Decision Points for Operations Continuation

CONTINUE FULL OPERATIONS IF:

- Adequate manual spotters available
- · Clear radio communication maintained
- · Crew comfortable with manual procedures
- · No correlation with other system failures

REDUCE OPERATIONS IF:

- Limited spotter coverage available
- · Communication challenges identified
- · Crew expressing safety concerns
- · Multiple systems affected simultaneously

HALT OPERATIONS IF:

- Cannot ensure safe container movements
- · Inadequate personnel for manual spotting
- Crew refusing to work without visual confirmation
- · Safety risk assessment indicates high danger

Communication Protocols

To Crane Operators

• "CCTV blackout in [zones]. Manual spotters deployed at [locations]. Reduce speed, require verbal clearance for all moves."

To Operations Team

"CCTV system [partially/fully] compromised. Manual procedures implemented. Current capacity: [X]%. Safety [maintained/at risk]."

To Technical Team

• "CCTV blackout affects [zones]. Correlates with [network/AIS] issues at [time]. Technical investigation and restoration required urgently."

To Incident Coordinator

"CCTV Status: [description]. Manual procedures: [implemented]. Operations: [continuing/reduced/halted]. Restoration priority: HIGH."

Safety Risk Assessment Matrix

LOW RISK (Continue normal operations)

- · Single non-critical camera failure
- · Adequate alternative visual coverage
- · Clear weather and good visibility
- · Minimal personnel in affected area

MEDIUM RISK (Enhanced procedures required)

- · Multiple camera failures
- Critical zone coverage lost
- · Reduced but adequate spotter coverage
- Normal weather conditions

HIGH RISK (Consider operations reduction)

- · Major system failure affecting multiple critical zones
- · Limited spotter availability
- · Poor weather affecting visibility
- · Heavy operational activity in blind areas

CRITICAL RISK (Halt operations)

- · Complete CCTV failure with inadequate manual coverage
- · Safety concerns raised by operational personnel
- · Weather conditions limiting visibility
- Evidence of deliberate system interference

Technical Coordination Requirements

With Network Team

- Coordinate if CCTV loss correlates with network issues
- · Share timing information for cross-system analysis
- · Prioritise network restoration if CCTV depends on it

With Cyber Security (if applicable)

- · Escalate if CCTV failure appears deliberate
- · Preserve logs if cyber incident suspected
- · Coordinate with other system anomaly investigations

Restoration Verification Process

re-					

1.	Camera Functionality
	Test each camera feed individually Verify image quality and positioning Confirm recording functionality restored
2.	Network Connectivity
	Test network stability to camera systems Verify no packet loss or delay issues Confirm backup systems operational
Grad	ual Return to Automated Monitoring
1.	Phased Restoration
	Restore most critical cameras first Gradually reduce manual spotter coverage Maintain enhanced communication during transition
2.	Extended Monitoring
	Monitor system stability for first hour after restoration Keep backup spotters available Document any recurring issues

Success Criteria

- Safe operations maintained despite CCTV loss
- · Adequate manual monitoring coverage established
- · Clear communication protocols functioning
- · Crew confidence and safety maintained
- Smooth transition back to CCTV monitoring

Related Procedures

- Use with: Manual Override Authorisation (for modified operations)
- Coordinate with: Safety Risk Assessment Template
- Reference: Network Diagnostics SOP (if network correlation identified)
- Escalate to: Crisis Decision Authority Matrix (for operations halt decisions)