

Computer Architecture and Operating Systems Lecture 4: Instruction Set Architecture

Andrei Tatarnikov

atatarnikov@hse.ru
@andrewt0301

RISC-V ISA Base and Extensions

Name	Description	Version	Status
Base			
RVWMO	Weak Memory Ordering	2.0	Ratified
RV32I	Base Integer Instruction Set, 32-bit	2.1	Ratified
RV64I	Base Integer Instruction Set, 64-bit	2.1	Ratified
RV128I	Base Integer Instruction Set, 128-bit	1.7	Open
Extensions			
M	Standard Extension for Integer Multiplication and Division	2.0	Ratified
Α	Standard Extension for Atomic Instructions	2.1	Ratified
F	Standard Extension for Single-Precision Floating-Point	2.2	Ratified
D	Standard Extension for Double-Precision Floating-Point	2.2	Ratified
G	Shorthand for the base integer set (I) and above extensions (MAFD)	N/A	N/A
Q	Standard Extension for Quad-Precision Floating-Point	2.2	Ratified
С	Standard Extension for Compressed Instructions	2.0	Ratified
ZiCSR	Control and Status Register (CSR)	2.0	Ratified
Zifencei	Instruction-Fetch Fence	2.0	Ratified
And more standard and custom extensions			


ISA Design Principles

- Design Principle 1: Simplicity favors regularity
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost
- Design Principle 2: Smaller is faster
 - c.f. main memory: millions of locations
- Design Principle 3: Good design demands good compromises
 - Different formats complicate decoding, but allow 32-bit instructions uniformly
 - Keep formats as similar as possible

Six Instruction Formats

- R-format: instructions using 3 register inputs
 - add, xor, mul arithmetic/logical ops
- I-format: instructions with immediates, loads
 - addi, lw, jalr, slli
- **S-format:** store instructions
 - sw, sb
- **SB-format:** branch instructions
 - beq, bge
- U-format: instructions with upper immediates
 - lui, auipc upper immediate is 20-bits
- UJ-format: the jump instruction
 - jal

R-format Instructions



0000 0001 0101 1010 0000 0100 1011 0011_{two} = $015A04B3_{16}$


- Arithmetic Instructions
 - opcode: operation code
 - rd: destination register number
 - funct3: 3-bit function code (additional opcode)
 - rs1 and rs2: first and second source register 5-bit numbers
 - funct7: 7-bit function code (additional opcode)

I-format Instructions



- Immediate arithmetic and load instructions
 - rs1: source or base address register number
 - immediate: constant operand, or offset added to base address
 - 2s-complement, sign extended

S-format Instructions



- Different immediate format for store instructions
 - rs1: base address register number
 - rs2: source operand register number
 - immediate: offset added to base address
 - Split so that rs1 and rs2 fields always in the same place

Any Questions?

```
__start: addi t1, zero, 0x18
    addi t2, zero, 0x21

cycle: beg t1, t2, done
    slt t0, t1, t2
    bne t0, zero, if_less
    nop
    sub t1, t1, t2
    j cycle
    nop

if_less: sub t2, t2, t1
    j cycle

done: add t3, t1, zero
```