CS 341 – Lab 9 Computer Architecture and Organization Controlling the Position of a Servomotor

Equipment: Arduino UNO microcomputer, PC with Arduino IDE installed, and a USB cable. Parallax 4-6 VDC Standard Servo

Your assignment is to connect a standard servomotor to the Arduino board and control the position of its arm. This is a commonly required function in programming a robotic device. In manufacturing, a servomotor may control a robot arm to hold a tool in position for the required work. In a remote controlled hobby plane or a military drone, a servomotor may position a flight control surface. In a petroleum or chemical plant, a servomotor may open or close a valve controlling flow in a pipe.


The <u>Parallax Standard Servo DataSheet</u> provides information on programming the position of the servo. As in previous Parallax datasheets, the software examples shown are based on a different language and library so you can only use it for guidance and cannot use that code directly in our project.

We need to include the Arduino <Servo.h> library in our C code. It has a definition for a Servo class. We will use the Servo class "attach" method to configure a Servo object to use a Pulse Width Modulation (PWM) output pin by number. Like the digital output pin on which it is based, a PWM pin can generate only a +5 volt and 0 volt level. However, a PWM output pin can be modulated (changed in value) at a very fast rate (or as we might say with a short duty cycle). For example, if the pin is set to +5 volts half the time and 0 volts half the time quickly enough, the net voltage will behave like an analog 2.5 volts. Similarly, if the pin's voltage is set to +5 volts for a larger proportion than half of the time, the net voltage will be higher than 2.5 volts. If it is set to 0 volts for a larger proportion than half of the time, the net voltage will be lower than 2.5 volts. This is an inexpensive way to use digital outputs to create outputs that behave like analog outputs.

The Servo class contains a "write" method that takes an int value and sets the duty cycle of the attached PWM pin to the corresponding effective analog voltage. With the Standard Servo used in this assignment, the int value is scaled to a value between 0 and 180 corresponding to the desired position of the servo's arm in a semicircular arc. We will use the Arduino math library function "map" to scale an int input value to a value to be written to the servo.

We will use a real analog input to control the position of the servo. We will connect a potentiometer (a "pot") across +5 volts and ground (0 volts) and connect the center tap wire to the Arduino analog input pin A0. (A pot is an electronic component traditionally used for volume controls on audio devices and for other analog control purposes.) The center tap is controlled by the position of a knob/shaft and in each position it presents a voltage value that varies between 0 and +5 volts on the wire to the input pin. We will use the library analogRead function to read an int value between 0 and 1023 that corresponds to the voltage/position of the knob/shaft on the pot.

Disconnect the Arduino board from the USB port. Connect the power and ground wires to the pot and the servo. Connect the Arduino digital pin 9 to the control wire to the servomotor and analog input A0 to the center tap on the potentiometer.



NOTE: When you are adding, changing, or removing wiring on a prototype connected to the Arduino UNO board, always disconnect the power from the USB port and check your wiring carefully before reconnecting it to the USB port. Otherwise, you may damage the Arduino board. If you have any doubts, show your wiring to the TA before reconnecting it to the USB port.

In your sketch, you need to include the <Servo.h> library header file and define a global Servo object. In your setup code, you need to use the Servo's attach method to attach it to pin 9 (the PWM digital output pin). In your loop code, you need to use the analogRead function to read the value on A0 (from the pot), map the 0 - 1023 range of values to 0 - 180 via the map function, and pass that value to the Servo's write method as a parameter. Afterwards, delay for 15 millisecs (to allow time for the servo to react to the new position setting).

When you have it working correctly, you should be able to turn the knob/shaft on your pot and see that the servomotor turns and holds the new corresponding position. Show it to the TA to get credit for this lab.

Keep your wiring for the pot and the standard servo set up for your next lab session where you will use it to control a continuous motion servo.

As a team, write your lab report to explain what you did, how you did it, and what you learned about interfacing hardware to a microprocessor and its software (the "sketch"). Turn in your report including a copy of your team's final "sketch" at your next lab session.

____/10