# **DSM2** Bay-Delta Tutorial 4: Planning Simulation

**Purpose:** The goal of this tutorial is to learn to preprocess and launch a Bay-Delta planning simulation using CalSim Output as the basis for flow inputs.

The CalSim study we will use is the ocap\_2005A01A\_EWA2\_71\_novamp\_DV.dss provided in the tutorials/data directory. We will prepare and launch the run using both temporary barriers and permanent barriers configurations (SDIP: South Delta Improvements Program).

### Preparation

We will begin by creating a study space to house the planning study.

#### 1. Copy the study template:

- a. In windows, navigate to \{DSM2\_home}\\study\_templates. Copy the ocap\_sdip template to \{DSM2\_home}\\tutorial\\ocap\_sdip. Copy the ocap\_temp\_barrier template to \{DSM2\_home}\\tutorial\\ocap\_temp\_barrier
- b. In each new study folder, create a directory called "output" if there is not such a folder there already.

#### 2. Preprocess for sdip and temp\_barriers:

- a. Navigate to the sdip study directory and open config\_sdip\_ocap\_71.inp.
- b. Make sure that the run dates are set to the full 1974-1991 sixteen year planning period. It is a good idea to preprocess the full period even if you want to run a subset of these dates.
- c. Set the DSM2MODIFIER to ocap\_sdip\_tutorial.
- d. Make sure that the DICU version in the configuration file is 2020, representing a future (2020) level of development.
- e. Makes sure the STAGE\_VERSION in the configuration file is PLANNING-2-SL.
- f. Make sure the configuration file is pointing to the right data. Open config\_temp\_barriers. Make sure that it is pointing to the right directory, file and DSS path to find the CalSim results. In this case, set:
  - 1) CALSIMNAME to ocap\_2005A01A\_EWA2\_71\_novamp\_DV (CalSim output file without the ".dss" extension)
  - 2) CALSIMSTUDY\_ORIGINAL to 2005A01A

- 3) CALSIMDIR to ../data
- g. Save your data
- h. Launch the preprocessing system. Obtain a command prompt and type:
- > prepro config\_sdip.inp
- i. Repeat the steps above for the temporary barriers directory and the configuration file config\_ocap\_temp\_barriers.inp. You will have to make some changes! Make sure that the dates span the full 1974-1991 period and repeat the checks (d) and (e) for the temporary barrier configuration file.
- j. Set the DSM2MODIFIER to ocap\_temp\_barrier\_tutorial.
- k. Launch the preprocessor with the command:
  - > prepro config\_temp\_barriers.inp

#### 3. Run DSM2:

- a. In Windows Explorer, navigate to the directory, \{DSM2\_home}\tutorial\ocap\_temp\_barrier
- a. Open the launch files hydro.inp and qual.inp.
- b. Set the dates to a shorter period, say 1974-1976, so that the run will take reasonable time for the tutorial. Note that we always preprocess the full period even when we attempt to shorten the run. You can shorten the dates four ways:
  - 1) You can add new SCALAR entries to hydro.inp and qual.inp. Entries in this file always take priority.
  - 2) You can create a file scalar\_short\_run.inp with a SCALAR section that lists the new dates. To override the default SCALAR file, list the new file last in the PARAMETER section.
  - 3) You can change the configuration file. This requires vigilance to remember you did it, but you only make one change.
  - 4) You can add another configuration file that redefines RUN\_START\_DATE and the other run time ENVVAR definitions. List the new configuration file below the original configuration file in hydro.inp and qual.inp.
- c. Run the sdip simulation, for hydro and qual by typing:
- > hydro hydro.inp

- > qual qual.inp
- d. Follow these steps (a-c) and run the temporary barrier simulation, for hydro and qual.

## 4. Examine the output:

e. The temporary barriers and permanent barriers protect water levels in the South Delta in very different ways. Compare the output at ROLD059, Old River at Tracy Blvd for your two runs to see the differences.