#### Lab 01



## Today's Goal


- Guide you to write your first 8051 assembly program
  - and perhaps your first assembly program
- Your work: write a program to compute

$$S = \sum_{i=0}^{N-1} A[i] * B[i]$$

• where A[i], B[i] are integer arrays (8-bit) in 8051's internal memory


### Overview: the C8051F040 SoC


 a system-on-a-chip integrating the processor core, memory, peripheral devices, everything in a computer syste,





# Fundamental: von Neumann model in assembly level

$$D = A+B*C;$$
  
 $E = D+F;$   
 $A = A-1;$ 























- follow the von Neumann model
  - step by step
  - one *instruction* per step
- but decompose operations into primitive and regular ones


```
assembly program
load R1, A;
                 //R1 = mem[A]:
load R2, B;
                 //R2 = mem[B];
load R3, C;
                 //R3 = mem[C]:
mult R4, R2, R3;
                 //R4=R2*R3;
add R5, R1, R4;
                  //R5=R1+R4;
store D, R5;
                  //mem[D] = R5;
load R6, F;
                 //R6 = mem[D];
add R7, R5, R6;
                 //R7 = R5 + R6;
store E, R7;
                 //mem[E] = R7;
sub R1, R1, 1;
                 //R1 = R1-1;
store A, R1;
                 //mem[A] = R1;
```

## Question

• Q: what's the major difference between assembly programming and high-level language programming?


A: you have to imagine how hardware works!

- from hardware design perspective
- the data path:




registers to store variables

registers




function units to perform computation


function units



```
A = B+C;
```


```
load R1, B; //R1 = mem[B];
load R2, C; //R2 = mem[C];
add R3, R1, R2; //R3 = R1+R2;
store A, R3; //mem[A] = R3;
```






```
A = B+C;
```

```
load R1, B; //R1 = mem[B];
load R2, C; //R2 = mem[C];
add R3, R1, R2; //R3 = R1+R2;
store A, R3; //mem[A] = R3;
```




```
A = B+C;
```


```
load R1, B; //R1 = mem[B];
load R2, C; //R2 = mem[C];
add R3, R1, R2; //R3 = R1+R2;
store A, R3; //mem[A] = R3;
```



```
A = B+C;
```


```
load R1, B; //R1 = mem[B];
load R2, C; //R2 = mem[C];
add R3, R1, R2; //R3 = R1+R2;
store A, R3; //mem[A] = R3;
```






```
A = B+C;
```


```
load R1, B; //R1 = mem[B];
load R2, C; //R2 = mem[C];
add R3, R1, R2; //R3 = R1+R2;
store A, R3; //mem[A] = R3;
```




## 8051 Architecture Model


Imagine how data flow in the architecture!






• flow of an arithmetic instruction







- datamovementbetweenmemory andregisters
- the MOV instruction





the MOV also for registers






- Feature: most of instructions have limited use on registers
- Example:
  - ADD uses ACC
  - MUL (multiply) uses A and B





## Special Function Registers (SFR)



# A first look on 8051 assembly program

# Features of 8051 CPU and assembly

8-bit data operation

- two-operand assembly instruction
  - Example: ADD A, R1 //A=A+R1

#### Classification of instructions

- Arithmetic (ADD, SUBB, MUL, etc.)
  - Notice: the use of register
  - e.g. ADD A, R0
  - e.g. MUL AB
- Branch (AJMP, ACALL, RET)
  - Notice: the jump range
- Data Transfer (MOV)
  - direct/indirect addressing mode
- Logical
  - bit-addressible instruction

```
[label:] mnemonic [operands] [;comment]
```

```
ORG 0H
                         ;start (origin) at location 0
                         ;load 25H into R5
       MOV R5,#25H
       MOV R7,#34H
                         :load 34H into R7
       MOV A,#0
                           ;load 0 into A
                           ;add contents of R5 to A
       ADD A.R5
                           now A = A + R5
       ADD A,R7
                            add contents of R7 to A
                            ;now A = A + R7
       ADD A,#12H
                            ;add to A value 12H
                            now A = A + 12H
```

HERE: SJMP HERE ;stay in this loop ;end of asm source file

general form

```
[label:] mnemonic [operands] [;comment]
```

```
;start (origin) at location 0
ORG 0H
                         ;load 25H into R5
        MOV R5,#25H
       MOV R7,#34H
                         :load 34H into R7
       MOV A,#0
                            ;load 0 into A
                            ;add contents of R5 to A
        ADD A.R5
                            now A = A + R5
        ADD A,R7
                            add contents of R7 to A
                            ;now A = A + R7
        ADD A,#12H
                            ;add to A value 12H
                            now A = A + 12H
HERE: SJMP HERE
                        ;stay in this loop
                            ;end of asm source file
        END
```

```
[label:]
        mnemonic [operands] [;comment]
ORG 0H
                          ;start (origin) at location 0
        MOV R5.#25H
                         ;load 25H into R5
        MOV R7,#34H
                         :load 34H into R7
                            ·load 0 into A
        MOV A,#U
        ADD A.R5
                                    ents of R5 to A
                           R7 = 0x34
                                     A + R5
                            add contents of R7 to A
        ADD A,R7
                            ;now A = A + R7
        ADD A,#12H
                            ;add to A value 12H
                            now A = A + 12H
HERE: SJMP HERE
                        stay in this loop
                            ;end of asm source file
        END
```

```
[label:]
        mnemonic [operands] [;comment]
ORG 0H
                           ;start (origin) at location 0
                          ;load 25H into R5
        MOV R5,#25H
        MOV R7,#34H
                          :load 34H into R7
        MOV A #0
                             ;load 0 into A
        ADD A.R5
                             ;add contents of R5 to A
                              \cdot now \Delta - \Delta \perp R5
        ADD A,R7
                                 ACC=ACC+R5
                                                 ) A
        ADD A,#12H
                             ;add to A value 12H
                             now A = A + 12H
HERE: SJMP HERE
                         stay in this loop
        END
                             end of asm source file
```

```
[label:] mnemonic [operands] [;comment]
```

```
ORG 0H

MOV R5,#25H

MOV R7,#34H

MOV A,#0

ADD A,R5
```

ADD A,R7

ADD A,#12H

HERE: SJMP HERE

END

```
;start (origin) at location 0
```

;load 25H into R5 ;load 34H into R7 ;load 0 into A

;add contents of R5 to A

;now A = A + R5

;add contents of R7 to A

;now A = A + R7

;add to A value 12H

;now A = A + 12H

stay in this loop

;end of asm source file

goto HERE

## Example 1: d=a\*b+c

#### In-Class Exercise

- write the program d=a\*b+c
  - where a, b, c are originally in the memory
- 8051 instructions you need:
  - add
  - mul (multiplication)
  - inc (increment)
  - mov (move)
- Check the instruction reference manual for restrictions on using register operands!

## Example: d=a\*b+c

mov

R1, #30h

; R1=30

mov

A, @R1

; A=mem[R1]

inc

**R**1

; R1++

mov

B, @R1

; B=mem[R1]

inc

R1

; R1++

mov

R0, @R1

; R0=mem[R1]=C

mul

AB

 $; \{A,B\} = A*B$ 

add


A, R0


A=A+R0

wait:

sjmp

wait





mov mov R1, #30h

; R1=30

inc

A, @R1

; A=mem[R1]

ınc

R1

; R1++

mov

B, @R1

; B=mem[R1]

inc

R1

; R1++

mov

R0, @R1

; R0=mem[R1]=C

mul

AB

 $\{A,B\} = A*B$ 


add


A, R0

; A=A+R0

wait:

sjmp






mov R1, #30h ; R1=30 mov A, @R1 ; A=mem[R1] inc R1 ; R1++ mov B, @R1 ; B=mem[R1] inc R1 ; R1++

 $mov \hspace{1cm} R0, \ @R1 \hspace{0.5cm} ; \ R0 = mem[R1] = C$ 

mul AB  $;\{A,B\} = A*B$  add A, R0 ;A=A+R0

wait:




mov R1, #30h ; R1=30 mov A, @R1 ; A=mem[R1] inc R1 ; R1++ mov B, @R1 ; B=mem[R1] inc R1 ; R1++

mov R0, @R1 ; R0=mem[R1]=C

mul AB  $;{A,B} = A*B$  add A, R0 ;A=A+R0

wait:



mov

R1, #30h

; R1=30

mov

A, @R1

; A=mem[R1]

inc

R1

; R1++

mov

B, @R1

; B=mem[R1]

inc

**R**1

; R1++

mov

R0, @R1

; R0=mem[R1]=C

mul

AB

 $; \{A,B\} = A*B$ 


add


A, R0

; A=A+R0

wait:

sjmp





mov mov R1, #30h

; R1=30

mov

A, @R1

; A=mem[R1]

inc

R1

; R1++

mov

B, @R1

; B=mem[R1]

inc

R1

; R1++

mov

R0, @R1

; R0=mem[R1]=C

mul

AB

 $\{A,B\} = A*B$ 


add


A, R0

; A=A+R0

wait:

sjmp







mov R1, #30h ; R1=30 mov A, @R1 ; A=mem[R1] inc R1 ; R1++ mov B, @R1 ; B=mem[R1] inc R1 ; R1++

mov R0, @R1 ; R0=mem[R1]=C

mul AB  $;\{A,B\} = A*B$  add A, R0 ;A=A+R0

wait:





mov

R1, #30h

; R1=30

mov

A, @R1

B, @R1

; A=mem[R1]

inc

R1

; R1++ ; B=mem[R1]

mov inc

R1

; R1++

mov

R0, @R1

; R0=mem[R1]=C

mul

AB

 $\{A,B\} = A*B$ 


add


A, R0

; A=A+R0

wait:

sjmp





mov

R1, #30h

; R1=30

mov

A, @R1

; A=mem[R1]

inc

R1

; R1++

mov

B, @R1

; B=mem[R1]

inc

R1

; R1++

mov

R0, @R1

; R0=mem[R1]=C

mul

AB

 $\{A,B\} = A*B$ 


add

A, R0

; A=A+R0

wait:

sjmp



mov

R1, #30h ; R1=30

mov

A, @R1

; A=mem[R1]; R1++

inc

R1

; B=mem[R1]

mov inc

R1

; R1++

mov

R0, @R1

B, @R1

; R0=mem[R1]=C

mul

AB

 $\{A,B\} = A*B$ 


add


A, R0

; A=A+R0

wait:

sjmp





mov R1, #30h ; R1=30 mov A, @R1 ; A=mem[R1]

inc R1; R1++


mov B, @R1 ; B=mem[R1]


inc R1; R1++

mov R0, @R1 ; R0=mem[R1]=C

 $\begin{array}{lll} \text{mul} & AB & ; \{A,B\} = A*B \\ \text{add} & A,R0 & ; A=A+R0 \end{array}$ 

wait:






mov R1, #30h ; R1=30 mov A, @R1 ; A=mem[R1] inc R1 ; R1++ mov B, @R1 ; B=mem[R1]


inc R1 ; R1++

mov R0, @R1 ; R0=mem[R1]=C

 $\begin{array}{lll} \text{mul} & AB & ; \{A,B\} = A*B \\ \text{add} & A,R0 & ; A=A+R0 \end{array}$ 

wait:







mov R1, #30h ; R1=30 mov A, @R1 ; A=mem[R1] inc R1 ; R1++ mov B, @R1 ; B=mem[R1] inc R1 ; R1++

mov R0, @R1 ; R0=mem[R1]=C

 $\begin{array}{lll} \text{mul} & AB & ; \{A,B\} = A*B \\ \text{add} & A,R0 & ; A=A+R0 \end{array}$ 

wait:





# Branch (Jump) Instruction

# What is a branch/jump instruction

the "goto" to control program execution path

```
the mul instruction won't be executed add A, RT simp label; coto label_1 mul AB ...
label_1:
add A, R2
```

# Frequently used branch instructions of 8051

LJMP addr16	Long jump	3	4
SJMP rel	Short jump (from –128 to +127 locations relative to the following instruction)	2	3
JC rel	Jump if carry flag is set. Short jump.	2	3
JNC rel	Jump if carry flag is not set. Short jump.	2	3
JB bit,rel	Jump if direct bit is set. Short jump.	3	4
JBC bit,rel	Jump if direct bit is set and clears bit. Short jump.	3	4
JMP @A+DPTR	Jump indirect relative to the DPTR	1	2
JZ rel	Jump if the accumulator is zero. Short jump.	2	3
JNZ rel	Jump if the accumulator is not zero. Short jump.	2	3

for more, check http://www.mikroe.com/en/books/8051book/ch3/

#### Conditional Branch Instructions


- JC: Jump if Carry=1
- JNC: Jump if Carry=0
- JZ: Jump if A=0
- JNZ: Jump if A!=0
- DJNZ Rn, location
  - $\blacksquare$  Rn = Rn-1
  - jump if Rn!=0

# How conditional branch works in 8051?

- an arithmetic instruction sets bits in PSW
- the conditional branch checks bits in PSW to determine whether to jump or not


# How conditional branch works in 8051?

- an arithmetic instruction sets bits in PSW
- the conditional branch checks bits in PSW to determine whether to jump or not



# How conditional branch works in 8051?

- an arithmetic instruction sets bits in PSW
- the conditional branch checks bits in PSW to determine whether to jump or not



# Example of conditional branch instruction

- JC label
  - if (C==1) goto *label*
- JNC label
  - if (C==0) goto *label*

#### In-Class Exercise

write the program:

```
if (R0+R1>0xff)

A = 0xff;

else

A = R0+R1
```

# Example: using JNC

```
if (R0+R1>0xff)
A = 0xff;
else
A = R0+R1
```



```
A = R0;

A = A+R1; //implicitly set C

if (C==0) goto exit;

A = 0xff;

exit:
```



```
mov A, R0
add A, R1
JNC exit
mov A, #ffh
exit:
```

# Example: a simple for loop

### A useful instruction

- DJNZ Rn, location
  - $\blacksquare$  Rn = Rn-1
  - jump if Rn!=0

### Loop example

```
sum = 0;
for (i=10;i>0;i--)
sum = sum+i;
```



A = 0; //A is sum R0 = 10; //R0 is i

loop\_start:

A = A+R0; if (--R0) goto loop\_start; mov A, #0 mov R0, #10

loop\_start:
add A, R0

djnz R0, loop\_start

# Now you should be able to do your work

write a program to compute

$$S = \sum_{i=0}^{N-1} A[i] * B[i]$$

- where A[i], B[i] are integer array (8-bit) in 8051's internal memory
- instructions you may use:
  - ADD (addition)
  - MUL (multiply)
  - MOV (move data)
  - DJNZ (decrement and jump if not zero)
- Check the instruction reference manual!

# How to build an executable program

Recap on the system programming before the practical guide

# The Next Lab: LED lights