



AIX LYON PARIS STRASBOURG

WWW.CLEARSY.COM

# Airlock Safety Controller

Thierry Lecomte R&D Director



PART II



## Door Opening Enabler (safety)

### Modelling embedded system (SW + HW)

- ➤ Supervisor **independent** from functional controller
- System to check if a door can be open, based on sensors
- ► Works all the time

Hackathon

► If disagree or OFF, disables door opening







## Safety Property

- Instead of giving a deterministic specification involving all possible cases (usually is the transcription of an algorithm)
- ► Specify what is really important when a safety issue may arise
- We distinguish
  - Restrictive position: doors are closed → nothing bad could happen
  - $\triangleright$  **Permissive** position: doors are opening  $\rightarrow$  we could have a pressure problem
- Formalizing safety property: when we are moving to a permissive situation, we need to be sure that all conditions are OK






## Safety Property

► For example

```
(door opening=TRUE => pressure check=TRUE &
HW conditions=OK)
```


And a valid (but not very useful) controller implementation could be door opening := FALSE
















## **Hypotheses**


- ► PRESSURE\_A sufficiently different from PRESSURE\_B to injure people in case of "illegal" opening
- ▶ pressure\_a and pressure\_b always return the same value and are ignored (constants)
- contact\_a and contact\_b are "almost perfect" and do not generate "illegal" "closed" signal
- ► We are not sensing people, where they are in the airlock, if they are wearing equipment (suit) compatible with pressure in the other room (could be done with RFID tag on the suit and proper interface)







- Develop a B model of this enabling function [8 pts]
  - > 3 sensors to read (pressure\_I, contact\_a, contact\_b
  - > 2 enabling variables (enable\_door\_a, enable\_door\_b)
  - > safety properties







END

► CTX model

We do not model the exact value of the pressure

- **PRESSURE\_A** means sufficiently close to the pressure in room A to avoid injury
- **PRESSURE OTHER** means sufficiently different from PRESSURE A and B to ensure injuries

```
MACHINE
    CTX
SETS
    PRESSURES = {
        PRESSURE A,
        PRESSURE B,
        PRESSURE OTHER
```







#### ► SENSORS model

Any values in their domain but a door open has an impact on the pressure in the airlock

#### Your turn

```
MACHINE
    SENSORS
SEES
    CTX
CONCRETE VARIABLES
    pressure sensor 1,
    contact sensor a,
    contact sensor b
INVARIANT
    pressure sensor 1 : PRESSURES &
    contact sensor a : BOOL & // TRUE means door closed
    contact sensor b : BOOL // TRUE means door closed
INITIALISATION
OPERATIONS
    update sensors states =
    BEGIN
        pressure sensor 1,
        contact sensor_a,
        contact_sensor_b: (
    END
END
```







► ENABLER model

The safety property of the airlock (what do we want to ensure all the time)

We suppose that if pressure\_I is not PRESSURE\_A than the door A is closed (similarly for B)

The safety property of the control of each enabling variable

```
MACHINE
    ENABLER
SEES
    CTX, SENSORS
CONCRETE VARIABLES
    enable door a,
    enable door b
INVARIANT
    enable door a : BOOL &
    enable door b : BOOL &
INITIALISATION
    enable door a := FALSE ||
    enable door b := FALSE
OPERATIONS
    compute enabling =
    PRE
    THEN
        enable door a,
        enable door_b :(
    END
END
```





- Check the enabling with ProB [2 pts]
  - > run the operation 10 times
  - > Save the probtrace file with the value of oks

```
MACHINE
    test ENABLER
OPERATIONS
    test compute enabling = skip
END
```

```
IMPLEMENTATION test ENABLER i
REFINES test ENABLER
IMPORTS CTX, SENSORS, ENABLER
OPERATIONS
    test compute enabling =
    BEGIN
        update sensors states;
        compute enabling
    END
END
```





- Optional: what happens if we chose the INITIALISATION with both doors open ? [1 pt]
  - ► INITIALISATION(contact sensor a:=FALSE, contact sensor b:=FALSE)
- Optional: in the operation test\_compute\_enabling, what happens if we forgot to update the sensors (we forget to call update sensors states) ? [1 pt]
- Optional: how would you simply ensure a correct (i.e. proved) sequencing of the two operations update sensors states and compute enabling ? [3 pt]



Hackathon



