CNES Large Scale SWOT Simulator

User's Tutorial for Terrestrial Surface Water Applications

Nicholas J. Elmer

NASA Postdoctoral Program, NASA Marshall Space Flight Center NASA Short-term Prediction Research and Transition (SPORT) Center Huntsville, Alabama, USA January 28, 2020

Contents

1.	Introduction	2
2.	Download the CNES Simulator	2
3.	Create the input polygon shapefile(s)	3
	A. You already have a polygon shapefile	3
	B. You have a polyline shapefile of river reaches	8
	C. You have a water mask raster	10
	D. You have a Digital Elevation Map	10
4.	Run the CNES simulator	14
	A. Set up your working directory	14
	B. Set up your .rdf files	14
	C. Create the orbit file	16
	D. Run the simulator	16
Α	ppendix – Creating a time series (Advanced User)	18

1. Introduction

The CNES Large Scale SWOT Hydrology Simulator creates proxy SWOT water surface elevations (WSE). A large portion of the effort required to run the CNES simulator is upfront in creating the simulator input. This tutorial describes the steps to create the simulator input and then run the CNES simulator. Since many applications will utilize a time series of proxy SWOT WSE, a short description of that process is included in the Appendix for advanced users.

2. Download the CNES Simulator

The CNES simulator can be downloaded from Github at https://github.com/CNES/swot-hydrology-toolbox. The README.md file describes the cloning process using the "git clone" command and setting environment variables.

Installation procedure

Get the repository

1. Clone swot_hydrology_toolbox repo

% git clone https://github.com/cnes/swot-hydrology-toolbox.git

The repository swot_hydrology_toolbox should be assignated to the SWOT_HYDROLOGY_TOOLBOX variable.


% export SWOT_HYDROLOGY_TOOLBOX=your_installation_path/swot-hydrology-toolbox

3. Create the input polygon shapefile(s)

Once the CNES Simulator is set up, you need to create the required polygon shapefile input, one shapefile per observation time. The CNES simulator uses the polygon extent to calculate river width, whereas a height (HEIGHT) attribute specifies the initial WSE and a river flag (RIV_FLAG) designates polygons as river segments. There are many ways to create a polygon shapefile, and the ideal process will vary depending on your application. However, four methods are demonstrated below based on different starting points. Although the steps are based on ArcGIS, QGIS or even Python (for experienced users) can be used instead.


A. You already have a polygon shapefile

If you already have a polygon shapefile of your river network similar to what is shown below, you simply need to add surface height (HEIGHT) and river flag (RIV_FLAG) attributes for each river segment.




In ArcGIS:


1. Right-click on your reach polygon, then click "Open Attribute Table".




2. Click the "Table Options" dropdown and select "Add Field".




3. Name the field "RIV_FLAG" and specify the type as a short integer. Click "OK".




4. Right-click on the RIV_FLAG header and select "Field Calculator".




5. If you receive this message, click "Yes".




6. Set RIV_FLAG to "1" for all river segments. RIV_FLAG should be set to 1 for river segments, but 0 for an lakes or reservoirs along the network. Then click "OK".



7. Now add the HEIGHT attribute. Click the "Table Options" dropdown and select "Add Field".



8. Name the field "HEIGHT" and specify the type as "Double". Click "OK".




9. Populate the HEIGHT field. Height values can be manually assigned from observations (in situ or satellite), programmatically from model output, or a best estimate using the Field Calculator. For complex height assignments, you can use a simple Python script using the Pyshp module (https://pypi.org/project/pyshp/). If you are an advanced user and wish to process a time series using the CNES simulator, refer to the Appendix. The final result is shown below (Note that only the HEIGHT and RIV_FLAG fields are required).

FI	D Shape 0 Polygor 1 Polygor 2 Polygor 3 Polygor 4 Polygor 5 Polygor 6 Polygor	2349 2462 2505 2569 2735	5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	2320 2496 2601 2642 2703	2496 2601 2642 2703	62.5 62.5 62.5 62.5 62.5	midlat 63.309616 63.289706 63.273131	midlon -147.348604 -147.406328 -147.42358	62.5 62.5	ORIG_FID 0	773.1807 768.3092	125 125	2350 2463	RIV_FLAG
	1 Polygor 2 Polygor 3 Polygor 4 Polygor 5 Polygor	2462 2505 2569 2735	5 5 5	2496 2601 2642	2601 2642 2703	62.5 62.5	63.289706	-147.406328	62.5	1				-
	2 Polygor 3 Polygor 4 Polygor 5 Polygor	2505 2569 2735	5 5 5	2601 2642	2642 2703	62.5				1	700.3092	125	2403	
	3 Polygor 4 Polygor 5 Polygor	2569 2735	5	2642	2703		03.2/3131			2	765.8078	125	2506	
	4 Polygor 5 Polygor	2735	_				63.267518	-147.42330	62.5 62.5	3	764.2208	125	2570	
	5 Polygo		_	2/03		62.5	63.250622	-147.448351	62.5	3	761.9642	125	2736	
F		2/94		2884	2884 2937		63.226147			5	759.4504	125	2795	
╢	6 Polygo	2020				62.5		-147.467224	62.5	_				
	7 0-1		5	2937	2986	62.5	63.215489	-147.479786	62.5	6	758.5098	125	2839	
1-	7 Polygo		5	2986	3180	62.5	63.195512	-147.495404	62.5	7	756.9344	125	3027	
₩.	8 Polygo		5	3180	3190	62.5	63.174808	-147.505726	62.5	8	754.9109	125	3034	
┞	9 Polygo		5	3190	3375	62.5	63.159357	-147.51017	62.5	9	751.8478	125	3217	
	10 Polygo		5	3375	3528	62.5	63.127082	-147.511037	62.5	10	746.8743	125	3363	
	11 Polygo		5	3528	3534	62.5	63.115571	-147.52043	62.5	11	745.04	125	3370	
	12 Polygo		5	3534	3631	62.5	63.105082	-147.519335	62.5	12	744.1782	125	3467	
	13 Polygo		5	3631	3845	62.5	63.078689	-147.52362	62.5	13	742.43	125	3670	
	14 Polygo		5	3743	3870	62.5	63.035575	-149.615256	62.5	14	440.4758	125	3694	
	15 Polygo		5	3845	3961	62.5	63.048005	-147.528084	62.5	15	738.5846	125	3779	1
	16 Polygo	3783	5	3870	3966	62.5	63.018162	-149.633335	62.5	16	410.6104	125	3784	1
	17 Polygo	3905	5	3966	4091	62.5	63.004926	-149.640056	62.5	17	394.3589	125	3906	1
	18 Polygo	3927	5	4091	4109	62.5	62.992155	-149.658476	62.5	18	393.9034	125	3928	
	19 Polygo	3951	5	3961	4134	62.5	63.027077	-147.437126	62.5	19	733.2291	125	3952	
•		1 → н		out of 368 Selec	-t()									
•	•	, , ,		out or 508 Selec	cted)									


In some cases, the entire river network of interest may be described by a single polygon. Since only one height value can be assigned per polygon, you will need to split the polygon into smaller pieces using the ArcGIS or QGIS editing and cutting tools (https://desktop.arcgis.com/en/arcmap/latest/extensions/3d-analyst/using-the-cut-polygons-tool.htm) if you wish to assign different height values to different areas of your river network. Once you have created the polygon shapefile with required attributes, move to Section 4 to run the CNES simulator.

B. You have a polyline shapefile of river reaches

If you have a polyline shapefile of river reaches, you can easily convert to a polygon shapefile using the ArcGIS Buffer tool.




Distance can be specified using either a width field (if your polyline includes this attribute) or simply a constant linear value (e.g., 50 meters). Note that the distance is one-sided, meaning that to set a value of 50 meters results in a polygon width of 100 meters. A comparison between the polygon river reaches (black outline) and polyline river reaches (blue lines) is shown below. Once you have created the polygon shapefile, continue with the steps in Section 3A.




C. You have a water mask raster

If you have a raster with a water mask, you can create a polygon shapefile using the ArcGIS Raster to Polygon tool. Once you create the polygon shapefile, continue with the steps in Section 3A.




D. You have a Digital Elevation Map




Example DEM from which a polygon shapefile of the river network can be derived.

If you have a Digital Elevation Map (DEM) similar to the figure above, you can derive the polygon shapefile using the ArcGIS Spatial Analysis Hydrology Toolbox. Using your DEM raster (named "topography" in this example), run the following tools in ArcGIS (similar tools are available in QGIS):


1. Fill. Hydrologically conditions your DEM to remove sinks.




2. Flow Direction. Calculates the direction of flow based on elevation.




3. Flow Accumulation.



4. Raster Calculator. Extract the channel network using the command "Con(flowacc >= Threshold, 1)" where flowacc is your flow accumulation raster and Threshold is an integer (e.g., 1000). A smaller Threshold value yields a more complex channel network. The result is a raster where channel points are indicated by 1, with all other areas NoData.



5. Stream to feature. Yields a polyline shapefile.



6. Once these steps are completed, continue with the steps in Section 3B.

4. Run the CNES simulator

A. Set up your working directory

With "SWOT_HYDROLOGY_TOOLBOX" set in Section 2 as your environment variable, on the command line issue the following commands (Do not include ">>". This merely indicates a new command line):

```
>> cd $SWOT_HYDROLOGY_TOOLBOX/test/
>>mkdir testcase
>>cd testcase
>>mkdir data output rdf
>>cd output
>>mkdir orbit simu
>>cd ../rdf
>>cp ../../river_and_lake/rdf/*.rdf ./
>>cd $SWOT_HYDROLOGY_TOOLBOX/test/testcase
```

Move/save your input polygon shapefile(s) created in Section 3 to \$\$SWOT_HYDROLOGY_TOOLBOX/test/testcase/data/. \$\$SWOT_HYDROLOGY_TOOLBOX/test/testcase is your working directory, where testcase can be interchanged with a name describing your study area (e.g., Amazon, Mississippi, Scandinavia, etc.)

B. Set up your .rdf files

Navigate to your rdf directory:

>>cd \$SWOT HYDROLOGY TOOLBOX/test/testcase/rdf/

1. Open parameter_orbit.rdf in your favorite Linux text editor (e.g., vi, gedit, nano, etc.). This file sets parameters describing the SWOT orbit which will be used to determine the observation times for your study area. Specify your mission start time (used to determine SWOT overpass times), your study area bounding box (determined by your river network extent), and simulation start and end times. You may modify the other parameters as needed, although the defaults will likely work for most applications. Save and exit.

```
1 !== Mission specific parameters ==
 2 Mission name = SWOT
 3 Mission start time = 2015-02-01
6 !== Orbit parameters ==
8 !Directory of theoretical orbit files
9 Orbit repository = $SWOT HYDROLOGY TOOLBOX/select orbit cnes/
  swot science orbit june 2015
10
11 !Studied area bounding box
12 DEM south latitude (deg) = 62.8
13 DEM north latitude (deg) = 65.5
14 DEM west longitude (deg) = -149.8
15 DEM east longitude (deg) = -142.0
17 !PixC mapping parameters
18 Azimuth spacing (m) = 21.875000
19 Swath width (m) = 120000.000000
20 NR cross track (m) = 10000.000
21
22
23!== Pass plan parameters ==
24 passplan = yes
25 simulation_start_time = 2015-06-01
26 simulation stop time = 2015-07-06
28
29 !== Output parameters ==
30 GDEM Orbit prefix = test.gdem_orbit
```

- 2. Open parameter_sisimp.rdf in your favorite text editor. Specify the polygon shapefile path as \$SWOT_HYDROLOGY_TOOLBOX/test/testcase/data/ and the output directory as \$SWOT_HYDROLOGY_TOOLBOX/test/testcase/output/simu/.
- 3. Specify the orbit parameters. The easiest option is shown below, with "Multiple orbit = no". The Orbit" and "Cycle number" correspond to an entry in the orbit passplan file (\$SWOT_HYDROLOGY_TOOLBOX/test/testcase/output/orbit/passplan.txt) created in Section 4C. If you want to process multiple shapefiles at once, see the Appendix for instructions.

```
11 !### orbit parameters
12 !3 options =
13 !Multiple orbit = yes (default) => all orbit files in orbit directory will be processed
14 !Multiple orbit = no => set the Orbit to a correct number found in the Orbit directory; only this orbit file will be processed
15 !Multiple orbit = passplan => orbit files will be processed according to passplan.txt file (generated if passplan = yes in select_orbit.rdf)
16 Multiple orbit = no
17 Orbit = 14
18 Cycle number = 1
```

4. Specify the height parameters. This tutorial describes the steps for using height model option 2. Ensure the "Height model" and "Height shp attribute name" parameters are not commented out and that the parameters for options 1 and 3 are commented out with a "!". Make sure the height attribute field in your polygon shapefile matches the "Height shp attribute name" parameter.

```
57 !== Height ==
58
59 !### Option 1 - Constant height model, uniform over each water body; height
 varies sinusoidally with time
60 | Specific option: [Height model A = 0.] [ [|Height model] => no height applied,
 height in output onlyt contains errors
61!### Constant height model parameters (same height for each water body)
62 !Constant height model A = 0. !=0 to disable
63 !Constant height model t0 = 47076
64 !Constant height model period (days) = 365.25
65 ! ### Complex 2D height model parameters (2D variations added for lakes > [Height
  model min areal)
66 !Height model = polynomial !=polynomial or gaussian; if disabled, only
 constant height model
67 !Height 2d model min area = 100.
                                   !(ha) min area of water bodies on which to
 add complex 2D height model (default=100.)
68 !Height 2d model stdv = 1. | !stdv for gaussian model (ie Height model =
  gaussian)
69
70 !### Option 2 - Height is given from a specific attribute in the shapefile of
 water bodies
71 Height model = reference height
```

5. You may modify the other parameters in the parameter_sisimp.rdf as needed (e.g., error parameters), although the defaults will likely work for most applications. Save and exit.

C. Create the orbit file

Create the orbit file from your working directory with the command:

```
>> cd $SWOT_HYDROLOGY_TOOLBOX/test/testcase
>>python $SWOT_HYDROLOGY_TOOLBOX/select_orbit_cnes/select_orbit_cnes.py r
df/parameter_orbit.rdf_output/orbit
```

A passplan.txt file (along with several other files) will be created in your \$\$SWOT_HYDROLOGY_TOOLBOX/test/testcase/output/orbit/ directory. Update your parameter sisimp.rdf orbit parameters to match the passplan.txt orbit and cycle of interest.

D. Run the simulator

Now you are ready to run the simulator to create proxy SWOT WSE. Start the simulator from your working directory using the command:

>> cd \$SWOT HYDROLOGY TOOLBOX/test/testcase

>>python \$SWOT_HYDROLOGY_TOOLBOX/sisimp/proc_sisimp.py rdf/parameter_sisimp.rdf

Output, including pixel cloud shapefiles, will be created in the \$SWOT_HYDROLOGY_TOOLBOX/test/testcase/output/simu/ directory. Further post-processing can be done using the parameter_river.rdf and the RiverObs simulator (https://github.com/SWOTAlgorithms/RiverObs) as needed.

Appendix – Creating a time series (Advanced User)

A time series of input polygon shapefiles can be created from model output, but observations and best estimates may also be used. First, create the orbit file (Section 4C) to obtain observations times from the passplan.txt file

(\$SWOT_HYDROLOGY_TOOLBOX/test/testcase/output/orbit/passplan.txt). For each observation time in the passplan.txt file, create a separate polygon shapefile with the appropriate HEIGHT values. This can be done manually or using the Field Calculator in ArcGIS, or if you would like to do this programmatically using Python see the Pyshp manual (https://pypi.org/project/pyshp/) for more information.

Once a time series of input polygon shapefiles is created (one shapefile per time), a simple python wrapper (https://github.com/njelmer/swot-hydrology-toolbox/blob/master/scripts/process multiple shp CNES.py) is available to process the full time series through the CNES simulator quickly and efficiently.