The uIP Embedded TCP/IP Stack

The uIP 1.0 Reference Manual

June 2006



Adam Dunkels adam@sics.se

Swedish Institute of Computer Science

Contents

1	The	uIP TCP/IP stack	1
	1.1	Introduction	1
	1.2	TCP/IP Communication	2
	1.3	Main Control Loop	2
	1.4	Architecture Specific Functions	3
	1.5	Memory Management	3
	1.6	Application Program Interface (API)	4
	1.7	Examples	7
	1.8	Protocol Implementations	14
	1.9	Performance	16
2	uIP	1.0 Module Index	19
	2.1	uIP 1.0 Modules	19
3	uIP	1.0 Hierarchical Index	21
	3.1	uIP 1.0 Class Hierarchy	21
4	uIP	1.0 Data Structure Index	23
	4.1	uIP 1.0 Data Structures	23
5	uIP	1.0 File Index	25
	5.1	uIP 1.0 File List	25
6	uIP	1.0 Module Documentation	27
	6.1	Protothreads	27
	6.2	Applications	36
	6.3	uIP configuration functions	37
	6.4	uIP initialization functions	40
	6.5	uIP device driver functions	41
	6.6	uIP application functions	46

ii CONTENTS

	6.7	uIP conversion functions	55
	6.8	Variables used in uIP device drivers	61
	6.9	The uIP TCP/IP stack	62
	6.10	Architecture specific uIP functions	74
	6.11	uIP Address Resolution Protocol	76
	6.12	Configuration options for uIP	79
	6.13	uIP TCP throughput booster hack	89
	6.14	Local continuations	90
	6.15	Timer library	91
	6.16	Clock interface	94
	6.17	Protosockets library	95
	6.18	Memory block management functions	102
	6.19	DNS resolver	105
	6.20	SMTP E-mail sender	108
	6.21	Telnet server	110
	6.22	Hello, world	113
	6.23	Web client	114
	6.24	Web server	120
7	uIP :	1.0 Data Structure Documentation	123
7	uIP 3	1.0 Data Structure Documentation dhcpc_state Struct Reference	
7			123
7	7.1	dhcpc_state Struct Reference	123 124
7	7.1 7.2	dhcpc_state Struct Reference	123 124 125
7	7.17.27.3	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference	123 124 125 126
7	7.17.27.37.4	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference	123 124 125 126 127
7	7.1 7.2 7.3 7.4 7.5	dhcpc_state Struct Reference	123 124 125 126 127 128
7	7.1 7.2 7.3 7.4 7.5 7.6	dhcpc_state Struct Reference	123 124 125 126 127 128 129
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference	123 124 125 126 127 128 129 130
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9	dhcpc_state Struct Reference	123 124 125 126 127 128 129 130
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9 7.10	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference pt Struct Reference smtp_state Struct Reference	123 124 125 126 127 128 129 130 131
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9 7.10 7.11	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference pt Struct Reference smtp_state Struct Reference telnetd_state Struct Reference	123 124 125 126 127 128 129 130 131 132
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9 7.10 7.11 7.12	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference pt Struct Reference smtp_state Struct Reference telnetd_state Struct Reference timer Struct Reference	123 124 125 126 127 128 129 130 131 132 133
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9 7.10 7.11 7.12 7.13	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference psock_buf Struct Reference tstruct Reference smtp_state Struct Reference telnetd_state Struct Reference timer Struct Reference uip_conn Struct Reference	123 124 125 126 127 128 129 130 131 132 133 134
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9 7.10 7.11 7.12 7.13 7.14	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference pt Struct Reference smtp_state Struct Reference telnetd_state Struct Reference timer Struct Reference uip_conn Struct Reference uip_eth_addr Struct Reference	123 124 125 126 127 128 129 130 131 132 133 134 136
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9 7.10 7.11 7.12 7.13 7.14 7.15	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference pt Struct Reference smtp_state Struct Reference telnetd_state Struct Reference timer Struct Reference uip_conn Struct Reference uip_eth_addr Struct Reference uip_eth_hdr Struct Reference	123 124 125 126 127 128 129 130 131 132 133 134 136 137
7	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.8 7.9 7.10 7.11 7.12 7.13 7.14 7.15 7.16	dhcpc_state Struct Reference hello_world_state Struct Reference httpd_cgi_call Struct Reference httpd_state Struct Reference httpd_state Struct Reference memb_blocks Struct Reference psock Struct Reference psock_buf Struct Reference pt Struct Reference smtp_state Struct Reference telnetd_state Struct Reference timer Struct Reference uip_conn Struct Reference uip_eth_addr Struct Reference uip_eth_hdr Struct Reference uip_icmpip_hdr Struct Reference	123 124 125 126 127 128 129 130 131 132 133 134 136 137 138

CONTENTS

	7.18	uip_tcpip_hdr Struct Reference	142
	7.19	uip_udp_conn Struct Reference	143
	7.20	uip_udpip_hdr Struct Reference	144
	7.21	webclient_state Struct Reference	145
8	uIP 1	.0 File Documentation	147
	8.1	apps/hello-world/hello-world.c File Reference	147
	8.2	apps/hello-world/hello-world.h File Reference	148
	8.3	apps/resolv/resolv.c File Reference	149
	8.4	apps/resolv/resolv.h File Reference	151
	8.5	apps/smtp/smtp.c File Reference	153
	8.6	apps/smtp.h File Reference	154
	8.7	apps/telnetd/shell.c File Reference	156
	8.8	apps/telnetd/shell.h File Reference	157
	8.9	apps/telnetd/telnetd.c File Reference	158
	8.10	apps/telnetd/telnetd.h File Reference	159
	8.11	apps/webclient/webclient.c File Reference	160
	8.12	apps/webclient/webclient.h File Reference	162
	8.13	apps/webserver/httpd-cgi.c File Reference	164
	8.14	apps/webserver/httpd-cgi.h File Reference	165
	8.15	apps/webserver/httpd.c File Reference	166
	8.16	lib/memb.c File Reference	167
	8.17	lib/memb.h File Reference	168
	8.18	uip/lc-addrlabels.h File Reference	169
	8.19	uip/lc-switch.h File Reference	170
	8.20	uip/lc.h File Reference	171
	8.21	uip/psock.h File Reference	172
	8.22	uip/pt.h File Reference	174
	8.23	uip/timer.c File Reference	176
	8.24	uip/timer.h File Reference	177
	8.25	uip/uip-neighbor.c File Reference	178
	8.26	uip/uip-neighbor.h File Reference	179
	8.27	uip/uip-split.h File Reference	180
	8.28	uip/uip.c File Reference	181
		uip/uip.h File Reference	184
	8.30	uip/uip_arch.h File Reference	190
	8.31	uip/uip_arp.c File Reference	191

	8.32	uip/uip_arp.h File Reference	192
	8.33	uip/uipopt.h File Reference	193
	8.34	unix/uip-conf.h File Reference	196
9	uIP :	1.0 Example Documentation	197
	9.1	dhepe.c	197
	9.2	$dhepe.h \ \ldots \ldots$	203
	9.3	example-mainloop-with-arp.c	205
	9.4	example-mainloop-without-arp.c	207
	9.5	hello-world.c	208
	9.6	hello-world.h	210
	9.7	resolv.c	211
	9.8	resolv.h	218
	9.9	smtp.c	220
	9.10	smtp.h	224
	9.11	telnetd.c	226
	9.12	$telnetd.h \ \dots $	232
	9.13	uip-code-style.c	234
	9.14	uip-conf.h	236
	9.15	webclient.c	239
	9.16	webclient.h	246

The uIP TCP/IP stack

Author:

Adam Dunkels, http://www.sics.se/~adam/

The uIP TCP/IP stack is intended to make it possible to communicate using the TCP/IP protocol suite even on small 8-bit micro-controllers. Despite being small and simple, uIP do not require their peers to have complex, full-size stacks, but can communicate with peers running a similarly light-weight stack. The code size is on the order of a few kilobytes and RAM usage can be configured to be as low as a few hundred bytes.

uIP can be found at the uIP web page: http://www.sics.se/~adam/uip/

See also:

Application programs
Compile-time configuration options
Run-time configuration functions
Initialization functions
Device driver interface and variables used by device drivers
uIP functions called from application programs (see below) and the protosockets API and their underlying protothreads

1.1 Introduction

With the success of the Internet, the TCP/IP protocol suite has become a global standard for communication. TCP/IP is the underlying protocol used for web page transfers, e-mail transmissions, file transfers, and peer-to-peer networking over the Internet. For embedded systems, being able to run native TCP/IP makes it possible to connect the system directly to an intranet or even the global Internet. Embedded devices with full TCP/IP support will be first-class network citizens, thus being able to fully communicate with other hosts in the network.

Traditional TCP/IP implementations have required far too much resources both in terms of code size and memory usage to be useful in small 8 or 16-bit systems. Code size of a few hundred kilobytes and RAM requirements of several hundreds of kilobytes have made it impossible to fit the full TCP/IP stack into systems with a few tens of kilobytes of RAM and room for less than 100 kilobytes of code.

The uIP implementation is designed to have only the absolute minimal set of features needed for a full TCP/IP stack. It can only handle a single network interface and contains the IP, ICMP, UDP and TCP protocols. uIP is written in the C programming language.

Many other TCP/IP implementations for small systems assume that the embedded device always will communicate with a full-scale TCP/IP implementation running on a workstation-class machine. Under this assumption, it is possible to remove certain TCP/IP mechanisms that are very rarely used in such situations. Many of those mechanisms are essential, however, if the embedded device is to communicate with another equally limited device, e.g., when running distributed peer-to-peer services and protocols. uIP is designed to be RFC compliant in order to let the embedded devices to act as first-class network citizens. The uIP TCP/IP implementation that is not tailored for any specific application.

1.2 TCP/IP Communication

The full TCP/IP suite consists of numerous protocols, ranging from low level protocols such as ARP which translates IP addresses to MAC addresses, to application level protocols such as SMTP that is used to transfer e-mail. The uIP is mostly concerned with the TCP and IP protocols and upper layer protocols will be referred to as "the application". Lower layer protocols are often implemented in hardware or firmware and will be referred to as "the network device" that are controlled by the network device driver.

TCP provides a reliable byte stream to the upper layer protocols. It breaks the byte stream into appropriately sized segments and each segment is sent in its own IP packet. The IP packets are sent out on the network by the network device driver. If the destination is not on the physically connected network, the IP packet is forwarded onto another network by a router that is situated between the two networks. If the maximum packet size of the other network is smaller than the size of the IP packet, the packet is fragmented into smaller packets by the router. If possible, the size of the TCP segments are chosen so that fragmentation is minimized. The final recipient of the packet will have to reassemble any fragmented IP packets before they can be passed to higher layers.

The formal requirements for the protocols in the TCP/IP stack is specified in a number of RFC documents published by the Internet Engineering Task Force, IETF. Each of the protocols in the stack is defined in one more RFC documents and RFC1122 collects all requirements and updates the previous RFCs.

The RFC1122 requirements can be divided into two categories; those that deal with the host to host communication and those that deal with communication between the application and the networking stack. An example of the first kind is "A TCP MUST be able to receive a TCP option in any segment" and an example of the second kind is "There MUST be a mechanism for reporting soft TCP error conditions to the application." A TCP/IP implementation that violates requirements of the first kind may not be able to communicate with other TCP/IP implementations and may even lead to network failures. Violation of the second kind of requirements will only affect the communication within the system and will not affect host-to-host communication.

In uIP, all RFC requirements that affect host-to-host communication are implemented. However, in order to reduce code size, we have removed certain mechanisms in the interface between the application and the stack, such as the soft error reporting mechanism and dynamically configurable type-of-service bits for TCP connections. Since there are only very few applications that make use of those features they can be removed without loss of generality.

1.3 Main Control Loop

The uIP stack can be run either as a task in a multitasking system, or as the main program in a singletasking system. In both cases, the main control loop does two things repeatedly:

- Check if a packet has arrived from the network.
- Check if a periodic timeout has occurred.

If a packet has arrived, the input handler function, uip_input(), should be invoked by the main control loop. The input handler function will never block, but will return at once. When it returns, the stack or the application for which the incoming packet was intended may have produced one or more reply packets which should be sent out. If so, the network device driver should be called to send out these packets.

Periodic timeouts are used to drive TCP mechanisms that depend on timers, such as delayed acknowledgments, retransmissions and round-trip time estimations. When the main control loop infers that the periodic timer should fire, it should invoke the timer handler function uip_periodic(). Because the TCP/IP stack may perform retransmissions when dealing with a timer event, the network device driver should called to send out the packets that may have been produced.

1.4 Architecture Specific Functions

uIP requires a few functions to be implemented specifically for the architecture on which uIP is intended to run. These functions should be hand-tuned for the particular architecture, but generic C implementations are given as part of the uIP distribution.

1.4.1 Checksum Calculation

The TCP and IP protocols implement a checksum that covers the data and header portions of the TCP and IP packets. Since the calculation of this checksum is made over all bytes in every packet being sent and received it is important that the function that calculates the checksum is efficient. Most often, this means that the checksum calculation must be fine-tuned for the particular architecture on which the uIP stack runs.

While uIP includes a generic checksum function, it also leaves it open for an architecture specific implementation of the two functions uip_ipchksum() and uip_tcpchksum(). The checksum calculations in those functions can be written in highly optimized assembler rather than generic C code.

1.4.2 32-bit Arithmetic

The TCP protocol uses 32-bit sequence numbers, and a TCP implementation will have to do a number of 32-bit additions as part of the normal protocol processing. Since 32-bit arithmetic is not natively available on many of the platforms for which uIP is intended, uIP leaves the 32-bit additions to be implemented by the architecture specific module and does not make use of any 32-bit arithmetic in the main code base.

While uIP implements a generic 32-bit addition, there is support for having an architecture specific implementation of the uip_add32() function.

1.5 Memory Management

In the architectures for which uIP is intended, RAM is the most scarce resource. With only a few kilobytes of RAM available for the TCP/IP stack to use, mechanisms used in traditional TCP/IP cannot be directly applied.

The uIP stack does not use explicit dynamic memory allocation. Instead, it uses a single global buffer for holding packets and has a fixed table for holding connection state. The global packet buffer is large enough to contain one packet of maximum size. When a packet arrives from the network, the device driver places it in the global buffer and calls the TCP/IP stack. If the packet contains data, the TCP/IP stack will notify the corresponding application. Because the data in the buffer will be overwritten by the next incoming packet, the application will either have to act immediately on the data or copy the data into a secondary buffer for later processing. The packet buffer will not be overwritten by new packets before the

application has processed the data. Packets that arrive when the application is processing the data must be queued, either by the network device or by the device driver. Most single-chip Ethernet controllers have on-chip buffers that are large enough to contain at least 4 maximum sized Ethernet frames. Devices that are handled by the processor, such as RS-232 ports, can copy incoming bytes to a separate buffer during application processing. If the buffers are full, the incoming packet is dropped. This will cause performance degradation, but only when multiple connections are running in parallel. This is because uIP advertises a very small receiver window, which means that only a single TCP segment will be in the network per connection.

In uIP, the same global packet buffer that is used for incoming packets is also used for the TCP/IP headers of outgoing data. If the application sends dynamic data, it may use the parts of the global packet buffer that are not used for headers as a temporary storage buffer. To send the data, the application passes a pointer to the data as well as the length of the data to the stack. The TCP/IP headers are written into the global buffer and once the headers have been produced, the device driver sends the headers and the application data out on the network. The data is not queued for retransmissions. Instead, the application will have to reproduce the data if a retransmission is necessary.

The total amount of memory usage for uIP depends heavily on the applications of the particular device in which the implementations are to be run. The memory configuration determines both the amount of traffic the system should be able to handle and the maximum amount of simultaneous connections. A device that will be sending large e-mails while at the same time running a web server with highly dynamic web pages and multiple simultaneous clients, will require more RAM than a simple Telnet server. It is possible to run the uIP implementation with as little as 200 bytes of RAM, but such a configuration will provide extremely low throughput and will only allow a small number of simultaneous connections.

1.6 Application Program Interface (API)

The Application Program Interface (API) defines the way the application program interacts with the TCP/IP stack. The most commonly used API for TCP/IP is the BSD socket API which is used in most Unix systems and has heavily influenced the Microsoft Windows WinSock API. Because the socket API uses stop-and-wait semantics, it requires support from an underlying multitasking operating system. Since the overhead of task management, context switching and allocation of stack space for the tasks might be too high in the intended uIP target architectures, the BSD socket interface is not suitable for our purposes.

uIP provides two APIs to programmers: protosockets, a BSD socket-like API without the overhead of full multi-threading, and a "raw" event-based API that is nore low-level than protosockets but uses less memory.

See also:

Protosockets library Protothreads

1.6.1 The uIP raw API

The "raw" uIP API uses an event driven interface where the application is invoked in response to certain events. An application running on top of uIP is implemented as a C function that is called by uIP in response to certain events. uIP calls the application when data is received, when data has been successfully delivered to the other end of the connection, when a new connection has been set up, or when data has to be retransmitted. The application is also periodically polled for new data. The application program provides only one callback function; it is up to the application to deal with mapping different network services to different ports and connections. Because the application is able to act on incoming data and connection requests as soon as the TCP/IP stack receives the packet, low response times can be achieved even in low-end systems.

uIP is different from other TCP/IP stacks in that it requires help from the application when doing retransmissions. Other TCP/IP stacks buffer the transmitted data in memory until the data is known to be successfully delivered to the remote end of the connection. If the data needs to be retransmitted, the stack takes care of the retransmission without notifying the application. With this approach, the data has to be buffered in memory while waiting for an acknowledgment even if the application might be able to quickly regenerate the data if a retransmission has to be made.

In order to reduce memory usage, uIP utilizes the fact that the application may be able to regenerate sent data and lets the application take part in retransmissions. uIP does not keep track of packet contents after they have been sent by the device driver, and uIP requires that the application takes an active part in performing the retransmission. When uIP decides that a segment should be retransmitted, it calls the application with a flag set indicating that a retransmission is required. The application checks the retransmission flag and produces the same data that was previously sent. From the application's standpoint, performing a retransmission is not different from how the data originally was sent. Therefore the application can be written in such a way that the same code is used both for sending data and retransmitting data. Also, it is important to note that even though the actual retransmission operation is carried out by the application, it is the responsibility of the stack to know when the retransmission should be made. Thus the complexity of the application does not necessarily increase because it takes an active part in doing retransmissions.

1.6.1.1 Application Events

The application must be implemented as a C function, UIP_APPCALL(), that uIP calls whenever an event occurs. Each event has a corresponding test function that is used to distinguish between different events. The functions are implemented as C macros that will evaluate to either zero or non-zero. Note that certain events can happen in conjunction with each other (i.e., new data can arrive at the same time as data is acknowledged).

1.6.1.2 The Connection Pointer

When the application is called by uIP, the global variable uip_conn is set to point to the uip_conn structure for the connection that currently is handled, and is called the "current connection". The fields in the uip_conn structure for the current connection can be used, e.g., to distinguish between different services, or to check to which IP address the connection is connected. One typical use would be to inspect the uip_conn>lport (the local TCP port number) to decide which service the connection should provide. For instance, an application might decide to act as an HTTP server if the value of uip_conn->lport is equal to 80 and act as a TELNET server if the value is 23.

1.6.1.3 Receiving Data

If the uIP test function uip_newdata() is non-zero, the remote host of the connection has sent new data. The uip_appdata pointer point to the actual data. The size of the data is obtained through the uIP function uip_datalen(). The data is not buffered by uIP, but will be overwritten after the application function returns, and the application will therefor have to either act directly on the incoming data, or by itself copy the incoming data into a buffer for later processing.

1.6.1.4 Sending Data

When sending data, uIP adjusts the length of the data sent by the application according to the available buffer space and the current TCP window advertised by the receiver. The amount of buffer space is dictated by the memory configuration. It is therefore possible that all data sent from the application does not arrive

at the receiver, and the application may use the uip_mss() function to see how much data that actually will be sent by the stack.

The application sends data by using the uIP function uip_send(). The uip_send() function takes two arguments; a pointer to the data to be sent and the length of the data. If the application needs RAM space for producing the actual data that should be sent, the packet buffer (pointed to by the uip_appdata pointer) can be used for this purpose.

The application can send only one chunk of data at a time on a connection and it is not possible to call uip_send() more than once per application invocation; only the data from the last call will be sent.

1.6.1.5 Retransmitting Data

Retransmissions are driven by the periodic TCP timer. Every time the periodic timer is invoked, the retransmission timer for each connection is decremented. If the timer reaches zero, a retransmission should be made. As uIP does not keep track of packet contents after they have been sent by the device driver, uIP requires that the application takes an active part in performing the retransmission. When uIP decides that a segment should be retransmitted, the application function is called with the uip_rexmit() flag set, indicating that a retransmission is required.

The application must check the uip_rexmit() flag and produce the same data that was previously sent. From the application's standpoint, performing a retransmission is not different from how the data originally was sent. Therefor, the application can be written in such a way that the same code is used both for sending data and retransmitting data. Also, it is important to note that even though the actual retransmission operation is carried out by the application, it is the responsibility of the stack to know when the retransmission should be made. Thus the complexity of the application does not necessarily increase because it takes an active part in doing retransmissions.

1.6.1.6 Closing Connections

The application closes the current connection by calling the uip_close() during an application call. This will cause the connection to be cleanly closed. In order to indicate a fatal error, the application might want to abort the connection and does so by calling the uip_abort() function.

If the connection has been closed by the remote end, the test function uip_closed() is true. The application may then do any necessary cleanups.

1.6.1.7 Reporting Errors

There are two fatal errors that can happen to a connection, either that the connection was aborted by the remote host, or that the connection retransmitted the last data too many times and has been aborted. uIP reports this by calling the application function. The application can use the two test functions uip_aborted() and uip_timedout() to test for those error conditions.

1.6.1.8 **Polling**

When a connection is idle, uIP polls the application every time the periodic timer fires. The application uses the test function uip_poll() to check if it is being polled by uIP.

The polling event has two purposes. The first is to let the application periodically know that a connection is idle, which allows the application to close connections that have been idle for too long. The other purpose is to let the application send new data that has been produced. The application can only send data when invoked by uIP, and therefore the poll event is the only way to send data on an otherwise idle connection.

1.7 Examples 7

1.6.1.9 Listening Ports

uIP maintains a list of listening TCP ports. A new port is opened for listening with the uip_listen() function. When a connection request arrives on a listening port, uIP creates a new connection and calls the application function. The test function uip_connected() is true if the application was invoked because a new connection was created.

The application can check the lport field in the uip_conn structure to check to which port the new connection was connected.

1.6.1.10 Opening Connections

New connections can be opened from within uIP by the function uip_connect(). This function allocates a new connection and sets a flag in the connection state which will open a TCP connection to the specified IP address and port the next time the connection is polled by uIP. The uip_connect() function returns a pointer to the uip_conn structure for the new connection. If there are no free connection slots, the function returns NULL.

The function uip_ipaddr() may be used to pack an IP address into the two element 16-bit array used by uIP to represent IP addresses.

Two examples of usage are shown below. The first example shows how to open a connection to TCP port 8080 of the remote end of the current connection. If there are not enough TCP connection slots to allow a new connection to be opened, the uip_connect() function returns NULL and the current connection is aborted by uip_abort().

```
void connect_example1_app(void) {
   if(uip_connect(uip_conn->ripaddr, HTONS(8080)) == NULL) {
      uip_abort();
   }
}
```

The second example shows how to open a new connection to a specific IP address. No error checks are made in this example.

```
void connect_example2(void) {
  u16_t ipaddr[2];

  uip_ipaddr(ipaddr, 192,168,0,1);
  uip_connect(ipaddr, HTONS(8080));
}
```

1.7 Examples

This section presents a number of very simple uIP applications. The uIP code distribution contains several more complex applications.

1.7.1 A Very Simple Application

This first example shows a very simple application. The application listens for incoming connections on port 1234. When a connection has been established, the application replies to all data sent to it by saying "ok"

The implementation of this application is shown below. The application is initialized with the function called example1_init() and the uIP callback function is called example1_app(). For this application, the configuration variable UIP_APPCALL should be defined to be example1_app().

```
void example1_init(void) {
   uip_listen(HTONS(1234));
}

void example1_app(void) {
   if(uip_newdata() || uip_rexmit()) {
      uip_send("ok\n", 3);
   }
}
```

The initialization function calls the uIP function uip_listen() to register a listening port. The actual application function example1_app() uses the test functions uip_newdata() and uip_rexmit() to determine why it was called. If the application was called because the remote end has sent it data, it responds with an "ok". If the application function was called because data was lost in the network and has to be retransmitted, it also sends an "ok". Note that this example actually shows a complete uIP application. It is not required for an application to deal with all types of events such as uip_connected() or uip_timedout().

1.7.2 A More Advanced Application

This second example is slightly more advanced than the previous one, and shows how the application state field in the uip_conn structure is used.

This application is similar to the first application in that it listens to a port for incoming connections and responds to data sent to it with a single "ok". The big difference is that this application prints out a welcoming "Welcome!" message when the connection has been established.

This seemingly small change of operation makes a big difference in how the application is implemented. The reason for the increase in complexity is that if data should be lost in the network, the application must know what data to retransmit. If the "Welcome!" message was lost, the application must retransmit the welcome and if one of the "ok" messages is lost, the application must send a new "ok".

The application knows that as long as the "Welcome!" message has not been acknowledged by the remote host, it might have been dropped in the network. But once the remote host has sent an acknowledgment back, the application can be sure that the welcome has been received and knows that any lost data must be an "ok" message. Thus the application can be in either of two states: either in the WELCOME-SENT state where the "Welcome!" has been sent but not acknowledged, or in the WELCOME-ACKED state where the "Welcome!" has been acknowledged.

When a remote host connects to the application, the application sends the "Welcome!" message and sets it's state to WELCOME-SENT. When the welcome message is acknowledged, the application moves to the WELCOME-ACKED state. If the application receives any new data from the remote host, it responds by sending an "ok" back.

If the application is requested to retransmit the last message, it looks at in which state the application is. If the application is in the WELCOME-SENT state, it sends a "Welcome!" message since it knows that the previous welcome message hasn't been acknowledged. If the application is in the WELCOME-ACKED state, it knows that the last message was an "ok" message and sends such a message.

The implementation of this application is seen below. This configuration settings for the application is follows after its implementation.

```
struct example2_state {
   enum {WELCOME_SENT, WELCOME_ACKED} state;
};
```

1.7 Examples 9

```
void example2_init(void) {
  uip_listen(HTONS(2345));
void example2_app(void) {
  struct example2_state *s;
  s = (struct example2_state *)uip_conn->appstate;
  if(uip_connected()) {
     s->state = WELCOME_SENT;
     uip_send("Welcome!\n", 9);
     return;
   if(uip_acked() && s->state == WELCOME_SENT) {
      s->state = WELCOME_ACKED;
  if(uip_newdata()) {
     uip_send("ok\n", 3);
   if(uip_rexmit()) {
     switch(s->state) {
      case WELCOME_SENT:
         uip_send("Welcome!\n", 9);
        break:
      case WELCOME_ACKED:
         uip_send("ok\n", 3);
         break;
  }
}
```

The configuration for the application:

```
#define UIP_APPCALL example2_app
#define UIP_APPSTATE_SIZE sizeof(struct example2_state)
```

1.7.3 Differentiating Between Applications

If the system should run multiple applications, one technique to differentiate between them is to use the TCP port number of either the remote end or the local end of the connection. The example below shows how the two examples above can be combined into one application.

```
void example3_init(void) {
    example1_init();
    example2_init();
}

void example3_app(void) {
    switch(uip_conn->lport) {
    case HTONS(1234):
        example1_app();
        break;
    case HTONS(2345):
        example2_app();
        break;
    }
}
```

1.7.4 Utilizing TCP Flow Control

This example shows a simple application that connects to a host, sends an HTTP request for a file and downloads it to a slow device such a disk drive. This shows how to use the flow control functions of uIP.

```
void example4 init(void) {
  u16_t ipaddr[2];
  uip_ipaddr(ipaddr, 192,168,0,1);
  uip_connect(ipaddr, HTONS(80));
void example4_app(void) {
   if(uip_connected() || uip_rexmit()) {
     uip_send("GET /file HTTP/1.0\r\nServer:192.186.0.1\r\n\r\n",
               48);
   }
   if(uip_newdata()) {
      device_enqueue(uip_appdata, uip_datalen());
      if(device_queue_full()) {
         uip_stop();
   if(uip_poll() && uip_stopped()) {
      if(!device_queue_full()) {
         uip_restart();
   }
}
```

When the connection has been established, an HTTP request is sent to the server. Since this is the only data that is sent, the application knows that if it needs to retransmit any data, it is that request that should be retransmitted. It is therefore possible to combine these two events as is done in the example.

When the application receives new data from the remote host, it sends this data to the device by using the function device_enqueue(). It is important to note that this example assumes that this function copies the data into its own buffers. The data in the uip_appdata buffer will be overwritten by the next incoming packet.

If the device's queue is full, the application stops the data from the remote host by calling the uIP function uip_stop(). The application can then be sure that it will not receive any new data until uip_restart() is called. The application polling event is used to check if the device's queue is no longer full and if so, the data flow is restarted with uip_restart().

1.7.5 A Simple Web Server

This example shows a very simple file server application that listens to two ports and uses the port number to determine which file to send. If the files are properly formatted, this simple application can be used as a web server with static pages. The implementation follows.

```
struct example5_state {
   char *dataptr;
   unsigned int dataleft;
};

void example5_init(void) {
   uip_listen(HTONS(80));
   uip_listen(HTONS(81));
```

1.7 Examples

```
void example5_app(void) {
  struct example5_state *s;
  s = (struct example5_state)uip_conn->appstate;
   if(uip connected()) {
      switch(uip_conn->lport) {
      case HTONS(80):
         s->dataptr = data_port_80;
         s->dataleft = datalen_port_80;
        break;
      case HTONS(81):
        s->dataptr = data_port_81;
         s->dataleft = datalen_port_81;
         break;
      uip_send(s->dataptr, s->dataleft);
      return;
   if(uip_acked()) {
      if(s->dataleft < uip_mss()) {</pre>
         uip_close();
         return;
      s->dataptr += uip_conn->len;
      s->dataleft -= uip_conn->len;
      uip_send(s->dataptr, s->dataleft);
}
```

The application state consists of a pointer to the data that should be sent and the size of the data that is left to send. When a remote host connects to the application, the local port number is used to determine which file to send. The first chunk of data is sent using uip_send(). uIP makes sure that no more than MSS bytes of data is actually sent, even though s->dataleft may be larger than the MSS.

The application is driven by incoming acknowledgments. When data has been acknowledged, new data can be sent. If there is no more data to send, the connection is closed using uip_close().

1.7.6 Structured Application Program Design

When writing larger programs using uIP it is useful to be able to utilize the uIP API in a structured way. The following example provides a structured design that has showed itself to be useful for writing larger protocol implementations than the previous examples showed here. The program is divided into an uIP event handler function that calls seven application handler functions that process new data, act on acknowledged data, send new data, deal with connection establishment or closure events and handle errors. The functions are called newdata(), acked(), senddata(), connected(), closed(), aborted(), and timedout(), and needs to be written specifically for the protocol that is being implemented.

The uIP event handler function is shown below.

```
void example6_app(void) {
  if(uip_aborted()) {
    aborted();
  }
  if(uip_timedout()) {
    timedout();
  }
  if(uip_closed()) {
    closed();
  }
```

```
if(uip_connected()) {
   connected();
}
if(uip_acked()) {
   acked();
}
if(uip_newdata()) {
   newdata();
}
if(uip_rexmit() ||
   uip_newdata() ||
   uip_acked() ||
   uip_acked() ||
   uip_connected() ||
   uip_poll()) {
   senddata();
}
```

The function starts with dealing with any error conditions that might have happened by checking if uip_aborted() or uip_timedout() are true. If so, the appropriate error function is called. Also, if the connection has been closed() function is called to the it deal with the event.

Next, the function checks if the connection has just been established by checking if uip_connected() is true. The connected() function is called and is supposed to do whatever needs to be done when the connection is established, such as intializing the application state for the connection. Since it may be the case that data should be sent out, the senddata() function is called to deal with the outgoing data.

The following very simple application serves as an example of how the application handler functions might look. This application simply waits for any data to arrive on the connection, and responds to the data by sending out the message "Hello world!". To illustrate how to develop an application state machine, this message is sent in two parts, first the "Hello" part and then the "world!" part.

```
#define STATE_WAITING 0
#define STATE_HELLO
#define STATE_WORLD
struct example6 state {
 u8_t state;
 char *textptr;
 int textlen;
static void aborted(void) {}
static void timedout(void) {}
static void closed(void) {}
static void connected(void) {
  struct example6_state *s = (struct example6_state *)uip_conn->appstate;
  s->state = STATE_WAITING;
  s->textlen = 0;
static void newdata(void) {
  struct example6_state *s = (struct example6_state *)uip_conn->appstate;
  if(s->state == STATE_WAITING) {
   s->state = STATE_HELLO;
   s->textptr = "Hello ";
    s->textlen = 6;
}
static void acked(void) {
  struct example6_state *s = (struct example6_state *)uip_conn->appstate;
```

1.7 Examples

```
s->textlen -= uip_conn->len;
  s->textptr += uip_conn->len;
  if(s->textlen == 0) {
   switch(s->state) {
    case STATE_HELLO:
     s->state = STATE WORLD:
      s->textptr = "world!\n";
     s->textlen = 7;
     break:
    case STATE_WORLD:
     uip_close();
     break:
  }
}
static void senddata(void) {
  struct example6_state *s = (struct example6_state *)uip_conn->appstate;
  if(s->textlen > 0) {
   uip_send(s->textptr, s->textlen);
}
```

The application state consists of a "state" variable, a "textptr" pointer to a text message and the "textlen" length of the text message. The "state" variable can be either "STATE_WAITING", meaning that the application is waiting for data to arrive from the network, "STATE_HELLO", in which the application is sending the "Hello" part of the message, or "STATE_WORLD", in which the application is sending the "world!" message.

The application does not handle errors or connection closing events, and therefore the aborted(), timedout() and closed() functions are implemented as empty functions.

The connected() function will be called when a connection has been established, and in this case sets the "state" variable to be "STATE_WAITING" and the "textlen" variable to be zero, indicating that there is no message to be sent out.

When new data arrives from the network, the newdata() function will be called by the event handler function. The newdata() function will check if the connection is in the "STATE_WAITING" state, and if so switches to the "STATE_HELLO" state and registers a 6 byte long "Hello" message with the connection. This message will later be sent out by the senddata() function.

The acked() function is called whenever data that previously was sent has been acknowleged by the receiving host. This acked() function first reduces the amount of data that is left to send, by subtracting the length of the previously sent data (obtained from "uip_conn \rightarrow len") from the "textlen" variable, and also adjusts the "textptr" pointer accordingly. It then checks if the "textlen" variable now is zero, which indicates that all data now has been successfully received, and if so changes application state. If the application was in the "STATE_HELLO" state, it switches state to "STATE_WORLD" and sets up a 7 byte "world!\n" message to be sent. If the application was in the "STATE_WORLD" state, it closes the connection.

Finally, the senddata() function takes care of actually sending the data that is to be sent. It is called by the event handler function when new data has been received, when data has been acknowledged, when a new connection has been established, when the connection is polled because of inactivity, or when a retransmission should be made. The purpose of the senddata() function is to optionally format the data that is to be sent, and to call the uip_send() function to actually send out the data. In this particular example, the function simply calls uip_send() with the appropriate arguments if data is to be sent, after checking if data should be sent out or not as indicated by the "textlen" variable.

It is important to note that the senddata() function never should affect the application state; this should only be done in the acked() and newdata() functions.

1.8 Protocol Implementations

The protocols in the TCP/IP protocol suite are designed in a layered fashion where each protocol performs a specific function and the interactions between the protocol layers are strictly defined. While the layered approach is a good way to design protocols, it is not always the best way to implement them. In uIP, the protocol implementations are tightly coupled in order to save code space.

This section gives detailed information on the specific protocol implementations in uIP.

1.8.1 IP — Internet Protocol

When incoming packets are processed by uIP, the IP layer is the first protocol that examines the packet. The IP layer does a few simple checks such as if the destination IP address of the incoming packet matches any of the local IP address and verifies the IP header checksum. Since there are no IP options that are strictly required and because they are very uncommon, any IP options in received packets are dropped.

1.8.1.1 IP Fragment Reassembly

IP fragment reassembly is implemented using a separate buffer that holds the packet to be reassembled. An incoming fragment is copied into the right place in the buffer and a bit map is used to keep track of which fragments have been received. Because the first byte of an IP fragment is aligned on an 8-byte boundary, the bit map requires a small amount of memory. When all fragments have been reassembled, the resulting IP packet is passed to the transport layer. If all fragments have not been received within a specified time frame, the packet is dropped.

The current implementation only has a single buffer for holding packets to be reassembled, and therefore does not support simultaneous reassembly of more than one packet. Since fragmented packets are uncommon, this ought to be a reasonable decision. Extending the implementation to support multiple buffers would be straightforward, however.

1.8.1.2 Broadcasts and Multicasts

IP has the ability to broadcast and multicast packets on the local network. Such packets are addressed to special broadcast and multicast addresses. Broadcast is used heavily in many UDP based protocols such as the Microsoft Windows file-sharing SMB protocol. Multicast is primarily used in protocols used for multimedia distribution such as RTP. TCP is a point-to-point protocol and does not use broadcast or multicast packets. uIP current supports broadcast packets as well as sending multicast packets. Joining multicast groups (IGMP) and receiving non-local multicast packets is not currently supported.

1.8.2 ICMP — Internet Control Message Protocol

The ICMP protocol is used for reporting soft error conditions and for querying host parameters. Its main use is, however, the echo mechanism which is used by the "ping" program.

The ICMP implementation in uIP is very simple as it is restricted to only implement ICMP echo messages. Replies to echo messages are constructed by simply swapping the source and destination IP addresses of incoming echo requests and rewriting the ICMP header with the Echo-Reply message type. The ICMP checksum is adjusted using standard techniques (see RFC1624).

Since only the ICMP echo message is implemented, there is no support for Path MTU discovery or ICMP redirect messages. Neither of these is strictly required for interoperability; they are performance enhancement mechanisms.

1.8.3 TCP — Transmission Control Protocol

The TCP implementation in uIP is driven by incoming packets and timer events. Incoming packets are parsed by TCP and if the packet contains data that is to be delivered to the application, the application is invoked by the means of the application function call. If the incoming packet acknowledges previously sent data, the connection state is updated and the application is informed, allowing it to send out new data.

1.8.3.1 Listening Connections

TCP allows a connection to listen for incoming connection requests. In uIP, a listening connection is identified by the 16-bit port number and incoming connection requests are checked against the list of listening connections. This list of listening connections is dynamic and can be altered by the applications in the system.

1.8.3.2 Sliding Window

Most TCP implementations use a sliding window mechanism for sending data. Multiple data segments are sent in succession without waiting for an acknowledgment for each segment.

The sliding window algorithm uses a lot of 32-bit operations and because 32-bit arithmetic is fairly expensive on most 8-bit CPUs, uIP does not implement it. Also, uIP does not buffer sent packets and a sliding window implementation that does not buffer sent packets will have to be supported by a complex application layer. Instead, uIP allows only a single TCP segment per connection to be unacknowledged at any given time.

It is important to note that even though most TCP implementations use the sliding window algorithm, it is not required by the TCP specifications. Removing the sliding window mechanism does not affect interoperability in any way.

1.8.3.3 Round-Trip Time Estimation

TCP continuously estimates the current Round-Trip Time (RTT) of every active connection in order to find a suitable value for the retransmission time-out.

The RTT estimation in uIP is implemented using TCP's periodic timer. Each time the periodic timer fires, it increments a counter for each connection that has unacknowledged data in the network. When an acknowledgment is received, the current value of the counter is used as a sample of the RTT. The sample is used together with Van Jacobson's standard TCP RTT estimation function to calculate an estimate of the RTT. Karn's algorithm is used to ensure that retransmissions do not skew the estimates.

1.8.3.4 Retransmissions

Retransmissions are driven by the periodic TCP timer. Every time the periodic timer is invoked, the retransmission timer for each connection is decremented. If the timer reaches zero, a retransmission should be made.

As uIP does not keep track of packet contents after they have been sent by the device driver, uIP requires that the application takes an active part in performing the retransmission. When uIP decides that a segment should be retransmitted, it calls the application with a flag set indicating that a retransmission is required. The application checks the retransmission flag and produces the same data that was previously sent. From the application's standpoint, performing a retransmission is not different from how the data originally was sent. Therefore the application can be written in such a way that the same code is used both for sending data and retransmitting data. Also, it is important to note that even though the actual retransmission operation is

carried out by the application, it is the responsibility of the stack to know when the retransmission should be made. Thus the complexity of the application does not necessarily increase because it takes an active part in doing retransmissions.

1.8.3.5 Flow Control

The purpose of TCP's flow control mechanisms is to allow communication between hosts with wildly varying memory dimensions. In each TCP segment, the sender of the segment indicates its available buffer space. A TCP sender must not send more data than the buffer space indicated by the receiver.

In uIP, the application cannot send more data than the receiving host can buffer. And application cannot send more data than the amount of bytes it is allowed to send by the receiving host. If the remote host cannot accept any data at all, the stack initiates the zero window probing mechanism.

1.8.3.6 Congestion Control

The congestion control mechanisms limit the number of simultaneous TCP segments in the network. The algorithms used for congestion control are designed to be simple to implement and require only a few lines of code.

Since uIP only handles one in-flight TCP segment per connection, the amount of simultaneous segments cannot be further limited, thus the congestion control mechanisms are not needed.

1.8.3.7 Urgent Data

TCP's urgent data mechanism provides an application-to-application notification mechanism, which can be used by an application to mark parts of the data stream as being more urgent than the normal stream. It is up to the receiving application to interpret the meaning of the urgent data.

In many TCP implementations, including the BSD implementation, the urgent data feature increases the complexity of the implementation because it requires an asynchronous notification mechanism in an otherwise synchronous API. As uIP already use an asynchronous event based API, the implementation of the urgent data feature does not lead to increased complexity.

1.9 Performance

In TCP/IP implementations for high-end systems, processing time is dominated by the checksum calculation loop, the operation of copying packet data and context switching. Operating systems for high-end systems often have multiple protection domains for protecting kernel data from user processes and user processes from each other. Because the TCP/IP stack is run in the kernel, data has to be copied between the kernel space and the address space of the user processes and a context switch has to be performed once the data has been copied. Performance can be enhanced by combining the copy operation with the checksum calculation. Because high-end systems usually have numerous active connections, packet demultiplexing is also an expensive operation.

A small embedded device does not have the necessary processing power to have multiple protection domains and the power to run a multitasking operating system. Therefore there is no need to copy data between the TCP/IP stack and the application program. With an event based API there is no context switch between the TCP/IP stack and the applications.

In such limited systems, the TCP/IP processing overhead is dominated by the copying of packet data from the network device to host memory, and checksum calculation. Apart from the checksum calculation

1.9 Performance

and copying, the TCP processing done for an incoming packet involves only updating a few counters and flags before handing the data over to the application. Thus an estimate of the CPU overhead of our TCP/IP implementations can be obtained by calculating the amount of CPU cycles needed for the checksum calculation and copying of a maximum sized packet.

1.9.1 The Impact of Delayed Acknowledgments

Most TCP receivers implement the delayed acknowledgment algorithm for reducing the number of pure acknowledgment packets sent. A TCP receiver using this algorithm will only send acknowledgments for every other received segment. If no segment is received within a specific time-frame, an acknowledgment is sent. The time-frame can be as high as 500 ms but typically is 200 ms.

A TCP sender such as uIP that only handles a single outstanding TCP segment will interact poorly with the delayed acknowledgment algorithm. Because the receiver only receives a single segment at a time, it will wait as much as 500 ms before an acknowledgment is sent. This means that the maximum possible throughput is severely limited by the 500 ms idle time.

Thus the maximum throughput equation when sending data from uIP will be $p = s / (t + t_d)$ where \$s\$ is the segment size and t_d is the delayed acknowledgment timeout, which typically is between 200 and 500 ms. With a segment size of 1000 bytes, a round-trip time of 40 ms and a delayed acknowledgment timeout of 200 ms, the maximum throughput will be 4166 bytes per second. With the delayed acknowledgment algorithm disabled at the receiver, the maximum throughput would be 25000 bytes per second.

It should be noted, however, that since small systems running uIP are not very likely to have large amounts of data to send, the delayed acknowledgment throughput degradation of uIP need not be very severe. Small amounts of data sent by such a system will not span more than a single TCP segment, and would therefore not be affected by the throughput degradation anyway.

The maximum throughput when uIP acts as a receiver is not affected by the delayed acknowledgment throughput degradation.

uIP 1.0 Module Index

2.1 uIP 1.0 Modules

Here is a list of all module	C

Protothreads
Local continuations
Applications
DNS resolver
SMTP E-mail sender
Telnet server
Hello, world
Web client
Web server
The uIP TCP/IP stack
uIP configuration functions
uIP initialization functions
uIP device driver functions
uIP application functions
uIP conversion functions
Variables used in uIP device drivers
uIP Address Resolution Protocol
uIP TCP throughput booster hack
Architecture specific uIP functions
Configuration options for uIP
Timer library
Clock interface
Protosockets library
Memory block management functions 102

20 uIP 1.0 Module Index

uIP 1.0 Hierarchical Index

3.1 uIP 1.0 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

dhcpc_state
hello_world_state
httpd_cgi_call
httpd_state
memb_blocks
psock
psock_buf
pt
smtp_state
telnetd_state
timer
uip_conn
uip_eth_addr
uip_eth_hdr
uip_icmpip_hdr 138
uip_neighbor_addr
uip_stats
uip_tcpip_hdr
uip_udp_conn
uip_udpip_hdr
webclient state

uIP 1.0 Data Structure Index

4.1 uIP 1.0 Data Structures

Here are the data structures with brief descriptions:

dhcpc_state
hello_world_state
httpd_cgi_call
httpd_state
memb_blocks
psock (The representation of a protosocket)
psock_buf
pt
smtp_state
telnetd_state
timer (A timer)
uip_conn (Representation of a uIP TCP connection)
uip_eth_addr (Representation of a 48-bit Ethernet address)
uip_eth_hdr (The Ethernet header)
uip_icmpip_hdr
uip_neighbor_addr 139
uip_stats (The structure holding the TCP/IP statistics that are gathered if UIP_STATISTICS is
set to 1)
uip_tcpip_hdr
uip_udp_conn (Representation of a uIP UDP connection)
uip_udpip_hdr
webclient_state

uIP 1.0 File Index

5.1 uIP 1.0 File List

Here is a list of all documented files with brief descriptions:

apps/dhcpc/dhcpc.c ??
apps/hello-world/hello-world.c (An example of how to write uIP applications with protosockets) 147
apps/hello-world/hello-world.h (Header file for an example of how to write uIP applications with
protosockets)
apps/resolv/resolv.c (DNS host name to IP address resolver)
apps/resolv/resolv.h (DNS resolver code header file)
apps/smtp/smtp.c (SMTP example implementation)
apps/smtp.h (SMTP header file)
apps/telnetd/shell.c (Simple shell)
apps/telnetd/shell.h (Simple shell, header file)
apps/telnetd/telnetd.c (Shell server)
apps/telnetd/telnetd.h (Shell server)
apps/webclient/webclient.c (Implementation of the HTTP client)
apps/webclient/webclient.h (Header file for the HTTP client)
apps/webserver/httpd-cgi.c (Web server script interface)
apps/webserver/httpd-cgi.h (Web server script interface header file)
apps/webserver/httpd.c (Web server)
apps/webserver/httpd.h
lib/memb.c (Memory block allocation routines)
lib/memb.h (Memory block allocation routines)
uip/clock.h
uip/lc-addrlabels.h (Implementation of local continuations based on the "Labels as values" fea-
ture of gcc)
uip/lc-switch.h (Implementation of local continuations based on switch() statment) 170
uip/lc.h (Local continuations)
uip/psock.c
uip/psock.h (Protosocket library header file)
uip/pt.h (Protothreads implementation)
uip/timer.c (Timer library implementation)
uip/timer.h (Timer library header file)
uip/uip-neighbor.c (Database of link-local neighbors, used by IPv6 code and to be used by a
future ARP code rewrite)

26 uIP 1.0 File Index

uip/uip-neighbor.h (Header file for database of link-local neighbors, used by IPv6 code and to be	
used by future ARP code)	179
uip/ uip-split.c	??
uip/uip-split.h (Module for splitting outbound TCP segments in two to avoid the delayed ACK	
throughput degradation)	180
uip/uip.c (The uIP TCP/IP stack code)	181
uip/uip.h (Header file for the uIP TCP/IP stack)	184
uip/uip_arch.h (Declarations of architecture specific functions)	<mark>19</mark> 0
uip/uip_arp.c (Implementation of the ARP Address Resolution Protocol)	191
uip/uip_arp.h (Macros and definitions for the ARP module)	192
uip/uipopt.h (Configuration options for uIP)	193
unix/uip-conf.h (An example uIP configuration file)	

uIP 1.0 Module Documentation

6.1 Protothreads

6.1.1 Detailed Description

Protothreads are a type of lightweight stackless threads designed for severly memory constrained systems such as deeply embedded systems or sensor network nodes.

Protothreads provides linear code execution for event-driven systems implemented in C. Protothreads can be used with or without an RTOS.

Protothreads are a extremely lightweight, stackless type of threads that provides a blocking context on top of an event-driven system, without the overhead of per-thread stacks. The purpose of protothreads is to implement sequential flow of control without complex state machines or full multi-threading. Protothreads provides conditional blocking inside C functions.

The advantage of protothreads over a purely event-driven approach is that protothreads provides a sequential code structure that allows for blocking functions. In purely event-driven systems, blocking must be implemented by manually breaking the function into two pieces - one for the piece of code before the blocking call and one for the code after the blocking call. This makes it hard to use control structures such as if() conditionals and while() loops.

The advantage of protothreads over ordinary threads is that a protothread do not require a separate stack. In memory constrained systems, the overhead of allocating multiple stacks can consume large amounts of the available memory. In contrast, each protothread only requires between two and twelve bytes of state, depending on the architecture.

Note:

Because protothreads do not save the stack context across a blocking call, **local variables are not preserved when the protothread blocks**. This means that local variables should be used with utmost care - if in doubt, do not use local variables inside a protothread!

Main features:

- No machine specific code the protothreads library is pure C
- Does not use error-prone functions such as longjmp()
- Very small RAM overhead only two bytes per protothread

- Can be used with or without an OS
- · Provides blocking wait without full multi-threading or stack-switching

Examples applications:

- · Memory constrained systems
- Event-driven protocol stacks
- Deeply embedded systems
- · Sensor network nodes

The protothreads API consists of four basic operations: initialization: PT_INIT(), execution: PT_BEGIN(), conditional blocking: PT_WAIT_UNTIL() and exit: PT_END(). On top of these, two convenience functions are built: reversed condition blocking: PT_WAIT_WHILE() and protothread blocking: PT_WAIT_THREAD().

See also:

Protothreads API documentation

The protothreads library is released under a BSD-style license that allows for both non-commercial and commercial usage. The only requirement is that credit is given.

6.1.2 Authors

The protothreads library was written by Adam Dunkels <adam@sics.se> with support from Oliver Schmidt <ol.sc@web.de>.

6.1.3 Protothreads

Protothreads are a extremely lightweight, stackless threads that provides a blocking context on top of an event-driven system, without the overhead of per-thread stacks. The purpose of protothreads is to implement sequential flow of control without using complex state machines or full multi-threading. Protothreads provides conditional blocking inside a C function.

In memory constrained systems, such as deeply embedded systems, traditional multi-threading may have a too large memory overhead. In traditional multi-threading, each thread requires its own stack, that typically is over-provisioned. The stacks may use large parts of the available memory.

The main advantage of protothreads over ordinary threads is that protothreads are very lightweight: a protothread does not require its own stack. Rather, all protothreads run on the same stack and context switching is done by stack rewinding. This is advantageous in memory constrained systems, where a stack for a thread might use a large part of the available memory. A protothread only requires only two bytes of memory per protothread. Moreover, protothreads are implemented in pure C and do not require any machine-specific assembler code.

A protothread runs within a single C function and cannot span over other functions. A protothread may call normal C functions, but cannot block inside a called function. Blocking inside nested function calls is instead made by spawning a separate protothread for each potentially blocking function. The advantage of

6.1 Protothreads

this approach is that blocking is explicit: the programmer knows exactly which functions that block that which functions the never blocks.

Protothreads are similar to asymmetric co-routines. The main difference is that co-routines uses a separate stack for each co-routine, whereas protothreads are stackless. The most similar mechanism to protothreads are Python generators. These are also stackless constructs, but have a different purpose. Protothreads provides blocking contexts inside a C function, whereas Python generators provide multiple exit points from a generator function.

6.1.4 Local variables

Note:

Because protothreads do not save the stack context across a blocking call, local variables are not preserved when the protothread blocks. This means that local variables should be used with utmost care - if in doubt, do not use local variables inside a protothread!

6.1.5 Scheduling

A protothread is driven by repeated calls to the function in which the protothread is running. Each time the function is called, the protothread will run until it blocks or exits. Thus the scheduling of protothreads is done by the application that uses protothreads.

6.1.6 Implementation

Protothreads are implemented using local continuations. A local continuation represents the current state of execution at a particular place in the program, but does not provide any call history or local variables. A local continuation can be set in a specific function to capture the state of the function. After a local continuation has been set can be resumed in order to restore the state of the function at the point where the local continuation was set.

Local continuations can be implemented in a variety of ways:

- 1. by using machine specific assembler code,
- 2. by using standard C constructs, or
- 3. by using compiler extensions.

The first way works by saving and restoring the processor state, except for stack pointers, and requires between 16 and 32 bytes of memory per protothread. The exact amount of memory required depends on the architecture.

The standard C implementation requires only two bytes of state per protothread and utilizes the C switch() statement in a non-obvious way that is similar to Duff's device. This implementation does, however, impose a slight restriction to the code that uses protothreads in that the code cannot use switch() statements itself.

Certain compilers has C extensions that can be used to implement protothreads. GCC supports label pointers that can be used for this purpose. With this implementation, protothreads require 4 bytes of RAM per protothread.

Files

• file pt.h

Protothreads implementation.

Modules

• Local continuations

Local continuations form the basis for implementing protothreads.

Data Structures

• struct pt

Initialization

• #define PT_INIT(pt)

Initialize a protothread.

Declaration and definition

- #define PT_THREAD(name_args)

 Declaration of a protothread.
- #define PT_BEGIN(pt)

Declare the start of a protothread inside the C function implementing the protothread.

• #define PT_END(pt)

Declare the end of a protothread.

Blocked wait

- #define PT_WAIT_UNTIL(pt, condition)

 Block and wait until condition is true.
- #define PT_WAIT_WHILE(pt, cond)

 Block and wait while condition is true.

Hierarchical protothreads

- #define PT_WAIT_THREAD(pt, thread)

 Block and wait until a child protothread completes.
- #define PT_SPAWN(pt, child, thread)

 Spawn a child protothread and wait until it exits.

6.1 Protothreads 31

Exiting and restarting

```
• #define PT_RESTART(pt)

Restart the protothread.
```

• #define PT_EXIT(pt)

Exit the protothread.

Calling a protothread

• #define PT_SCHEDULE(f) Schedule a protothread.

Yielding from a protothread

• #define PT_YIELD(pt)

Yield from the current protothread.

• #define PT_YIELD_UNTIL(pt, cond)

Yield from the protothread until a condition occurs.

Defines

- #define PT_WAITING 0
- #define PT_EXITED 1
- #define PT_ENDED 2
- #define PT_YIELDED 3

6.1.7 Define Documentation

6.1.7.1 #define PT_BEGIN(pt)

Declare the start of a protothread inside the C function implementing the protothread.

This macro is used to declare the starting point of a protothread. It should be placed at the start of the function in which the protothread runs. All C statements above the PT_BEGIN() invokation will be executed each time the protothread is scheduled.

Parameters:

pt A pointer to the protothread control structure.

Examples:

dhcpc.c.

Definition at line 115 of file pt.h.

6.1.7.2 #define PT_END(pt)

Declare the end of a protothread.

This macro is used for declaring that a protothread ends. It must always be used together with a matching PT_BEGIN() macro.

Parameters:

pt A pointer to the protothread control structure.

Examples:

dhcpc.c.

Definition at line 127 of file pt.h.

6.1.7.3 #define PT_EXIT(pt)

Exit the protothread.

This macro causes the protothread to exit. If the protothread was spawned by another protothread, the parent protothread will become unblocked and can continue to run.

Parameters:

pt A pointer to the protothread control structure.

Definition at line 246 of file pt.h.

6.1.7.4 #define PT_INIT(pt)

Initialize a protothread.

Initializes a protothread. Initialization must be done prior to starting to execute the protothread.

Parameters:

pt A pointer to the protothread control structure.

See also:

PT_SPAWN()

Examples:

dhcpc.c.

Definition at line 80 of file pt.h.

Referenced by httpd_appcall().

6.1.7.5 #define PT_RESTART(pt)

Restart the protothread.

This macro will block and cause the running protothread to restart its execution at the place of the PT_-BEGIN() call.

6.1 Protothreads 33

Parameters:

pt A pointer to the protothread control structure.

Examples:

dhcpc.c.

Definition at line 229 of file pt.h.

6.1.7.6 #define PT_SCHEDULE(f)

Schedule a protothread.

This function shedules a protothread. The return value of the function is non-zero if the protothread is running or zero if the protothread has exited.

Parameters:

f The call to the C function implementing the protothread to be scheduled

Definition at line 271 of file pt.h.

6.1.7.7 #define PT_SPAWN(pt, child, thread)

Spawn a child protothread and wait until it exits.

This macro spawns a child protothread and waits until it exits. The macro can only be used within a protothread.

Parameters:

pt A pointer to the protothread control structure.

child A pointer to the child protothread's control structure.

thread The child protothread with arguments

Definition at line 206 of file pt.h.

6.1.7.8 #define PT_THREAD(name_args)

Declaration of a protothread.

This macro is used to declare a protothread. All protothreads must be declared with this macro.

Parameters:

name_args The name and arguments of the C function implementing the protothread.

Examples:

dhcpc.c, and smtp.c.

Definition at line 100 of file pt.h.

6.1.7.9 #define PT_WAIT_THREAD(pt, thread)

Block and wait until a child protothread completes.

This macro schedules a child protothread. The current protothread will block until the child protothread completes.

Note:

The child protothread must be manually initialized with the PT_INIT() function before this function is used.

Parameters:

```
pt A pointer to the protothread control structure.thread The child protothread with arguments
```

See also:

```
PT_SPAWN()
```

Definition at line 192 of file pt.h.

6.1.7.10 #define PT_WAIT_UNTIL(pt, condition)

Block and wait until condition is true.

This macro blocks the protothread until the specified condition is true.

Parameters:

```
pt A pointer to the protothread control structure.condition The condition.
```

Examples:

dhcpc.c.

Definition at line 148 of file pt.h.

6.1.7.11 #define PT_WAIT_WHILE(pt, cond)

Block and wait while condition is true.

This function blocks and waits while condition is true. See PT_WAIT_UNTIL().

Parameters:

```
pt A pointer to the protothread control structure.cond The condition.
```

Definition at line 167 of file pt.h.

6.1.7.12 #define PT_YIELD(pt)

Yield from the current protothread.

This function will yield the protothread, thereby allowing other processing to take place in the system.

6.1 Protothreads 35

Parameters:

pt A pointer to the protothread control structure.

Examples:

dhcpc.c.

Definition at line 290 of file pt.h.

6.1.7.13 #define PT_YIELD_UNTIL(pt, cond)

Yield from the protothread until a condition occurs.

Parameters:

pt A pointer to the protothread control structure.

cond The condition.

This function will yield the protothread, until the specified condition evaluates to true.

Definition at line 310 of file pt.h.

6.2 Applications

6.2.1 Detailed Description

The uIP distribution contains a number of example applications that can be either used directory or studied when learning to develop applications for uIP.

Modules

• DNS resolver

The uIP DNS resolver functions are used to lookup a hostname and map it to a numerical IP address.

• SMTP E-mail sender

The Simple Mail Transfer Protocol (SMTP) as defined by RFC821 is the standard way of sending and transfering e-mail on the Internet.

• Telnet server

The uIP telnet server.

· Hello, world

A small example showing how to write applications with protosockets.

Web client

This example shows a HTTP client that is able to download web pages and files from web servers.

• Web server

The uIP web server is a very simplistic implementation of an HTTP server.

Variables

- char telnetd_state::buf [TELNETD_CONF_LINELEN]
- char telnetd_state::bufptr
- u8_t telnetd_state::numsent
- u8_t telnetd_state::state

6.3 uIP configuration functions

6.3.1 Detailed Description

The uIP configuration functions are used for setting run-time parameters in uIP such as IP addresses.

Defines

- #define uip_sethostaddr(addr)

 Set the IP address of this host.
- #define uip_gethostaddr(addr)

 Get the IP address of this host.
- #define uip_setdraddr(addr)

 Set the default router's IP address.
- #define uip_setnetmask(addr)

 Set the netmask.
- #define uip_getdraddr(addr)

 Get the default router's IP address.
- #define uip_getnetmask(addr)

 Get the netmask.
- #define uip_setethaddr(eaddr)

 Specifiy the Ethernet MAC address.

6.3.2 Define Documentation

6.3.2.1 #define uip_getdraddr(addr)

Get the default router's IP address.

Parameters:

addr A pointer to a uip_ipaddr_t variable that will be filled in with the IP address of the default router.

Definition at line 161 of file uip.h.

6.3.2.2 #define uip_gethostaddr(addr)

Get the IP address of this host.

The IP address is represented as a 4-byte array where the first octet of the IP address is put in the first member of the 4-byte array.

Example:

```
uip_ipaddr_t hostaddr;
uip_gethostaddr(&hostaddr);
```

Parameters:

addr A pointer to a uip_ipaddr_t variable that will be filled in with the currently configured IP address.

Definition at line 126 of file uip.h.

6.3.2.3 #define uip_getnetmask(addr)

Get the netmask.

Parameters:

addr A pointer to a uip_ipaddr_t variable that will be filled in with the value of the netmask.

Definition at line 171 of file uip.h.

6.3.2.4 #define uip_setdraddr(addr)

Set the default router's IP address.

Parameters:

addr A pointer to a uip_ipaddr_t variable containing the IP address of the default router.

See also:

uip_ipaddr()

Definition at line 138 of file uip.h.

6.3.2.5 #define uip_setethaddr(eaddr)

Specifiy the Ethernet MAC address.

The ARP code needs to know the MAC address of the Ethernet card in order to be able to respond to ARP queries and to generate working Ethernet headers.

Note:

This macro only specifies the Ethernet MAC address to the ARP code. It cannot be used to change the MAC address of the Ethernet card.

Parameters:

eaddr A pointer to a struct uip_eth_addr containing the Ethernet MAC address of the Ethernet card.

Definition at line 134 of file uip_arp.h.

6.3.2.6 #define uip_sethostaddr(addr)

Set the IP address of this host.

The IP address is represented as a 4-byte array where the first octet of the IP address is put in the first member of the 4-byte array.

Example:

```
uip_ipaddr_t addr;
uip_ipaddr(&addr, 192,168,1,2);
uip_sethostaddr(&addr);
```

Parameters:

addr A pointer to an IP address of type uip_ipaddr_t;

See also:

```
uip_ipaddr()
```

Examples:

dhcpc.c, example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 106 of file uip.h.

6.3.2.7 #define uip_setnetmask(addr)

Set the netmask.

Parameters:

addr A pointer to a uip_ipaddr_t variable containing the IP address of the netmask.

See also:

```
uip_ipaddr()
```

Definition at line 150 of file uip.h.

6.4 uIP initialization functions

6.4.1 Detailed Description

The uIP initialization functions are used for booting uIP.

Functions

- void uip_init (void)

 uIP initialization function.
- void uip_setipid (u16_t id)

 uIP initialization function.

6.4.2 Function Documentation

6.4.2.1 void uip_init (void)

uIP initialization function.

This function should be called at boot up to initilize the uIP TCP/IP stack.

Examples:

example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 379 of file uip.c.

References UIP_LISTENPORTS.

6.4.2.2 void uip_setipid (u16_t id)

uIP initialization function.

This function may be used at boot time to set the initial ip_id.

Definition at line 181 of file uip.c.

6.5 uIP device driver functions

6.5.1 Detailed Description

These functions are used by a network device driver for interacting with uIP.

Defines

• #define uip_input()

Process an incoming packet.

• #define uip_periodic(conn)

Periodic processing for a connection identified by its number.

- #define uip_conn_active(conn) (uip_conns[conn].tcpstateflags != UIP_CLOSED)
- #define uip_periodic_conn(conn)

Perform periodic processing for a connection identified by a pointer to its structure.

• #define uip_poll_conn(conn)

Reugest that a particular connection should be polled.

• #define uip udp periodic(conn)

Periodic processing for a UDP connection identified by its number.

• #define uip_udp_periodic_conn(conn)

Periodic processing for a UDP connection identified by a pointer to its structure.

Variables

• u8_t uip_buf [UIP_BUFSIZE+2]

The uIP packet buffer.

6.5.2 Define Documentation

6.5.2.1 #define uip_input()

Process an incoming packet.

This function should be called when the device driver has received a packet from the network. The packet from the device driver must be present in the uip_buf buffer, and the length of the packet should be placed in the uip_len variable.

When the function returns, there may be an outbound packet placed in the uip_buf packet buffer. If so, the uip_len variable is set to the length of the packet. If no packet is to be sent out, the uip_len variable is set to 0.

The usual way of calling the function is presented by the source code below.

```
uip_len = devicedriver_poll();
if(uip_len > 0) {
  uip_input();
  if(uip_len > 0) {
    devicedriver_send();
  }
}
```

Note:

If you are writing a uIP device driver that needs ARP (Address Resolution Protocol), e.g., when running uIP over Ethernet, you will need to call the uIP ARP code before calling this function:

```
#define BUF ((struct uip_eth_hdr *)&uip_buf[0])
uip_len = ethernet_devicedrver_poll();
if(uip_len > 0) {
   if(BUF->type == HTONS(UIP_ETHTYPE_IP)) {
      uip_arp_ipin();
      uip_input();
      if(uip_len > 0) {
       uip_arp_out();
       ethernet_devicedriver_send();
    }
} else if(BUF->type == HTONS(UIP_ETHTYPE_ARP)) {
    uip_arp_arpin();
   if(uip_len > 0) {
      ethernet_devicedriver_send();
   }
}
```

Examples:

example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 257 of file uip.h.

6.5.2.2 #define uip_periodic(conn)

Periodic processing for a connection identified by its number.

This function does the necessary periodic processing (timers, polling) for a uIP TCP conneciton, and should be called when the periodic uIP timer goes off. It should be called for every connection, regardless of whether they are open of closed.

When the function returns, it may have an outbound packet waiting for service in the uIP packet buffer, and if so the uip_len variable is set to a value larger than zero. The device driver should be called to send out the packet.

The ususal way of calling the function is through a for() loop like this:

```
for(i = 0; i < UIP_CONNS; ++i) {
  uip_periodic(i);
  if(uip_len > 0) {
    devicedriver_send();
  }
}
```

Note:

If you are writing a uIP device driver that needs ARP (Address Resolution Protocol), e.g., when running uIP over Ethernet, you will need to call the uip_arp_out() function before calling the device driver:

```
for(i = 0; i < UIP_CONNS; ++i) {
  uip_periodic(i);
  if(uip_len > 0) {
    uip_arp_out();
    ethernet_devicedriver_send();
  }
}
```

Parameters:

conn The number of the connection which is to be periodically polled.

Examples:

example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 301 of file uip.h.

6.5.2.3 #define uip_periodic_conn(conn)

Perform periodic processing for a connection identified by a pointer to its structure.

Same as uip_periodic() but takes a pointer to the actual uip_conn struct instead of an integer as its argument. This function can be used to force periodic processing of a specific connection.

Parameters:

conn A pointer to the uip_conn struct for the connection to be processed.

Definition at line 323 of file uip.h.

6.5.2.4 #define uip_poll_conn(conn)

Reuqest that a particular connection should be polled.

Similar to uip_periodic_conn() but does not perform any timer processing. The application is polled for new data.

Parameters:

conn A pointer to the uip_conn struct for the connection to be processed.

Definition at line 337 of file uip.h.

6.5.2.5 #define uip_udp_periodic(conn)

Periodic processing for a UDP connection identified by its number.

This function is essentially the same as uip_periodic(), but for UDP connections. It is called in a similar fashion as the uip_periodic() function:

```
for(i = 0; i < UIP_UDP_CONNS; i++) {
  uip_udp_periodic(i);
  if(uip_len > 0) {
    devicedriver_send();
  }
}
```

Note:

As for the uip_periodic() function, special care has to be taken when using uIP together with ARP and Ethernet:

```
for(i = 0; i < UIP_UDP_CONNS; i++) {
  uip_udp_periodic(i);
  if(uip_len > 0) {
    uip_arp_out();
    ethernet_devicedriver_send();
  }
}
```

Parameters:

conn The number of the UDP connection to be processed.

Examples

example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 373 of file uip.h.

6.5.2.6 #define uip_udp_periodic_conn(conn)

Periodic processing for a UDP connection identified by a pointer to its structure.

Same as uip_udp_periodic() but takes a pointer to the actual uip_conn struct instead of an integer as its argument. This function can be used to force periodic processing of a specific connection.

Parameters:

conn A pointer to the uip_udp_conn struct for the connection to be processed.

Definition at line 390 of file uip.h.

6.5.3 Variable Documentation

6.5.3.1 u8_t uip_buf[UIP_BUFSIZE+2]

The uIP packet buffer.

The uip_buf array is used to hold incoming and outgoing packets. The device driver should place incoming data into this buffer. When sending data, the device driver should read the link level headers and the TCP/IP headers from this buffer. The size of the link level headers is configured by the UIP_LLH_LEN define.

Note:

The application data need not be placed in this buffer, so the device driver must read it from the place pointed to by the uip_appdata pointer as illustrated by the following example:

```
void
devicedriver_send(void)
{
   hwsend(&uip_buf[0], UIP_LLH_LEN);
   if(uip_len <= UIP_LLH_LEN + UIP_TCPIP_HLEN) {
     hwsend(&uip_buf[UIP_LLH_LEN], uip_len - UIP_LLH_LEN);
   } else {
     hwsend(&uip_buf[UIP_LLH_LEN], UIP_TCPIP_HLEN);
     hwsend(&uip_appdata, uip_len - UIP_TCPIP_HLEN - UIP_LLH_LEN);
   }
}</pre>
```

Definition at line 139 of file uip.c.

Referenced by uip_process().

6.6 uIP application functions

6.6.1 Detailed Description

Functions used by an application running of top of uIP.

Defines

- #define uip_outstanding(conn) ((conn) → len)
- #define uip_datalen()

The length of any incoming data that is currently avaliable (if avaliable) in the uip_appdata buffer.

• #define uip_urgdatalen()

The length of any out-of-band data (urgent data) that has arrived on the connection.

• #define uip_close()

Close the current connection.

• #define uip_abort()

Abort the current connection.

• #define uip_stop()

Tell the sending host to stop sending data.

• #define uip_stopped(conn)

Find out if the current connection has been previously stopped with uip_stop().

• #define uip restart()

Restart the current connection, if is has previously been stopped with uip_stop().

• #define uip_udpconnection()

Is the current connection a UDP connection?

• #define uip_newdata()

Is new incoming data available?

• #define uip_acked()

Has previously sent data been acknowledged?

• #define uip_connected()

Has the connection just been connected?

• #define uip_closed()

Has the connection been closed by the other end?

• #define uip_aborted()

Has the connection been aborted by the other end?

• #define uip_timedout()

Has the connection timed out?

• #define uip rexmit()

Do we need to retransmit previously data?

• #define uip poll()

Is the connection being polled by uIP?

• #define uip_initialmss()

Get the initial maxium segment size (MSS) of the current connection.

• #define uip_mss()

Get the current maxium segment size that can be sent on the current connection.

• #define uip_udp_remove(conn)

Removed a UDP connection.

• #define uip_udp_bind(conn, port)

Bind a UDP connection to a local port.

• #define uip_udp_send(len)

Send a UDP datagram of length len on the current connection.

Functions

• void uip_listen (u16_t port)

Start listening to the specified port.

• void uip_unlisten (u16_t port)

Stop listening to the specified port.

• uip_conn * uip_connect (uip_ipaddr_t *ripaddr, u16_t port)

Connect to a remote host using TCP.

• void uip_send (const void *data, int len)

Send data on the current connection.

• uip_udp_conn * uip_udp_new (uip_ipaddr_t *ripaddr, u16_t rport)

Set up a new UDP connection.

6.6.2 Define Documentation

6.6.2.1 #define uip_abort()

Abort the current connection.

This function will abort (reset) the current connection, and is usually used when an error has occured that prevents using the uip_close() function.

Examples:

webclient.c.

Definition at line 581 of file uip.h.

Referenced by httpd_appcall(), and webclient_appcall().

6.6.2.2 #define uip_aborted()

Has the connection been aborted by the other end?

Non-zero if the current connection has been aborted (reset) by the remote host.

Examples:

smtp.c, telnetd.c, and webclient.c.

Definition at line 680 of file uip.h.

Referenced by httpd_appcall(), smtp_appcall(), and webclient_appcall().

6.6.2.3 #define uip_acked()

Has previously sent data been acknowledged?

Will reduce to non-zero if the previously sent data has been acknowledged by the remote host. This means that the application can send new data.

Examples:

telnetd.c, and webclient.c.

Definition at line 648 of file uip.h.

Referenced by webclient_appcall().

6.6.2.4 #define uip_close()

Close the current connection.

This function will close the current connection in a nice way.

Examples:

telnetd.c.

Definition at line 570 of file uip.h.

6.6.2.5 #define uip_closed()

Has the connection been closed by the other end?

Is non-zero if the connection has been closed by the remote host. The application may then do the necessary clean-ups.

Examples:

smtp.c, telnetd.c, and webclient.c.

Definition at line 670 of file uip.h.

Referenced by httpd_appcall(), smtp_appcall(), and webclient_appcall().

6.6.2.6 #define uip_connected()

Has the connection just been connected?

Reduces to non-zero if the current connection has been connected to a remote host. This will happen both if the connection has been actively opened (with uip_connect()) or passively opened (with uip_listen()).

Examples:

hello-world.c, telnetd.c, and webclient.c.

Definition at line 660 of file uip.h.

Referenced by hello_world_appcall(), httpd_appcall(), telnetd_appcall(), and webclient_appcall().

6.6.2.7 #define uip_datalen()

The length of any incoming data that is currently available (if available) in the uip_appdata buffer.

The test function uip data() must first be used to check if there is any data available at all.

Examples:

dhcpc.c, telnetd.c, and webclient.c.

Definition at line 550 of file uip.h.

6.6.2.8 #define uip_mss()

Get the current maxium segment size that can be sent on the current connection.

The current maximum segment size that can be sent on the connection is computed from the receiver's window and the MSS of the connection (which also is available by calling uip_initialmss()).

Examples:

telnetd.c, and webclient.c.

Definition at line 737 of file uip.h.

6.6.2.9 #define uip_newdata()

Is new incoming data available?

Will reduce to non-zero if there is new data for the application present at the uip_appdata pointer. The size of the data is avaliable through the uip_len variable.

Examples:

dhcpc.c, resolv.c, telnetd.c, and webclient.c.

Definition at line 637 of file uip.h.

Referenced by psock_newdata(), resolv_appcall(), and webclient_appcall().

6.6.2.10 #define uip poll()

Is the connection being polled by uIP?

Is non-zero if the reason the application is invoked is that the current connection has been idle for a while and should be polled.

The polling event can be used for sending data without having to wait for the remote host to send data.

Examples:

resolv.c, telnetd.c, and webclient.c.

Definition at line 716 of file uip.h.

Referenced by httpd_appcall(), resolv_appcall(), and webclient_appcall().

6.6.2.11 #define uip_restart()

Restart the current connection, if is has previously been stopped with uip_stop().

This function will open the receiver's window again so that we start receiving data for the current connection.

Definition at line 610 of file uip.h.

6.6.2.12 #define uip_rexmit()

Do we need to retransmit previously data?

Reduces to non-zero if the previously sent data has been lost in the network, and the application should retransmit it. The application should send the exact same data as it did the last time, using the uip_send() function.

Examples:

telnetd.c, and webclient.c.

Definition at line 702 of file uip.h.

Referenced by webclient_appcall().

6.6.2.13 #define uip_stop()

Tell the sending host to stop sending data.

This function will close our receiver's window so that we stop receiving data for the current connection.

Definition at line 591 of file uip.h.

6.6.2.14 #define uip_timedout()

Has the connection timed out?

Non-zero if the current connection has been aborted due to too many retransmissions.

Examples:

smtp.c, telnetd.c, and webclient.c.

Definition at line 690 of file uip.h.

Referenced by httpd_appcall(), smtp_appcall(), and webclient_appcall().

6.6.2.15 #define uip_udp_bind(conn, port)

Bind a UDP connection to a local port.

Parameters:

conn A pointer to the uip_udp_conn structure for the connection.port The local port number, in network byte order.

Examples:

dhcpc.c.

Definition at line 787 of file uip.h.

6.6.2.16 #define uip_udp_remove(conn)

Removed a UDP connection.

Parameters:

conn A pointer to the uip_udp_conn structure for the connection.

Examples:

resolv.c.

Definition at line 775 of file uip.h.

Referenced by resolv_conf().

6.6.2.17 #define uip_udp_send(len)

Send a UDP datagram of length len on the current connection.

This function can only be called in response to a UDP event (poll or newdata). The data must be present in the uip_buf buffer, at the place pointed to by the uip_appdata pointer.

Parameters:

len The length of the data in the uip_buf buffer.

Examples:

resolv.c.

Definition at line 800 of file uip.h.

6.6.2.18 #define uip_udpconnection()

Is the current connection a UDP connection?

This function checks whether the current connection is a UDP connection.

Definition at line 626 of file uip.h.

6.6.2.19 #define uip_urgdatalen()

The length of any out-of-band data (urgent data) that has arrived on the connection.

Note:

The configuration parameter UIP_URGDATA must be set for this function to be enabled.

Definition at line 561 of file uip.h.

6.6.3 Function Documentation

```
6.6.3.1 struct uip_conn* uip_connect (uip_ipaddr_t * ripaddr, u16_t port)
```

Connect to a remote host using TCP.

This function is used to start a new connection to the specified port on the specied host. It allocates a new connection identifier, sets the connection to the SYN_SENT state and sets the retransmission timer to 0. This will cause a TCP SYN segment to be sent out the next time this connection is periodically processed, which usually is done within 0.5 seconds after the call to uip_connect().

Note:

This function is avaliable only if support for active open has been configured by defining UIP_ACTIVE_OPEN to 1 in uipopt.h.

Since this function requires the port number to be in network byte order, a conversion using HTONS() or htons() is necessary.

```
uip_ipaddr_t ipaddr;
uip_ipaddr(&ipaddr, 192,168,1,2);
uip_connect(&ipaddr, HTONS(80));
```

Parameters:

ripaddr The IP address of the remote hot.

port A 16-bit port number in network byte order.

Returns:

A pointer to the uIP connection identifier for the new connection, or NULL if no connection could be allocated.

Examples:

```
smtp.c, and webclient.c.
```

Definition at line 407 of file uip.c.

References htons(), uip_conn::lport, uip_conn::tcpstateflags, UIP_CLOSED, uip_conn, UIP_CONNS, and uip_conns.

Referenced by smtp_send(), and webclient_get().

6.6.3.2 void uip_listen (u16_t port)

Start listening to the specified port.

Note:

Since this function expects the port number in network byte order, a conversion using HTONS() or htons() is necessary.

```
uip_listen(HTONS(80));
```

Parameters:

port A 16-bit port number in network byte order.

Examples:

hello-world.c, and telnetd.c.

Definition at line 529 of file uip.c.

References UIP_LISTENPORTS.

Referenced by hello world init(), httpd init(), and telnetd init().

6.6.3.3 void uip_send (const void * data, int len)

Send data on the current connection.

This function is used to send out a single segment of TCP data. Only applications that have been invoked by uIP for event processing can send data.

The amount of data that actually is sent out after a call to this funcion is determined by the maximum amount of data TCP allows. uIP will automatically crop the data so that only the appropriate amount of data is sent. The function uip_mss() can be used to query uIP for the amount of data that actually will be sent.

Note:

This function does not guarantee that the sent data will arrive at the destination. If the data is lost in the network, the application will be invoked with the uip_rexmit() event being set. The application will then have to resend the data using this function.

Parameters:

data A pointer to the data which is to be sent.

len The maximum amount of data bytes to be sent.

Examples:

```
dhcpc.c, telnetd.c, and webclient.c.
```

Definition at line 1888 of file uip.c.

References uip_sappdata, and uip_slen.

6.6.3.4 struct uip_udp_conn* uip_udp_new (uip_ipaddr_t * ripaddr, u16_t rport)

Set up a new UDP connection.

This function sets up a new UDP connection. The function will automatically allocate an unused local port for the new connection. However, another port can be chosen by using the uip_udp_bind() call, after the uip_udp_new() function has been called.

Example:

```
uip_ipaddr_t addr;
struct uip_udp_conn *c;
uip_ipaddr(&addr, 192,168,2,1);
c = uip_udp_new(&addr, HTONS(12345));
if(c != NULL) {
   uip_udp_bind(c, HTONS(12344));
}
```

Parameters:

ripaddr The IP address of the remote host.

rport The remote port number in network byte order.

Returns:

The uip_udp_conn structure for the new connection or NULL if no connection could be allocated.

Examples:

```
dhcpc.c, and resolv.c.
```

Definition at line 473 of file uip.c.

References htons(), uip_udp_conn::lport, uip_udp_conn, UIP_UDP_CONNS, and uip_udp_conns.

Referenced by resolv_conf().

6.6.3.5 void uip_unlisten (u16_t port)

Stop listening to the specified port.

Note:

Since this function expects the port number in network byte order, a conversion using HTONS() or htons() is necessary.

```
uip_unlisten(HTONS(80));
```

Parameters:

port A 16-bit port number in network byte order.

Definition at line 518 of file uip.c.

References UIP_LISTENPORTS.

6.7 uIP conversion functions

6.7.1 Detailed Description

These functions can be used for converting between different data formats used by uIP.

Defines

- #define uip_ipaddr(addr, addr0, addr1, addr2, addr3)

 Construct an IP address from four bytes.
- #define uip_ip6addr(addr, addr0, addr1, addr2, addr3, addr4, addr5, addr6, addr7) Construct an IPv6 address from eight 16-bit words.
- #define uip_ipaddr_copy(dest, src)

 Copy an IP address to another IP address.
- #define uip_ipaddr_cmp(addr1, addr2)

 Compare two IP addresses.
- #define uip_ipaddr_maskcmp(addr1, addr2, mask)

 Compare two IP addresses with netmasks.
- #define uip_ipaddr_mask(dest, src, mask)
 Mask out the network part of an IP address.
- #define uip_ipaddr1(addr)

 Pick the first octet of an IP address.
- #define uip_ipaddr2(addr)

 Pick the second octet of an IP address.
- #define uip_ipaddr3(addr)
 Pick the third octet of an IP address.
- #define uip_ipaddr4(addr)

 Pick the fourth octet of an IP address.
- #define HTONS(n)
 Convert 16-bit quantity from host byte order to network byte order.
- #define ntohs htons

Functions

• u16_t htons (u16_t val)

Convert 16-bit quantity from host byte order to network byte order.

6.7.2 Define Documentation

6.7.2.1 #define HTONS(n)

Convert 16-bit quantity from host byte order to network byte order.

This macro is primarily used for converting constants from host byte order to network byte order. For converting variables to network byte order, use the https://htm.nction.nct

Examples:

dhcpc.c, hello-world.c, resolv.c, smtp.c, and telnetd.c.

Definition at line 1070 of file uip.h.

Referenced by hello_world_init(), htons(), httpd_init(), resolv_appcall(), resolv_conf(), smtp_send(), telnetd_init(), uip_arp_arpin(), and uip_process().

6.7.2.2 #define uip_ip6addr(addr, addr0, addr1, addr2, addr3, addr4, addr5, addr6, addr7)

Construct an IPv6 address from eight 16-bit words.

This function constructs an IPv6 address.

Definition at line 852 of file uip.h.

6.7.2.3 #define uip_ipaddr(addr, addr0, addr1, addr2, addr3)

Construct an IP address from four bytes.

This function constructs an IP address of the type that uIP handles internally from four bytes. The function is handy for specifying IP addresses to use with e.g. the uip_connect() function.

Example:

```
uip_ipaddr_t ipaddr;
struct uip_conn *c;
uip_ipaddr(&ipaddr, 192,168,1,2);
c = uip_connect(&ipaddr, HTONS(80));
```

Parameters:

addr A pointer to a uip_ipaddr_t variable that will be filled in with the IP address.

addr0 The first octet of the IP address.

addr1 The second octet of the IP address.

addr2 The third octet of the IP address.

addr3 The forth octet of the IP address.

Examples:

dhcpc.c, example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 840 of file uip.h.

6.7.2.4 #define uip_ipaddr1(addr)

Pick the first octet of an IP address.

Picks out the first octet of an IP address.

Example:

```
uip_ipaddr_t ipaddr;
u8_t octet;
uip_ipaddr(&ipaddr, 1,2,3,4);
octet = uip_ipaddr1(&ipaddr);
```

In the example above, the variable "octet" will contain the value 1.

Examples:

```
dhcpc.c.
```

Definition at line 995 of file uip.h.

6.7.2.5 #define uip_ipaddr2(addr)

Pick the second octet of an IP address.

Picks out the second octet of an IP address.

Example:

```
uip_ipaddr_t ipaddr;
u8_t octet;
uip_ipaddr(&ipaddr, 1,2,3,4);
octet = uip_ipaddr2(&ipaddr);
```

In the example above, the variable "octet" will contain the value 2.

Examples:

dhcpc.c.

Definition at line 1015 of file uip.h.

6.7.2.6 #define uip_ipaddr3(addr)

Pick the third octet of an IP address.

Picks out the third octet of an IP address.

Example:

```
uip_ipaddr_t ipaddr;
u8_t octet;
uip_ipaddr(&ipaddr, 1,2,3,4);
octet = uip_ipaddr3(&ipaddr);
```

In the example above, the variable "octet" will contain the value 3.

Examples:

dhcpc.c.

Definition at line 1035 of file uip.h.

6.7.2.7 #define uip_ipaddr4(addr)

Pick the fourth octet of an IP address.

Picks out the fourth octet of an IP address.

Example:

```
uip_ipaddr_t ipaddr;
u8_t octet;
uip_ipaddr(&ipaddr, 1,2,3,4);
octet = uip_ipaddr4(&ipaddr);
```

In the example above, the variable "octet" will contain the value 4.

Examples:

dhcpc.c.

Definition at line 1055 of file uip.h.

6.7.2.8 #define uip_ipaddr_cmp(addr1, addr2)

Compare two IP addresses.

Compares two IP addresses.

Example:

```
uip_ipaddr_t ipaddr1, ipaddr2;
uip_ipaddr(&ipaddr1, 192,16,1,2);
if(uip_ipaddr_cmp(&ipaddr2, &ipaddr1)) {
    printf("They are the same");
}
```

Parameters:

addr1 The first IP address.

addr2 The second IP address.

Definition at line 911 of file uip.h.

Referenced by uip_arp_arpin(), uip_arp_out(), and uip_process().

6.7.2.9 #define uip_ipaddr_copy(dest, src)

Copy an IP address to another IP address.

Copies an IP address from one place to another.

Example:

```
uip_ipaddr_t ipaddr1, ipaddr2;
uip_ipaddr(&ipaddr1, 192,16,1,2);
uip_ipaddr_copy(&ipaddr2, &ipaddr1);
```

Parameters:

dest The destination for the copy.src The source from where to copy.

Examples:

smtp.c.

Definition at line 882 of file uip.h.

Referenced by smtp_configure(), uip_arp_out(), and uip_process().

6.7.2.10 #define uip_ipaddr_mask(dest, src, mask)

Mask out the network part of an IP address.

Masks out the network part of an IP address, given the address and the netmask.

Example:

```
uip_ipaddr_t ipaddr1, ipaddr2, netmask;
uip_ipaddr(&ipaddr1, 192,16,1,2);
uip_ipaddr(&netmask, 255,255,255,0);
uip_ipaddr_mask(&ipaddr2, &ipaddr1, &netmask);
```

In the example above, the variable "ipaddr2" will contain the IP address 192.168.1.0.

Parameters:

```
dest Where the result is to be placed.src The IP address.mask The netmask.
```

Definition at line 972 of file uip.h.

6.7.2.11 #define uip_ipaddr_maskcmp(addr1, addr2, mask)

Compare two IP addresses with netmasks.

Compares two IP addresses with netmasks. The masks are used to mask out the bits that are to be compared.

Example:

```
uip_ipaddr_t ipaddr1, ipaddr2, mask;
uip_ipaddr(&mask, 255,255,255,0);
uip_ipaddr(&ipaddr1, 192,16,1,2);
uip_ipaddr(&ipaddr2, 192,16,1,3);
if(uip_ipaddr_maskcmp(&ipaddr1, &ipaddr2, &mask)) {
    printf("They are the same");
}
```

Parameters:

addr1 The first IP address.addr2 The second IP address.mask The netmask.

Definition at line 941 of file uip.h.

Referenced by uip_arp_out().

6.7.3 Function Documentation

6.7.3.1 u16_t htons (**u16_t** *val*)

Convert 16-bit quantity from host byte order to network byte order.

This function is primarily used for converting variables from host byte order to network byte order. For converting constants to network byte order, use the HTONS() macro instead.

Examples:

example-mainloop-with-arp.c, resolv.c, and webclient.c.

Definition at line 1882 of file uip.c.

References HTONS.

Referenced by uip_chksum(), uip_connect(), uip_ipchksum(), uip_udp_new(), and webclient_get().

6.8 Variables used in uIP device drivers

6.8.1 Detailed Description

uIP has a few global variables that are used in device drivers for uIP.

Variables

• u16_t uip_len

The length of the packet in the uip_buf buffer.

6.8.2 Variable Documentation

6.8.2.1 u16_t uip_len

The length of the packet in the uip_buf buffer.

The global variable uip_len holds the length of the packet in the uip_buf buffer.

When the network device driver calls the uIP input function, uip_len should be set to the length of the packet in the uip_buf buffer.

When sending packets, the device driver should use the contents of the uip_len variable to determine the length of the outgoing packet.

Examples:

example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 155 of file uip.c.

Referenced by uip_arp_arpin(), uip_process(), and uip_split_output().

6.9 The uIP TCP/IP stack

6.9.1 Detailed Description

uIP is an implementation of the TCP/IP protocol stack intended for small 8-bit and 16-bit microcontrollers.

uIP provides the necessary protocols for Internet communication, with a very small code footprint and RAM requirements - the uIP code size is on the order of a few kilobytes and RAM usage is on the order of a few hundred bytes.

Files

• file uip.h

Header file for the uIP TCP/IP stack.

• file uip.c

The uIP TCP/IP stack code.

Modules

• uIP configuration functions

The uIP configuration functions are used for setting run-time parameters in uIP such as IP addresses.

• uIP initialization functions

The uIP initialization functions are used for booting uIP.

• uIP device driver functions

These functions are used by a network device driver for interacting with uIP.

• uIP application functions

Functions used by an application running of top of uIP.

• uIP conversion functions

These functions can be used for converting between different data formats used by uIP.

• Variables used in uIP device drivers

uIP has a few global variables that are used in device drivers for uIP.

• uIP Address Resolution Protocol

The Address Resolution Protocol ARP is used for mapping between IP addresses and link level addresses such as the Ethernet MAC addresses.

• uIP TCP throughput booster hack

The basic uIP TCP implementation only allows each TCP connection to have a single TCP segment in flight at any given time.

• Architecture specific uIP functions

The functions in the architecture specific module implement the IP check sum and 32-bit additions.

6.9 The uIP TCP/IP stack 63

Data Structures

• struct uip_conn

Representation of a uIP TCP connection.

• struct uip_udp_conn

Representation of a uIP UDP connection.

• struct uip_stats

The structure holding the TCP/IP statistics that are gathered if UIP_STATISTICS is set to 1.

- struct uip_tcpip_hdr
- struct uip_icmpip_hdr
- struct uip_udpip_hdr
- struct uip_eth_addr

Representation of a 48-bit Ethernet address.

Defines

- #define UIP_ACKDATA 1
- #define UIP_NEWDATA 2
- #define UIP_REXMIT 4
- #define UIP_POLL 8
- #define UIP_CLOSE 16
- #define UIP_ABORT 32
- #define UIP CONNECTED 64
- #define UIP_TIMEDOUT 128
- #define UIP_DATA 1
- #define UIP_TIMER 2
- #define UIP_POLL_REQUEST 3
- #define UIP UDP SEND CONN 4
- #define UIP_UDP_TIMER 5
- #define UIP_CLOSED 0
- #define UIP_SYN_RCVD 1
- #define UIP_SYN_SENT 2
- #define UIP_ESTABLISHED 3
- #define UIP_FIN_WAIT_1 4
- #define UIP_FIN_WAIT_2 5
- #define UIP_CLOSING 6
- #define UIP_TIME_WAIT 7
- #define UIP_LAST_ACK 8
- #define UIP_TS_MASK 15
- #define UIP STOPPED 16
- #define UIP_APPDATA_SIZE

The buffer size available for user data in the uip_buf buffer.

- #define UIP_PROTO_ICMP 1
- #define UIP_PROTO_TCP 6
- #define UIP_PROTO_UDP 17

- #define UIP_PROTO_ICMP6 58
- #define UIP_IPH_LEN 20
- #define UIP_UDPH_LEN 8
- #define UIP_TCPH_LEN 20
- #define UIP_IPUDPH_LEN (UIP_UDPH_LEN + UIP_IPH_LEN)
- #define UIP IPTCPH LEN (UIP TCPH LEN + UIP IPH LEN)
- #define UIP_TCPIP_HLEN UIP_IPTCPH_LEN
- #define TCP_FIN 0x01
- #define TCP_SYN 0x02
- #define TCP_RST 0x04
- #define TCP PSH 0x08
- #define TCP_ACK 0x10
- #define TCP_URG 0x20
- #define TCP_CTL 0x3f
- #define TCP OPT END 0
- #define TCP_OPT_NOOP 1
- #define TCP_OPT_MSS 2
- #define TCP_OPT_MSS_LEN 4
- #define ICMP_ECHO_REPLY 0
- #define ICMP_ECHO 8
- #define ICMP6 ECHO REPLY 129
- #define ICMP6 ECHO 128
- #define ICMP6_NEIGHBOR_SOLICITATION 135
- #define ICMP6_NEIGHBOR_ADVERTISEMENT 136
- #define ICMP6_FLAG_S (1 << 6)
- #define ICMP6_OPTION_SOURCE_LINK_ADDRESS 1
- #define ICMP6_OPTION_TARGET_LINK_ADDRESS 2
- #define BUF ((struct uip_tcpip_hdr *)&uip_buf[UIP_LLH_LEN])
- #define FBUF ((struct uip_tcpip_hdr *)&uip_reassbuf[0])
- #define ICMPBUF ((struct uip_icmpip_hdr *)&uip_buf[UIP_LLH_LEN])
- #define UDPBUF ((struct uip_udpip_hdr *)&uip_buf[UIP_LLH_LEN])
- #define UIP_STAT(s)
- #define UIP LOG(m)

Typedefs

- typedef u16_t uip_ip4addr_t [2]
 - Repressentation of an IP address.
- typedef u16_t uip_ip6addr_t [8]
- typedef uip_ip4addr_t uip_ipaddr_t

Functions

- void uip_process (u8_t flag)
- u16_t uip_chksum (u16_t *buf, u16_t len)

Calculate the Internet checksum over a buffer.

• u16_t uip_ipchksum (void)

6.9 The uIP TCP/IP stack 65

Calculate the IP header checksum of the packet header in uip_buf.

• u16_t uip_tcpchksum (void)

Calculate the TCP checksum of the packet in uip_buf and uip_appdata.

• u16_t uip_udpchksum (void)

Calculate the UDP checksum of the packet in uip_buf and uip_appdata.

• void uip_setipid (u16_t id)

uIP initialization function.

• void uip_add32 (u8_t *op32, u16_t op16)

Carry out a 32-bit addition.

• void uip_init (void)

uIP initialization function.

• uip_conn * uip_connect (uip_ipaddr_t *ripaddr, u16_t rport)

Connect to a remote host using TCP.

• uip_udp_conn * uip_udp_new (uip_ipaddr_t *ripaddr, u16_t rport)

Set up a new UDP connection.

• void uip_unlisten (u16_t port)

Stop listening to the specified port.

• void uip_listen (u16_t port)

Start listening to the specified port.

• u16_t htons (u16_t val)

Convert 16-bit quantity from host byte order to network byte order.

• void uip_send (const void *data, int len)

Send data on the current connection.

Variables

• void * uip_appdata

Pointer to the application data in the packet buffer.

• uip_conn * uip_conn

Pointer to the current TCP connection.

- uip_conn uip_conns [UIP_CONNS]
- uip_udp_conn * uip_udp_conn

The current UDP connection.

- uip_udp_conn uip_udp_conns [UIP_UDP_CONNS]
- uip_stats uip_stat

The uIP TCP/IP statistics.

- u8_t uip_flags
- uip_ipaddr_t uip_hostaddr
- uip_ipaddr_t uip_netmask
- uip_ipaddr_t uip_draddr
- uip_ipaddr_t uip_hostaddr
- uip_ipaddr_t uip_draddr
- uip_ipaddr_t uip_netmask
- $uip_eth_addr uip_ethaddr = \{\{0,0,0,0,0,0,0\}\}$
- u8_t uip_buf [UIP_BUFSIZE+2]

The uIP packet buffer.

• void * uip_appdata

Pointer to the application data in the packet buffer.

- void * uip_sappdata
- u16_t uip_len

The length of the packet in the uip_buf buffer.

- u16 tuip slen
- u8_t uip_flags
- uip_conn * uip_conn

Pointer to the current TCP connection.

- uip_conn uip_conns [UIP_CONNS]
- u16_t uip_listenports [UIP_LISTENPORTS]
- uip_udp_conn * uip_udp_conn

The current UDP connection.

- uip_udp_conn uip_udp_conns [UIP_UDP_CONNS]
- u8_t uip_acc32 [4]

4-byte array used for the 32-bit sequence number calculations.

6.9.2 Define Documentation

6.9.2.1 #define UIP_APPDATA_SIZE

The buffer size available for user data in the uip_buf buffer.

This macro holds the available size for user data in the uip_buf buffer. The macro is intended to be used for checking bounds of available user data.

Example:

```
snprintf(uip_appdata, UIP_APPDATA_SIZE, "%u\n", i);
```

Definition at line 1506 of file uip.h.

6.9.3 Function Documentation

6.9.3.1 **u16_t** htons (**u16_t** *val*)

Convert 16-bit quantity from host byte order to network byte order.

This function is primarily used for converting variables from host byte order to network byte order. For converting constants to network byte order, use the HTONS() macro instead.

Definition at line 1882 of file uip.c.

References HTONS.

Referenced by uip_chksum(), uip_connect(), uip_ipchksum(), uip_udp_new(), and webclient_get().

6.9.3.2 void uip_add32 ($u8_t * op32$, $u16_t op16$)

Carry out a 32-bit addition.

Because not all architectures for which uIP is intended has native 32-bit arithmetic, uIP uses an external C function for doing the required 32-bit additions in the TCP protocol processing. This function should add the two arguments and place the result in the global variable uip_acc32.

Note:

The 32-bit integer pointed to by the op32 parameter and the result in the uip_acc32 variable are in network byte order (big endian).

Parameters:

op32 A pointer to a 4-byte array representing a 32-bit integer in network byte order (big endian).

op16 A 16-bit integer in host byte order.

Definition at line 249 of file uip.c.

Referenced by uip_split_output().

6.9.3.3 $u16_t uip_chksum (u16_t * buf, u16_t len)$

Calculate the Internet checksum over a buffer.

The Internet checksum is the one's complement of the one's complement sum of all 16-bit words in the buffer.

See RFC1071.

Parameters:

buf A pointer to the buffer over which the checksum is to be computed.

len The length of the buffer over which the checksum is to be computed.

Returns:

The Internet checksum of the buffer.

Definition at line 311 of file uip.c.

References htons().

6.9.3.4 struct uip_conn* uip_connect (uip_ipaddr_t * ripaddr, u16_t port)

Connect to a remote host using TCP.

This function is used to start a new connection to the specified port on the specied host. It allocates a new connection identifier, sets the connection to the SYN_SENT state and sets the retransmission timer to 0. This will cause a TCP SYN segment to be sent out the next time this connection is periodically processed, which usually is done within 0.5 seconds after the call to uip_connect().

Note:

This function is avaliable only if support for active open has been configured by defining UIP_-ACTIVE_OPEN to 1 in uipopt.h.

Since this function requires the port number to be in network byte order, a conversion using HTONS() or htons() is necessary.

```
uip_ipaddr_t ipaddr;
uip_ipaddr(&ipaddr, 192,168,1,2);
uip_connect(&ipaddr, HTONS(80));
```

Parameters:

ripaddr The IP address of the remote hot.

port A 16-bit port number in network byte order.

Returns

A pointer to the uIP connection identifier for the new connection, or NULL if no connection could be allocated.

Definition at line 407 of file uip.c.

References htons(), uip_conn::lport, uip_conn::tcpstateflags, UIP_CLOSED, uip_conn, uip_conns, and UIP_CONNS.

Referenced by smtp_send(), and webclient_get().

6.9.3.5 void uip_init (void)

uIP initialization function.

This function should be called at boot up to initilize the uIP TCP/IP stack.

Definition at line 379 of file uip.c.

References UIP_LISTENPORTS.

6.9.3.6 u16_t uip_ipchksum (void)

Calculate the IP header checksum of the packet header in uip_buf.

The IP header checksum is the Internet checksum of the 20 bytes of the IP header.

Returns:

The IP header checksum of the IP header in the uip_buf buffer.

Definition at line 318 of file uip.c.

References DEBUG_PRINTF, htons(), UIP_IPH_LEN, and UIP_LLH_LEN.

Referenced by uip_process(), and uip_split_output().

6.9.3.7 void uip_listen (u16_t port)

Start listening to the specified port.

Note:

Since this function expects the port number in network byte order, a conversion using HTONS() or htons() is necessary.

```
uip_listen(HTONS(80));
```

Parameters:

port A 16-bit port number in network byte order.

Definition at line 529 of file uip.c.

References UIP LISTENPORTS.

Referenced by hello_world_init(), httpd_init(), and telnetd_init().

6.9.3.8 void uip_send (const void * data, int len)

Send data on the current connection.

This function is used to send out a single segment of TCP data. Only applications that have been invoked by uIP for event processing can send data.

The amount of data that actually is sent out after a call to this funcion is determined by the maximum amount of data TCP allows. uIP will automatically crop the data so that only the appropriate amount of data is sent. The function uip_mss() can be used to query uIP for the amount of data that actually will be sent.

Note:

This function does not guarantee that the sent data will arrive at the destination. If the data is lost in the network, the application will be invoked with the uip_rexmit() event being set. The application will then have to resend the data using this function.

Parameters:

data A pointer to the data which is to be sent.

len The maximum amount of data bytes to be sent.

Definition at line 1888 of file uip.c.

References uip_sappdata, and uip_slen.

6.9.3.9 void uip_setipid (u16_t id)

uIP initialization function.

This function may be used at boot time to set the initial ip_id.

Definition at line 181 of file uip.c.

6.9.3.10 u16_t uip_tcpchksum (void)

Calculate the TCP checksum of the packet in uip_buf and uip_appdata.

The TCP checksum is the Internet checksum of data contents of the TCP segment, and a pseudo-header as defined in RFC793.

Returns:

The TCP checksum of the TCP segment in uip_buf and pointed to by uip_appdata.

Definition at line 364 of file uip.c.

References UIP_PROTO_TCP.

Referenced by uip_split_output().

6.9.3.11 struct uip_udp_conn* uip_udp_new (uip_ipaddr_t * ripaddr, u16_t rport)

Set up a new UDP connection.

This function sets up a new UDP connection. The function will automatically allocate an unused local port for the new connection. However, another port can be chosen by using the uip_udp_bind() call, after the uip_udp_new() function has been called.

Example:

```
uip_ipaddr_t addr;
struct uip_udp_conn *c;
uip_ipaddr(&addr, 192,168,2,1);
c = uip_udp_new(&addr, HTONS(12345));
if(c != NULL) {
   uip_udp_bind(c, HTONS(12344));
}
```

Parameters:

ripaddr The IP address of the remote host.

rport The remote port number in network byte order.

Returns:

The uip_udp_conn structure for the new connection or NULL if no connection could be allocated.

Definition at line 473 of file uip.c.

References htons(), uip_udp_conn::lport, uip_udp_conn, uip_udp_conns, and UIP_UDP_CONNS.

Referenced by resolv_conf().

6.9.3.12 u16_t uip_udpchksum (void)

Calculate the UDP checksum of the packet in uip_buf and uip_appdata.

The UDP checksum is the Internet checksum of data contents of the UDP segment, and a pseudo-header as defined in RFC768.

Returns:

The UDP checksum of the UDP segment in uip buf and pointed to by uip appdata.

Referenced by uip_process().

6.9 The uIP TCP/IP stack 71

6.9.3.13 void uip_unlisten (u16_t port)

Stop listening to the specified port.

Note:

Since this function expects the port number in network byte order, a conversion using HTONS() or htons() is necessary.

```
uip_unlisten(HTONS(80));
```

Parameters:

port A 16-bit port number in network byte order.

Definition at line 518 of file uip.c.

References UIP_LISTENPORTS.

6.9.4 Variable Documentation

6.9.4.1 void* uip_appdata

Pointer to the application data in the packet buffer.

This pointer points to the application data when the application is called. If the application wishes to send data, the application may use this space to write the data into before calling uip_send().

Definition at line 143 of file uip.c.

Referenced by uip_process(), and uip_split_output().

6.9.4.2 void* uip_appdata

Pointer to the application data in the packet buffer.

This pointer points to the application data when the application is called. If the application wishes to send data, the application may use this space to write the data into before calling uip_send().

Examples:

dhcpc.c, resolv.c, telnetd.c, and webclient.c.

Definition at line 143 of file uip.c.

Referenced by uip_process(), and uip_split_output().

6.9.4.3 u8_t uip_buf[UIP_BUFSIZE+2]

The uIP packet buffer.

The uip_buf array is used to hold incoming and outgoing packets. The device driver should place incoming data into this buffer. When sending data, the device driver should read the link level headers and the TCP/IP headers from this buffer. The size of the link level headers is configured by the UIP_LLH_LEN define.

Note:

The application data need not be placed in this buffer, so the device driver must read it from the place pointed to by the uip_appdata pointer as illustrated by the following example:

```
void
devicedriver_send(void)
{
   hwsend(&uip_buf[0], UIP_LLH_LEN);
   if(uip_len <= UIP_LLH_LEN + UIP_TCPIP_HLEN) {
     hwsend(&uip_buf[UIP_LLH_LEN], uip_len - UIP_LLH_LEN);
   } else {
     hwsend(&uip_buf[UIP_LLH_LEN], UIP_TCPIP_HLEN);
     hwsend(uip_appdata, uip_len - UIP_TCPIP_HLEN - UIP_LLH_LEN);
   }
}</pre>
```

Definition at line 139 of file uip.c.

Referenced by uip_process().

6.9.4.4 struct uip_conn* uip_conn

Pointer to the current TCP connection.

The uip_conn pointer can be used to access the current TCP connection.

Definition at line 163 of file uip.c.

Referenced by uip_connect().

6.9.4.5 struct uip_conn* uip_conn

Pointer to the current TCP connection.

The uip_conn pointer can be used to access the current TCP connection.

Examples:

hello-world.c, smtp.c, and webclient.c.

Definition at line 163 of file uip.c.

Referenced by uip_connect().

6.9.4.6 **u16_t uip_len**

The length of the packet in the uip_buf buffer.

The global variable uip_len holds the length of the packet in the uip_buf buffer.

When the network device driver calls the uIP input function, uip_len should be set to the length of the packet in the uip_buf buffer.

When sending packets, the device driver should use the contents of the uip_len variable to determine the length of the outgoing packet.

Definition at line 155 of file uip.c.

Referenced by uip_arp_arpin(), uip_process(), and uip_split_output().

6.9.4.7 struct uip_stats uip_stat

The uIP TCP/IP statistics.

6.9 The uIP TCP/IP stack 73

This is the variable in which the uIP TCP/IP statistics are gathered. Referenced by uip_process().

6.10 Architecture specific uIP functions

6.10.1 Detailed Description

The functions in the architecture specific module implement the IP check sum and 32-bit additions.

The IP checksum calculation is the most computationally expensive operation in the TCP/IP stack and it therefore pays off to implement this in efficient assembler. The purpose of the uip-arch module is to let the checksum functions to be implemented in architecture specific assembler.

Files

• file uip_arch.h

Declarations of architecture specific functions.

Functions

```
• void uip_add32 (u8_t *op32, u16_t op16)

Carry out a 32-bit addition.
```

```
• u16_t uip_chksum (u16_t *buf, u16_t len)

Calculate the Internet checksum over a buffer.
```

• u16_t uip_ipchksum (void)

Calculate the IP header checksum of the packet header in uip_buf.

• u16_t uip_tcpchksum (void)

Calculate the TCP checksum of the packet in uip_buf and uip_appdata.

Variables

• u8_t uip_acc32 [4]

4-byte array used for the 32-bit sequence number calculations.

6.10.2 Function Documentation

```
6.10.2.1 void uip_add32 (u8_t * op32, u16_t op16)
```

Carry out a 32-bit addition.

Because not all architectures for which uIP is intended has native 32-bit arithmetic, uIP uses an external C function for doing the required 32-bit additions in the TCP protocol processing. This function should add the two arguments and place the result in the global variable uip_acc32.

Note:

The 32-bit integer pointed to by the op32 parameter and the result in the uip_acc32 variable are in network byte order (big endian).

op32 A pointer to a 4-byte array representing a 32-bit integer in network byte order (big endian).

op16 A 16-bit integer in host byte order.

Definition at line 249 of file uip.c.

Referenced by uip_split_output().

6.10.2.2 $u16_t uip_chksum (u16_t * buf, u16_t len)$

Calculate the Internet checksum over a buffer.

The Internet checksum is the one's complement of the one's complement sum of all 16-bit words in the buffer.

See RFC1071.

Note:

This function is not called in the current version of uIP, but future versions might make use of it.

Parameters:

buf A pointer to the buffer over which the checksum is to be computed.

len The length of the buffer over which the checksum is to be computed.

Returns:

The Internet checksum of the buffer.

6.10.2.3 u16_t uip_ipchksum (void)

Calculate the IP header checksum of the packet header in uip_buf.

The IP header checksum is the Internet checksum of the 20 bytes of the IP header.

Returns:

The IP header checksum of the IP header in the uip_buf buffer.

6.10.2.4 u16_t uip_tcpchksum (void)

Calculate the TCP checksum of the packet in uip_buf and uip_appdata.

The TCP checksum is the Internet checksum of data contents of the TCP segment, and a pseudo-header as defined in RFC793.

Note:

The uip_appdata pointer that points to the packet data may point anywhere in memory, so it is not possible to simply calculate the Internet checksum of the contents of the uip_buf buffer.

Returns:

The TCP checksum of the TCP segment in uip_buf and pointed to by uip_appdata.

6.11 uIP Address Resolution Protocol

6.11.1 Detailed Description

The Address Resolution Protocol ARP is used for mapping between IP addresses and link level addresses such as the Ethernet MAC addresses.

ARP uses broadcast queries to ask for the link level address of a known IP address and the host which is configured with the IP address for which the query was meant, will respond with its link level address.

Note:

This ARP implementation only supports Ethernet.

Files

• file uip_arp.h

Macros and definitions for the ARP module.

• file uip_arp.c

Implementation of the ARP Address Resolution Protocol.

Data Structures

• struct uip_eth_hdr

The Ethernet header.

Defines

- #define UIP_ETHTYPE_ARP 0x0806
- #define UIP_ETHTYPE_IP 0x0800
- #define UIP_ETHTYPE_IP6 0x86dd
- #define uip_arp_ipin()
- #define ARP_REQUEST 1
- #define ARP_REPLY 2
- #define ARP_HWTYPE_ETH 1
- #define BUF ((struct arp_hdr *)&uip_buf[0])
- #define IPBUF ((struct ethip_hdr *)&uip_buf[0])

Functions

• void uip_arp_init (void)

Initialize the ARP module.

• void uip_arp_arpin (void)

ARP processing for incoming ARP packets.

• void uip_arp_out (void)

Prepend Ethernet header to an outbound IP packet and see if we need to send out an ARP request.

void uip_arp_timer (void)
 Periodic ARP processing function.

Variables

• uip_eth_addr uip_ethaddr

6.11.2 Function Documentation

6.11.2.1 void uip_arp_arpin (void)

ARP processing for incoming ARP packets.

This function should be called by the device driver when an ARP packet has been received. The function will act differently depending on the ARP packet type: if it is a reply for a request that we previously sent out, the ARP cache will be filled in with the values from the ARP reply. If the incoming ARP packet is an ARP request for our IP address, an ARP reply packet is created and put into the uip_buf[] buffer.

When the function returns, the value of the global variable uip_len indicates whether the device driver should send out a packet or not. If uip_len is zero, no packet should be sent. If uip_len is non-zero, it contains the length of the outbound packet that is present in the uip_buf[] buffer.

This function expects an ARP packet with a prepended Ethernet header in the uip_buf[] buffer, and the length of the packet in the global variable uip_len.

Examples:

example-mainloop-with-arp.c.

Definition at line 278 of file uip_arp.c.

References uip_eth_addr::addr, ARP_REPLY, ARP_REQUEST, BUF, HTONS, uip_ethaddr, UIP_ETHTYPE_ARP, uip_hostaddr, uip_ipaddr_cmp, and uip_len.

6.11.2.2 void uip_arp_out (void)

Prepend Ethernet header to an outbound IP packet and see if we need to send out an ARP request.

This function should be called before sending out an IP packet. The function checks the destination IP address of the IP packet to see what Ethernet MAC address that should be used as a destination MAC address on the Ethernet.

If the destination IP address is in the local network (determined by logical ANDing of netmask and our IP address), the function checks the ARP cache to see if an entry for the destination IP address is found. If so, an Ethernet header is prepended and the function returns. If no ARP cache entry is found for the destination IP address, the packet in the uip_buf[] is replaced by an ARP request packet for the IP address. The IP packet is dropped and it is assumed that they higher level protocols (e.g., TCP) eventually will retransmit the dropped packet.

If the destination IP address is not on the local network, the IP address of the default router is used instead.

When the function returns, a packet is present in the uip_buf[] buffer, and the length of the packet is in the global variable uip_len.

Examples:

example-mainloop-with-arp.c.

Definition at line 354 of file uip_arp.c.

References uip_eth_addr::addr, IPBUF, UIP_ARPTAB_SIZE, uip_draddr, uip_hostaddr, uip_ipaddr_cmp, uip_ipaddr_copy, and uip_ipaddr_maskcmp.

6.11.2.3 void uip_arp_timer (void)

Periodic ARP processing function.

This function performs periodic timer processing in the ARP module and should be called at regular intervals. The recommended interval is 10 seconds between the calls.

Examples:

example-mainloop-with-arp.c.

Definition at line 142 of file uip_arp.c.

References UIP_ARP_MAXAGE, and UIP_ARPTAB_SIZE.

6.12 Configuration options for uIP

6.12.1 Detailed Description

uIP is configured using the per-project configuration file uipopt.h.

This file contains all compile-time options for uIP and should be tweaked to match each specific project. The uIP distribution contains a documented example "uipopt.h" that can be copied and modified for each project.

Note:

Most of the configuration options in the uipopt.h should not be changed, but rather the per-project uip-conf.h file.

Files

• file uip-conf.h

An example uIP configuration file.

• file uipopt.h

Configuration options for uIP.

Project-specific configuration options

uIP has a number of configuration options that can be overridden for each project. These are kept in a project-specific uip-conf.h file and all configuration names have the prefix UIP_CONF.

• #define UIP_CONF_MAX_CONNECTIONS

Maximum number of TCP connections.

• #define UIP_CONF_MAX_LISTENPORTS

Maximum number of listening TCP ports.

• #define UIP_CONF_BUFFER_SIZE uIP buffer size.

• #define UIP_CONF_BYTE_ORDER

• #define UIP_CONF_LOGGING

Logging on or off.

CPU byte order.

• #define UIP CONF UDP

UDP support on or off.

• #define UIP_CONF_UDP_CHECKSUMS

UDP checksums on or off.

• #define UIP_CONF_STATISTICS

uIP statistics on or off

```
• typedef uint8_t u8_t
8 bit datatype
```

- typedef uint16_t u16_t

 16 bit datatype
- typedef unsigned short uip_stats_t Statistics datatype.

Static configuration options

These configuration options can be used for setting the IP address settings statically, but only if UIP_-FIXEDADDR is set to 1. The configuration options for a specific node includes IP address, netmask and default router as well as the Ethernet address. The netmask, default router and Ethernet address are appliciable only if uIP should be run over Ethernet.

All of these should be changed to suit your project.

• #define UIP_FIXEDADDR

Determines if uIP should use a fixed IP address or not.

• #define UIP_PINGADDRCONF

Ping IP address asignment.

• #define UIP FIXEDETHADDR

Specifies if the uIP ARP module should be compiled with a fixed Ethernet MAC address or not.

IP configuration options

• #define UIP_TTL 64

The IP TTL (time to live) of IP packets sent by uIP.

• #define UIP REASSEMBLY

Turn on support for IP packet reassembly.

• #define UIP_REASS_MAXAGE 40

The maximum time an IP fragment should wait in the reassembly buffer before it is dropped.

UDP configuration options

• #define UIP_UDP

Toggles wether UDP support should be compiled in or not.

• #define UIP_UDP_CHECKSUMS

Toggles if UDP checksums should be used or not.

• #define UIP_UDP_CONNS

The maximum amount of concurrent UDP connections.

TCP configuration options

• #define UIP ACTIVE OPEN

Determines if support for opening connections from uIP should be compiled in.

• #define UIP CONNS

The maximum number of simultaneously open TCP connections.

• #define UIP_LISTENPORTS

The maximum number of simultaneously listening TCP ports.

• #define UIP_URGDATA

Determines if support for TCP urgent data notification should be compiled in.

• #define UIP RTO 3

The initial retransmission timeout counted in timer pulses.

• #define UIP_MAXRTX 8

The maximum number of times a segment should be retransmitted before the connection should be aborted.

• #define UIP_MAXSYNRTX 5

The maximum number of times a SYN segment should be retransmitted before a connection request should be deemed to have been unsuccessful.

• #define UIP_TCP_MSS (UIP_BUFSIZE - UIP_LLH_LEN - UIP_TCPIP_HLEN)

The TCP maximum segment size.

• #define UIP RECEIVE WINDOW

The size of the advertised receiver's window.

• #define UIP_TIME_WAIT_TIMEOUT 120

How long a connection should stay in the TIME_WAIT state.

ARP configuration options

• #define UIP_ARPTAB_SIZE

The size of the ARP table.

• #define UIP_ARP_MAXAGE 120

The maxium age of ARP table entries measured in 10ths of seconds.

General configuration options

• #define UIP_BUFSIZE

The size of the uIP packet buffer.

• #define UIP_STATISTICS

Determines if statistics support should be compiled in.

• #define UIP_LOGGING

Determines if logging of certain events should be compiled in.

• #define UIP BROADCAST

Broadcast support.

• #define UIP LLH LEN

The link level header length.

• void uip_log (char *msg)

Print out a uIP log message.

CPU architecture configuration

The CPU architecture configuration is where the endianess of the CPU on which uIP is to be run is specified. Most CPUs today are little endian, and the most notable exception are the Motorolas which are big endian. The BYTE ORDER macro should be changed to reflect the CPU architecture on which uIP is to be run.

• #define UIP_BYTE_ORDER

The byte order of the CPU architecture on which uIP is to be run.

Appication specific configurations

An uIP application is implemented using a single application function that is called by uIP whenever a TCP/IP event occurs. The name of this function must be registered with uIP at compile time using the UIP_APPCALL definition.

uIP applications can store the application state within the uip_conn structure by specifying the type of the application structure by typedef:ing the type uip_tcp_appstate_t and uip_udp_appstate_t.

The file containing the definitions must be included in the uipopt.h file.

The following example illustrates how this can look.

```
void httpd_appcall(void);
#define UIP_APPCALL httpd_appcall

struct httpd_state {
   u8_t state;
   u16_t count;
   char *dataptr;
   char *script;
};
typedef struct httpd_state uip_tcp_appstate_t
```

#define UIP_APPCALL smtp_appcall

The name of the application function that uIP should call in response to TCP/IP events.

• typedef smtp_state uip_tcp_appstate_t

The type of the application state that is to be stored in the uip_conn structure.

• typedef int uip_udp_appstate_t

The type of the application state that is to be stored in the uip_conn structure.

Defines

- #define UIP LITTLE ENDIAN 3412
- #define UIP_BIG_ENDIAN 1234

6.12.2 Define Documentation

6.12.2.1 #define UIP_ACTIVE_OPEN

Determines if support for opening connections from uIP should be compiled in.

If the applications that are running on top of uIP for this project do not need to open outgoing TCP connections, this configration option can be turned off to reduce the code size of uIP.

Definition at line 233 of file uipopt.h.

6.12.2.2 #define UIP_ARP_MAXAGE 120

The maxium age of ARP table entries measured in 10ths of seconds.

An UIP_ARP_MAXAGE of 120 corresponds to 20 minutes (BSD default).

Definition at line 358 of file uipopt.h.

Referenced by uip_arp_timer().

6.12.2.3 #define UIP_ARPTAB_SIZE

The size of the ARP table.

This option should be set to a larger value if this uIP node will have many connections from the local network.

Definition at line 349 of file uipopt.h.

Referenced by uip_arp_init(), uip_arp_out(), and uip_arp_timer().

6.12.2.4 #define UIP_BROADCAST

Broadcast support.

This flag configures IP broadcast support. This is useful only together with UDP.

Definition at line 423 of file uipopt.h.

6.12.2.5 #define UIP_BUFSIZE

The size of the uIP packet buffer.

The uIP packet buffer should not be smaller than 60 bytes, and does not need to be larger than 1500 bytes. Lower size results in lower TCP throughput, larger size results in higher TCP throughput.

Definition at line 379 of file uipopt.h.

Referenced by uip_split_output().

6.12.2.6 #define UIP_BYTE_ORDER

The byte order of the CPU architecture on which uIP is to be run.

This option can be either BIG_ENDIAN (Motorola byte order) or LITTLE_ENDIAN (Intel byte order).

Definition at line 475 of file uipopt.h.

6.12.2.7 #define UIP_CONNS

The maximum number of simultaneously open TCP connections.

Since the TCP connections are statically allocated, turning this configuration knob down results in less RAM used. Each TCP connection requires approximatly 30 bytes of memory.

Examples:

example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 245 of file uipopt.h.

Referenced by uip_connect().

6.12.2.8 #define UIP FIXEDADDR

Determines if uIP should use a fixed IP address or not.

If uIP should use a fixed IP address, the settings are set in the uipopt.h file. If not, the macros uip_sethostaddr(), uip_setdraddr() and uip_setnetmask() should be used instead.

Definition at line 97 of file uipopt.h.

6.12.2.9 #define UIP_FIXEDETHADDR

Specifies if the uIP ARP module should be compiled with a fixed Ethernet MAC address or not.

If this configuration option is 0, the macro uip_setethaddr() can be used to specify the Ethernet address at run-time.

Definition at line 127 of file uipopt.h.

6.12.2.10 #define UIP_LISTENPORTS

The maximum number of simultaneously listening TCP ports.

Each listening TCP port requires 2 bytes of memory.

Definition at line 259 of file uipopt.h.

Referenced by uip_init(), uip_listen(), and uip_unlisten().

6.12.2.11 #define UIP_LLH_LEN

The link level header length.

This is the offset into the uip_buf where the IP header can be found. For Ethernet, this should be set to 14. For SLIP, this should be set to 0.

Definition at line 448 of file uipopt.h.

Referenced by uip_ipchksum(), uip_process(), and uip_split_output().

6.12.2.12 #define UIP_LOGGING

Determines if logging of certain events should be compiled in.

This is useful mostly for debugging. The function uip_log() must be implemented to suit the architecture of the project, if logging is turned on.

Definition at line 408 of file uipopt.h.

6.12.2.13 #define UIP_MAXRTX 8

The maximum number of times a segment should be retransmitted before the connection should be aborted.

This should not be changed.

Definition at line 288 of file uipopt.h.

Referenced by uip_process().

6.12.2.14 #define UIP_MAXSYNRTX 5

The maximum number of times a SYN segment should be retransmitted before a connection request should be deemed to have been unsuccessful.

This should not need to be changed.

Definition at line 297 of file uipopt.h.

Referenced by uip_process().

6.12.2.15 #define UIP_PINGADDRCONF

Ping IP address asignment.

uIP uses a "ping" packets for setting its own IP address if this option is set. If so, uIP will start with an empty IP address and the destination IP address of the first incoming "ping" (ICMP echo) packet will be used for setting the hosts IP address.

Note:

This works only if UIP_FIXEDADDR is 0.

Definition at line 114 of file uipopt.h.

6.12.2.16 #define UIP_REASSEMBLY

Turn on support for IP packet reassembly.

uIP supports reassembly of fragmented IP packets. This features requires an additional amount of RAM to hold the reassembly buffer and the reassembly code size is approximately 700 bytes. The reassembly buffer is of the same size as the uip_buf buffer (configured by UIP_BUFSIZE).

Note:

IP packet reassembly is not heavily tested.

Definition at line 156 of file uipopt.h.

6.12.2.17 #define UIP_RECEIVE_WINDOW

The size of the advertised receiver's window.

Should be set low (i.e., to the size of the uip_buf buffer) is the application is slow to process incoming data, or high (32768 bytes) if the application processes data quickly.

Definition at line 317 of file uipopt.h.

6.12.2.18 #define UIP_RTO 3

The initial retransmission timeout counted in timer pulses.

This should not be changed.

Definition at line 280 of file uipopt.h.

Referenced by uip_process().

6.12.2.19 #define UIP_STATISTICS

Determines if statistics support should be compiled in.

The statistics is useful for debugging and to show the user.

Definition at line 393 of file uipopt.h.

6.12.2.20 #define UIP_TCP_MSS (UIP_BUFSIZE - UIP_LLH_LEN - UIP_TCPIP_HLEN)

The TCP maximum segment size.

This is should not be to set to more than UIP_BUFSIZE - UIP_LLH_LEN - UIP_TCPIP_HLEN.

Definition at line 305 of file uipopt.h.

6.12.2.21 #define UIP_TIME_WAIT_TIMEOUT 120

How long a connection should stay in the TIME_WAIT state.

This configiration option has no real implication, and it should be left untouched.

Definition at line 328 of file uipopt.h.

Referenced by uip_process().

6.12.2.22 #define UIP_TTL 64

The IP TTL (time to live) of IP packets sent by uIP.

This should normally not be changed.

Definition at line 141 of file uipopt.h.

6.12.2.23 #define UIP_UDP_CHECKSUMS

Toggles if UDP checksums should be used or not.

Note:

Support for UDP checksums is currently not included in uIP, so this option has no function.

Definition at line 195 of file uipopt.h.

6.12.2.24 #define UIP_URGDATA

Determines if support for TCP urgent data notification should be compiled in.

Urgent data (out-of-band data) is a rarely used TCP feature that very seldom would be required.

Definition at line 273 of file uipopt.h.

6.12.3 Typedef Documentation

6.12.3.1 typedef uint16_t u16_t

16 bit datatype

This typedef defines the 16-bit type used throughout uIP.

Examples:

dhepe.e, dhepe.h, resolv.e, resolv.h, smtp.e, smtp.h, telnetd.e, and uip-conf.h.

Definition at line 76 of file uip-conf.h.

6.12.3.2 typedef uint8_t u8_t

8 bit datatype

This typedef defines the 8-bit type used throughout uIP.

Examples:

dhcpc.c, dhcpc.h, resolv.c, smtp.h, telnetd.c, telnetd.h, and uip-conf.h.

Definition at line 67 of file uip-conf.h.

6.12.3.3 typedef unsigned short uip_stats_t

Statistics datatype.

This typedef defines the dataype used for keeping statistics in uIP.

Definition at line 86 of file uip-conf.h.

6.12.3.4 typedef uip_tcp_appstate_t

The type of the application state that is to be stored in the uip_conn structure.

This usually is typedef:ed to a struct holding application state information.

Examples:

smtp.h, telnetd.h, and webclient.h.

Definition at line 98 of file smtp.h.

6.12.3.5 typedef uip_udp_appstate_t

The type of the application state that is to be stored in the uip_conn structure.

This usually is typedef:ed to a struct holding application state information.

Examples:

dhcpc.h.

Definition at line 47 of file resolv.h.

6.12.4 Function Documentation

6.12.4.1 void uip_log (char * *msg)*

Print out a uIP log message.

This function must be implemented by the module that uses uIP, and is called by uIP whenever a log message is generated.

6.13 uIP TCP throughput booster hack

6.13.1 Detailed Description

The basic uIP TCP implementation only allows each TCP connection to have a single TCP segment in flight at any given time.

Because of the delayed ACK algorithm employed by most TCP receivers, uIP's limit on the amount of in-flight TCP segments seriously reduces the maximum achievable throughput for sending data from uIP.

The uip-split module is a hack which tries to remedy this situation. By splitting maximum sized outgoing TCP segments into two, the delayed ACK algorithm is not invoked at TCP receivers. This improves the throughput when sending data from uIP by orders of magnitude.

The uip-split module uses the uip-fw module (uIP IP packet forwarding) for sending packets. Therefore, the uip-fw module must be set up with the appropriate network interfaces for this module to work.

Files

• file uip-split.h

Module for splitting outbound TCP segments in two to avoid the delayed ACK throughput degradation.

Functions

void uip_split_output (void)
 Handle outgoing packets.

6.13.2 Function Documentation

6.13.2.1 void uip_split_output (void)

Handle outgoing packets.

This function inspects an outgoing packet in the uip_buf buffer and sends it out using the uip_fw_output() function. If the packet is a full-sized TCP segment it will be split into two segments and transmitted separately. This function should be called instead of the actual device driver output function, or the uip_fw_output() function.

The headers of the outgoing packet is assumed to be in the uip_buf buffer and the payload is assumed to be wherever uip_appdata points. The length of the outgoing packet is assumed to be in the uip_len variable.

Definition at line 49 of file uip-split.c.

References BUF, uip_acc32, uip_add32(), uip_appdata, UIP_BUFSIZE, uip_ipchksum(), UIP_IPH_LEN, uip_len, UIP_LLH_LEN, UIP_PROTO_TCP, uip_tcpchksum(), and UIP_TCPIP_HLEN.

6.14 Local continuations

6.14.1 Detailed Description

Local continuations form the basis for implementing protothreads.

A local continuation can be *set* in a specific function to capture the state of the function. After a local continuation has been set can be *resumed* in order to restore the state of the function at the point where the local continuation was set.

Files

• file lc.h

Local continuations.

• file lc-switch.h

Implementation of local continuations based on switch() statment.

• file lc-addrlabels.h

Implementation of local continuations based on the "Labels as values" feature of gcc.

Defines

```
#define __LC_SWTICH_H__
#define LC_INIT(s) s = 0;
#define LC_RESUME(s) switch(s) { case 0:
#define LC_SET(s) s = __LINE__; case __LINE__:
#define LC_END(s) }
#define LC_INIT(s) s = NULL
#define LC_RESUME(s)
#define LC_SET(s) do { ({ __label__ resume; resume: (s) = &&resume; }); }while(0)
#define LC_END(s)
```

Typedefs

- typedef unsigned short lc_t
- typedef void * lc_t

6.15 Timer library 91

6.15 Timer library

6.15.1 Detailed Description

The timer library provides functions for setting, resetting and restarting timers, and for checking if a timer has expired.

An application must "manually" check if its timers have expired; this is not done automatically.

A timer is declared as a struct timer and all access to the timer is made by a pointer to the declared timer.

Note:

The timer library uses the Clock library to measure time. Intervals should be specified in the format used by the clock library.

Files

• file timer.h

Timer library header file.

• file timer.c

Timer library implementation.

Data Structures

• struct timer

A timer.

Functions

• void timer_set (struct timer *t, clock_time_t interval)

Set a timer.

• void timer_reset (struct timer *t)

Reset the timer with the same interval.

• void timer_restart (struct timer *t)

Restart the timer from the current point in time.

• int timer_expired (struct timer *t)

Check if a timer has expired.

6.15.2 Function Documentation

6.15.2.1 int timer_expired (struct timer *t)

Check if a timer has expired.

This function tests if a timer has expired and returns true or false depending on its status.

Parameters:

t A pointer to the timer

Returns:

Non-zero if the timer has expired, zero otherwise.

Examples:

dhcpc.c, example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 121 of file timer.c.

References clock_time(), interval, and start.

6.15.2.2 void timer_reset (struct timer *t)

Reset the timer with the same interval.

This function resets the timer with the same interval that was given to the timer_set() function. The start point of the interval is the exact time that the timer last expired. Therefore, this function will cause the timer to be stable over time, unlike the timer_rester() function.

Parameters:

t A pointer to the timer.

See also:

timer_restart()

Examples:

example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 84 of file timer.c.

References interval, and start.

6.15.2.3 void timer_restart (struct timer * t)

Restart the timer from the current point in time.

This function restarts a timer with the same interval that was given to the timer_set() function. The timer will start at the current time.

Note:

A periodic timer will drift if this function is used to reset it. For preioric timers, use the timer_reset() function instead.

Parameters:

t A pointer to the timer.

6.15 Timer library 93

See also:

timer_reset()

Definition at line 104 of file timer.c.

References clock_time(), and start.

6.15.2.4 void timer_set (struct timer * t, clock_time_t interval)

Set a timer.

This function is used to set a timer for a time sometime in the future. The function timer_expired() will evaluate to true after the timer has expired.

Parameters:

t A pointer to the timer

interval The interval before the timer expires.

Examples:

dhcpc.c, example-mainloop-with-arp.c, and example-mainloop-without-arp.c.

Definition at line 64 of file timer.c.

References clock_time(), interval, and start.

6.16 Clock interface

6.16.1 Detailed Description

The clock interface is the interface between the timer library and the platform specific clock functionality.

The clock interface must be implemented for each platform that uses the timer library.

The clock interface does only one this: it measures time. The clock interface provides a macro, CLOCK_-SECOND, which corresponds to one second of system time.

See also:

Timer library

Defines

• #define CLOCK_SECOND

A second, measured in system clock time.

Functions

• void clock_init (void)

Initialize the clock library.

• clock_time_t clock_time (void)

Get the current clock time.

6.16.2 Function Documentation

6.16.2.1 void clock_init (void)

Initialize the clock library.

This function initializes the clock library and should be called from the main() function of the system.

6.16.2.2 clock_time_t clock_time (void)

Get the current clock time.

This function returns the current system clock time.

Returns:

The current clock time, measured in system ticks.

Referenced by timer_expired(), timer_restart(), and timer_set().

6.17 Protosockets library

6.17.1 Detailed Description

The protosocket library provides an interface to the uIP stack that is similar to the traditional BSD socket interface.

Unlike programs written for the ordinary uIP event-driven interface, programs written with the protosocket library are executed in a sequential fashion and does not have to be implemented as explicit state machines.

Protosockets only work with TCP connections.

The protosocket library uses Protothreads protothreads to provide sequential control flow. This makes the protosockets lightweight in terms of memory, but also means that protosockets inherits the functional limitations of protothreads. Each protosocket lives only within a single function. Automatic variables (stack variables) are not retained across a protosocket library function call.

Note:

Because the protosocket library uses protothreads, local variables will not always be saved across a call to a protosocket library function. It is therefore advised that local variables are used with extreme care.

The protosocket library provides functions for sending data without having to deal with retransmissions and acknowledgements, as well as functions for reading data without having to deal with data being split across more than one TCP segment.

Because each protosocket runs as a protothread, the protosocket has to be started with a call to PSOCK_BEGIN() at the start of the function in which the protosocket is used. Similarly, the protosocket protothread can be terminated by a call to PSOCK_EXIT().

Files

• file psock.h

Protosocket library header file.

Data Structures

- struct psock_buf
- struct psock

The representation of a protosocket.

Defines

• #define PSOCK_INIT(psock, buffer, buffersize)

Initialize a protosocket.

• #define PSOCK_BEGIN(psock)

Start the protosocket protothread in a function.

• #define PSOCK_SEND(psock, data, datalen)

Send data.

• #define PSOCK_SEND_STR(psock, str)

Send a null-terminated string.

• #define PSOCK_GENERATOR_SEND(psock, generator, arg)

Generate data with a function and send it.

• #define PSOCK_CLOSE(psock)

Close a protosocket.

• #define PSOCK_READBUF(psock)

Read data until the buffer is full.

• #define PSOCK_READTO(psock, c)

Read data up to a specified character.

• #define PSOCK_DATALEN(psock)

The length of the data that was previously read.

• #define PSOCK_EXIT(psock)

Exit the protosocket's protothread.

• #define PSOCK_CLOSE_EXIT(psock)

Close a protosocket and exit the protosocket's protothread.

• #define PSOCK_END(psock)

Declare the end of a protosocket's protothread.

• #define PSOCK_NEWDATA(psock)

Check if new data has arrived on a protosocket.

• #define PSOCK_WAIT_UNTIL(psock, condition)

Wait until a condition is true.

#define PSOCK_WAIT_THREAD(psock, condition) PT_WAIT_THREAD(&((psock) → pt), (condition))

Functions

- u16_t psock_datalen (struct psock *psock)
- char psock_newdata (struct psock *s)

6.17.2 Define Documentation

6.17.2.1 #define PSOCK_BEGIN(psock)

Start the protosocket protothread in a function.

This macro starts the protothread associated with the protosocket and must come before other protosocket calls in the function it is used.

psock (struct psock *) A pointer to the protosocket to be started.

Examples:

hello-world.c, and smtp.c.

Definition at line 158 of file psock.h.

6.17.2.2 #define PSOCK_CLOSE(psock)

Close a protosocket.

This macro closes a protosocket and can only be called from within the protothread in which the protosocket lives.

Parameters:

psock (struct psock *) A pointer to the protosocket that is to be closed.

Examples:

hello-world.c, and smtp.c.

Definition at line 235 of file psock.h.

6.17.2.3 #define PSOCK_CLOSE_EXIT(psock)

Close a protosocket and exit the protosocket's protothread.

This macro closes a protosocket and exits the protosocket's protothread.

Parameters:

psock (struct psock *) A pointer to the protosocket.

Definition at line 308 of file psock.h.

6.17.2.4 #define PSOCK_DATALEN(psock)

The length of the data that was previously read.

This macro returns the length of the data that was previously read using PSOCK_READTO() or PSOCK_READ().

Parameters:

psock (struct psock *) A pointer to the protosocket holding the data.

Definition at line 281 of file psock.h.

6.17.2.5 #define PSOCK_END(psock)

Declare the end of a protosocket's protothread.

This macro is used for declaring that the protosocket's protothread ends. It must always be used together with a matching PSOCK_BEGIN() macro.

psock (struct psock *) A pointer to the protosocket.

Examples:

hello-world.c, and smtp.c.

Definition at line 325 of file psock.h.

6.17.2.6 #define PSOCK_EXIT(psock)

Exit the protosocket's protothread.

This macro terminates the protothread of the protosocket and should almost always be used in conjunction with PSOCK CLOSE().

See also:

```
PSOCK_CLOSE_EXIT()
```

Parameters:

psock (struct psock *) A pointer to the protosocket.

Examples:

smtp.c.

Definition at line 297 of file psock.h.

6.17.2.7 #define PSOCK_GENERATOR_SEND(psock, generator, arg)

Generate data with a function and send it.

Parameters:

psock Pointer to the protosocket.generator Pointer to the generator functionarg Argument to the generator function

This function generates data and sends it over the protosocket. This can be used to dynamically generate data for a transmission, instead of generating the data in a buffer beforehand. This function reduces the need for buffer memory. The generator function is implemented by the application, and a pointer to the function is given as an argument with the call to PSOCK_GENERATOR_SEND().

The generator function should place the generated data directly in the uip_appdata buffer, and return the length of the generated data. The generator function is called by the protosocket layer when the data first is sent, and once for every retransmission that is needed.

Definition at line 219 of file psock.h.

6.17.2.8 #define PSOCK_INIT(psock, buffer, buffersize)

Initialize a protosocket.

This macro initializes a protosocket and must be called before the protosocket is used. The initialization also specifies the input buffer for the protosocket.

psock (struct psock *) A pointer to the protosocket to be initializedbuffer (char *) A pointer to the input buffer for the protosocket.buffersize (unsigned int) The size of the input buffer.

Examples:

hello-world.c, and smtp.c.

Definition at line 144 of file psock.h.

Referenced by hello_world_appcall(), httpd_appcall(), and smtp_send().

6.17.2.9 #define PSOCK_NEWDATA(psock)

Check if new data has arrived on a protosocket.

This macro is used in conjunction with the PSOCK_WAIT_UNTIL() macro to check if data has arrived on a protosocket.

Parameters:

psock (struct psock *) A pointer to the protosocket.

Definition at line 339 of file psock.h.

6.17.2.10 #define PSOCK_READBUF(psock)

Read data until the buffer is full.

This macro will block waiting for data and read the data into the input buffer specified with the call to PSOCK INIT(). Data is read until the buffer is full..

Parameters:

psock (struct psock *) A pointer to the protosocket from which data should be read.

Definition at line 250 of file psock.h.

6.17.2.11 #define PSOCK_READTO(psock, c)

Read data up to a specified character.

This macro will block waiting for data and read the data into the input buffer specified with the call to PSOCK_INIT(). Data is only read until the specifieed character appears in the data stream.

Parameters:

psock (struct psock *) A pointer to the protosocket from which data should be read.

c (char) The character at which to stop reading.

Examples:

hello-world.c, and smtp.c.

Definition at line 268 of file psock.h.

6.17.2.12 #define PSOCK_SEND(psock, data, datalen)

Send data.

This macro sends data over a protosocket. The protosocket protothread blocks until all data has been sent and is known to have been received by the remote end of the TCP connection.

Parameters:

```
psock (struct psock *) A pointer to the protosocket over which data is to be sent.data (char *) A pointer to the data that is to be sent.datalen (unsigned int) The length of the data that is to be sent.
```

Examples:

smtp.c.

Definition at line 178 of file psock.h.

6.17.2.13 #define PSOCK_SEND_STR(psock, str)

Send a null-terminated string.

Parameters:

```
psock Pointer to the protosocket.str The string to be sent.
```

This function sends a null-terminated string over the protosocket.

Examples:

hello-world.c, and smtp.c.

Definition at line 191 of file psock.h.

6.17.2.14 #define PSOCK_WAIT_UNTIL(psock, condition)

Wait until a condition is true.

This macro blocks the protothread until the specified condition is true. The macro PSOCK_NEWDATA() can be used to check if new data arrives when the protosocket is waiting.

Typically, this macro is used as follows:

```
PT_THREAD(thread(struct psock *s, struct timer *t))
{
    PSOCK_BEGIN(s);

    PSOCK_WAIT_UNTIL(s, PSOCK_NEWADATA(s) || timer_expired(t));

    if(PSOCK_NEWDATA(s)) {
        PSOCK_READTO(s, '\n');
    } else {
        handle_timed_out(s);
    }

    PSOCK_END(s);
}
```

psock (struct psock *) A pointer to the protosocket.condition The condition to wait for.

Definition at line 372 of file psock.h.

6.18 Memory block management functions

6.18.1 Detailed Description

The memory block allocation routines provide a simple yet powerful set of functions for managing a set of memory blocks of fixed size.

A set of memory blocks is statically declared with the MEMB() macro. Memory blocks are allocated from the declared memory by the memb_alloc() function, and are deallocated with the memb_free() function.

Note:

Because of namespace clashes only one MEMB() can be declared per C module, and the name scope of a MEMB() memory block is local to each C module.

The following example shows how to declare and use a memory block called "cmem" which has 8 chunks of memory with each memory chunk being 20 bytes large.

Files

• file memb.c

Memory block allocation routines.

• file memb.h

Memory block allocation routines.

Data Structures

• struct memb_blocks

Defines

- #define MEMB_CONCAT2(s1, s2) s1##s2
- #define MEMB_CONCAT(s1, s2) MEMB_CONCAT2(s1, s2)
- #define MEMB(name, structure, num)

Declare a memory block.

Functions

void memb_init (struct memb_blocks *m)
 Initialize a memory block that was declared with MEMB().

void * memb_alloc (struct memb_blocks *m)
 Allocate a memory block from a block of memory declared with MEMB().

• char memb_free (struct memb_blocks *m, void *ptr)

Deallocate a memory block from a memory block previously declared with MEMB().

6.18.2 Define Documentation

6.18.2.1 #define MEMB(name, structure, num)

Value:

Declare a memory block.

This macro is used to staticall declare a block of memory that can be used by the block allocation functions. The macro statically declares a C array with a size that matches the specified number of blocks and their individual sizes.

Example:

```
MEMB(connections, sizeof(struct connection), 16);
```

Parameters:

name The name of the memory block (later used with memb_init(), memb_alloc() and memb_free()).size The size of each memory chunk, in bytes.

num The total number of memory chunks in the block.

Examples:

telnetd.c.

Definition at line 98 of file memb.h.

6.18.3 Function Documentation

```
6.18.3.1 void * memb alloc (struct memb blocks * m)
```

Allocate a memory block from a block of memory declared with MEMB().

Parameters:

m A memory block previously declared with MEMB().

Examples:

telnetd.c.

Definition at line 59 of file memb.c.

References memb_blocks::count, memb_blocks::mem, memb_blocks::num, and memb_blocks::size.

6.18.3.2 char memb_free (struct memb_blocks * m, void * ptr)

Deallocate a memory block from a memory block previously declared with MEMB().

Parameters:

m m A memory block previously declared with MEMB().

ptr A pointer to the memory block that is to be deallocated.

Returns:

The new reference count for the memory block (should be 0 if successfully deallocated) or -1 if the pointer "ptr" did not point to a legal memory block.

Examples:

telnetd.c.

Definition at line 79 of file memb.c.

References memb_blocks::count, memb_blocks::mem, and memb_blocks::size.

6.18.3.3 void memb_init (struct memb_blocks * m)

Initialize a memory block that was declared with MEMB().

Parameters:

m A memory block previously declared with MEMB().

Examples:

telnetd.c.

Definition at line 52 of file memb.c.

References memb_blocks::count, memb_blocks::mem, memb_blocks::num, and memb_blocks::size.

Referenced by telnetd_init().

6.19 DNS resolver

6.19 DNS resolver

6.19.1 Detailed Description

The uIP DNS resolver functions are used to lookup a hostname and map it to a numerical IP address.

It maintains a list of resolved hostnames that can be queried with the resolv_lookup() function. New hostnames can be resolved using the resolv_query() function.

When a hostname has been resolved (or found to be non-existant), the resolver code calls a callback function called resolv_found() that must be implemented by the module that uses the resolver.

Files

• file resolv.h

DNS resolver code header file.

• file resolv.c

DNS host name to IP address resolver.

Defines

- #define UIP_UDP_APPCALL resolv_appcall
- #define NULL (void *)0
- #define MAX RETRIES 8
- #define RESOLV_ENTRIES 4

Functions

- void resolv_appcall (void)
- void resolv_found (char *name, u16_t *ipaddr)

Callback function which is called when a hostname is found.

• void resolv_conf (u16_t *dnsserver)

Configure which DNS server to use for queries.

• u16_t * resolv_getserver (void)

Obtain the currently configured DNS server.

• void resolv_init (void)

Initalize the resolver.

• u16_t * resolv_lookup (char *name)

Look up a hostname in the array of known hostnames.

• void resolv_query (char *name)

Queues a name so that a question for the name will be sent out.

6.19.2 Function Documentation

6.19.2.1 void resolv_conf ($u16_t * dnsserver$)

Configure which DNS server to use for queries.

Parameters:

dnsserver A pointer to a 4-byte representation of the IP address of the DNS server to be configured.

Examples:

resolv.c, and resolv.h.

Definition at line 438 of file resolv.c.

References HTONS, NULL, uip_udp_new(), and uip_udp_remove.

6.19.2.2 void resolv_found (char * name, $u16_t * ipaddr$)

Callback function which is called when a hostname is found.

This function must be implemented by the module that uses the DNS resolver. It is called when a hostname is found, or when a hostname was not found.

Parameters:

name A pointer to the name that was looked up.

ipaddr A pointer to a 4-byte array containing the IP address of the hostname, or NULL if the hostname could not be found.

Examples:

resolv.c, and resolv.h.

6.19.2.3 $u16_t * resolv_getserver (void)$

Obtain the currently configured DNS server.

Returns:

A pointer to a 4-byte representation of the IP address of the currently configured DNS server or NULL if no DNS server has been configured.

Examples:

resolv.c, and resolv.h.

Definition at line 422 of file resolv.c.

References NULL, and uip_udp_conn::ripaddr.

6.19.2.4 $u16_t * resolv_lookup (char * name)$

Look up a hostname in the array of known hostnames.

6.19 DNS resolver

Note:

This function only looks in the internal array of known hostnames, it does not send out a query for the hostname if none was found. The function resolv_query() can be used to send a query for a hostname.

Returns:

A pointer to a 4-byte representation of the hostname's IP address, or NULL if the hostname was not found in the array of hostnames.

Examples:

resolv.c, resolv.h, and webclient.c.

Definition at line 396 of file resolv.c.

References RESOLV_ENTRIES, and STATE_DONE.

Referenced by webclient_appcall(), and webclient_get().

6.19.2.5 void resolv_query (char * name)

Queues a name so that a question for the name will be sent out.

Parameters:

name The hostname that is to be queried.

Examples:

resolv.c, resolv.h, and webclient.c.

Definition at line 350 of file resolv.c.

References RESOLV_ENTRIES, and STATE_UNUSED.

Referenced by webclient_appcall().

6.20 SMTP E-mail sender

6.20.1 Detailed Description

The Simple Mail Transfer Protocol (SMTP) as defined by RFC821 is the standard way of sending and transfering e-mail on the Internet.

This simple example implementation is intended as an example of how to implement protocols in uIP, and is able to send out e-mail but has not been extensively tested.

Files

- file smtp.h

 SMTP header file.
- file smtp.c

 SMTP example implementation.

Data Structures

• struct smtp_state

Defines

- #define SMTP_ERR_OK 0

 Error number that signifies a non-error condition.
- #define SMTP_SEND(to, cc, from, subject, msg) smtp_send(to, cc, from, subject, msg, strlen(msg))
- #define ISO_nl 0x0a
- #define ISO_cr 0x0d
- #define ISO_period 0x2e
- #define ISO_2 0x32
- #define ISO_3 0x33
- #define ISO_4 0x34
- #define ISO 5 0x35

Functions

- void smtp_done (unsigned char error)
 - Callback function that is called when an e-mail transmission is done.
- void smtp_init (void)
- void smtp_appcall (void)
- void smtp_configure (char *lhostname, void *server)

Specificy an SMTP server and hostname.

• unsigned char smtp_send (char *to, char *cc, char *from, char *subject, char *msg, u16_t msglen)

Send an e-mail.

6.20 SMTP E-mail sender 109

6.20.2 Function Documentation

6.20.2.1 void smtp_configure (char * lhostname, void * server)

Specificy an SMTP server and hostname.

This function is used to configure the SMTP module with an SMTP server and the hostname of the host.

Parameters:

lhostname The hostname of the uIP host.

server A pointer to a 4-byte array representing the IP address of the SMTP server to be configured.

Definition at line 216 of file smtp.c.

References uip_ipaddr_copy.

6.20.2.2 void smtp_done (unsigned char *error*)

Callback function that is called when an e-mail transmission is done.

This function must be implemented by the module that uses the SMTP module.

Parameters:

error The number of the error if an error occured, or SMTP_ERR_OK.

Examples:

smtp.c, and smtp.h.

Referenced by smtp_appcall().

6.20.2.3 unsigned char smtp_send (char * to, char * cc, char * from, char * subject, char * msg, u16_t msglen)

Send an e-mail.

Parameters:

```
to The e-mail address of the receiver of the e-mail.
```

cc The e-mail address of the CC: receivers of the e-mail.

from The e-mail address of the sender of the e-mail.

subject The subject of the e-mail.

msg The actual e-mail message.

msglen The length of the e-mail message.

Definition at line 233 of file smtp.c.

References smtp_state::from, HTONS, smtp_state::msg, smtp_state::msglen, NULL, PSOCK_INIT, smtp_state::subject, smtp_state::to, and uip_connect().

6.21 Telnet server

6.21.1 Detailed Description

The uIP telnet server.

Files

- file telnetd.h
 - Shell server.
- file telnetd.c

Shell server.

- file shell.h
 - Simple shell, header file.
- file shell.c

Simple shell.

Data Structures

• struct telnetd_state

Defines

- #define TELNETD_CONF_LINELEN 40
- #define TELNETD_CONF_NUMLINES 16
- #define UIP_APPCALL telnetd_appcall
- #define ISO_nl 0x0a
- #define ISO_cr 0x0d
- #define STATE_NORMAL 0
- #define STATE_IAC 1
- #define STATE_WILL 2
- #define STATE_WONT 3
- #define STATE_DO 4
- #define STATE_DONT 5
- #define STATE CLOSE 6
- #define TELNET_IAC 255
- #define TELNET_WILL 251
- #define TELNET_WONT 252
- #define TELNET_DO 253
- #define TELNET_DONT 254
- #define SHELL PROMPT "uIP 1.0> "

Typedefs

• typedef telnetd_state uip_tcp_appstate_t

6.21 Telnet server

Functions

- void telnetd_appcall (void)
- void shell_quit (char *)

Quit the shell.

• void shell_prompt (char *prompt)

Print a prompt to the shell window.

• void shell_output (char *str1, char *str2)

Print a string to the shell window.

- void telnetd_init (void)
- void shell init (void)

Initialize the shell.

• void shell_start (void)

Start the shell back-end.

• void shell_input (char *command)

Process a shell command.

6.21.2 Function Documentation

6.21.2.1 void shell_init (void)

Initialize the shell.

Called when the shell front-end process starts. This function may be used to start listening for signals.

Examples:

telnetd.c.

Definition at line 117 of file shell.c.

Referenced by telnetd_init().

6.21.2.2 void shell_input (char * command)

Process a shell command.

This function will be called by the shell GUI / telnet server whan a command has been entered that should be processed by the shell back-end.

Parameters:

command The command to be processed.

Examples:

telnetd.c.

Definition at line 130 of file shell.c.

References SHELL_PROMPT, and shell_prompt().

6.21.2.3 void shell_output (char * str1, char * str2)

Print a string to the shell window.

This function is implemented by the shell GUI / telnet server and can be called by the shell back-end to output a string in the shell window. The string is automatically appended with a linebreak.

Parameters:

str1 The first half of the string to be output.

str2 The second half of the string to be output.

Examples:

telnetd.c.

Definition at line 125 of file telnetd.c.

References ISO_cr, ISO_nl, NULL, and TELNETD_CONF_LINELEN.

Referenced by shell_start().

6.21.2.4 void shell_prompt (char * prompt)

Print a prompt to the shell window.

This function can be used by the shell back-end to print out a prompt to the shell window.

Parameters:

prompt The prompt to be printed.

Examples:

telnetd.c.

Definition at line 113 of file telnetd.c.

References NULL, and TELNETD CONF LINELEN.

Referenced by shell_input(), and shell_start().

6.21.2.5 void shell_start (void)

Start the shell back-end.

Called by the front-end when a new shell is started.

Examples:

telnetd.c.

Definition at line 122 of file shell.c.

References shell_output(), SHELL_PROMPT, and shell_prompt().

Referenced by telnetd_appcall().

6.22 Hello, world

6.22 Hello, world

6.22.1 Detailed Description

A small example showing how to write applications with protosockets.

Files

• file hello-world.h

Header file for an example of how to write uIP applications with protosockets.

• file hello-world.c

An example of how to write uIP applications with protosockets.

Data Structures

• struct hello_world_state

Defines

• #define UIP_APPCALL hello_world_appcall

Functions

- void hello_world_appcall (void)
- void hello_world_init (void)

6.23 Web client

6.23.1 Detailed Description

This example shows a HTTP client that is able to download web pages and files from web servers.

It requires a number of callback functions to be implemented by the module that utilizes the code: webclient_datahandler(), webclient_connected(), webclient_timedout(), webclient_aborted(), webclient_closed().

Files

• file webclient.h

Header file for the HTTP client.

• file webclient.c

Implementation of the HTTP client.

Data Structures

• struct webclient state

Defines

- #define WEBCLIENT_CONF_MAX_URLLEN 100
- #define UIP_APPCALL webclient_appcall
- #define WEBCLIENT_TIMEOUT 100
- #define WEBCLIENT_STATE_STATUSLINE 0
- #define WEBCLIENT_STATE_HEADERS 1
- #define WEBCLIENT_STATE_DATA 2
- #define WEBCLIENT_STATE_CLOSE 3
- #define HTTPFLAG_NONE 0
- #define HTTPFLAG_OK 1
- #define HTTPFLAG_MOVED 2
- #define HTTPFLAG_ERROR 3
- #define ISO_nl 0x0a
- #define ISO_cr 0x0d
- #define ISO_space 0x20

Typedefs

• typedef webclient_state uip_tcp_appstate_t

6.23 Web client 115

Functions

• void webclient_datahandler (char *data, u16_t len)

Callback function that is called from the webclient code when HTTP data has been received.

• void webclient_connected (void)

Callback function that is called from the webclient code when the HTTP connection has been connected to the web server.

• void webclient timedout (void)

Callback function that is called from the webclient code if the HTTP connection to the web server has timed out

• void webclient aborted (void)

Callback function that is called from the webclient code if the HTTP connection to the web server has been aborted by the web server.

• void webclient_closed (void)

Callback function that is called from the webclient code when the HTTP connection to the web server has been closed.

• void webclient_init (void)

Initialize the webclient module.

• unsigned char webclient_get (char *host, u16_t port, char *file)

Open an HTTP connection to a web server and ask for a file using the GET method.

• void webclient_close (void)

Close the currently open HTTP connection.

- void webclient_appcall (void)
- char * webclient_mimetype (void)

Obtain the MIME type of the current HTTP data stream.

• char * webclient_filename (void)

Obtain the filename of the current HTTP data stream.

• char * webclient_hostname (void)

Obtain the hostname of the current HTTP data stream.

unsigned short webclient_port (void)

Obtain the port number of the current HTTP data stream.

6.23.2 Function Documentation

6.23.2.1 void webclient_aborted (void)

Callback function that is called from the webclient code if the HTTP connection to the web server has been aborted by the web server.

This function must be implemented by the module that uses the webclient code.

Examples:

webclient.c, and webclient.h.

Referenced by webclient_appcall().

6.23.2.2 void webclient closed (void)

Callback function that is called from the webclient code when the HTTP connection to the web server has been closed.

This function must be implemented by the module that uses the webclient code.

Examples:

webclient.c, and webclient.h.

Referenced by webclient_appcall().

6.23.2.3 void webclient_connected (void)

Callback function that is called from the webclient code when the HTTP connection has been connected to the web server.

This function must be implemented by the module that uses the webclient code.

Examples:

webclient.c, and webclient.h.

Referenced by webclient_appcall().

6.23.2.4 void webclient_datahandler (char * data, u16_t len)

Callback function that is called from the webclient code when HTTP data has been received.

This function must be implemented by the module that uses the webclient code. The function is called from the webclient module when HTTP data has been received. The function is not called when HTTP headers are received, only for the actual data.

Note:

This function is called many times, repetedly, when data is being received, and not once when all data has been received.

Parameters:

data A pointer to the data that has been received.

len The length of the data that has been received.

Examples:

webclient.c, and webclient.h.

Referenced by webclient_appcall().

6.23 Web client 117

6.23.2.5 char * webclient_filename (void)

Obtain the filename of the current HTTP data stream.

The filename of an HTTP request may be changed by the web server, and may therefore not be the same as when the original GET request was made with webclient_get(). This function is used for obtaining the current filename.

Returns:

A pointer to the current filename.

Examples:

webclient.c, and webclient.h.

Definition at line 93 of file webclient.c.

References webclient_state::file.

6.23.2.6 unsigned char webclient_get (char * host, u16_t port, char * file)

Open an HTTP connection to a web server and ask for a file using the GET method.

This function opens an HTTP connection to the specified web server and requests the specified file using the GET method. When the HTTP connection has been connected, the webclient_connected() callback function is called and when the HTTP data arrives the webclient_datahandler() callback function is called.

The callback function webclient_timedout() is called if the web server could not be contacted, and the webclient_aborted() callback function is called if the HTTP connection is aborted by the web server.

When the HTTP request has been completed and the HTTP connection is closed, the webclient_closed() callback function will be called.

Note:

If the function is passed a host name, it must already be in the resolver cache in order for the function to connect to the web server. It is therefore up to the calling module to implement the resolver calls and the signal handler used for reporting a resolv query answer.

Parameters:

host A pointer to a string containing either a host name or a numerical IP address in dotted decimal notation (e.g., 192.168.23.1).

port The port number to which to connect, in host byte order.

file A pointer to the name of the file to get.

Return values:

0 if the host name could not be found in the cache, or if a TCP connection could not be created.

1 if the connection was initiated.

Examples:

webclient.c, and webclient.h.

Definition at line 140 of file webclient.c.

 $References\ webclient_state::file,\ webclient_state::host,\ htms(),\ NULL,\ webclient_state::port,\ resolv_lookup(),\ and\ uip_connect().$

Referenced by webclient_appcall().

6.23.2.7 char * webclient_hostname (void)

Obtain the hostname of the current HTTP data stream.

The hostname of the web server of an HTTP request may be changed by the web server, and may therefore not be the same as when the original GET request was made with webclient_get(). This function is used for obtaining the current hostname.

Returns:

A pointer to the current hostname.

Examples:

webclient.c, and webclient.h.

Definition at line 99 of file webclient.c.

References webclient_state::host.

6.23.2.8 char * webclient_mimetype (void)

Obtain the MIME type of the current HTTP data stream.

Returns:

A pointer to a string contaning the MIME type. The string may be empty if no MIME type was reported by the web server.

Examples:

webclient.c, and webclient.h.

Definition at line 87 of file webclient.c.

References webclient_state::mimetype.

6.23.2.9 unsigned short webclient_port (void)

Obtain the port number of the current HTTP data stream.

The port number of an HTTP request may be changed by the web server, and may therefore not be the same as when the original GET request was made with webclient_get(). This function is used for obtaining the current port number.

Returns:

The port number of the current HTTP data stream, in host byte order.

Examples:

webclient.c, and webclient.h.

Definition at line 105 of file webclient.c.

References webclient_state::port.

6.23 Web client 119

6.23.2.10 void webclient_timedout (void)

Callback function that is called from the webclient code if the HTTP connection to the web server has timed out.

This function must be implemented by the module that uses the webclient code.

Examples:

webclient.c, and webclient.h.

Referenced by webclient_appcall().

6.24 Web server

6.24.1 Detailed Description

The uIP web server is a very simplistic implementation of an HTTP server.

It can serve web pages and files from a read-only ROM filesystem, and provides a very small scripting language.

Files

• file httpd-cgi.h

Web server script interface header file.

• file httpd-cgi.c

Web server script interface.

• file httpd.c

Web server.

Data Structures

• struct httpd_cgi_call

Defines

- #define HTTPD_CGI_CALL(name, str, function)
 - HTTPD CGI function declaration.
- #define STATE_WAITING 0
- #define STATE OUTPUT 1
- #define ISO_nl 0x0a
- #define ISO_space 0x20
- #define ISO_bang 0x21
- #define ISO_percent 0x25
- #define ISO_period 0x2e
- #define ISO_slash 0x2f
- #define ISO_colon 0x3a

Functions

- httpd_cgifunction httpd_cgi (char *name)
- void httpd_appcall (void)
- void httpd_init (void)

Initialize the web server.

6.24 Web server

6.24.2 Define Documentation

6.24.2.1 #define HTTPD_CGI_CALL(name, str, function)

HTTPD CGI function declaration.

Parameters:

name The C variable name of the functionstr The string name of the function, used in the script filefunction A pointer to the function that implements it

This macro is used for declaring a HTTPD CGI function. This function is then added to the list of HTTPD CGI functions with the httpd_cgi_add() function.

Definition at line 77 of file httpd-cgi.h.

6.24.3 Function Documentation

6.24.3.1 void httpd_init (void)

Initialize the web server.

This function initializes the web server and should be called at system boot-up.

Definition at line 333 of file httpd.c.

References HTONS, and uip_listen().

Chapter 7

uIP 1.0 Data Structure Documentation

7.1 dhcpc_state Struct Reference

7.1.1 Detailed Description

Examples:

dhepc.c, and dhepc.h.

Definition at line 39 of file dhcpc.h.

- pt pt
- char state
- uip_udp_conn * conn
- timer timer
- u16_t ticks
- const void * mac_addr
- int mac_len
- u8_t serverid [4]
- u16_t lease_time [2]
- u16_t ipaddr [2]
- u16_t netmask [2]
- u16_t dnsaddr [2]
- u16_t default_router [2]

7.2 hello_world_state Struct Reference

7.2.1 Detailed Description

Examples:

hello-world.c, and hello-world.h.

Definition at line 36 of file hello-world.h.

- psock p
- char inputbuffer [10]
- char name [40]

7.3 httpd_cgi_call Struct Reference

7.3.1 Detailed Description

Definition at line 60 of file httpd-cgi.h.

- const char * name
- const httpd_cgifunction function

7.4 httpd_state Struct Reference

7.4.1 Detailed Description

Definition at line 41 of file httpd.h.

- unsigned char timer
- psock sin sout
- pt outputpt scriptpt
- char inputbuf [50]
- char filename [20]
- char state
- httpd_fs_file file
- int len
- char * scriptptr
- int scriptlen
- unsigned short count

7.5 memb_blocks Struct Reference

7.5.1 Detailed Description

Definition at line 105 of file memb.h.

- unsigned short size
- unsigned short num
- char * count
- void * mem

7.6 psock Struct Reference

#include <psock.h>

7.6.1 Detailed Description

The representation of a protosocket.

The protosocket structrure is an opaque structure with no user-visible elements.

Examples:

hello-world.h.

Definition at line 106 of file psock.h.

- pt pt psockpt
- const u8_t * sendptr
- u8_t * readptr
- char * bufptr
- u16_t sendlen
- u16_t readlen
- psock_buf buf
- unsigned int bufsize
- unsigned char state

7.7 psock_buf Struct Reference

7.7.1 Detailed Description

Definition at line 95 of file psock.h.

- u8_t * ptr
- unsigned short left

7.8 pt Struct Reference

7.8.1 Detailed Description

Examples:

dhcpc.h.

Definition at line 54 of file pt.h.

Data Fields

• lc_t lc

7.9 smtp_state Struct Reference

7.9.1 Detailed Description

Examples:

hello-world.h, smtp.c, and smtp.h.

Definition at line 81 of file smtp.h.

- u8_t state
- char * to
- char * from
- char * subject
- char * msg
- u16_t msglen
- u16_t sentlen
- u16_t textlen
- u16_t sendptr

7.10 telnetd_state Struct Reference

7.10.1 Detailed Description

Examples:

telnetd.c, and telnetd.h.

Definition at line 69 of file telnetd.h.

- char * lines [TELNETD_CONF_NUMLINES]
- char buf [TELNETD_CONF_LINELEN]
- char bufptr
- u8_t numsent
- u8_t state

7.11 timer Struct Reference

#include <timer.h>

7.11.1 Detailed Description

A timer.

This structure is used for declaring a timer. The timer must be set with timer_set() before it can be used.

Examples:

dhcpc.h, example-mainloop-with-arp.c, example-mainloop-without-arp.c, and webclient.h.

Definition at line 74 of file timer.h.

- clock_time_t start
- clock_time_t interval

7.12 uip_conn Struct Reference

#include <uip.h>

7.12.1 Detailed Description

Representation of a uIP TCP connection.

The uip_conn structure is used for identifying a connection. All but one field in the structure are to be considered read-only by an application. The only exception is the appstate field whos purpose is to let the application store application-specific state (e.g., file pointers) for the connection. The type of this field is configured in the "uipopt.h" header file.

Definition at line 1153 of file uip.h.

Data Fields

• uip_ipaddr_t ripaddr

The IP address of the remote host.

• u16_t lport

The local TCP port, in network byte order.

• u16_t rport

The local remote TCP port, in network byte order.

• u8_t rcv_nxt [4]

The sequence number that we expect to receive next.

• u8_t snd_nxt [4]

The sequence number that was last sent by us.

• u16_t len

Length of the data that was previously sent.

• u16_t mss

Current maximum segment size for the connection.

• u16 t initialmss

Initial maximum segment size for the connection.

• u8_t sa

Retransmission time-out calculation state variable.

• u8_t sv

Retransmission time-out calculation state variable.

• u8_t rto

Retransmission time-out.

• u8_t tcpstateflags

 $TCP\ state\ and\ flags.$

• u8_t timer

The retransmission timer.

• u8_t nrtx

 ${\it The number of retransmissions for the last segment sent.}$

• uip_tcp_appstate_t appstate

The application state.

7.13 uip_eth_addr Struct Reference

#include <uip.h>

7.13.1 Detailed Description

Representation of a 48-bit Ethernet address. Definition at line 1542 of file uip.h.

Data Fields

• u8_t addr [6]

7.14 uip_eth_hdr Struct Reference

#include <uip_arp.h>

7.14.1 Detailed Description

The Ethernet header.

Definition at line 63 of file uip_arp.h.

- uip_eth_addr dest
- uip_eth_addr src
- u16_t type

7.15 uip_icmpip_hdr Struct Reference

7.15.1 Detailed Description

Definition at line 1423 of file uip.h.

- u8_t vhl
- u8_t tos
- u8_t len [2]
- u8_t ipid [2]
- u8_t ipoffset [2]
- u8_t ttl
- u8_t proto
- u16_t ipchksum
- u16_t srcipaddr [2]
- u16_t destipaddr [2]
- u8_t type
- u8_t icode
- u16_t icmpchksum
- u16_t id
- u16_t seqno

7.16 uip_neighbor_addr Struct Reference

7.16.1 Detailed Description

Definition at line 47 of file uip-neighbor.h.

Data Fields

• uip_eth_addr addr

7.17 uip_stats Struct Reference

```
#include <uip.h>
```

7.17.1 Detailed Description

The structure holding the TCP/IP statistics that are gathered if UIP_STATISTICS is set to 1. Definition at line 1232 of file uip.h.

Data Fields

```
• struct {
    uip_stats_t drop
       Number of dropped packets at the IP layer.
    uip stats t recv
       Number of received packets at the IP layer.
    uip_stats_t sent
       Number of sent packets at the IP layer.
    uip_stats_t vhlerr
       Number of packets dropped due to wrong IP version or header length.
    uip_stats_t hblenerr
       Number of packets dropped due to wrong IP length, high byte.
    uip stats t lblenerr
       Number of packets dropped due to wrong IP length, low byte.
    uip_stats_t fragerr
       Number of packets dropped since they were IP fragments.
    uip_stats_t chkerr
       Number of packets dropped due to IP checksum errors.
    uip_stats_t protoerr
       Number of packets dropped since they were neither ICMP, UDP nor TCP.
  } ip
     IP statistics.
• struct {
    uip_stats_t drop
       Number of dropped ICMP packets.
    uip_stats_t recv
       Number of received ICMP packets.
    uip_stats_t sent
       Number of sent ICMP packets.
    uip stats t typeerr
       Number of ICMP packets with a wrong type.
  } icmp
     ICMP statistics.
struct {
    uip_stats_t drop
       Number of dropped TCP segments.
    uip_stats_t recv
```

```
Number of recived TCP segments.
    uip_stats_t sent
      Number of sent TCP segments.
    uip_stats_t chkerr
      Number of TCP segments with a bad checksum.
    uip_stats_t ackerr
      Number of TCP segments with a bad ACK number.
    uip_stats_t rst
      Number of recevied TCP RST (reset) segments.
    uip_stats_t rexmit
      Number of retransmitted TCP segments.
    uip_stats_t syndrop
      Number of dropped SYNs due to too few connections was avaliable.
    uip_stats_t synrst
       Number of SYNs for closed ports, triggering a RST.
  } tcp
     TCP statistics.
• struct {
    uip_stats_t drop
      Number of dropped UDP segments.
    uip_stats_t recv
      Number of recived UDP segments.
    uip_stats_t sent
      Number of sent UDP segments.
    uip_stats_t chkerr
      Number of UDP segments with a bad checksum.
  } udp
     UDP statistics.
```

7.18 uip_tcpip_hdr Struct Reference

7.18.1 Detailed Description

Definition at line 1386 of file uip.h.

Data Fields

- u8_t vhl
- u8_t tos
- u8_t len [2]
- u8_t ipid [2]
- u8_t ipoffset [2]
- u8_t ttl
- u8_t proto
- u16_t ipchksum
- u16_t srcipaddr [2]
- u16_t destipaddr [2]
- u16_t srcport
- u16_t destport
- u8_t seqno [4]
- u8_t ackno [4]
- u8_t tcpoffset
- u8_t flags
- u8_t wnd [2]
- u16_t tepchksum
- u8_t urgp [2]
- u8_t optdata [4]

7.19 uip_udp_conn Struct Reference

#include <uip.h>

7.19.1 Detailed Description

Representation of a uIP UDP connection.

Examples:

dhcpc.h, and resolv.c.

Definition at line 1210 of file uip.h.

Data Fields

• uip_ipaddr_t ripaddr

The IP address of the remote peer.

• u16_t lport

The local port number in network byte order.

• u16_t rport

The remote port number in network byte order.

• u8_t ttl

Default time-to-live.

• uip_udp_appstate_t appstate

The application state.

7.20 uip_udpip_hdr Struct Reference

7.20.1 Detailed Description

Definition at line 1460 of file uip.h.

Data Fields

- u8_t vhl
- u8_t tos
- u8_t len [2]
- u8_t ipid [2]
- u8_t ipoffset [2]
- u8_t ttl
- u8_t proto
- u16_t ipchksum
- u16_t srcipaddr [2]
- u16_t destipaddr [2]
- u16_t srcport
- u16_t destport
- u16_t udplen
- u16_t udpchksum

7.21 webclient_state Struct Reference

7.21.1 Detailed Description

Examples:

webclient.c, and webclient.h.

Definition at line 55 of file webclient.h.

Data Fields

- u8_t timer
- u8_t state
- u8_t httpflag
- u16_t port
- char host [40]
- char file [WEBCLIENT_CONF_MAX_URLLEN]
- u16_t getrequestptr
- u16_t getrequestleft
- char httpheaderline [200]
- u16_t httpheaderlineptr
- char mimetype [32]

Chapter 8

uIP 1.0 File Documentation

8.1 apps/hello-world/hello-world.c File Reference

8.1.1 Detailed Description

An example of how to write uIP applications with protosockets.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file hello-world.c.

```
#include "hello-world.h"
#include "uip.h"
#include <string.h>
```

- void hello_world_init (void)
- void hello_world_appcall (void)

8.2 apps/hello-world/hello-world.h File Reference

8.2.1 Detailed Description

Header file for an example of how to write uIP applications with protosockets.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file hello-world.h.

```
#include "uipopt.h"
#include "psock.h"
```

Data Structures

• struct hello_world_state

Defines

• #define UIP_APPCALL hello_world_appcall

- void hello_world_appcall (void)
- void hello_world_init (void)

8.3 apps/resolv/resolv.c File Reference

8.3.1 Detailed Description

DNS host name to IP address resolver.

Author:

```
Adam Dunkels <adam@dunkels.com>
```

This file implements a DNS host name to IP address resolver.

Definition in file resolv.c.

```
#include "resolv.h"
#include "uip.h"
#include <string.h>
```

Defines

- #define NULL (void *)0
- #define MAX RETRIES 8
- #define DNS_FLAG1_RESPONSE 0x80
- #define DNS_FLAG1_OPCODE_STATUS 0x10
- #define DNS_FLAG1_OPCODE_INVERSE 0x08
- #define DNS_FLAG1_OPCODE_STANDARD 0x00
- #define DNS FLAG1 AUTHORATIVE 0x04
- #define DNS_FLAG1_TRUNC 0x02
- #define DNS_FLAG1_RD 0x01
- #define DNS_FLAG2_RA 0x80
- #define DNS_FLAG2_ERR_MASK 0x0f
- #define DNS_FLAG2_ERR_NONE 0x00
- #define DNS_FLAG2_ERR_NAME 0x03
- #define STATE_UNUSED 0
- #define STATE_NEW 1
- #define STATE ASKING 2
- #define STATE_DONE 3
- #define STATE_ERROR 4
- #define RESOLV_ENTRIES 4

Functions

- void resolv_appcall (void)
- void resolv_query (char *name)

Queues a name so that a question for the name will be sent out.

• u16_t * resolv_lookup (char *name)

 $Look\ up\ a\ hostname\ in\ the\ array\ of\ known\ hostnames.$

• u16_t * resolv_getserver (void)

 $Obtain\ the\ currently\ configured\ DNS\ server.$

- void resolv_conf (u16_t *dnsserver)

 Configure which DNS server to use for queries.
- void resolv_init (void)

 Initalize the resolver.

8.4 apps/resolv/resolv.h File Reference

8.4.1 Detailed Description

DNS resolver code header file.

Author:

```
Adam Dunkels <adam@dunkels.com>
```

Definition in file resolv.h.

```
#include "uipopt.h"
```

Appication specific configurations

An uIP application is implemented using a single application function that is called by uIP whenever a TCP/IP event occurs. The name of this function must be registered with uIP at compile time using the UIP_APPCALL definition.

uIP applications can store the application state within the uip_conn structure by specifying the type of the application structure by typedef:ing the type uip_tcp_appstate_t and uip_udp_appstate_t.

The file containing the definitions must be included in the uipopt.h file.

The following example illustrates how this can look.

```
void httpd_appcall(void);
#define UIP_APPCALL httpd_appcall

struct httpd_state {
    u8_t state;
    u16_t count;
    char *dataptr;
    char *script;
};
typedef struct httpd_state uip_tcp_appstate_t
```

• typedef int uip_udp_appstate_t

The type of the application state that is to be stored in the uip_conn structure.

Defines

• #define UIP_UDP_APPCALL resolv_appcall

Functions

- void resolv_appcall (void)
- void resolv_found (char *name, u16_t *ipaddr)

Callback function which is called when a hostname is found.

• void resolv_conf (u16_t *dnsserver)

Configure which DNS server to use for queries.

• u16_t * resolv_getserver (void)

 $Obtain\ the\ currently\ configured\ DNS\ server.$

• void resolv_init (void)

Initalize the resolver.

• u16_t * resolv_lookup (char *name)

Look up a hostname in the array of known hostnames.

• void resolv_query (char *name)

Queues a name so that a question for the name will be sent out.

8.5 apps/smtp/smtp.c File Reference

8.5.1 Detailed Description

SMTP example implementation.

Author:

Adam Dunkels <adam@dunkels.com>

Definition in file smtp.c.

```
#include "smtp.h"
#include "smtp-strings.h"
#include "psock.h"
#include "uip.h"
#include <string.h>
```

Defines

- #define ISO_nl 0x0a
- #define ISO_cr 0x0d
- #define ISO_period 0x2e
- #define ISO 2 0x32
- #define ISO_3 0x33
- #define ISO_4 0x34
- #define ISO_5 0x35

- void smtp_appcall (void)
- void smtp_configure (char *lhostname, void *server) Specificy an SMTP server and hostname.
- unsigned char smtp_send (char *to, char *cc, char *from, char *subject, char *msg, u16_t msglen)

 Send an e-mail.
- void smtp_init (void)

8.6 apps/smtp/smtp.h File Reference

8.6.1 Detailed Description

SMTP header file.

Author:

Adam Dunkels <adam@dunkels.com>

Definition in file smtp.h.

```
#include "uipopt.h"
```

Data Structures

• struct smtp state

Appication specific configurations

An uIP application is implemented using a single application function that is called by uIP whenever a TCP/IP event occurs. The name of this function must be registered with uIP at compile time using the UIP_APPCALL definition.

uIP applications can store the application state within the uip_conn structure by specifying the type of the application structure by typedef:ing the type uip_tcp_appstate_t and uip_udp_appstate_t.

The file containing the definitions must be included in the uipopt.h file.

The following example illustrates how this can look.

```
void httpd_appcall(void);
#define UIP_APPCALL httpd_appcall

struct httpd_state {
    u8_t state;
    u16_t count;
    char *dataptr;
    char *script;
};
typedef struct httpd_state uip_tcp_appstate_t
```

• #define UIP_APPCALL smtp_appcall

The name of the application function that uIP should call in response to TCP/IP events.

• typedef smtp_state uip_tcp_appstate_t

The type of the application state that is to be stored in the uip_conn structure.

Defines

• #define SMTP_ERR_OK 0

Error number that signifies a non-error condition.

• #define SMTP_SEND(to, cc, from, subject, msg) smtp_send(to, cc, from, subject, msg, strlen(msg))

- void smtp_done (unsigned char error)

 Callback function that is called when an e-mail transmission is done.
- void smtp_init (void)
- void smtp_appcall (void)

8.7 apps/telnetd/shell.c File Reference

8.7.1 Detailed Description

Simple shell.

Author:

Adam Dunkels <adam@sics.se>

Definition in file shell.c.

```
#include "shell.h"
#include <string.h>
```

Defines

• #define SHELL_PROMPT "uIP 1.0> "

Functions

- void shell_init (void)

 Initialize the shell.
- void shell_start (void)

 Start the shell back-end.
- void shell_input (char *command)

Process a shell command.

8.8 apps/telnetd/shell.h File Reference

8.8.1 Detailed Description

Simple shell, header file.

Author:

Adam Dunkels <adam@sics.se>

Definition in file shell.h.

Functions

• void shell_init (void)

Initialize the shell.

• void shell_start (void)

Start the shell back-end.

• void shell_input (char *command)

Process a shell command.

• void shell_quit (char *)

Quit the shell.

• void shell_output (char *str1, char *str2)

Print a string to the shell window.

• void shell_prompt (char *prompt)

Print a prompt to the shell window.

8.9 apps/telnetd/telnetd.c File Reference

8.9.1 Detailed Description

Shell server.

Author:

Adam Dunkels <adam@sics.se>

Definition in file telnetd.c.

```
#include "uip.h"
#include "telnetd.h"
#include "memb.h"
#include "shell.h"
#include <string.h>
```

Defines

- #define ISO_nl 0x0a
- #define ISO_cr 0x0d
- #define STATE_NORMAL 0
- #define STATE_IAC 1
- #define STATE_WILL 2
- #define STATE_WONT 3
- #define STATE DO 4
- #define STATE_DONT 5
- #define STATE_CLOSE 6
- #define TELNET_IAC 255
- #define TELNET_WILL 251
- #define TELNET_WONT 252#define TELNET_DO 253
- #define TELNET_DONT 254

Functions

```
• void shell_quit (char *)

Quit the shell.
```

• void shell_prompt (char *prompt)

Print a prompt to the shell window.

• void shell_output (char *str1, char *str2)

Print a string to the shell window.

- void telnetd_init (void)
- void telnetd_appcall (void)

8.10 apps/telnetd/telnetd.h File Reference

8.10.1 Detailed Description

Shell server.

Author:

Adam Dunkels <adam@sics.se>

Definition in file telnetd.h.

#include "uipopt.h"

Data Structures

• struct telnetd_state

Defines

- #define TELNETD_CONF_LINELEN 40
- #define TELNETD_CONF_NUMLINES 16
- #define UIP_APPCALL telnetd_appcall

Typedefs

• typedef telnetd_state uip_tcp_appstate_t

Functions

• void telnetd_appcall (void)

8.11 apps/webclient/webclient.c File Reference

8.11.1 Detailed Description

Implementation of the HTTP client.

Author:

Adam Dunkels <adam@dunkels.com>

Definition in file webclient.c.

```
#include "uip.h"
#include "uiplib.h"
#include "webclient.h"
#include "resolv.h"
#include <string.h>
```

Defines

- #define WEBCLIENT TIMEOUT 100
- #define WEBCLIENT_STATE_STATUSLINE 0
- #define WEBCLIENT_STATE_HEADERS 1
- #define WEBCLIENT_STATE_DATA 2
- #define WEBCLIENT_STATE_CLOSE 3
- #define HTTPFLAG_NONE 0
- #define HTTPFLAG_OK 1
- #define HTTPFLAG_MOVED 2
- #define HTTPFLAG_ERROR 3
- #define ISO_nl 0x0a
- #define ISO_cr 0x0d
- #define ISO_space 0x20

Functions

- char * webclient_mimetype (void)
 Obtain the MIME type of the current HTTP data stream.
- char * webclient_filename (void)

 Obtain the filename of the current HTTP data stream.
- char * webclient_hostname (void)

Obtain the hostname of the current HTTP data stream.

- unsigned short webclient_port (void)
- Obtain the port number of the current HTTP data stream.
- void webclient_init (void)

Initialize the webclient module.

- void webclient_close (void)

 Close the currently open HTTP connection.
- unsigned char webclient_get (char *host, u16_t port, char *file)

 Open an HTTP connection to a web server and ask for a file using the GET method.
- void webclient_appcall (void)

8.12 apps/webclient/webclient.h File Reference

8.12.1 Detailed Description

Header file for the HTTP client.

Author:

Adam Dunkels <adam@dunkels.com>

Definition in file webclient.h.

```
#include "webclient-strings.h"
#include "uipopt.h"
```

Data Structures

• struct webclient_state

Defines

- #define WEBCLIENT_CONF_MAX_URLLEN 100
- #define UIP_APPCALL webclient_appcall

Typedefs

• typedef webclient_state uip_tcp_appstate_t

Functions

- void webclient_datahandler (char *data, u16_t len)

 Callback function that is called from the webclient code when HTTP data has been received.
- void webclient_connected (void)

Callback function that is called from the webclient code when the HTTP connection has been connected to the web server.

• void webclient_timedout (void)

Callback function that is called from the webclient code if the HTTP connection to the web server has timed out

• void webclient aborted (void)

Callback function that is called from the webclient code if the HTTP connection to the web server has been aborted by the web server.

• void webclient_closed (void)

Callback function that is called from the webclient code when the HTTP connection to the web server has been closed.

• void webclient_init (void)

Initialize the webclient module.

- unsigned char webclient_get (char *host, u16_t port, char *file)

 Open an HTTP connection to a web server and ask for a file using the GET method.
- void webclient_close (void)

 Close the currently open HTTP connection.
- void webclient_appcall (void)
- char * webclient_mimetype (void)

Obtain the MIME type of the current HTTP data stream.

• char * webclient_filename (void)

Obtain the filename of the current HTTP data stream.

• char * webclient_hostname (void)

Obtain the hostname of the current HTTP data stream.

• unsigned short webclient_port (void)

Obtain the port number of the current HTTP data stream.

8.13 apps/webserver/httpd-cgi.c File Reference

8.13.1 Detailed Description

Web server script interface.

Author:

Adam Dunkels <adam@sics.se>

Definition in file httpd-cgi.c.

```
#include "uip.h"
#include "psock.h"
#include "httpd.h"
#include "httpd-cgi.h"
#include "httpd-fs.h"
#include <stdio.h>
#include <string.h>
```

Functions

• httpd_cgifunction httpd_cgi (char *name)

8.14 apps/webserver/httpd-cgi.h File Reference

8.14.1 Detailed Description

Web server script interface header file.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file httpd-cgi.h.

```
#include "psock.h"
#include "httpd.h"
```

Data Structures

• struct httpd_cgi_call

Defines

```
• #define HTTPD_CGI_CALL(name, str, function) 
HTTPD CGI function declaration.
```

Functions

• httpd_cgifunction httpd_cgi (char *name)

8.15 apps/webserver/httpd.c File Reference

8.15.1 Detailed Description

Web server.

Author:

Adam Dunkels <adam@sics.se>

Definition in file httpd.c.

```
#include "uip.h"
#include "httpd.h"
#include "httpd-fs.h"
#include "httpd-cgi.h"
#include "http-strings.h"
#include <string.h>
```

Defines

- #define STATE_WAITING 0
- #define STATE OUTPUT 1
- #define ISO_nl 0x0a
- #define ISO_space 0x20
- #define ISO_bang 0x21
- #define ISO_percent 0x25
- #define ISO_period 0x2e
- #define ISO_slash 0x2f
- #define ISO_colon 0x3a

Functions

- void httpd_appcall (void)
- void httpd_init (void)

Initialize the web server.

8.16 lib/memb.c File Reference

8.16.1 Detailed Description

Memory block allocation routines.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file memb.c.

```
#include <string.h>
#include "memb.h"
```

- void memb_init (struct memb_blocks *m)
 Initialize a memory block that was declared with MEMB().
- void * memb_alloc (struct memb_blocks *m)
 Allocate a memory block from a block of memory declared with MEMB().
- char memb_free (struct memb_blocks *m, void *ptr)
 Deallocate a memory block from a memory block previously declared with MEMB().

8.17 lib/memb.h File Reference

8.17.1 Detailed Description

Memory block allocation routines.

Author:

Adam Dunkels <adam@sics.se>

Definition in file memb.h.

Data Structures

• struct memb_blocks

Defines

- #define MEMB_CONCAT2(s1, s2) s1##s2
- #define MEMB_CONCAT(s1, s2) MEMB_CONCAT2(s1, s2)
- #define MEMB(name, structure, num)

Declare a memory block.

- void memb_init (struct memb_blocks *m)
 Initialize a memory block that was declared with MEMB().
- void * memb_alloc (struct memb_blocks *m)
 Allocate a memory block from a block of memory declared with MEMB().
- char memb_free (struct memb_blocks *m, void *ptr)

 Deallocate a memory block from a memory block previously declared with MEMB().

8.18 uip/lc-addrlabels.h File Reference

8.18.1 Detailed Description

Implementation of local continuations based on the "Labels as values" feature of gcc.

Author:

```
Adam Dunkels <adam@sics.se>
```

This implementation of local continuations is based on a special feature of the GCC C compiler called "labels as values". This feature allows assigning pointers with the address of the code corresponding to a particular C label.

For more information, see the GCC documentation: http://gcc.gnu.org/onlinedocs/gcc/Labels-as-Values

Thanks to dividuum for finding the nice local scope label implementation.

Definition in file lc-addrlabels.h.

Defines

```
#define LC_INIT(s) s = NULL
#define LC_RESUME(s)
#define LC_SET(s) do { ({ __label__ resume; resume: (s) = &&resume; }); }while(0)
```

Typedefs

• typedef void * lc_t

• #define LC_END(s)

8.19 uip/lc-switch.h File Reference

8.19.1 Detailed Description

Implementation of local continuations based on switch() statment.

Author:

```
Adam Dunkels <adam@sics.se>
```

This implementation of local continuations uses the C switch() statement to resume execution of a function somewhere inside the function's body. The implementation is based on the fact that switch() statements are able to jump directly into the bodies of control structures such as if() or while() statements.

This implementation borrows heavily from Simon Tatham's coroutines implementation in C: http://www.chiark.greenend.org.uk/~sgtatham/coroutines.html

Definition in file lc-switch.h.

Defines

```
#define __LC_SWTICH_H__
#define LC_INIT(s) s = 0;
#define LC_RESUME(s) switch(s) { case 0:
#define LC_SET(s) s = __LINE__; case __LINE__:
#define LC_END(s) }
```

Typedefs

• typedef unsigned short lc_t

8.20 uip/lc.h File Reference

8.20.1 Detailed Description

Local continuations.

Author:

Adam Dunkels <adam@sics.se>

Definition in file lc.h.

#include "lc-switch.h"

8.21 uip/psock.h File Reference

8.21.1 Detailed Description

Protosocket library header file.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file psock.h.

```
#include "uipopt.h"
#include "pt.h"
```

Data Structures

- struct psock_buf
- struct psock

The representation of a protosocket.

Defines

- #define PSOCK_INIT(psock, buffer, buffersize) *Initialize a protosocket*.
- #define PSOCK_BEGIN(psock)

Start the protosocket protothread in a function.

- #define PSOCK_SEND(psock, data, datalen) Send data.
- #define PSOCK_SEND_STR(psock, str)
 Send a null-terminated string.
- #define PSOCK_GENERATOR_SEND(psock, generator, arg)
 Generate data with a function and send it.
- #define PSOCK_CLOSE(psock)

 $Close\ a\ protosocket.$

- #define PSOCK_READBUF(psock)

 Read data until the buffer is full.
- #define PSOCK_READTO(psock, c)

 Read data up to a specified character.
- #define PSOCK_DATALEN(psock)

The length of the data that was previously read.

• #define PSOCK_EXIT(psock)

Exit the protosocket's protothread.

• #define PSOCK_CLOSE_EXIT(psock)

Close a protosocket and exit the protosocket's protothread.

• #define PSOCK_END(psock)

Declare the end of a protosocket's protothread.

• #define PSOCK_NEWDATA(psock)

Check if new data has arrived on a protosocket.

• #define PSOCK_WAIT_UNTIL(psock, condition)

Wait until a condition is true.

• #define PSOCK_WAIT_THREAD(psock, condition) PT_WAIT_THREAD(&((psock) → pt), (condition))

- u16_t psock_datalen (struct psock *psock)
- char psock_newdata (struct psock *s)

8.22 uip/pt.h File Reference

8.22.1 Detailed Description

Protothreads implementation.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file pt.h.

```
#include "lc.h"
```

Data Structures

• struct pt

Initialization

• #define PT_INIT(pt)

Initialize a protothread.

Declaration and definition

```
• #define PT_THREAD(name_args)

Declaration of a protothread.
```

• #define PT_BEGIN(pt)

 $Declare\ the\ start\ of\ a\ protothread\ inside\ the\ C\ function\ implementing\ the\ protothread.$

• #define PT_END(pt)

Declare the end of a protothread.

Blocked wait

• #define PT_WAIT_UNTIL(pt, condition)

Block and wait until condition is true.

• #define PT_WAIT_WHILE(pt, cond)

Block and wait while condition is true.

Hierarchical protothreads

- #define PT_WAIT_THREAD(pt, thread)

 Block and wait until a child protothread completes.
- #define PT_SPAWN(pt, child, thread)

 Spawn a child protothread and wait until it exits.

Exiting and restarting

- #define PT_RESTART(pt)

 Restart the protothread.
- #define PT_EXIT(pt)

 Exit the protothread.

Calling a protothread

• #define PT_SCHEDULE(f) Schedule a protothread.

Yielding from a protothread

- #define PT_YIELD(pt)

 Yield from the current protothread.
- #define PT_YIELD_UNTIL(pt, cond)
 Yield from the protothread until a condition occurs.

Defines

- #define PT_WAITING 0
- #define PT_EXITED 1
- #define PT_ENDED 2
- #define PT_YIELDED 3

8.23 uip/timer.c File Reference

8.23.1 Detailed Description

Timer library implementation.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file timer.c.

```
#include "clock.h"
#include "timer.h"
```

Functions

- void timer_set (struct timer *t, clock_time_t interval)

 Set a timer.
- void timer_reset (struct timer *t)

 Reset the timer with the same interval.
- void timer_restart (struct timer *t)

 Restart the timer from the current point in time.
- int timer_expired (struct timer *t)

 Check if a timer has expired.

8.24 uip/timer.h File Reference

8.24.1 Detailed Description

Timer library header file.

Author:

Adam Dunkels <adam@sics.se>

Definition in file timer.h.

#include "clock.h"

Data Structures

• struct timer

A timer.

Functions

- void timer_set (struct timer *t, clock_time_t interval)

 Set a timer.
- void timer_reset (struct timer *t)

Reset the timer with the same interval.

• void timer_restart (struct timer *t)

Restart the timer from the current point in time.

• int timer_expired (struct timer *t)

Check if a timer has expired.

8.25 uip/uip-neighbor.c File Reference

8.25.1 Detailed Description

Database of link-local neighbors, used by IPv6 code and to be used by a future ARP code rewrite.

Author:

```
Adam Dunkels <adam@sics.se>
Definition in file uip-neighbor.c.
```

```
#include "uip-neighbor.h"
#include <string.h>
```

Defines

- #define MAX_TIME 128
- #define ENTRIES 8

Functions

- void uip_neighbor_init (void)
- void uip_neighbor_periodic (void)
- void uip_neighbor_add (uip_ipaddr_t ipaddr, struct uip_neighbor_addr *addr)
- void uip_neighbor_update (uip_ipaddr_t ipaddr)
- uip_neighbor_addr * uip_neighbor_lookup (uip_ipaddr_t ipaddr)

8.26 uip/uip-neighbor.h File Reference

8.26.1 Detailed Description

Header file for database of link-local neighbors, used by IPv6 code and to be used by future ARP code.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file uip-neighbor.h.

```
#include "uip.h"
```

Data Structures

• struct uip_neighbor_addr

Functions

- void uip_neighbor_init (void)
- void uip_neighbor_add (uip_ipaddr_t ipaddr, struct uip_neighbor_addr *addr)
- void uip_neighbor_update (uip_ipaddr_t ipaddr)
- uip_neighbor_addr * uip_neighbor_lookup (uip_ipaddr_t ipaddr)
- void uip_neighbor_periodic (void)

8.27 uip/uip-split.h File Reference

8.27.1 Detailed Description

Module for splitting outbound TCP segments in two to avoid the delayed ACK throughput degradation.

Author:

Adam Dunkels <adam@sics.se>

Definition in file uip-split.h.

Functions

• void uip_split_output (void)

Handle outgoing packets.

8.28 uip/uip.c File Reference

8.28.1 Detailed Description

The uIP TCP/IP stack code.

Author:

Adam Dunkels <adam@dunkels.com>

```
Definition in file uip.c.
```

```
#include "uip.h"
#include "uipopt.h"
#include "uip_arch.h"
#include <string.h>
```

Defines

- #define DEBUG_PRINTF()
- #define TCP_FIN 0x01
- #define TCP_SYN 0x02
- #define TCP_RST 0x04
- #define TCP_PSH 0x08
- #define TCP_ACK 0x10
- #define TCP_URG 0x20
- #define TCP CTL 0x3f
- #define TCP_OPT_END 0
- #define TCP_OPT_NOOP 1
- #define TCP_OPT_MSS 2
- #define TCP_OPT_MSS_LEN 4
- #define ICMP_ECHO_REPLY 0
- #define ICMP_ECHO 8
- #define ICMP6_ECHO_REPLY 129
- #define ICMP6_ECHO 128
- #define ICMP6_NEIGHBOR_SOLICITATION 135
- #define ICMP6_NEIGHBOR_ADVERTISEMENT 136
- #define ICMP6_FLAG_S (1 << 6)
- #define ICMP6_OPTION_SOURCE_LINK_ADDRESS 1
- #define ICMP6_OPTION_TARGET_LINK_ADDRESS 2
- #define BUF ((struct uip_tcpip_hdr *)&uip_buf[UIP_LLH_LEN])
- #define FBUF ((struct uip_tcpip_hdr *)&uip_reassbuf[0])
- #define ICMPBUF ((struct uip_icmpip_hdr *)&uip_buf[UIP_LLH_LEN])
- #define UDPBUF ((struct uip_udpip_hdr *)&uip_buf[UIP_LLH_LEN])
- #define UIP_STAT(s)
- #define UIP LOG(m)

Functions

```
• void uip_setipid (u16_t id)
      uIP initialization function.
• void uip_add32 (u8_t *op32, u16_t op16)
      Carry out a 32-bit addition.
• u16_t uip_chksum (u16_t *buf, u16_t len)
      Calculate the Internet checksum over a buffer.
• u16_t uip_ipchksum (void)
      Calculate the IP header checksum of the packet header in uip_buf.
• u16_t uip_tcpchksum (void)
      Calculate the TCP checksum of the packet in uip_buf and uip_appdata.
• void uip_init (void)
      uIP initialization function.
• uip_conn * uip_connect (uip_ipaddr_t *ripaddr, u16_t rport)
      Connect to a remote host using TCP.
```

- uip_udp_conn * uip_udp_new (uip_ipaddr_t *ripaddr, u16_t rport) Set up a new UDP connection.
- void uip_unlisten (u16_t port) Stop listening to the specified port.
- void uip_listen (u16_t port) Start listening to the specified port.
- void uip_process (u8_t flag)
- u16_t htons (u16_t val)

Convert 16-bit quantity from host byte order to network byte order.

• void uip send (const void *data, int len) Send data on the current connection.

Variables

- uip_ipaddr_t uip_hostaddr
- uip_ipaddr_t uip_draddr
- uip_ipaddr_t uip_netmask
- $uip_eth_addr\ uip_ethaddr = \{\{0,0,0,0,0,0,0\}\}$
- u8_t uip_buf [UIP_BUFSIZE+2]

The uIP packet buffer.

• void * uip_appdata

Pointer to the application data in the packet buffer.

- void * uip_sappdata
- u16_t uip_len

The length of the packet in the uip_buf buffer.

- u16_t uip_slen
- u8_t uip_flags
- uip_conn * uip_conn

Pointer to the current TCP connection.

- uip_conn uip_conns [UIP_CONNS]
- u16_t uip_listenports [UIP_LISTENPORTS]
- uip_udp_conn * uip_udp_conn

The current UDP connection.

- uip_udp_conn uip_udp_conns [UIP_UDP_CONNS]
- u8_t uip_acc32 [4]

4-byte array used for the 32-bit sequence number calculations.

8.29 uip/uip.h File Reference

8.29.1 Detailed Description

Header file for the uIP TCP/IP stack.

Author:

Adam Dunkels <adam@dunkels.com>

The uIP TCP/IP stack header file contains definitions for a number of C macros that are used by uIP programs as well as internal uIP structures, TCP/IP header structures and function declarations.

Definition in file uip.h.

```
#include "uipopt.h"
```

Data Structures

• struct uip_conn

Representation of a uIP TCP connection.

• struct uip_udp_conn

Representation of a uIP UDP connection.

• struct uip_stats

The structure holding the TCP/IP statistics that are gathered if UIP_STATISTICS is set to 1.

- struct uip_tcpip_hdr
- struct uip_icmpip_hdr
- struct uip_udpip_hdr
- struct uip_eth_addr

Representation of a 48-bit Ethernet address.

Defines

• #define uip_sethostaddr(addr)

Set the IP address of this host.

• #define uip_gethostaddr(addr)

Get the IP address of this host.

• #define uip_setdraddr(addr)

Set the default router's IP address.

• #define uip_setnetmask(addr)

Set the netmask.

• #define uip_getdraddr(addr)

Get the default router's IP address.

• #define uip_getnetmask(addr)

Get the netmask.

• #define uip input()

Process an incoming packet.

• #define uip_periodic(conn)

Periodic processing for a connection identified by its number.

- #define uip_conn_active(conn) (uip_conns[conn].tcpstateflags != UIP_CLOSED)
- #define uip_periodic_conn(conn)

Perform periodic processing for a connection identified by a pointer to its structure.

• #define uip_poll_conn(conn)

Reugest that a particular connection should be polled.

• #define uip_udp_periodic(conn)

Periodic processing for a UDP connection identified by its number.

• #define uip_udp_periodic_conn(conn)

Periodic processing for a UDP connection identified by a pointer to its structure.

- #define uip_outstanding(conn) ((conn) → len)
- #define uip_datalen()

The length of any incoming data that is currently avaliable (if avaliable) in the uip_appdata buffer.

• #define uip_urgdatalen()

The length of any out-of-band data (urgent data) that has arrived on the connection.

• #define uip_close()

Close the current connection.

• #define uip_abort()

Abort the current connection.

• #define uip_stop()

Tell the sending host to stop sending data.

• #define uip_stopped(conn)

Find out if the current connection has been previously stopped with uip_stop().

• #define uip_restart()

Restart the current connection, if is has previously been stopped with uip_stop().

• #define uip_udpconnection()

Is the current connection a UDP connection?

• #define uip_newdata()

Is new incoming data available?

• #define uip_acked()

Has previously sent data been acknowledged?

• #define uip_connected()

Has the connection just been connected?

• #define uip_closed()

Has the connection been closed by the other end?

• #define uip_aborted()

Has the connection been aborted by the other end?

• #define uip_timedout()

Has the connection timed out?

• #define uip_rexmit()

Do we need to retransmit previously data?

• #define uip_poll()

Is the connection being polled by uIP?

• #define uip_initialmss()

Get the initial maxium segment size (MSS) of the current connection.

• #define uip_mss()

Get the current maxium segment size that can be sent on the current connection.

• #define uip_udp_remove(conn)

Removed a UDP connection.

• #define uip_udp_bind(conn, port)

Bind a UDP connection to a local port.

• #define uip_udp_send(len)

Send a UDP datagram of length len on the current connection.

• #define uip_ipaddr(addr, addr0, addr1, addr2, addr3)

Construct an IP address from four bytes.

• #define uip_ip6addr(addr, addr0, addr1, addr2, addr3, addr4, addr5, addr6, addr7)

Construct an IPv6 address from eight 16-bit words.

• #define uip_ipaddr_copy(dest, src)

Copy an IP address to another IP address.

• #define uip_ipaddr_cmp(addr1, addr2)

Compare two IP addresses.

• #define uip_ipaddr_maskcmp(addr1, addr2, mask)

Compare two IP addresses with netmasks.

• #define uip_ipaddr_mask(dest, src, mask)

Mask out the network part of an IP address.

• #define uip ipaddr1(addr)

Pick the first octet of an IP address.

• #define uip_ipaddr2(addr)

Pick the second octet of an IP address.

• #define uip ipaddr3(addr)

Pick the third octet of an IP address.

• #define uip_ipaddr4(addr)

Pick the fourth octet of an IP address.

• #define HTONS(n)

Convert 16-bit quantity from host byte order to network byte order.

- #define ntohs htons
- #define UIP_ACKDATA 1
- #define UIP_NEWDATA 2
- #define UIP_REXMIT 4
- #define UIP POLL 8
- #define UIP_CLOSE 16
- #define UIP_ABORT 32
- #define UIP_CONNECTED 64
- #define UIP_TIMEDOUT 128
- #define UIP_DATA 1
- #define UIP_TIMER 2
- #define UIP_POLL_REQUEST 3
- #define UIP_UDP_SEND_CONN 4
- #define UIP_UDP_TIMER 5
- #define UIP_CLOSED 0
- #define UIP_SYN_RCVD 1
- #define UIP_SYN_SENT 2
- #define UIP ESTABLISHED 3
- #define UIP_FIN_WAIT_1 4
- #define UIP_FIN_WAIT_2 5
- #define UIP_CLOSING 6
- #define UIP_TIME_WAIT 7
- #define UIP_LAST_ACK 8
- #define UIP_TS_MASK 15
- #define UIP_STOPPED 16
- #define UIP_APPDATA_SIZE

The buffer size available for user data in the uip_buf buffer.

- #define UIP PROTO ICMP 1
- #define UIP_PROTO_TCP 6

- #define UIP_PROTO_UDP 17
- #define UIP_PROTO_ICMP6 58
- #define UIP_IPH_LEN 20
- #define UIP_UDPH_LEN 8
- #define UIP_TCPH_LEN 20
- #define UIP_IPUDPH_LEN (UIP_UDPH_LEN + UIP_IPH_LEN)
- #define UIP_IPTCPH_LEN (UIP_TCPH_LEN + UIP_IPH_LEN)
- #define UIP_TCPIP_HLEN UIP_IPTCPH_LEN

Typedefs

- typedef u16_t uip_ip4addr_t [2]

 Repressentation of an IP address.
- typedef u16_t uip_ip6addr_t [8]
- typedef uip_ip4addr_t uip_ipaddr_t

Functions

- void uip_init (void)

 uIP initialization function.
- void uip_setipid (u16_t id)

 uIP initialization function.
- void uip_listen (u16_t port)

 Start listening to the specified port.
- void uip_unlisten (u16_t port)
 Stop listening to the specified port.
- uip_conn * uip_connect (uip_ipaddr_t *ripaddr, u16_t port)

 Connect to a remote host using TCP.
- void uip_send (const void *data, int len)

 Send data on the current connection.
- uip_udp_conn * uip_udp_new (uip_ipaddr_t *ripaddr, u16_t rport)

 Set up a new UDP connection.
- u16_t htons (u16_t val)

Convert 16-bit quantity from host byte order to network byte order.

- void uip_process (u8_t flag)
- u16_t uip_chksum (u16_t *buf, u16_t len)

Calculate the Internet checksum over a buffer.

• u16_t uip_ipchksum (void)

Calculate the IP header checksum of the packet header in uip_buf.

• u16_t uip_tcpchksum (void)

Calculate the TCP checksum of the packet in uip_buf and uip_appdata.

• u16_t uip_udpchksum (void)

Calculate the UDP checksum of the packet in uip_buf and uip_appdata.

Variables

• u8_t uip_buf [UIP_BUFSIZE+2]

The uIP packet buffer.

• void * uip_appdata

Pointer to the application data in the packet buffer.

• u16_t uip_len

The length of the packet in the uip_buf buffer.

• uip_conn * uip_conn

Pointer to the current TCP connection.

- uip_conn uip_conns [UIP_CONNS]
- u8_t uip_acc32 [4]

4-byte array used for the 32-bit sequence number calculations.

• uip_udp_conn * uip_udp_conn

The current UDP connection.

- uip_udp_conn uip_udp_conns [UIP_UDP_CONNS]
- uip_stats uip_stat

The uIP TCP/IP statistics.

- u8_t uip_flags
- uip_ipaddr_t uip_hostaddr
- uip_ipaddr_t uip_netmask
- uip_ipaddr_t uip_draddr

8.30 uip/uip_arch.h File Reference

8.30.1 Detailed Description

Declarations of architecture specific functions.

Author:

```
Adam Dunkels <adam@dunkels.com>
```

Definition in file uip_arch.h.

```
#include "uip.h"
```

Functions

- void uip_add32 (u8_t *op32, u16_t op16)

 Carry out a 32-bit addition.
- u16_t uip_chksum (u16_t *buf, u16_t len)

 Calculate the Internet checksum over a buffer.
- u16_t uip_ipchksum (void)

 Calculate the IP header checksum of the packet header in uip_buf.
- u16_t uip_tcpchksum (void)

Calculate the TCP checksum of the packet in uip_buf and uip_appdata.

8.31 uip/uip_arp.c File Reference

8.31.1 Detailed Description

Implementation of the ARP Address Resolution Protocol.

Author:

```
Adam Dunkels <adam@dunkels.com>
```

Definition in file uip_arp.c.

```
#include "uip_arp.h"
#include <string.h>
```

Defines

- #define ARP_REQUEST 1
- #define ARP_REPLY 2
- #define ARP_HWTYPE_ETH 1
- #define BUF ((struct arp_hdr *)&uip_buf[0])
- #define IPBUF ((struct ethip_hdr *)&uip_buf[0])

Functions

- void uip_arp_init (void)

 Initialize the ARP module.
- void uip_arp_timer (void)

 Periodic ARP processing function.
- void uip_arp_arpin (void)
 ARP processing for incoming ARP packets.
- void uip_arp_out (void)

Prepend Ethernet header to an outbound IP packet and see if we need to send out an ARP request.

8.32 uip/uip_arp.h File Reference

8.32.1 Detailed Description

Macros and definitions for the ARP module.

Author:

Adam Dunkels <adam@dunkels.com>

Definition in file uip_arp.h.

```
#include "uip.h"
```

Data Structures

• struct uip_eth_hdr

The Ethernet header.

Defines

- #define UIP_ETHTYPE_ARP 0x0806
- #define UIP_ETHTYPE_IP 0x0800
- #define UIP_ETHTYPE_IP6 0x86dd
- #define uip_arp_ipin()
- #define uip_setethaddr(eaddr)

Specifiy the Ethernet MAC address.

Functions

- void uip_arp_init (void)
 - Initialize the ARP module.

• void uip_arp_arpin (void)

ARP processing for incoming ARP packets.

• void uip_arp_out (void)

Prepend Ethernet header to an outbound IP packet and see if we need to send out an ARP request.

• void uip_arp_timer (void)

Periodic ARP processing function.

Variables

• uip_eth_addr uip_ethaddr

8.33 uip/uipopt.h File Reference

8.33.1 Detailed Description

Configuration options for uIP.

Author:

Adam Dunkels <adam@dunkels.com>

This file is used for tweaking various configuration options for uIP. You should make a copy of this file into one of your project's directories instead of editing this example "uipopt.h" file that comes with the uIP distribution.

Definition in file uipopt.h.

```
#include "uip-conf.h"
```

Static configuration options

These configuration options can be used for setting the IP address settings statically, but only if UIP_-FIXEDADDR is set to 1. The configuration options for a specific node includes IP address, netmask and default router as well as the Ethernet address. The netmask, default router and Ethernet address are appliciable only if uIP should be run over Ethernet.

All of these should be changed to suit your project.

• #define UIP_FIXEDADDR

Determines if uIP should use a fixed IP address or not.

• #define UIP PINGADDRCONF

Ping IP address asignment.

• #define UIP_FIXEDETHADDR

Specifies if the uIP ARP module should be compiled with a fixed Ethernet MAC address or not.

IP configuration options

• #define UIP_TTL 64

The IP TTL (time to live) of IP packets sent by uIP.

• #define UIP_REASSEMBLY

Turn on support for IP packet reassembly.

• #define UIP_REASS_MAXAGE 40

The maximum time an IP fragment should wait in the reassembly buffer before it is dropped.

UDP configuration options

• #define UIP_UDP

Toggles wether UDP support should be compiled in or not.

• #define UIP_UDP_CHECKSUMS

Toggles if UDP checksums should be used or not.

• #define UIP_UDP_CONNS

The maximum amount of concurrent UDP connections.

TCP configuration options

• #define UIP_ACTIVE_OPEN

Determines if support for opening connections from uIP should be compiled in.

• #define UIP CONNS

The maximum number of simultaneously open TCP connections.

• #define UIP_LISTENPORTS

The maximum number of simultaneously listening TCP ports.

• #define UIP_URGDATA

Determines if support for TCP urgent data notification should be compiled in.

• #define UIP_RTO 3

The initial retransmission timeout counted in timer pulses.

• #define UIP_MAXRTX 8

The maximum number of times a segment should be retransmitted before the connection should be aborted.

• #define UIP_MAXSYNRTX 5

The maximum number of times a SYN segment should be retransmitted before a connection request should be deemed to have been unsuccessful.

• #define UIP_TCP_MSS (UIP_BUFSIZE - UIP_LLH_LEN - UIP_TCPIP_HLEN)

The TCP maximum segment size.

• #define UIP_RECEIVE_WINDOW

The size of the advertised receiver's window.

• #define UIP_TIME_WAIT_TIMEOUT 120

How long a connection should stay in the TIME_WAIT state.

ARP configuration options

• #define UIP_ARPTAB_SIZE

The size of the ARP table.

• #define UIP_ARP_MAXAGE 120

The maxium age of ARP table entries measured in 10ths of seconds.

General configuration options

• #define UIP_BUFSIZE

The size of the uIP packet buffer.

• #define UIP_STATISTICS

Determines if statistics support should be compiled in.

• #define UIP_LOGGING

Determines if logging of certain events should be compiled in.

• #define UIP_BROADCAST

Broadcast support.

• #define UIP_LLH_LEN

The link level header length.

• void uip_log (char *msg)

Print out a uIP log message.

CPU architecture configuration

The CPU architecture configuration is where the endianess of the CPU on which uIP is to be run is specified. Most CPUs today are little endian, and the most notable exception are the Motorolas which are big endian. The BYTE_ORDER macro should be changed to reflect the CPU architecture on which uIP is to be run.

• #define UIP_BYTE_ORDER

The byte order of the CPU architecture on which uIP is to be run.

Defines

- #define UIP_LITTLE_ENDIAN 3412
- #define UIP_BIG_ENDIAN 1234

8.34 unix/uip-conf.h File Reference

8.34.1 Detailed Description

An example uIP configuration file.

Author:

```
Adam Dunkels <adam@sics.se>
```

Definition in file uip-conf.h.

```
#include <inttypes.h>
#include "webserver.h"
```

Project-specific configuration options

uIP has a number of configuration options that can be overridden for each project. These are kept in a project-specific uip-conf.h file and all configuration names have the prefix UIP_CONF.

```
• #define UIP_CONF_MAX_CONNECTIONS

Maximum number of TCP connections.
```

```
• #define UIP_CONF_MAX_LISTENPORTS

Maximum number of listening TCP ports.
```

```
• #define UIP_CONF_BUFFER_SIZE uIP buffer size.
```

```
• #define UIP_CONF_BYTE_ORDER 
CPU byte order.
```

```
• #define UIP_CONF_LOGGING Logging on or off.
```

```
• #define UIP_CONF_UDP 
 UDP support on or off.
```

• #define UIP_CONF_UDP_CHECKSUMS UDP checksums on or off.

```
33
```

```
• #define UIP_CONF_STATISTICS

uIP statistics on or off
```

```
• typedef uint8_t u8_t
8 bit datatype
```

```
• typedef uint16_t u16_t

16 bit datatype
```

• typedef unsigned short uip_stats_t Statistics datatype.

Chapter 9

uIP 1.0 Example Documentation

9.1 dhcpc.c

```
2 * Copyright (c) 2005, Swedish Institute of Computer Science
3 * All rights reserved.
  * Redistribution and use in source and binary forms, with or without
6 \star modification, are permitted provided that the following conditions
8 \star 1. Redistributions of source code must retain the above copyright
       notice, this list of conditions and the following disclaimer.
10 \star 2. Redistributions in binary form must reproduce the above copyright
        notice, this list of conditions and the following disclaimer in the
        documentation and/or other materials provided with the distribution.
13 \,\,\star\, 3. Neither the name of the Institute nor the names of its contributors
14 *
        may be used to endorse or promote products derived from this software
        without specific prior written permission.
16
   * THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS "AS IS" AND
17
18 \star ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
19 \star IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
20 \star ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE
21 * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
22 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
   * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
24 \star HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
25 * LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
26 \star OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
27 * SUCH DAMAGE.
28 +
29 * This file is part of the uIP TCP/IP stack
31 * @(#)$Id: dhcpc.c,v 1.2 2006/06/11 21:46:37 adam Exp $
32 */
33
34 #include <stdio.h>
35 #include <string.h>
37 #include "uip.h"
38 #include "dhcpc.h"
39 #include "timer.h"
40 #include "pt.h"
41
42 #define STATE_INITIAL
43 #define STATE SENDING
44 #define STATE_OFFER_RECEIVED 2
```

```
45 #define STATE_CONFIG_RECEIVED 3
47 static struct dhcpc_state s;
49 struct dhcp_msg {
    u8_t op, htype, hlen, hops;
    u8_t xid[4];
51
52
    u16_t secs, flags;
53
    u8_t ciaddr[4];
54
    u8 t viaddr[4]:
55
    u8_t siaddr[4];
56
    u8_t giaddr[4];
57
    u8_t chaddr[16];
58 #ifndef UIP_CONF_DHCP_LIGHT
59 u8_t sname[64];
60
    u8_t file[128];
61 #endif
62 u8_t options[312];
63 };
65 #define BOOTP_BROADCAST 0x8000
67 #define DHCP_REQUEST
68 #define DHCP_REPLY
69 #define DHCP_HTYPE_ETHERNET 1
70 #define DHCP_HLEN_ETHERNET 6
71 #define DHCP_MSG_LEN
                         236
72
73 #define DHCPC_SERVER_PORT 67
74 #define DHCPC_CLIENT_PORT 68
75
76 #define DHCPDISCOVER 1
77 #define DHCPOFFER
78 #define DHCPREQUEST
                       3
79 #define DHCPDECLINE
                        4
80 #define DHCPACK
81 #define DHCPNAK
                       6
82 #define DHCPRELEASE
84 #define DHCP_OPTION_SUBNET_MASK 1
85 #define DHCP_OPTION_ROUTER
86 #define DHCP_OPTION_DNS_SERVER
87 #define DHCP_OPTION_REQ_IPADDR
                                  50
88 #define DHCP_OPTION_LEASE_TIME
89 #define DHCP_OPTION_MSG_TYPE
                                  53
90 #define DHCP_OPTION_SERVER_ID
91 #define DHCP_OPTION_REQ_LIST
                                  55
92 #define DHCP_OPTION_END
                                 255
94 static const u8_t xid[4] = {0xad, 0xde, 0x12, 0x23};
95 static const u8_t magic_cookie[4] = {99, 130, 83, 99};
97 static u8_t *
98 add_msg_type(u8_t *optptr, u8_t type)
99 {
100 *optptr++ = DHCP_OPTION_MSG_TYPE;
101
     *optptr++ = 1;
    *optptr++ = type;
102
103
    return optptr;
105 /*-----*/
106 static u8_t *
107 add_server_id(u8_t *optptr)
108 {
109 *optptr++ = DHCP_OPTION_SERVER_ID;
    *optptr++ = 4;
memcpy(optptr, s.serverid, 4);
110
111
```

9.1 dhcpc.c 199

```
return optptr + 4;
113 }
                       114 /*----
115 static u8_t *
116 add_req_ipaddr(u8_t *optptr)
118 *optptr++ = DHCP_OPTION_REQ_IPADDR;
    *optptr++ = 4;
119
    memcpy(optptr, s.ipaddr, 4);
return optptr + 4;
120
121
122 }
123 /*----
124 static u8_t *
125 add_req_options(u8_t *optptr)
126 {
127
     *optptr++ = DHCP_OPTION_REQ_LIST;
    *optptr++ = 3;
128
    *optptr++ = DHCP_OPTION_SUBNET_MASK;
129
130
     *optptr++ = DHCP_OPTION_ROUTER;
    *optptr++ = DHCP_OPTION_DNS_SERVER;
131
132
    return optptr;
133 }
134 /*----
                      135 static u8_t *
136 add_end(u8_t *optptr)
137 {
138
    *optptr++ = DHCP_OPTION_END;
139
     return optptr;
140 }
141 /*-----
142 static void
143 create_msg(register struct dhcp_msg *m)
144 {
    m->op = DHCP_REQUEST;
m->htype = DHCP_HTYPE_ETHERNET;
145
146
    m->hlen = s.mac_len;
147
    m->hops = 0;
148
149
     memcpy(m->xid, xid, sizeof(m->xid));
150
    m->secs = 0;
151
    m->flags = HTONS(BOOTP_BROADCAST); /* Broadcast bit. */
152
     /* uip_ipaddr_copy(m->ciaddr, uip_hostaddr);*/
    memcpy(m->ciaddr, uip_hostaddr, sizeof(m->ciaddr));
153
154
    memset(m->yiaddr, 0, sizeof(m->yiaddr));
155
     memset(m->siaddr, 0, sizeof(m->siaddr));
    memset(m->giaddr, 0, sizeof(m->giaddr));
156
    memcpy(m->chaddr, s.mac_addr, s.mac_len);
157
158
     memset(&m->chaddr[s.mac_len], 0, sizeof(m->chaddr) - s.mac_len);
159 #ifndef UIP_CONF_DHCP_LIGHT
160 memset(m->sname, 0, sizeof(m->sname));
161
     memset(m->file, 0, sizeof(m->file));
162 #endif
163
    memcpy(m->options, magic_cookie, sizeof(magic_cookie));
164
165 }
166 /*----
167 static void
168 send_discover(void)
169 {
170
    u8_t *end;
     struct dhcp_msg *m = (struct dhcp_msg *)uip_appdata;
171
172
173
     create_msg(m);
174
175
     end = add_msg_type(&m->options[4], DHCPDISCOVER);
176
     end = add_req_options(end);
177
     end = add_end(end);
178
```

```
uip_send(uip_appdata, end - (u8_t *)uip_appdata);
180 }
181 /*-----*/
182 static void
183 send_request(void)
184 {
185
    u8 t *end;
186
    struct dhcp_msg *m = (struct dhcp_msg *)uip_appdata;
187
188
    create_msg(m);
189
190
     end = add_msg_type(&m->options[4], DHCPREQUEST);
    end = add_server_id(end);
191
192
    end = add_req_ipaddr(end);
193
    end = add_end(end);
194
    uip_send(uip_appdata, end - (u8_t *)uip_appdata);
195
196 }
197 /*-----*/
198 static u8_t
199 parse_options(u8_t *optptr, int len)
200 {
    u8_t *end = optptr + len;
201
2.02
    u8\_t type = 0;
203
    while(optptr < end) {
204
205
     switch(*optptr) {
      case DHCP_OPTION_SUBNET_MASK:
206
      memcpy(s.netmask, optptr + 2, 4);
207
208
       break;
     case DHCP_OPTION_ROUTER:
209
      memcpy(s.default_router, optptr + 2, 4);
break;
210
211
     case DHCP_OPTION_DNS_SERVER:
212
     memcpy(s.dnsaddr, optptr + 2, 4);
break;
213
214
     case DHCP_OPTION_MSG_TYPE:
215
      type = *(optptr + 2);
break;
216
217
     case DHCP_OPTION_SERVER_ID:
218
     memcpy(s.serverid, optptr + 2, 4);
break;
219
220
221 case DHCP_OPTION_LEASE_TIME:
      memcpy(s.lease_time, optptr + 2, 4);
break;
222
223
224
     case DHCP_OPTION_END:
225
       return type;
226
227
228
      optptr += optptr[1] + 2;
229
230
    return type;
231 }
232 /*----
233 static u8_t
234 parse_msg(void)
235 {
236
    struct dhcp_msg *m = (struct dhcp_msg *)uip_appdata;
2.37
     if(m->op == DHCP_REPLY &&
238
     memcmp(m->xid, xid, sizeof(xid)) == 0 &&
239
240
      memcmp(m->chaddr, s.mac_addr, s.mac_len) == 0) {
241
      memcpy(s.ipaddr, m->yiaddr, 4);
2.42
      return parse_options(&m->options[4], uip_datalen());
243
    return 0;
244
245 }
```

9.1 dhcpc.c 201

```
246 /*----
247 static
248 PT_THREAD(handle_dhcp(void))
249 {
250
     PT_BEGIN(&s.pt);
251
252
     /* try_again:*/
2.53
     s.state = STATE_SENDING;
2.54
     s.ticks = CLOCK_SECOND;
255
256
     do {
257
       send_discover();
258
        timer_set(&s.timer, s.ticks);
259
       PT_WAIT_UNTIL(&s.pt, uip_newdata() || timer_expired(&s.timer));
260
2.61
        if(uip_newdata() && parse_msg() == DHCPOFFER) {
2.62
         s.state = STATE_OFFER_RECEIVED;
263
          break:
264
265
266
       if(s.ticks < CLOCK_SECOND * 60) {</pre>
267
          s.ticks \star= 2;
268
     } while(s.state != STATE_OFFER_RECEIVED);
2.69
270
271
     s.ticks = CLOCK_SECOND;
272
273
      do {
274
       send_request();
275
        timer_set(&s.timer, s.ticks);
276
       PT_WAIT_UNTIL(&s.pt, uip_newdata() || timer_expired(&s.timer));
277
278
        if(uip_newdata() && parse_msg() == DHCPACK) {
279
         s.state = STATE_CONFIG_RECEIVED;
280
          break;
281
282
283
       if(s.ticks <= CLOCK_SECOND * 10) {</pre>
284
         s.ticks += CLOCK_SECOND;
2.85
        } else {
286
          PT_RESTART(&s.pt);
287
288
     } while(s.state != STATE_CONFIG_RECEIVED);
289
290 #if 0
291
    printf("Got IP address %d.%d.%d.%d\n",
             uip_ipaddr1(s.ipaddr), uip_ipaddr2(s.ipaddr),
uip_ipaddr3(s.ipaddr), uip_ipaddr4(s.ipaddr));
292
293
    printf("Got netmask %d.%d.%d.%d\n",
294
295
             uip_ipaddr1(s.netmask), uip_ipaddr2(s.netmask),
296
             uip_ipaddr3(s.netmask), uip_ipaddr4(s.netmask));
297
    printf("Got DNS server %d.%d.%d.%d\n",
298
             uip_ipaddr1(s.dnsaddr), uip_ipaddr2(s.dnsaddr),
299
             uip_ipaddr3(s.dnsaddr), uip_ipaddr4(s.dnsaddr));
    printf("Got default router %d.%d.%d.%d\n",
300
301
             uip_ipaddr1(s.default_router), uip_ipaddr2(s.default_router),
302
             uip_ipaddr3(s.default_router), uip_ipaddr4(s.default_router));
303
     printf("Lease expires in %ld seconds\n",
304
             ntohs(s.lease_time[0]) *65536ul + ntohs(s.lease_time[1]));
305 #endif
306
307
      dhcpc_configured(&s);
308
309
     /* timer_stop(&s.timer);*/
310
311
312
       \star PT_END restarts the thread so we do this instead. Eventually we
```

```
313
   * should reacquire expired leases here.
314
     * /
   while(1) {
315
316
   PT_YIELD(&s.pt);
317
   }
318
319
    PT_END(&s.pt);
320 }
321 /*---
322 void
323 dhcpc_init(const void *mac_addr, int mac_len)
324 {
325
   uip_ipaddr_t addr;
326
327
    s.mac_addr = mac_addr;
   s.mac_len = mac_len;
328
329
   s.state = STATE_INITIAL;
uip_ipaddr(addr, 255,255,255,255);
330
331
332
   s.conn = uip_udp_new(&addr, HTONS(DHCPC_SERVER_PORT));
   if(s.conn != NULL) {
333
   uip_udp_bind(s.conn, HTONS(DHCPC_CLIENT_PORT));
}
334
335
336 PT_INIT(&s.pt);
337 }
338 /*-----/
339 void
340 dhcpc_appcall(void)
341 {
342 handle_dhcp();
343 }
344 /*-----*/
345 void
346 dhcpc_request(void)
347 {
348 u16_t ipaddr[2];
349
350 if(s.state == STATE_INITIAL) {
351 uip_ipaddr(ipaddr, 0,0,0,0);
352
     uip_sethostaddr(ipaddr);
353
     /* handle_dhcp(PROCESS_EVENT_NONE, NULL);*/
354 }
355 }
356 /*----*/
```

9.2 dhepc.h

9.2 dhcpc.h

```
2 * Copyright (c) 2005, Swedish Institute of Computer Science
  * All rights reserved.
  * Redistribution and use in source and binary forms, with or without
  * modification, are permitted provided that the following conditions
  * are met:
8 	 * 1. Redistributions of source code must retain the above copyright
       notice, this list of conditions and the following disclaimer.
10 \star 2. Redistributions in binary form must reproduce the above copyright
11 \star notice, this list of conditions and the following disclaimer in the
        documentation and/or other materials provided with the distribution.
13 \star 3. Neither the name of the Institute nor the names of its contributors
14 *
       may be used to endorse or promote products derived from this software
15
        without specific prior written permission.
16
17 \star THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS "AS IS" AND
18 \star ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
19 * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
20 \star ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE
21 \star FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
   * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
23 * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
24 \star HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
   * LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
26 * OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
2.7
   * SUCH DAMAGE.
2.8
29 * This file is part of the uIP TCP/IP stack
30 +
31 * @(#)$Id: dhcpc.h,v 1.3 2006/06/11 21:46:37 adam Exp $ 32 */
33 #ifndef __DHCPC_H_
34 #define __DHCPC_H_
35
36 #include "timer.h"
37 #include "pt.h"
38
39 struct dhcpc_state {
40 struct pt pt;
41
    char state;
42
    struct uip_udp_conn *conn;
4.3
    struct timer timer;
44
    u16_t ticks;
    const void *mac_addr;
45
46
    int mac_len;
47
    u8_t serverid[4];
48
49
50
    u16_t lease_time[2];
51
    u16_t ipaddr[2];
    u16_t netmask[2];
53
    u16_t dnsaddr[2];
54
    u16_t default_router[2];
55 };
56
57 void dhcpc_init(const void *mac_addr, int mac_len);
58 void dhcpc_request(void);
59
60 void dhcpc_appcall(void);
61
62 void dhcpc_configured(const struct dhcpc_state *s);
64 typedef struct dhcpc_state uip_udp_appstate_t;
65 #define UIP_UDP_APPCALL dhcpc_appcall
```

```
66
67
68 #endif /* __DHCPC_H__ */
```

9.3 example-mainloop-with-arp.c

```
1 #include "uip.h"
2 #include "uip_arp.h"
3 #include "network-device.h"
4 #include "httpd.h"
5 #include "timer.h"
7 #define BUF ((struct uip_eth_hdr *)&uip_buf[0])
9 /*----*/
10 int
11 main (void)
12 {
13
    int i:
14
    uip_ipaddr_t ipaddr;
15
    struct timer periodic_timer, arp_timer;
16
    timer_set(&periodic_timer, CLOCK_SECOND / 2);
17
    timer_set(&arp_timer, CLOCK_SECOND * 10);
18
19
20
    network_device_init();
21
    uip_init();
22
    uip_ipaddr(ipaddr, 192,168,0,2);
23
2.4
    uip_sethostaddr(ipaddr);
25
26
    httpd_init();
27
28
    while(1) {
      uip_len = network_device_read();
29
30
      if(uip_len > 0) {
31
        if(BUF->type == htons(UIP_ETHTYPE_IP)) {
32
          uip_arp_ipin();
33
          uip_input();
34
          /\star If the above function invocation resulted in data that
35
             should be sent out on the network, the global variable
36
             uip_len is set to a value > 0. */
37
          if(uip_len > 0) {
38
            uip_arp_out();
            network_device_send();
40
41
        } else if(BUF->type == htons(UIP_ETHTYPE_ARP)) {
42
          uip_arp_arpin();
4.3
          /\star If the above function invocation resulted in data that
44
             should be sent out on the network, the global variable
45
             uip_len is set to a value > 0. */
46
          if(uip_len > 0) {
47
            network_device_send();
48
49
50
51
      } else if(timer_expired(&periodic_timer)) {
        timer_reset(&periodic_timer);
53
        for(i = 0; i < UIP_CONNS; i++) {
54
          uip_periodic(i);
55
          /\star If the above function invocation resulted in data that
56
             should be sent out on the network, the global variable
57
             uip_len is set to a value > 0. \star/
58
          if(uip_len > 0) {
59
            uip_arp_out();
            network_device_send();
61
62
        }
64 #if UIP UDP
        for(i = 0; i < UIP_UDP_CONNS; i++) {</pre>
```

```
66
         uip_udp_periodic(i);
67
         /\star If the above function invocation resulted in data that
68
            should be sent out on the network, the global variable
            uip_len is set to a value > 0. */
70
         if(uip_len > 0) {
71
           uip_arp_out();
72
           network_device_send();
73
74
       }
75 #endif /* UIP_UDP */
76
77
        /\star Call the ARP timer function every 10 seconds. \star/
78
       if(timer_expired(&arp_timer)) {
79
         timer_reset(&arp_timer);
80
         uip_arp_timer();
81
82
    }
83
84
    return 0;
85 }
86 /*-----*/
```

9.4 example-mainloop-without-arp.c

```
1 #include "uip.h"
2 #include "uip_arp.h"
3 #include "network-device.h"
4 #include "httpd.h"
5 #include "timer.h"
7 /*----*/
8 int
9 main(void)
10 {
11
12
    uip_ipaddr_t ipaddr;
1.3
    struct timer periodic_timer;
14
    timer_set(&periodic_timer, CLOCK_SECOND / 2);
15
16
17
    network_device_init();
18
    uip_init();
19
20
    uip_ipaddr(ipaddr, 192,168,0,2);
2.1
    uip_sethostaddr(ipaddr);
22
23
    httpd_init();
24
25
    while(1) {
26
      uip_len = network_device_read();
27
      if(uip_len > 0) {
        uip_input();
28
29
        /\star If the above function invocation resulted in data that
30
           should be sent out on the network, the global variable
31
           uip_len is set to a value > 0. \star/
32
        if(uip_len > 0) {
33
          network_device_send();
34
35
      } else if(timer_expired(&periodic_timer)) {
36
        timer_reset(&periodic_timer);
37
        for(i = 0; i < UIP_CONNS; i++) {
38
         uip_periodic(i);
39
          /\star If the above function invocation resulted in data that
40
             should be sent out on the network, the global variable
41
             uip_len is set to a value > 0. */
42
          if(uip_len > 0) {
43
            network_device_send();
4.5
        }
47 #if UIP_UDP
48
        for(i = 0; i < UIP_UDP_CONNS; i++) {</pre>
49
          uip_udp_periodic(i);
50
          /\star If the above function invocation resulted in data that
51
             should be sent out on the network, the global variable
             uip_len is set to a value > 0. \star/
          if(uip_len > 0) {
53
54
            network_device_send();
55
56
57 #endif /* UIP_UDP */
58
    }
59
60 return 0;
61 }
62 /*----
```

9.5 hello-world.c

```
2 * \addtogroup helloworld
3 * @{
4 */
5
6 /**
7 * \file
            An example of how to write uIP applications
9
            with protosockets.
10 * \author
11 *
             Adam Dunkels <adam@sics.se>
12 */
13
14 /*
15 \star This is a short example of how to write uIP applications using
16 * protosockets.
17 */
18
19 /*
20 * We define the application state (struct hello_world_state) in the
21 \star hello-world.h file, so we need to include it here. We also include
22 * uip.h (since this cannot be included in hello-world.h) and
^{23} * <string.h>, since we use the memcpy() function in the code.
24 */
25 #include "hello-world.h"
26 #include "uip.h"
27 #include <string.h>
28
29 /*
30 \star Declaration of the protosocket function that handles the connection
31 \star (defined at the end of the code). 32 \star/
33 static int handle_connection(struct hello_world_state *s);
34 /*-----/
35 /*
36 * The initialization function. We must explicitly call this function
37 \star from the system initialization code, some time after uip_init() is
38 \star called.
39 */
40 void
41 hello_world_init(void)
42 {
4.3
    /\star We start to listen for connections on TCP port 1000. \star/
    uip_listen(HTONS(1000));
44
45 }
46 /*-----*/
47 /*
48 \star In hello-world.h we have defined the UIP_APPCALL macro to
49 * hello_world_appeall so that this funcion is uIP's application
50 \star function. This function is called whenever an uIP event occurs
51 \, \star (e.g. when a new connection is established, new data arrives, sent
52 * data is acknowledged, data needs to be retransmitted, etc.).
53 */
54 void
55 hello_world_appcall(void)
56 {
57
    * The uip_conn structure has a field called "appstate" that holds
59
     \star the application state of the connection. We make a pointer to
60
     * this to access it easier.
61
62
    struct hello_world_state *s = &(uip_conn->appstate);
64
    * If a new connection was just established, we should initialize
```

9.5 hello-world.c 209

```
* the protosocket in our applications' state structure.
66
67
68
    if(uip_connected()) {
     PSOCK_INIT(&s->p, s->inputbuffer, sizeof(s->inputbuffer));
69
70
71
72
    * Finally, we run the protosocket function that actually handles * the communication. We pass it a pointer to the application state
73
74
    \star of the current connection.
75
76
     */
77
    handle_connection(s);
78 }
79 /*-----*/
80 /*
81 \, \star This is the protosocket function that handles the communication. A
82 * protosocket function must always return an int, but must never
83 \star explicitly return - all return statements are hidden in the PSOCK 84 \star macros.
85 */
86 static int
87 handle_connection(struct hello_world_state *s)
88 {
89
    PSOCK_BEGIN(&s->p);
90
PSOCK_SEND_STR(&s->p, "Hello. What is your name?\n");
PSOCK_READTO(&s->p, '\n');
93
    strncpy(s->name, s->inputbuffer, sizeof(s->name));
94 PSOCK_SEND_STR(&s->p, "Hello ");
95 PSOCK_SEND_STR(&s->p, s->name);
96
    PSOCK_CLOSE(&s->p);
97
98 PSOCK_END(&s->p);
99 }
100 /*-----*/
```

9.6 hello-world.h

```
2 * \addtogroup apps
3 * @{
4 */
7 * \defgroup helloworld Hello, world
8 * @{
11 * \ref psock "protosockets".
1.3
14 /**
15 * \file
16 *
             Header file for an example of how to write uIP applications
17 *
             with protosockets.
18 * \author
19 *
             Adam Dunkels <adam@sics.se>
20 */
2.1
22 #ifndef __HELLO_WORLD_H__
23 #define __HELLO_WORLD_H_
25 /\star Since this file will be included by uip.h, we cannot include uip.h
26
     here. But we might need to include uipopt.h if we need the u8_t and
27
     u16_t datatypes. */
28 #include "uipopt.h"
29
30 #include "psock.h"
31
32 /\star Next, we define the uip_tcp_appstate_t datatype. This is the state
     of our application, and the memory required for this state is
     allocated together with each TCP connection. One application state
34
35
     for each TCP connection. */
36 typedef struct hello_world_state {
37 struct psock p;
38 char inputbuffer[10];
39
    char name[40];
40 } uip_tcp_appstate_t;
42 /\star Finally we define the application function to be called by uIP. \star/
43 void hello_world_appcall(void);
44 #ifndef UIP_APPCALL
45 #define UIP_APPCALL hello_world_appcall
46 #endif /* UIP_APPCALL */
47
48 void hello_world_init(void);
49
50 #endif /* __HELLO_WORLD_H__ */
51 /** @} */
52 /** @} */
```

```
2 * \addtogroup apps
3 * @{
4 */
5
6 /**
7 * \defgroup resolv DNS resolver
8 * @{
9
10 \star The uIP DNS resolver functions are used to lookup a hostname and
11 \star map it to a numerical IP address. It maintains a list of resolved
   * hostnames that can be queried with the resolv_lookup()
13 \star function. New hostnames can be resolved using the resolv_query()
14 \star function.
15
16 \star When a hostname has been resolved (or found to be non-existant),
17 * the resolver code calls a callback function called resolv_found()
18 \star that must be implemented by the module that uses the resolver.
19 */
20
21 /**
22 * \file
23 \star DNS host name to IP address resolver.
24 * \author Adam Dunkels <adam@dunkels.com>
2.5
26 \star This file implements a DNS host name to IP address resolver.
27 */
28
29 /*
30 \star Copyright (c) 2002-2003, Adam Dunkels.
31
   * All rights reserved.
32
33 \star Redistribution and use in source and binary forms, with or without
34 \star modification, are permitted provided that the following conditions
35 * are met:
36 	 * 1. Redistributions of source code must retain the above copyright
37 *
        notice, this list of conditions and the following disclaimer.
38 \star 2. Redistributions in binary form must reproduce the above copyright
39 \star notice, this list of conditions and the following disclaimer in the
40 *
        documentation and/or other materials provided with the distribution.
41
   \star 3. The name of the author may not be used to endorse or promote
        products derived from this software without specific prior
42 *
4.3 *
        written permission.
44
45 * THIS SOFTWARE IS PROVIDED BY THE AUTHOR ''AS IS'' AND ANY EXPRESS
46 \star OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
   * WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
48 \, * ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY
49 * DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
50 \star DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
51 \star GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
52 * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
53 \star WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING
54 * NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
55 * SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
56 *
57 \star This file is part of the uIP TCP/IP stack.
59 * $Id: resolv.c,v 1.5 2006/06/11 21:46:37 adam Exp $
60 *
61 */
62
63 #include "resolv.h"
64 #include "uip.h"
65
```

```
66 #include <string.h>
67
68 #ifndef NULL
69 #define NULL (void *)0
70 #endif /* NULL */
72 /** \internal The maximum number of retries when asking for a name. */
73 #define MAX_RETRIES 8
75 /** \internal The DNS message header. */
76 struct dns_hdr {
77 u16_t id;
78 u8_t flags1, flags2;
79 #define DNS_FLAG1_RESPONSE
80 #define DNS_FLAG1_OPCODE_STATUS
                                     0x10
81 #define DNS_FLAG1_OPCODE_INVERSE 0x08
82 #define DNS_FLAG1_OPCODE_STANDARD 0x00
83 #define DNS_FLAG1_AUTHORATIVE
84 #define DNS_FLAG1_TRUNC
                                     0x02
85 #define DNS_FLAG1_RD
86 #define DNS_FLAG2_RA
                                     0x80
87 #define DNS_FLAG2_ERR_MASK
                                     0x0f
88 #define DNS_FLAG2_ERR_NONE
                                     0x00
89 #define DNS_FLAG2_ERR_NAME
                                     0x03
90
    u16_t numquestions;
91 u16_t numanswers;
92 u16_t numauthrr;
93
    u16_t numextrarr;
94 };
9.5
96 /** \internal The DNS answer message structure. */
97 struct dns_answer {
98 /* DNS answer record starts with either a domain name or a pointer
99
       to a name already present somewhere in the packet. */
    u16_t type;
100
    u16_t class;
102
    u16_t ttl[2];
103
     u16_t len;
104
     uip_ipaddr_t ipaddr;
105 };
106
107 struct namemap {
108 #define STATE_UNUSED 0
109 #define STATE_NEW
110 #define STATE ASKING 2
111 #define STATE_DONE 3
112 #define STATE_ERROR 4
    u8_t state;
113
    u8_t tmr;
114
115
     u8_t retries;
116
     u8_t seqno;
117
     u8_t err;
118
     char name[32];
119
     uip_ipaddr_t ipaddr;
120 };
121
122 #ifndef UIP_CONF_RESOLV_ENTRIES
123 #define RESOLV_ENTRIES 4
124 #else /* UIP_CONF_RESOLV_ENTRIES */
125 #define RESOLV_ENTRIES UIP_CONF_RESOLV_ENTRIES
126 #endif /* UIP_CONF_RESOLV_ENTRIES */
127
128
129 static struct namemap names[RESOLV_ENTRIES];
131 static u8_t seqno;
132
```

```
133 static struct uip_udp_conn *resolv_conn = NULL;
135
136 /*----
137 /** \internal
138
    \star Walk through a compact encoded DNS name and return the end of it.
139 *
140 \star \return The end of the name.
141 */
142 /*-----*/
143 static unsigned char *
144 parse_name(unsigned char *query)
145 {
146
    unsigned char n;
147
    do {
148
     n = *query++;
149
150
151
     while(n > 0) {
      /* printf("%c", *query);*/
152
153
        ++query;
        --n;
154
     };
/* printf(".");*/
155
156
157
    } while(*query != 0);
158 /* printf("\n");*/
159
    return query + 1;
160 }
161 /*-----*/
162 /** \internal
163 \star Runs through the list of names to see if there are any that have
^{164} \,\star not yet been queried and, if so, sends out a query.
166 /*-----*/
167 static void
168 check_entries(void)
169 {
170
    register struct dns_hdr *hdr;
171 char *query, *nptr, *nameptr;
172
    static u8_t i;
173
    static u8_t n;
174
    register struct namemap *namemapptr;
175
176
    for(i = 0; i < RESOLV_ENTRIES; ++i) {</pre>
     namemapptr = &names[i];
177
178
     if(namemapptr->state == STATE_NEW ||
         namemapptr->state == STATE_ASKING) {
179
        if(namemapptr->state == STATE_ASKING) {
180
         if(--namemapptr->tmr == 0) {
182
           if(++namemapptr->retries == MAX_RETRIES) {
183
             namemapptr->state = STATE_ERROR;
184
             resolv_found(namemapptr->name, NULL);
185
             continue;
186
187
           namemapptr->tmr = namemapptr->retries;
188
          } else {
189
                  printf("Timer %d\n", namemapptr->tmr);*/
            /\star Its timer has not run out, so we move on to next
190
191
             entry. */
192
            continue;
193
          }
194
       } else {
         namemapptr->state = STATE_ASKING;
195
         namemapptr->tmr = 1;
196
197
         namemapptr->retries = 0;
198
199
        hdr = (struct dns_hdr *)uip_appdata;
```

```
2.00
         memset(hdr, 0, sizeof(struct dns_hdr));
201
         hdr->id = htons(i);
202
         hdr->flags1 = DNS_FLAG1_RD;
         hdr->numquestions = HTONS(1);
204
         query = (char *)uip_appdata + 12;
205
         nameptr = namemapptr->name;
206
         --nameptr;
2.07
         /* Convert hostname into suitable query format. */
208
         do {
209
          ++nameptr;
210
          nptr = query;
211
           ++query;
           for(n = 0; *nameptr != '.' && *nameptr != 0; ++nameptr) {
212
213
            *query = *nameptr;
214
             ++query;
215
             ++n;
216
          }
217
           *nptr = n;
218
         } while(*nameptr != 0);
219
220
           static unsigned char endquery[] =
221
             {0,0,1,0,1};
           memcpy(query, endquery, 5);
222
223
         }
224
         uip_udp_send((unsigned char)(query + 5 - (char *)uip_appdata));
225
          break;
226
      }
227
     }
228 }
229 /*---
230 /** \internal
231 \star Called when new UDP data arrives.
232 */
233 /*-----*/
234 static void
235 newdata(void)
236 {
237
     char *nameptr;
    struct dns_answer *ans;
238
2.39
    struct dns_hdr *hdr;
     static u8_t nquestions, nanswers;
240
241
     static u8 t i:
242
     register struct namemap *namemapptr;
243
244
    hdr = (struct dns_hdr *)uip_appdata;
245
    /* printf("ID %d\n", htons(hdr->id));
         printf("Query %d\n", hdr->flags1 & DNS_FLAG1_RESPONSE);
printf("Error %d\n", hdr->flags2 & DNS_FLAG2_ERR_MASK);
246
247
         printf("Num questions %d, answers %d, authrr %d, extrarr %d\n",
248
249
         htons(hdr->numquestions),
250
         htons (hdr->numanswers),
251
         htons(hdr->numauthrr),
252
         htons(hdr->numextrarr));
253
254
     /\star The ID in the DNS header should be our entry into the name
2.5.5
256
        table. */
     i = htons(hdr->id);
257
258
     namemapptr = &names[i];
259
     if(i < RESOLV_ENTRIES &&
260
        namemapptr->state == STATE_ASKING) {
261
262
       /* This entry is now finished. */
       namemapptr->state = STATE_DONE;
263
264
       namemapptr->err = hdr->flags2 & DNS_FLAG2_ERR_MASK;
265
266
       /\star Check for error. If so, call callback to inform. \star/
```

```
if(namemapptr->err != 0) {
268
         namemapptr->state = STATE_ERROR;
269
         resolv_found(namemapptr->name, NULL);
270
         return;
271
       }
272
273
       /\star We only care about the question(s) and the answers. The authrr
2.74
         and the extrarr are simply discarded. \star/
275
       nquestions = htons(hdr->numquestions);
276
       nanswers = htons(hdr->numanswers);
277
278
       /\star Skip the name in the question. XXX: This should really be
279
          checked agains the name in the question, to be sure that they
280
          match. */
281
       nameptr = parse_name((char *)uip_appdata + 12) + 4;
282
283
       while(nanswers > 0) {
284
         /\star The first byte in the answer resource record determines if it
285
            is a compressed record or a normal one. */
         if(*nameptr & 0xc0) {
287
           /* Compressed name. */
288
           nameptr +=2;
                  printf("Compressed anwser\n");*/
289
           /*
2.90
         } else {
291
           /* Not compressed name. */
292
           nameptr = parse_name((char *)nameptr);
293
294
         ans = (struct dns_answer *)nameptr;
295
296
                printf("Answer: type %x, class %x, ttl %x, length %x\n",
297
                htons(ans->type), htons(ans->class), (htons(ans->ttl[0])
298
                << 16) | htons(ans->ttl[1]), htons(ans->len)); */
299
300
         /\star Check for IP address type and Internet class. Others are
301
           discarded. */
         if(ans->type == HTONS(1) &&
302
303
            ans->class == HTONS(1) &&
304
            ans->len == HTONS(4)) {
305
           /*
                  printf("IP address %d.%d.%d.%d\n",
306
                  htons(ans->ipaddr[0]) >> 8,
307
                  htons(ans->ipaddr[0]) & 0xff,
308
                 htons(ans->ipaddr[1]) >> 8,
309
                 htons(ans->ipaddr[1]) & 0xff); */
310
           /\star XXX: we should really check that this IP address is the one
311
             we want. */
312
           namemapptr->ipaddr[0] = ans->ipaddr[0];
313
           namemapptr->ipaddr[1] = ans->ipaddr[1];
314
315
          resolv_found(namemapptr->name, namemapptr->ipaddr);
316
           return;
317
         } else {
          nameptr = nameptr + 10 + htons(ans->len);
318
319
320
          --nanswers;
321
       }
322
    }
323
324 }
325 /*-----*/
326 /** \internal
327 \star The main UDP function.
328 */
329 /*--
330 void
331 resolv_appcall(void)
332 {
333
    if(uip_udp_conn->rport == HTONS(53)) {
```

```
334
     if(uip_poll()) {
335
       check_entries();
336
     if(uip_newdata()) {
    newdata();
338
339
340 }
341 }
342 /*--
343 /**
344 \,\,\star\, Queues a name so that a question for the name will be sent out.
345
346 \, \star \param name The hostname that is to be queried.
347 */
348 /*--
349 void
350 resolv_query(char *name)
351 {
352
    static u8_t i;
    static u8_t lseq, lseqi;
353
354
    register struct namemap *nameptr;
355
356
    lseq = lseqi = 0;
357
358
    for(i = 0; i < RESOLV_ENTRIES; ++i) {</pre>
      nameptr = &names[i];
359
360
      if(nameptr->state == STATE_UNUSED) {
361
       break;
362
363
     if(seqno - nameptr->seqno > lseq) {
      lseq = seqno - nameptr->seqno;
364
         lseqi = i;
365
366
     }
367
     }
368
     if(i == RESOLV_ENTRIES) {
369
    i = lseqi;
370
371
      nameptr = &names[i];
372
373
374
     /* printf("Using entry %d\n", i);*/
375
376
     strcpy(nameptr->name, name);
377
     nameptr->state = STATE_NEW;
378
     nameptr->seqno = seqno;
379
     ++seqno;
380 }
381 /*-----*/
382 /**
383 \star Look up a hostname in the array of known hostnames.
384
385 \star \note This function only looks in the internal array of known
386 \,* hostnames, it does not send out a query for the hostname if none
387
    \star was found. The function resolv_query() can be used to send a query
388 \star for a hostname.
389
390
    \star \return A pointer to a 4-byte representation of the hostname's IP
391 \star address, or NULL if the hostname was not found in the array of
392 * hostnames.
393 */
394 /*-----*/
395 u16_t *
396 resolv_lookup(char *name)
397 {
398 static u8_t i;
399
    struct namemap *nameptr;
400
```

```
401
    /* Walk through the list to see if the name is in there. If it is
     not, we return NULL. \star/
402
    for(i = 0; i < RESOLV_ENTRIES; ++i) {
403
     nameptr = &names[i];
405
     if(nameptr->state == STATE_DONE &&
406
         strcmp(name, nameptr->name) == 0) {
407
        return nameptr->ipaddr;
     }
408
409
    }
    return NULL;
410
411 }
412 /*----
413 /**
414 \star Obtain the currently configured DNS server.
415
416 \star \return A pointer to a 4-byte representation of the IP address of
417 \star the currently configured DNS server or NULL if no DNS server has
418 \star been configured.
419 */
420 /*---
421 u16_t *
422 resolv_getserver(void)
423 {
424 if(resolv_conn == NULL) {
425
     return NULL;
426 }
427 return resolv_conn->ripaddr;
428 }
429 /*-----*/
430 /**
431 * Configure which DNS server to use for gueries.
432 *
433 \star \param dnsserver A pointer to a 4-byte representation of the IP
434 \, * address of the DNS server to be configured. 435 \, */
436 /*---
437 void
438 resolv_conf(u16_t *dnsserver)
439 {
440 if(resolv_conn != NULL) {
441
     uip_udp_remove(resolv_conn);
442
443
444
    resolv_conn = uip_udp_new(dnsserver, HTONS(53));
445 }
446 /*---
447 /**
448 \star Initalize the resolver.
450 /*---
        -----*/
451 void
452 resolv_init(void)
453 {
    static u8_t i;
454
455
456 for(i = 0; i < RESOLV_ENTRIES; ++i) {
457
     names[i].state = STATE_DONE;
458
459
460 }
461 /*-----*/
462
463 /** @} */
464 /** @} */
```

9.8 resolv.h

```
2 * \addtogroup resolv
3 * @{
4 */
5 /**
6 * \file
  * DNS resolver code header file.
8 * \author Adam Dunkels <adam@dunkels.com>
9
10
11 /*
12 * Copyright (c) 2002-2003, Adam Dunkels.
13 * All rights reserved.
14 +
15
   * Redistribution and use in source and binary forms, with or without
16 \star modification, are permitted provided that the following conditions
17 * are met:
18 \star 1. Redistributions of source code must retain the above copyright
19 *
        notice, this list of conditions and the following disclaimer.
20 * 2. Redistributions in binary form must reproduce the above copyright
21 *
        notice, this list of conditions and the following disclaimer in the
22
        documentation and/or other materials provided with the distribution.
  \star 3. The name of the author may not be used to endorse or promote
2.4 *
       products derived from this software without specific prior
25
        written permission.
26
   * THIS SOFTWARE IS PROVIDED BY THE AUTHOR ''AS IS'' AND ANY EXPRESS
2.7
   * OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
29 * WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
30 \star ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY
   * DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
32 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
33 * GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
34 * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
35 \star WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING
36 * NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
   * SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
37
38
39 \star This file is part of the uIP TCP/IP stack.
40 *
41
   * $Id: resolv.h,v 1.4 2006/06/11 21:46:37 adam Exp $
42 *
43 */
44 #ifndef ___RESOLV_H_
45 #define ___RESOLV_H_
46
47 typedef int uip_udp_appstate_t;
48 void resolv_appcall(void);
49 #define UIP_UDP_APPCALL resolv_appcall
50
51 #include "uipopt.h"
53 /**
54 * Callback function which is called when a hostname is found.
56 * This function must be implemented by the module that uses the DNS
57
   * resolver. It is called when a hostname is found, or when a hostname
58 * was not found.
59 +
   * \param name A pointer to the name that was looked up. \param
61 * ipaddr A pointer to a 4-byte array containing the IP address of the
62 \star hostname, or NULL if the hostname could not be found.
64 void resolv_found(char *name, u16_t *ipaddr);
```

9.8 resolv.h 219

```
66 /* Functions. */
67 void resolv_conf(u16_t *dnsserver);
68 u16_t *resolv_getserver(void);
69 void resolv_init(void);
70 u16_t *resolv_lookup(char *name);
71 void resolv_query(char *name);
72
73 #endif /* __RESOLV_H__ */
74
75 /** @} */
```

9.9 smtp.c

```
2 * \addtogroup apps
3 * @{
4 */
5
6 /**
 * \defgroup smtp SMTP E-mail sender
8 * @{
9
10 \star The Simple Mail Transfer Protocol (SMTP) as defined by RFC821 is
11 \star the standard way of sending and transfering e-mail on the
   * Internet. This simple example implementation is intended as an
13 \,\,\star\, example of how to implement protocols in uIP, and is able to send
14 \star out e-mail but has not been extensively tested.
15
   */
16
17 /**
18 * \file
19 \star SMTP example implementation
20 * \author Adam Dunkels <adam@dunkels.com>
21 */
22
23 /*
24 * Copyright (c) 2004, Adam Dunkels.
25
   * All rights reserved.
27 * Redistribution and use in source and binary forms, with or without
   * modification, are permitted provided that the following conditions
29 * are met:
30 \star 1. Redistributions of source code must retain the above copyright
        notice, this list of conditions and the following disclaimer.
   \star 2. Redistributions in binary form must reproduce the above copyright
33 \star notice, this list of conditions and the following disclaimer in the
34 *
        documentation and/or other materials provided with the distribution.
35
   \star 3. Neither the name of the Institute nor the names of its contributors
       may be used to endorse or promote products derived from this software
37
        without specific prior written permission.
38
39 \star THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS "AS IS" AND
40 \star ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
   * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
42 \star ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE
43 * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
   * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
45 * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
46 * HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
   * LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
48 \, \star OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
49 * SUCH DAMAGE.
50
51 \star This file is part of the uIP TCP/IP stack.
53
   * Author: Adam Dunkels <adam@sics.se>
54
55 * $Id: smtp.c, v 1.4 2006/06/11 21:46:37 adam Exp $
56 */
57 #include "smtp.h"
59 #include "smtp-strings.h"
60 #include "psock.h"
61 #include "uip.h"
62
63 #include <string.h>
65 static struct smtp_state s;
```

9.9 smtp.c 221

```
67 static char *localhostname;
68 static uip_ipaddr_t smtpserver;
70 #define ISO_nl 0x0a
71 #define ISO_cr 0x0d
72
73 #define ISO_period 0x2e
75 #define ISO_2 0x32
76 #define ISO_3 0x33
77 #define ISO_4 0x34
78 #define ISO_5 0x35
79
80
81 /*----
                   82 static
83 PT_THREAD(smtp_thread(void))
84 {
   PSOCK_BEGIN(&s.psock);
86
87
    PSOCK_READTO(&s.psock, ISO_nl);
88
    if(strncmp(s.inputbuffer, smtp_220, 3) != 0) {
89
90
     PSOCK_CLOSE(&s.psock);
91
      smtp_done(2);
92
     PSOCK_EXIT(&s.psock);
93
94
    PSOCK_SEND_STR(&s.psock, (char *)smtp_helo);
PSOCK_SEND_STR(&s.psock, localhostname);
95
96
97
    PSOCK_SEND_STR(&s.psock, (char *)smtp_crnl);
98
99
    PSOCK_READTO(&s.psock, ISO_nl);
100
     if(s.inputbuffer[0] != ISO_2) {
101
      PSOCK_CLOSE(&s.psock);
102
103
       smtp_done(3);
      PSOCK_EXIT(&s.psock);
104
105
106
     PSOCK_SEND_STR(&s.psock, (char *)smtp_mail_from);
107
108
     PSOCK_SEND_STR(&s.psock, s.from);
109
     PSOCK_SEND_STR(&s.psock, (char *)smtp_crnl);
110
111
     PSOCK_READTO(&s.psock, ISO_nl);
112
     if(s.inputbuffer[0] != ISO_2) {
113
      PSOCK_CLOSE(&s.psock);
114
115
       smtp_done(4);
116
       PSOCK_EXIT(&s.psock);
117
118
119
      PSOCK_SEND_STR(&s.psock, (char *)smtp_rcpt_to);
120
     PSOCK_SEND_STR(&s.psock, s.to);
121
     PSOCK_SEND_STR(&s.psock, (char *)smtp_crnl);
122
123
     PSOCK_READTO(&s.psock, ISO_nl);
124
125
     if(s.inputbuffer[0] != ISO_2) {
      PSOCK_CLOSE(&s.psock);
126
127
       smtp_done(5);
128
       PSOCK_EXIT(&s.psock);
129
130
     if(s.cc != 0) {
131
132
       PSOCK_SEND_STR(&s.psock, (char *)smtp_rcpt_to);
```

```
133
       PSOCK_SEND_STR(&s.psock, s.cc);
134
       PSOCK_SEND_STR(&s.psock, (char *)smtp_crnl);
135
136
       PSOCK_READTO(&s.psock, ISO_nl);
137
138
       if(s.inputbuffer[0] != ISO_2) {
        PSOCK_CLOSE(&s.psock);
139
140
         smtp_done(6);
141
         PSOCK_EXIT(&s.psock);
142
143
     }
144
145
     PSOCK_SEND_STR(&s.psock, (char *)smtp_data);
146
147
     PSOCK_READTO(&s.psock, ISO_nl);
148
149
     if(s.inputbuffer[0] != ISO_3) {
      PSOCK_CLOSE(&s.psock);
150
151
       smtp_done(7);
152
      PSOCK_EXIT(&s.psock);
153
154
155
     PSOCK_SEND_STR(&s.psock, (char *)smtp_to);
156
     PSOCK_SEND_STR(&s.psock, s.to);
157
     PSOCK_SEND_STR(&s.psock, (char *) smtp_crnl);
158
159
     if(s.cc != 0) {
160
      PSOCK_SEND_STR(&s.psock, (char *)smtp_cc);
161
       PSOCK_SEND_STR(&s.psock, s.cc);
162
      PSOCK_SEND_STR(&s.psock, (char *)smtp_crnl);
163
164
165
     PSOCK_SEND_STR(&s.psock, (char *)smtp_from);
     PSOCK_SEND_STR(&s.psock, s.from);
166
167
     PSOCK_SEND_STR(&s.psock, (char *)smtp_crnl);
168
169
     PSOCK_SEND_STR(&s.psock, (char *)smtp_subject);
170
     PSOCK_SEND_STR(&s.psock, s.subject);
171
     PSOCK_SEND_STR(&s.psock, (char *)smtp_crnl);
172
173
     PSOCK_SEND(&s.psock, s.msg, s.msglen);
174
175
     PSOCK_SEND_STR(&s.psock, (char *)smtp_crnlperiodcrnl);
176
177
     PSOCK_READTO(&s.psock, ISO_nl);
178
     if(s.inputbuffer[0] != ISO_2) {
      PSOCK_CLOSE(&s.psock);
179
180
       smtp_done(8);
181
      PSOCK_EXIT(&s.psock);
182
     }
183
184
     PSOCK_SEND_STR(&s.psock, (char *) smtp_quit);
185
     smtp_done(SMTP_ERR_OK);
186
     PSOCK_END(&s.psock);
187 }
188 /*-----*/
189 void
190 smtp_appcall(void)
191 {
     if(uip_closed()) {
192
193
      s.connected = 0;
194
195
    if(uip_aborted() || uip_timedout()) {
196
197
     s.connected = 0;
      smtp_done(1);
198
199
       return;
```

9.9 smtp.c 223

```
200 }
201
    smtp_thread();
202 }
203 /*--
204 /**
205
    * Specificy an SMTP server and hostname.
206 *
207 \,\, * This function is used to configure the SMTP module with an SMTP 208 \,\, * server and the hostname of the host.
209 +
210 \star \param lhostname The hostname of the uIP host.
211
212 \, \star \param server A pointer to a 4-byte array representing the IP
213 \star address of the SMTP server to be configured.
214 */
215 void
216 smtp_configure(char *lhostname, void *server)
217 {
218
    localhostname = lhostname;
    uip_ipaddr_copy(smtpserver, server);
219
220 }
221 /*--
222 /**
223 \star Send an e-mail.
2.2.4
225 \star \param to The e-mail address of the receiver of the e-mail.
226 \star \param cc The e-mail address of the CC: receivers of the e-mail.
    * \param from The e-mail address of the sender of the e-mail.
228 * \gamma param subject The subject of the e-mail.
229 \star \param msg The actual e-mail message.
230
    \star \param msglen The length of the e-mail message.
231 */
232 unsigned char
233 smtp_send(char *to, char *cc, char *from,
2.34
          char *subject, char *msg, u16_t msglen)
235 {
236
    struct uip_conn *conn;
237
238
    conn = uip_connect(smtpserver, HTONS(25));
239
    if(conn == NULL) {
240
     return 0;
241
    s.connected = 1;
242
243
     s.to = to;
    s.cc = cc;
244
245
    s.from = from;
246
     s.subject = subject;
    s.msg = msg;
247
248
    s.msglen = msglen;
249
2.50
    PSOCK_INIT(&s.psock, s.inputbuffer, sizeof(s.inputbuffer));
251
252
    return 1;
253 }
254 /*---
                255 void
256 smtp_init(void)
257 {
258 s.connected = 0;
259 }
260 /*--
        261 /** @} */
262 /** @} */
```

9.10 smtp.h

```
2 /**
3 * \addtogroup smtp
4 * @{
5 */
6
8 /**
9
  * \file
10 * SMTP header file
11 * \author Adam Dunkels <adam@dunkels.com>
12 */
13
14 /*
15 * Copyright (c) 2002, Adam Dunkels.
16 * All rights reserved.
17
18 * Redistribution and use in source and binary forms, with or without
19 \star modification, are permitted provided that the following conditions
20 * are met:
21 \, * 1. Redistributions of source code must retain the above copyright
22
         notice, this list of conditions and the following disclaimer.
23 \star 2. Redistributions in binary form must reproduce the above copyright
24 *
       notice, this list of conditions and the following disclaimer in the
25
        documentation and/or other materials provided with the distribution.
26 \,\star\, 3. The name of the author may not be used to endorse or promote
27 * products derived from this software without specific prior
2.8
        written permission.
29 *
30 \star THIS SOFTWARE IS PROVIDED BY THE AUTHOR ''AS IS'' AND ANY EXPRESS
   * OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
32 \star WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
33 \star ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY
34 * DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
35 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
36 * GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
37 * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
38 \star WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING
39 * NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
40 * SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
41
42 * This file is part of the uIP TCP/IP stack.
43 +
   * $Id: smtp.h, v 1.4 2006/06/11 21:46:37 adam Exp $
44
45
46 */
47 #ifndef ___SMTP_H__
48 #define ___SMTP_H_
49
50 #include "uipopt.h"
51
53 \star Error number that signifies a non-error condition.
54 */
55 #define SMTP_ERR_OK 0
56
57 /**
58 * Callback function that is called when an e-mail transmission is
59 * done.
61 * This function must be implemented by the module that uses the SMTP
62 * module.
64 \star \param error The number of the error if an error occured, or
65 * SMTP_ERR_OK.
```

9.10 smtp.h 225

```
67 void smtp_done(unsigned char error);
69 void smtp_init(void);
70
71 /* Functions. */
72 void smtp_configure(char *localhostname, u16_t *smtpserver);
73 unsigned char smtp\_send(char *to, char *from,
                            char *subject, char *msg,
u16_t msglen);
75
76 #define SMTP_SEND(to, cc, from, subject, msg) \
77 smtp_send(to, cc, from, subject, msg, strlen(msg))
78
79 void smtp_appcall(void);
80
81 struct smtp_state {
82 u8_t state;
83 char *to;
84
    char *from;
85 char *subject;
86 char *msg;
87
    u16_t msglen;
88
89 u16_t sentlen, textlen;
90 u16_t sendptr;
91
92 };
93
94
95 #ifndef UIP_APPCALL
96 #define UIP_APPCALL
                           smtp_appcall
97 #endif
98 typedef struct smtp_state uip_tcp_appstate_t;
99
100
101 #endif /* __SMTP_H__ */
102
103 /** @} */
```

```
2 * \addtogroup telnetd
3 * @{
4 */
5
6 /**
7 * \file
8 *
            Shell server
9
  * \author
10 *
             Adam Dunkels <adam@sics.se>
11 */
12
13 /*
14 * Copyright (c) 2003, Adam Dunkels.
15
   * All rights reserved.
16
17 * Redistribution and use in source and binary forms, with or without
18 \star modification, are permitted provided that the following conditions
19 * are met:
20 * 1. Redistributions of source code must retain the above copyright
21 *
        notice, this list of conditions and the following disclaimer.
22
   * 2. Redistributions in binary form must reproduce the above copyright
23 \star notice, this list of conditions and the following disclaimer in the
24 *
        documentation and/or other materials provided with the distribution.
25
   \star 3. The name of the author may not be used to endorse or promote
26 * products derived from this software without specific prior
2.7 *
        written permission.
2.8
29 * THIS SOFTWARE IS PROVIDED BY THE AUTHOR ''AS IS'' AND ANY EXPRESS
30 \star OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
   * WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
32 \star ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY
33 * DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
34 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
35 \star GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
36 * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
   * WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING
38 \star NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
39 * SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
40 *
41
   \star This file is part of the uIP TCP/IP stack
42
43 * $Id: telnetd.c,v 1.2 2006/06/07 09:43:54 adam Exp $
44
45 */
46
47 #include "uip.h"
48 #include "telnetd.h"
49 #include "memb.h"
50 #include "shell.h"
51
52 #include <string.h>
53
54 #define ISO_nl
                        0x0a
55 #define ISO_cr
56
57 struct telnetd_line {
58 char line[TELNETD_CONF_LINELEN];
59 }:
60 MEMB(linemem, struct telnetd_line, TELNETD_CONF_NUMLINES);
61
62 #define STATE_NORMAL 0
63 #define STATE_IAC
64 #define STATE WILL
65 #define STATE_WONT
```

```
66 #define STATE_DO
67 #define STATE_DONT 5
68 #define STATE_CLOSE 6
70 static struct telnetd_state s;
71
72 #define TELNET_IAC
73 #define TELNET_WILL 251
74 #define TELNET_WONT 252
75 #define TELNET_DO
                     253
76 #define TELNET_DONT 254
77 /*---
78 static char *
79 alloc_line(void)
80 {
81 return memb_alloc(&linemem);
82 }
83 /*-----*/
84 static void
85 dealloc_line(char *line)
86 {
87
   memb_free(&linemem, line);
88 }
89 /*-----/
90 void
91 shell_quit(char *str)
92 {
93 s.state = STATE_CLOSE;
94 }
95 /*----
96 static void
97 sendline(char *line)
98 {
99
   static unsigned int i;
100
101 for(i = 0; i < TELNETD_CONF_NUMLINES; ++i) {</pre>
if (s.lines[i] == NULL) {
     s.lines[i] = line;
103
104
        break;
     }
105
106
    if(i == TELNETD_CONF_NUMLINES) {
107
   dealloc_line(line);
108
109
110 }
111 /*---
112 void
113 shell_prompt(char *str)
114 {
    char *line;
line = alloc_line();
115
116
    if(line != NULL) {
117
    strncpy(line, str, TELNETD_CONF_LINELEN);
/* petsciiconv_toascii(line, TELNETD_CONF_LINELEN);*/
sendline(line);
118
119
120
121 }
122 }
123 /*-----*/
124 void
125 shell_output(char *str1, char *str2)
126 {
   static unsigned len;
127
128
    char *line;
129
130 line = alloc_line();
    if(line != NULL) {
131
132
     len = strlen(str1);
```

```
strncpy(line, str1, TELNETD_CONF_LINELEN);
133
134
       if(len < TELNETD_CONF_LINELEN) {</pre>
135
        strncpy(line + len, str2, TELNETD_CONF_LINELEN - len);
136
137
       len = strlen(line);
138
       if(len < TELNETD_CONF_LINELEN - 2) {</pre>
        line[len] = ISO_cr;
139
140
        line[len+1] = ISO_nl;
141
        line[len+2] = 0;
142
143
      /*
             petsciiconv_toascii(line, TELNETD_CONF_LINELEN); */
144
      sendline(line);
145
146 }
147 /*---
148 void
149 telnetd_init(void)
150 {
151
     uip_listen(HTONS(23));
   memb_init(&linemem);
152
153
    shell_init();
154 }
155 /*----
                 -----*/
156 static void
157 acked(void)
158 {
159
     static unsigned int i;
160
161
    while(s.numsent > 0) {
     dealloc_line(s.lines[0]);
162
      for(i = 1; i < TELNETD_CONF_NUMLINES; ++i) {
   s.lines[i - 1] = s.lines[i];</pre>
163
164
165
     s.lines[TELNETD_CONF_NUMLINES - 1] = NULL;
166
167
      --s.numsent;
168
    }
169 }
170 /*----
171 static void
172 senddata(void)
173 {
174
    static char *bufptr, *lineptr;
175
    static int buflen, linelen;
176
    bufptr = uip_appdata;
177
178
    buflen = 0;
179
     for(s.numsent = 0; s.numsent < TELNETD_CONF_NUMLINES &&</pre>
          s.lines[s.numsent] != NULL; ++s.numsent) {
180
      lineptr = s.lines[s.numsent];
182
       linelen = strlen(lineptr);
183
       if(linelen > TELNETD_CONF_LINELEN) {
        linelen = TELNETD_CONF_LINELEN;
185
186
      if(buflen + linelen < uip_mss()) {</pre>
       memcpy(bufptr, lineptr, linelen);
187
        bufptr += linelen;
188
189
         buflen += linelen;
190
      } else {
191
        break;
192
193
194
    uip_send(uip_appdata, buflen);
195 }
196 /*-----*/
197 static void
198 closed(void)
199 {
```

```
static unsigned int i;
201
    for(i = 0; i < TELNETD_CONF_NUMLINES; ++i) {</pre>
202
     if(s.lines[i] != NULL) {
     dealloc_line(s.lines[i]);
204
205
206 }
207 }
208 /*----
209 static void
210 get_char(u8_t c)
211 {
    if(c == ISO_cr) {
212
213
     return;
214
215
    s.buf[(int)s.bufptr] = c;
216
    if(s.buf[(int)s.bufptr] == ISO_nl ||
217
     s.bufptr == sizeof(s.buf) - 1) {
if(s.bufptr > 0) {
218
219
      s.buf[(int)s.bufptr] = 0;
220
221
              petsciiconv_topetscii(s.buf, TELNETD_CONF_LINELEN);*/
222
    shell_input(s.buf);
2.2.3
224
      s.bufptr = 0;
225 } else {
226
      ++s.bufptr;
227
228 }
229 /*----
230 static void
231 sendopt(u8_t option, u8_t value)
232 {
    char *line;
line = alloc_line();
233
234
235 if(line != NULL) {
    line[0] = TELNET_IAC;
236
     line[1] = option;
line[2] = value;
237
238
    line[3] = 0;
239
240
      sendline(line);
241 }
242 }
243 /*-----*/
244 static void
245 newdata(void)
246 {
247
    u16 t len;
    u8_t c;
249
    char *dataptr;
2.50
251
    len = uip_datalen();
252
253
     dataptr = (char *)uip_appdata;
2.5.5
    while(len > 0 && s.bufptr < sizeof(s.buf)) {</pre>
256
     c = *dataptr;
      ++dataptr;
257
2.58
      --len;
259
      switch(s.state) {
260
      case STATE_IAC:
261
       if(c == TELNET_IAC) {
         get_char(c);
262
           s.state = STATE_NORMAL;
263
        } else {
          switch(c) {
265
          case TELNET_WILL:
266
```

```
267
             s.state = STATE_WILL;
268
             break;
269
           case TELNET_WONT:
270
            s.state = STATE_WONT;
271
             break;
272
           case TELNET_DO:
273
             s.state = STATE_DO;
274
             break;
275
           case TELNET_DONT:
276
             s.state = STATE DONT;
277
             break;
278
           default:
279
             s.state = STATE_NORMAL;
280
              break;
281
           }
        }
2.82
283
         break;
284
      case STATE_WILL:
285
         /* Reply with a DONT */
         sendopt(TELNET_DONT, c);
287
         s.state = STATE_NORMAL;
288
         break;
289
      case STATE_WONT:
2.90
       /\star Reply with a DONT \star/
291
         sendopt (TELNET_DONT, c);
292
293
         s.state = STATE_NORMAL;
294
         break;
295
      case STATE_DO:
296
        /* Reply with a WONT */
297
         sendopt(TELNET_WONT, c);
298
         s.state = STATE_NORMAL;
299
        break;
300
      case STATE_DONT:
       /* Reply with a WONT */
sendopt(TELNET_WONT, c);
301
303
         s.state = STATE_NORMAL;
304
         break;
305
      case STATE_NORMAL:
         if(c == TELNET_IAC) {
306
307
           s.state = STATE_IAC;
308
         } else {
309
          get_char(c);
         }
310
311
         break;
312
       }
313
314
315
      }
316
317 }
318 /*--
319 void
320 telnetd_appcall(void)
321 {
322
    static unsigned int i;
323
     if(uip_connected()) {
      /* tcp_markconn(uip_conn, &s);*/
324
325
        for(i = 0; i < TELNETD_CONF_NUMLINES; ++i) {</pre>
326
        s.lines[i] = NULL;
327
328
       s.bufptr = 0;
       s.state = STATE_NORMAL;
329
330
331
       shell_start();
332
      }
333
```

```
if(s.state == STATE_CLOSE) {
    s.state = STATE_NORMAL;
uip_close();
335
336
     return;
337
338
   }
339
340
    if(uip_closed() ||
341
      uip_aborted() ||
342
       uip_timedout()) {
343
     closed();
    }
344
345
    if(uip_acked()) {
346
347
     acked();
348
349
350
     if(uip_newdata()) {
351
     newdata();
352
353
    if(uip_rexmit() ||
354
    uip_newdata() ||
uip_acked() ||
355
356
      uip_connected() ||
357
358
       uip_poll()) {
359
     senddata();
360
361 }
362 /*-----/
363 /** @} */
```

9.12 telnetd.h

```
2 * \addtogroup apps
3 * @{
4 */
5
6 /**
7 * \defgroup telnetd Telnet server
8 * @{
10 * The uIP telnet server
11 *
12 */
13
14 /**
15 * \file
16 *
              Shell server
17 * \added author
18 *
              Adam Dunkels <adam@sics.se>
19 */
20
21 /*
22
   * Copyright (c) 2003, Adam Dunkels.
23 * All rights reserved.
24 +
25
   * Redistribution and use in source and binary forms, with or without
26 \star modification, are permitted provided that the following conditions
27 * are met:
   * 1. Redistributions of source code must retain the above copyright
29 *
        notice, this list of conditions and the following disclaimer.
30 \,\star\, 2. Redistributions in binary form must reproduce the above
        copyright notice, this list of conditions and the following
32 *
        disclaimer in the documentation and/or other materials provided
33 *
        with the distribution.
34 \star 3. The name of the author may not be used to endorse or promote
35
        products derived from this software without specific prior
        written permission.
37
38 \star THIS SOFTWARE IS PROVIDED BY THE AUTHOR ''AS IS'' AND ANY EXPRESS
39 \star OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
40 \star WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
   * ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY
42 * DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
43 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
   * GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
45 * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
46 * WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING
   * NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
48 \star SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
49 +
50 * This file is part of the uIP TCP/IP stack
51
52 * $Id: telnetd.h,v 1.2 2006/06/07 09:43:54 adam Exp $
53 *
54 */
55 #ifndef __TELNETD_H__
56 #define ___TELNETD_H_
57
58 #include "uipopt.h"
59
60 void telnetd_appcall(void);
61
62 #ifndef TELNETD_CONF_LINELEN
63 #define TELNETD_CONF_LINELEN 40
64 #endif
65 #ifndef TELNETD_CONF_NUMLINES
```

9.12 telnetd.h 233

```
66 #define TELNETD_CONF_NUMLINES 16
67 #endif
68
69 struct telnetd_state {
70 char *lines[TELNETD_CONF_NUMLINES];
71 char buf[TELNETD_CONF_LINELEN];
72 char bufptr;
73 u8_t numsent;
74
    u8_t state;
75 };
76
77 typedef struct telnetd_state uip_tcp_appstate_t;
78
79 #ifndef UIP_APPCALL
80 #define UIP_APPCALL
                         telnetd_appcall
81 #endif
83 #endif /* __TELNETD_H__ */
84 /** @} */
```

9.13 uip-code-style.c

```
1 /\star This is the official code style of uIP. \star/
3 /**
4 * \defgroup codestyle Coding style
  * This is how a Doxygen module is documented - start with a \defgroup
  * Doxygen keyword at the beginning of the file to define a module,
8 * and use the \addtogroup Doxygen keyword in all other files that
  \star belong to the same module. Typically, the \defgroup is placed in
10 \star the .h file and \addtogroup in the .c file.
11 *
12 * @{
13 */
14
15 /**
16 * \file
             A brief description of what this file is.
17 *
18 \star \author
19 +
              Adam Dunkels <adam@sics.se>
2.0 *
              Every file that is part of a documented module has to have
21 *
22 *
              a \file block, else it will not show up in the Doxygen
              "Modules" * section.
24 */
25
26 /* Single line comments look like this. */
2.7
28 /*
29 \star Multi-line comments look like this. Comments should prefferably be
30 \star full sentences, filled to look like real paragraphs.
31 */
32
33 #include "uip.h"
34
35 /*
36 \star Make sure that non-global variables are all maked with the static
37 \, \star keyword. This keeps the size of the symbol table down. 38 \, \, \star/
39 static int flag;
40
42 * All variables and functions that are visible outside of the file
43 \,* should have the module name prepended to them. This makes it easy
44 \star to know where to look for function and variable definitions.
46 * Put dividers (a single-line comment consisting only of dashes)
   * between functions.
48 */
49 /*--
50 /**
51 * \brief
                  Use Doxygen documentation for functions.
52 * \param c
                  Briefly describe all parameters.
53 * \return
                  Briefly describe the return value.
54 * \retval 0
                  Functions that return a few specified values
55 * \retval 1
                  can use the \retval keyword instead of \return.
56 *
57
                  Put a longer description of what the function does
                  after the preamble of Doxygen keywords.
58 *
59
                  This template should always be used to document
61
                  functions. The text following the introduction is used
62 *
                  as the function's documentation.
64 *
                  Function prototypes have the return type on one line,
                  the name and arguments on one line (with no space
```

```
66 *
                between the name and the first parenthesis), followed
67 *
68 */
                by a single curly bracket on its own line.
69 void
70 code_style_example_function(void)
71 {
72
7.3
    * Local variables should always be declared at the start of the
74
     * function.
75
76
    int i;
                           /* Use short variable names for loop
77
                              counters. */
78
79
80
    * There should be no space between keywords and the first
     * parenthesis. There should be spaces around binary operators, no
81
    * spaces between a unary operator and its operand.
83
84
     * Curly brackets following for(), if(), do, and case() statements
85
    \star should follow the statement on the same line.
86
     * /
87
    for(i = 0; i < 10; ++i) {
88
89
     \star Always use full blocks (curly brackets) after if(), for(), and
90
      * while() statements, even though the statement is a single line
91
      * of code. This makes the code easier to read and modifications
92
      * are less error prone.
93
       */
     if(i == c) {
94
95
      return c;
                         /* No parentesis around return values. */
96
      } else {
                          /* The else keyword is placed inbetween
97
                             curly brackers, always on its own line. */
98
       c++;
99
     }
100 }
101 }
102 /*-----*/
103 /*
104 \star Static (non-global) functions do not need Doxygen comments. The
105 \, * name should not be prepended with the module name - doing so would
106 * create confusion.
107 */
108 static void
109 an_example_function(void)
110 {
111
112 }
113 /*-----//
115 /\star The following stuff ends the \defgroup block at the beginning of
116
    the file: */
117
118 /** @} */
```

9.14 uip-conf.h

```
2 * \addtogroup uipopt
3 * @{
4 */
5
6 /**
7 * \name Project-specific configuration options
8 * @{
9
11 \star for each project. These are kept in a project-specific uip-conf.h
12 \star file and all configuration names have the prefix UIP_CONF.
13 */
14
15 /*
16 * Copyright (c) 2006, Swedish Institute of Computer Science.
17 * All rights reserved.
18 ;
19 \star Redistribution and use in source and binary forms, with or without
20 \star modification, are permitted provided that the following conditions
21 * are met:
      * 1. Redistributions of source code must retain the above copyright
22
               notice, this list of conditions and the following disclaimer.
24 \, \star 2. Redistributions in binary form must reproduce the above copyright
25
               notice, this list of conditions and the following disclaimer in the
26 *
               documentation and/or other materials provided with the distribution.
27 \star 3. Neither the name of the Institute nor the names of its contributors
             may be used to endorse or promote products derived from this software
29 *
                without specific prior written permission.
30 *
      * THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS ''AS IS'' AND
32 \star ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
33 * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
34 \star ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE
35 \star FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
36 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
      * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
38 \star HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
39 \star LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
40 \, \star OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
41
      * SUCH DAMAGE.
42
43 \star This file is part of the uIP TCP/IP stack
45 * $Id: uip-conf.h, v 1.6 2006/06/12 08:00:31 adam Exp $
46 */
47
48 /**
49 * \file
50 *
                         An example uIP configuration file
51 * \arrownian \arr
                         Adam Dunkels <adam@sics.se>
53 */
54
55 #ifndef __UIP_CONF_H__
56 #define __UIP_CONF_H_
58 #include <inttypes.h>
59
60 /**
61 * 8 bit datatype
63 \star This typedef defines the 8-bit type used throughout uIP.
65 * \hideinitializer
```

9.14 uip-conf.h 237

```
66 */
67 typedef uint8_t u8_t;
68
69 /**
70 * 16 bit datatype
71 \star This typedef defines the 16-bit type used throughout uIP.
73 *
74 * \hideinitializer
75 */
76 typedef uint16_t u16_t;
78 /**
79 * Statistics datatype
80 \star 81 \star This typedef defines the dataype used for keeping statistics in
83 *
84 * \hideinitializer
86 typedef unsigned short uip_stats_t;
87
88 /**
89 * Maximum number of TCP connections.
90 *
91 * \hideinitializer
92 */
93 #define UIP_CONF_MAX_CONNECTIONS 40
94
95 /**
96 * Maximum number of listening TCP ports.
97 *
98 * \hideinitializer
99 */
100 #define UIP_CONF_MAX_LISTENPORTS 40
102 /**
103 * uIP buffer size.
104 *
105 * \hideinitializer
106 */
107 #define UIP_CONF_BUFFER_SIZE 420
108
109 /**
110 * CPU byte order.
111 *
112 * \hideinitializer
113 */
114 #define UIP_CONF_BYTE_ORDER LITTLE_ENDIAN
115
116 /**
117 * Logging on or off
118 *
119 * \hideinitializer
120 */
121 #define UIP_CONF_LOGGING
                                   1
122
123 /**
124 * UDP support on or off
125
126 * \hideinitializer
127 */
128 #define UIP_CONF_UDP
129
130 /**
131 * UDP checksums on or off
132 *
```

```
133 * \hideinitializer
134 */
135 #define UIP_CONF_UDP_CHECKSUMS 1
137 /**
138 \star uIP statistics on or off
139 *
140 \star \hideinitializer 141 \star/
142 #define UIP_CONF_STATISTICS
143
144 /\star Here we include the header file for the application(s) we use in
145 our project. */
146 /*#include "smtp.h"*/
147 /*#include "hello-world.h"*/
148 /*#include "telnetd.h"*/
149 #include "webserver.h"
150 /*#include "dhcpc.h"*/
151 /*#include "resolv.h"*/
152 /*#include "webclient.h"*/
153
154 #endif /* __UIP_CONF_H__ */
155
156 /** @} */
157 /** @} */
```

```
2 * \addtogroup apps
3 * @{
4 */
5
6 /**
7 * \defgroup webclient Web client
8 * @{
9
10 \star This example shows a HTTP client that is able to download web pages
11 \,\,\star\, and files from web servers. It requires a number of callback
   * functions to be implemented by the module that utilizes the code:
13 * webclient_datahandler(), webclient_connected(),
14 * webclient_timedout(), webclient_aborted(), webclient_closed().
15 */
16
17 /**
18 * \file
19 \star Implementation of the HTTP client.
20 * \author Adam Dunkels <adam@dunkels.com>
21 */
22
23 /*
24 * Copyright (c) 2002, Adam Dunkels.
25
   * All rights reserved.
27 * Redistribution and use in source and binary forms, with or without
   * modification, are permitted provided that the following conditions
29 * are met:
30 \, * 1. Redistributions of source code must retain the above copyright
        notice, this list of conditions and the following disclaimer.
   \star 2. Redistributions in binary form must reproduce the above
32
        copyright notice, this list of conditions and the following
34
        disclaimer in the documentation and/or other materials provided
35
         with the distribution.
   \star 3. The name of the author may not be used to endorse or promote
37
        products derived from this software without specific prior
38
         written permission.
39
40 \, \star THIS SOFTWARE IS PROVIDED BY THE AUTHOR ''AS IS'' AND ANY EXPRESS
   * OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
42 * WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
43 \star ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY
   * DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
45 \star DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
46 * GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
   * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
48 \star WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING
49 \star NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
50
   * SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
51
52 * This file is part of the uIP TCP/IP stack.
53 *
54 * $Id: webclient.c,v 1.2 2006/06/11 21:46:37 adam Exp $
55 *
56 */
57
58 #include "uip.h"
59 #include "uiplib.h"
60 #include "webclient.h"
61 #include "resolv.h"
62
63 #include <string.h>
64
65 #define WEBCLIENT_TIMEOUT 100
```

```
66
67 #define WEBCLIENT_STATE_STATUSLINE 0
68 #define WEBCLIENT_STATE_HEADERS
69 #define WEBCLIENT_STATE_DATA
70 #define WEBCLIENT_STATE_CLOSE
72 #define HTTPFLAG_NONE 0
73 #define HTTPFLAG_OK
                   1
74 #define HTTPFLAG_MOVED 2
75 #define HTTPFLAG_ERROR 3
76
77
78 #define ISO_nl 0x0a
79 #define ISO_cr 0x0d
80 #define ISO_space 0x20
81
83 static struct webclient_state s;
84
85 /*-----/
86 char *
87 webclient_mimetype(void)
88 {
89 return s.mimetype;
90 }
91 /*-----*/
92 char *
93 webclient_filename(void)
94 {
95 return s.file;
96 }
97 /*-----*/
98 char *
99 webclient_hostname(void)
100 {
101 return s.host;
102 }
103 /*----
104 unsigned short
105 webclient_port(void)
107 return s.port;
108 }
109 /*-----/
110 void
111 webclient_init(void)
112 {
113
114 }
115 /*-----/
116 static void
117 init_connection(void)
118 {
119
    s.state = WEBCLIENT_STATE_STATUSLINE;
120
121 s.getrequestleft = sizeof(http_get) - 1 + 1 +
    sizeof(http_10) - 1 +
sizeof(http_crnl) - 1 +
122
123
124
    sizeof(http_host) - 1 +
    sizeof(http_crnl) - 1 +
strlen(http_user_agent_fields) +
125
126
    strlen(s.file) + strlen(s.host);
127
128
   s.getrequestptr = 0;
129
130
   s.httpheaderlineptr = 0;
131 }
132 /*-----*/
```

```
133 void
134 webclient_close(void)
135 {
136    s.state = WEBCLIENT_STATE_CLOSE;
137 }
138 /*-----/
139 unsigned char
140 webclient_get(char *host, u16_t port, char *file)
141 {
    struct uip_conn *conn;
142
143
    uip_ipaddr_t *ipaddr;
144
    static uip_ipaddr_t addr;
145
146
    /\star First check if the host is an IP address. \star/
147
     ipaddr = &addr:
148
     if(uiplib_ipaddrconv(host, (unsigned char *)addr) == 0) {
149
      ipaddr = (uip_ipaddr_t *)resolv_lookup(host);
150
     if(ipaddr == NULL) {
151
152
       return 0;
153
154
     }
155
156
     conn = uip_connect(ipaddr, htons(port));
157
    if(conn == NULL) {
158
159
     return 0;
160
161
     s.port = port;
162
163
     strncpy(s.file, file, sizeof(s.file));
     strncpy(s.host, host, sizeof(s.host));
164
165
166
    init_connection();
167
    return 1;
168 }
169 /*----*/
170 static unsigned char \star
171 copy_string(unsigned char *dest,
172
            const unsigned char *src, unsigned char len)
173 {
174 strncpy(dest, src, len);
175
    return dest + len;
176 }
177 /*------/
178 static void
179 senddata(void)
180 {
181 u16_t len;
182
    char *getrequest;
183
     char *cptr;
184
185
    if(s.getrequestleft > 0) {
186
     cptr = getrequest = (char *)uip_appdata;
187
      cptr = copy_string(cptr, http_get, sizeof(http_get) - 1);
188
189
      cptr = copy_string(cptr, s.file, strlen(s.file));
190
      *cptr++ = ISO_space;
191
       cptr = copy_string(cptr, http_10, sizeof(http_10) - 1);
192
193
       cptr = copy_string(cptr, http_crnl, sizeof(http_crnl) - 1);
194
195
      cptr = copy_string(cptr, http_host, sizeof(http_host) - 1);
196
       cptr = copy_string(cptr, s.host, strlen(s.host));
197
      cptr = copy_string(cptr, http_crnl, sizeof(http_crnl) - 1);
198
199
       cptr = copy_string(cptr, http_user_agent_fields,
```

```
200
                           strlen(http_user_agent_fields));
201
202
       len = s.getrequestleft > uip_mss()?
        uip_mss():
204
         s.getrequestleft;
205
       uip_send(&(getrequest[s.getrequestptr]), len);
206
207 }
208 /*----
209 static void
210 acked(void)
211 {
212
     u16_t len;
213
     if(s.getrequestleft > 0) {
214
      len = s.getrequestleft > uip_mss()?
215
216
        uip_mss():
217
         s.getrequestleft;
      s.getrequestleft -= len;
218
      s.getrequestptr += len;
219
220
    }
221 }
222 /*-----
223 static u16_t
224 parse_statusline(u16_t len)
225 {
226
     char *cptr;
227
228
     while(len > 0 && s.httpheaderlineptr < sizeof(s.httpheaderline)) {</pre>
229
      s.httpheaderline[s.httpheaderlineptr] = *(char *)uip_appdata;
230
        ++((char *)uip_appdata);
2.31
        --len;
232
       if(s.httpheaderline[s.httpheaderlineptr] == ISO_nl) {
233
2.34
          if((strncmp(s.httpheaderline, http_10,
235
                     sizeof(http_10) - 1) == 0) ||
236
             (strncmp(s.httpheaderline, http_11,
237
                      sizeof(http_11) - 1) == 0)) {
            cptr = &(s.httpheaderline[9]);
238
2.39
            s.httpflag = HTTPFLAG_NONE;
            if(strncmp(cptr, http_200, sizeof(http_200) - 1) == 0) {
240
             /* 200 OK */
241
242
             s.httpflag = HTTPFLAG_OK;
           } else if(strncmp(cptr, http_301, sizeof(http_301) - 1) == 0 ||
243
                      strncmp(cptr, http_302, sizeof(http_302) - 1) == 0) {
244
245
              /\star 301 Moved permanently or 302 Found. Location: header line
246
                will contain thw new location. */
247
             s.httpflag = HTTPFLAG_MOVED;
           } else {
249
             s.httpheaderline[s.httpheaderlineptr - 1] = 0;
250
251
         } else {
252
          uip_abort();
253
           webclient_aborted();
254
           return 0:
255
         }
256
257
         /\star We're done parsing the status line, so we reset the pointer
2.58
            and start parsing the HTTP headers.*/
259
          s.httpheaderlineptr = 0;
260
         s.state = WEBCLIENT_STATE_HEADERS;
261
         break;
262
       } else {
263
          ++s.httpheaderlineptr;
264
265
     }
266
     return len;
```

```
268 /*-----*/
269 static char
270 casecmp(char *str1, const char *str2, char len)
271 {
272
     static char c;
273
2.74
     while(len > 0) {
2.75
      c = *str1;
276
       /\star Force lower-case characters. \star/
277
       if(c & 0x40) {
278
        c \mid = 0x20;
279
280
      if(*str2 != c) {
281
       return 1;
2.82
283
       ++str1;
284
       ++str2;
285
       --len;
286
    }
287
     return 0;
288 }
289 /*--
290 static u16_t
291 parse_headers(u16_t len)
292 {
293
    char *cptr;
294
     static unsigned char i;
295
296
    while(len > 0 && s.httpheaderlineptr < sizeof(s.httpheaderline)) {</pre>
297
       s.httpheaderline[s.httpheaderlineptr] = *(char *)uip_appdata;
298
       ++((char *)uip_appdata);
299
       --len;
300
       if(s.httpheaderline[s.httpheaderlineptr] == ISO_nl) {
301
         /\star We have an entire HTTP header line in s.httpheaderline, so
            we parse it. */
303
         if(s.httpheaderline[0] == ISO_cr) {
304
           /\star This was the last header line (i.e., and empty "\r\n"), so
305
              we are done with the headers and proceed with the actual
306
              data. */
307
           s.state = WEBCLIENT_STATE_DATA;
308
           return len;
309
         }
310
311
         s.httpheaderline[s.httpheaderlineptr - 1] = 0;
312
         /\star Check for specific HTTP header fields. \star/
313
         if(casecmp(s.httpheaderline, http_content_type,
                        sizeof(http_content_type) - 1) == 0) {
314
          /* Found Content-type field. */
315
316
           cptr = strchr(s.httpheaderline, ';');
317
           if(cptr != NULL) {
            *cptr = 0;
318
319
320
           strncpy(s.mimetype, s.httpheaderline +
321
                   sizeof(http_content_type) - 1, sizeof(s.mimetype));
322
         } else if(casecmp(s.httpheaderline, http_location,
323
                               sizeof(http_location) - 1) == 0) {
324
           cptr = s.httpheaderline +
325
             sizeof(http_location) - 1;
326
327
           if(strncmp(cptr, http_http, 7) == 0) {
             cptr += 7;
328
              for (i = 0; i < s.httpheaderlineptr - 7; ++i) {
329
               if(*cptr == 0 ||
330
331
                  *cptr == '/' ||
                  *cptr == ' ' ||
332
                  *cptr == ':') {
333
```

```
334
                s.host[i] = 0;
335
               break;
336
              s.host[i] = *cptr;
338
              ++cptr;
339
            }
340
          }
341
          strncpy(s.file, cptr, sizeof(s.file));
342
                 s.file[s.httpheaderlineptr - i] = 0;*/
343
344
345
         /\star We're done parsing, so we reset the pointer and start the
346
347
          next line. */
        s.httpheaderlineptr = 0;
348
349
       } else {
350
        ++s.httpheaderlineptr;
      }
351
352
353
    return len;
354 }
355 /*----
356 static void
357 newdata(void)
358 {
359
    u16_t len;
360
361
    len = uip_datalen();
362
363
    if(s.state == WEBCLIENT_STATE_STATUSLINE) {
364
      len = parse_statusline(len);
365
366
     if(s.state == WEBCLIENT_STATE_HEADERS && len > 0) {
367
368
     len = parse_headers(len);
369
370
371
     if(len > 0 && s.state == WEBCLIENT_STATE_DATA &&
372
     s.httpflag != HTTPFLAG_MOVED) {
373
      webclient_datahandler((char *)uip_appdata, len);
374
     }
375 }
376 /*-----*/
377 void
378 webclient_appcall(void)
379 {
380
    if(uip_connected()) {
381
      s.timer = 0;
      s.state = WEBCLIENT_STATE_STATUSLINE;
383
      senddata();
384
      webclient_connected();
385
      return;
386
387
    if(s.state == WEBCLIENT_STATE_CLOSE) {
388
     webclient_closed();
389
     uip_abort();
390
391
       return;
392
393
394
     if(uip_aborted()) {
395
      webclient_aborted();
396
397
     if(uip_timedout()) {
398
      webclient_timedout();
399
400
```

```
401
402
     if(uip_acked()) {
     s.timer = 0;
acked();
403
404
405
406
     if(uip_newdata()) {
407
     s.timer = 0;
408
      newdata();
409
    if(uip_rexmit() ||
410
     uip_newdata() ||
411
        uip_acked()) {
412
      senddata();
413
414
    } else if(uip_poll()) {
415
       ++s.timer;
      if(s.timer == WEBCLIENT_TIMEOUT) {
416
417
        webclient_timedout();
418
         uip_abort();
419
         return;
420
      }
421
                 senddata();*/
422
     }
423
424
    if(uip_closed()) {
     if(s.httpflag != HTTPFLAG_MOVED) {
425
426
        /* Send NULL data to signal EOF. */
427
         webclient_datahandler(NULL, 0);
428
      } else {
        if(resolv_lookup(s.host) == NULL) {
429
430
          resolv_query(s.host);
431
432
         webclient_get(s.host, s.port, s.file);
433
      }
434
    }
435 }
436 /*----
437
438 /** @} */
439 /** @} */
```

9.16 webclient.h

```
2 * \addtogroup webclient
3 * @{
4 */
5
6 /**
7 * \file
8 \star Header file for the HTTP client.
  * \author Adam Dunkels <adam@dunkels.com>
10 */
11
12 /*
13 * Copyright (c) 2002, Adam Dunkels.
14 * All rights reserved.
15
17 * modification, are permitted provided that the following conditions
18 * are met:
19 \,\star\, 1. Redistributions of source code must retain the above copyright
20 \star notice, this list of conditions and the following disclaimer.
21 \star 2. Redistributions in binary form must reproduce the above
22
        copyright notice, this list of conditions and the following
        disclaimer in the documentation and/or other materials provided
24 *
        with the distribution.
25
   \star 3. The name of the author may not be used to endorse or promote
        products derived from this software without specific prior
2.7
        written permission.
2.8
29 * THIS SOFTWARE IS PROVIDED BY THE AUTHOR ''AS IS'' AND ANY EXPRESS
30 \star OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
   * WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
32 \star ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY
33 * DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
34 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
35 \star GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
36 * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
37 * WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING
38 \star NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
39 * SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
40 *
41
   \star This file is part of the uIP TCP/IP stack.
42 +
43 * $Id: webclient.h,v 1.2 2006/06/11 21:46:37 adam Exp $
44
45 */
46 #ifndef ___WEBCLIENT_H__
47 #define ___WEBCLIENT_H__
48
49
50 #include "webclient-strings.h"
51 #include "uipopt.h"
53 #define WEBCLIENT_CONF_MAX_URLLEN 100
54
55 struct webclient_state {
56
    u8_t timer;
57
    u8_t state;
58
    u8_t httpflag;
59
60
    u16_t port;
61
    char host[40];
62
    char file[WEBCLIENT_CONF_MAX_URLLEN];
    u16_t getrequestptr;
64
    u16_t getrequestleft;
65
```

9.16 webclient.h

```
char httpheaderline[200];
67
    u16_t httpheaderlineptr;
68
69
    char mimetype[32];
70 };
71
72 typedef struct webclient_state uip_tcp_appstate_t;
73 #define UIP_APPCALL webclient_appcall
75 /**
76 * Callback function that is called from the webclient code when HTTP
77
   * data has been received.
78
79 	 \star 	  This function must be implemented by the module that uses the
80 \star webclient code. The function is called from the webclient module
   \star when HTTP data has been received. The function is not called when
81
82 * HTTP headers are received, only for the actual data.
83 -
84 \star \note This function is called many times, repetedly, when data is
85 * being received, and not once when all data has been received.
86 -
87 \star \param data A pointer to the data that has been received.
88 \star \param len The length of the data that has been received.
89 */
90 void webclient_datahandler(char *data, u16_t len);
91
92 /**
93 \star Callback function that is called from the webclient code when the
94 \, * HTTP connection has been connected to the web server.
95 ;
96 \star This function must be implemented by the module that uses the
97 \star webclient code.
99 void webclient_connected(void);
100
101 /**
102 \star Callback function that is called from the webclient code if the
103
    * HTTP connection to the web server has timed out.
104
105 \,\,\star\, This function must be implemented by the module that uses the
106 * webclient code.
107 */
108 void webclient_timedout(void);
109
110 /**
111 \star Callback function that is called from the webclient code if the
112 \star HTTP connection to the web server has been aborted by the web
113 * server.
115
    * This function must be implemented by the module that uses the
116 * webclient code.
117 */
118 void webclient_aborted(void);
119
120 /**
121 \star Callback function that is called from the webclient code when the
    \star HTTP connection to the web server has been closed.
123
124 \,\, * This function must be implemented by the module that uses the 125 \,\, * webclient code.
126 */
127 void webclient_closed(void);
128
129
130
131 /**
132 \star Initialize the webclient module.
```

```
133 */
134 void webclient_init(void);
135
137 \,\,\star\,\, Open an HTTP connection to a web server and ask for a file using
138
    * the GET method.
139
140 \, * This function opens an HTTP connection to the specified web server
    \star and requests the specified file using the GET method. When the HTTP
142 * connection has been connected, the webclient connected() callback
143 \star function is called and when the HTTP data arrives the
     * webclient_datahandler() callback function is called.
145
146
    * The callback function webclient_timedout() is called if the web
147
    \star server could not be contacted, and the webclient_aborted() callback
148
    * function is called if the HTTP connection is aborted by the web
150
151
    \star When the HTTP request has been completed and the HTTP connection is
152 * closed, the webclient_closed() callback function will be called.
153
    \star \note If the function is passed a host name, it must already be in
154
155 \star the resolver cache in order for the function to connect to the web
156 \star server. It is therefore up to the calling module to implement the
157
     * resolver calls and the signal handler used for reporting a resolv
158 * query answer.
159
160
     \star \param host A pointer to a string containing either a host name or
161
    * a numerical IP address in dotted decimal notation (e.g., 192.168.23.1).
162
163
    * \param port The port number to which to connect, in host byte order.
164
165 * \param file A pointer to the name of the file to get.
166
167
    \star \retval 0 if the host name could not be found in the cache, or
168 \star if a TCP connection could not be created.
169
170
     * \retval 1 if the connection was initiated.
171 */
172 unsigned char webclient_get(char *host, u16_t port, char *file);
173
174 /**
175 \,\,\star\, Close the currently open HTTP connection.
176 */
177 void webclient_close(void);
178 void webclient_appcall(void);
179
180 /**
181 \star Obtain the MIME type of the current HTTP data stream.
182 *
183
    \star \return A pointer to a string contaning the MIME type. The string
184 \star may be empty if no MIME type was reported by the web server.
185 */
186 char *webclient_mimetype(void);
187
188 /**
    \star Obtain the filename of the current HTTP data stream.
189
190 *
191
    * The filename of an HTTP request may be changed by the web server,
    * and may therefore not be the same as when the original GET request
193 \star was made with webclient_get(). This function is used for obtaining
194
    * the current filename.
195
    \star \return A pointer to the current filename.
196
197 */
198 char *webclient_filename(void);
199
```

9.16 webclient.h

```
200 /**
201 \,\,\star\, Obtain the hostname of the current HTTP data stream.
202
203 * The hostname of the web server of an HTTP request may be changed
204 \,\, \star by the web server, and may therefore not be the same as when the
205
     * original GET request was made with webclient_get(). This function
206 \star is used for obtaining the current hostname.
207
208 * \return A pointer to the current hostname.
209 */
210 char *webclient_hostname(void);
211
212 /**
213 \star Obtain the port number of the current HTTP data stream.
214 *
215 * The port number of an HTTP request may be changed by the web
216 \,\,\star\,\, server, and may therefore not be the same as when the original GET
217 \, * request was made with webclient_get(). This function is used for 218 \, * obtaining the current port number.
219 *
220 \, \star \return The port number of the current HTTP data stream, in host byte order.
221 */
222 unsigned short webclient_port(void);
2.2.3
224
225
226 #endif /* __WEBCLIENT_H__ */
227
228 /** @} */
```

Index

Applications 26	hund 121
Applications, 36	httpd, 121
apps/hello-world/hello-world.c, 147	httpd_state, 126
apps/hello-world/hello-world.h, 148 apps/resolv/resolv.c, 149	lib/memb.c, 167
apps/resolv/resolv.h, 151	lib/memb.h, 168
11	Local continuations, 90
apps/smtp/smtp.c, 153	Local continuations, 70
apps/smtp/smtp.h, 154 apps/telnetd/shell.c, 156	MEMB
apps/tellietd/shell.h, 157	memb, 103
apps/tellietd/sheff.fl, 137 apps/tellnetd/tellnetd.c, 158	memb
apps/tellietd/tellietd.t, 158 apps/tellietd/tellietd.h, 159	MEMB, 103
apps/webclient/webclient.c, 160	memb_alloc, 103
apps/webclient/webclient.h, 162	memb_free, 103
apps/webserver/httpd-cgi.c, 164	memb_init, 104
apps/webserver/httpd-cgi.h, 165	memb_alloc
apps/webserver/httpd.c, 166	memb_anoc
Architecture specific uIP functions, 74	memb_blocks, 127
Architecture specific dir functions, 74	memb_free
clock	memb, 103
clock_init, 94	memb_init
clock_time, 94	memb, 104
Clock interface, 94	Memory block management functions, 102
clock_init	Tremery ereen management rune tions, 102
clock, 94	Protosockets library, 95
clock_time	Protothreads, 27
clock, 94	psock, 128
Configuration options for uIP, 79	PSOCK_BEGIN, 96
comparation options for all , 75	PSOCK_CLOSE, 97
dhcpc_state, 123	PSOCK_CLOSE_EXIT, 97
DNS resolver, 105	PSOCK_DATALEN, 97
	PSOCK_END, 97
Hello, world, 113	PSOCK_EXIT, 98
hello_world_state, 124	PSOCK_GENERATOR_SEND, 98
HTONS	PSOCK_INIT, 98
uipconvfunc, 56	PSOCK_NEWDATA, 99
htons	PSOCK_READBUF, 99
uip, 67	PSOCK_READTO, 99
uipconvfunc, 60	PSOCK_SEND, 99
httpd	PSOCK_SEND_STR, 100
HTTPD_CGI_CALL, 121	PSOCK_WAIT_UNTIL, 100
httpd_init, 121	PSOCK_BEGIN
HTTPD_CGI_CALL	psock, 96
httpd, 121	psock_buf, 129
httpd_cgi_call, 125	PSOCK_CLOSE
httpd_init	psock, 97

PSOCK_CLOSE_EXIT	PT_WAIT_THREAD
psock, 97	pt, 33
PSOCK_DATALEN	PT_WAIT_UNTIL
psock, 97	pt, 34
PSOCK_END	PT_WAIT_WHILE
psock, 97	pt, 34
PSOCK_EXIT	PT_YIELD
psock, 98	pt, 34
PSOCK_GENERATOR_SEND	PT_YIELD_UNTIL
psock, 98	pt, 35
PSOCK_INIT	
psock, 98	resolv
PSOCK_NEWDATA	resolv_conf, 106
psock, 99	resolv_found, 106
PSOCK_READBUF	resolv_getserver, 106
psock, 99	resolv_lookup, 106
PSOCK_READTO	resolv_query, 107
psock, 99	resolv_conf
PSOCK_SEND	resolv, 106
psock, 99	resolv found
PSOCK SEND STR	resolv, 106
psock, 100	resolv_getserver
PSOCK_WAIT_UNTIL	resolv, 106
psock, 100	resolv_lookup
pt, 130	resolv, 106
PT_BEGIN, 31	resolv_query
PT_END, 31	resolv, 107
PT_EXIT, 32	165617, 107
PT_INIT, 32	shell_init
PT_RESTART, 32	telnetd, 111
PT_SCHEDULE, 33	shell_input
PT_SPAWN, 33	telnetd, 111
PT_THREAD, 33	shell_output
PT_WAIT_THREAD, 33	telnetd, 111
PT WAIT UNTIL, 34	shell_prompt
PT_WAIT_UNTIL, 34 PT_WAIT_WHILE, 34	telnetd, 112
PT_YIELD, 34	shell_start
PT_YIELD, 34 PT_YIELD_UNTIL, 35	telnetd, 112
PT_TIELD_UNTIL, 33 PT_BEGIN	
-	smtp configure 100
pt, 31 PT END	smtp_configure, 109
-	smtp_done, 109
pt, 31	smtp_send, 109
PT_EXIT	SMTP E-mail sender, 108
pt, 32	smtp_configure
PT_INIT	smtp, 109
pt, 32	smtp_done
PT_RESTART	smtp, 109
pt, 32	smtp_send
PT_SCHEDULE	smtp, 109
pt, 33	smtp_state, 131
PT_SPAWN	T 1
pt, 33	Telnet server, 110
PT_THREAD	telnetd
pt, 33	shell_init, 111

shell_input, 111	uip/lc.h, 171
shell_output, 111	uip/psock.h, 172
shell_prompt, 112	uip/pt.h, 174
shell_start, 112	uip/timer.c, 176
telnetd_state, 132	uip/timer.h, 177
The uIP TCP/IP stack, 62	uip/uip-neighbor.c, 178
timer, 133	uip/uip-neighbor.h, 179
timer_expired, 92	uip/uip-split.h, 180
timer_reset, 92	uip/uip.c, 181
timer_restart, 92	uip/uip.h, 184
timer_set, 93	uip/uip_arch.h, 190
Timer library, 91	uip/uip_arp.c, 191
timer_expired	uip/uip_arp.h, 192
timer_expired	uip/uipopt.h, 193
timer reset	uip_abort
timer, 92	uipappfunc, 47
timer restart	uip_aborted
timer, 92	uipappfunc, 48
	uip_acked
timer_set timer, 93	uipappfunc, 48
uniei, 93	UIP_ACTIVE_OPEN
u16_t	
uipopt, 87	uipopt, 83 uip_add32
u8_t	_
uipopt, 87	uip, 67
	uiparch, 74
uip	uip_appdata
htons, 67 uip_add32, 67	uip, 71
*	UIP_APPDATA_SIZE
uip_appdata, 71	uip, 66
UIP_APPDATA_SIZE, 66	uip_arp_arpin
uip_buf, 71	uiparp, 77
uip_chksum, 67	UIP_ARP_MAXAGE
uip_conn, 72	uipopt, 83
uip_connect, 67	uip_arp_out
uip_init, 68	uiparp, 77
uip_ipchksum, 68	uip_arp_timer
uip_len, 72	uiparp, 78
uip_listen, 68	UIP_ARPTAB_SIZE
uip_send, 69	uipopt, 83
uip_setipid, 69	UIP_BROADCAST
uip_stat, 72	uipopt, 83
uip_tcpchksum, 69	uip_buf
uip_udp_new, 70	uip, 7 1
uip_udpchksum, 70	uipdevfunc, 44
uip_unlisten, 70	UIP_BUFSIZE
uIP Address Resolution Protocol, 76	uipopt, 83
uIP application functions, 46	UIP_BYTE_ORDER
uIP configuration functions, 37	uipopt, 84
uIP conversion functions, 55	uip_chksum
uIP device driver functions, 41	uip, 67
uIP initialization functions, 40	uiparch, 75
uIP TCP throughput booster hack, 89	uip_close
uip/lc-addrlabels.h, 169	uipappfunc, 48
uip/lc-switch.h, 170	uip_closed

uinennfune 49	uin 72
uipappfunc, 48	uip, 72
uip_conn, 134	uipdrivervars, 61
uip, 72	uip_listen
uip_connect	uip, 68
uip, 67	uipappfunc, 52
uipappfunc, 52	UIP_LISTENPORTS
uip_connected	uipopt, 84
uipappfunc, 48	UIP_LLH_LEN
UIP_CONNS	uipopt, 85
uipopt, 84	uip_log
uip_datalen	uipopt, 88
uipappfunc, 49	UIP_LOGGING
uip_eth_addr, 136	uipopt, 85
uip_eth_hdr, 137	UIP_MAXRTX
UIP_FIXEDADDR	uipopt, 85
uipopt, 84	UIP_MAXSYNRTX
UIP_FIXEDETHADDR	uipopt, 85
uipopt, 84	uip_mss
uip_getdraddr	uipappfunc, 49
uipconffunc, 37	uip_neighbor_addr, 139
uip_gethostaddr	uip_newdata
uipconffunc, 37	uipappfunc, 49
uip_getnetmask	uip_periodic
uipconffunc, 38	uipdevfunc, 42
uip_icmpip_hdr, 138	uip_periodic_conn
uip_init	uipdevfunc, 43
uip, 68	UIP_PINGADDRCONF
10.10.14 40	0 E
uipinit, 40	uipopt, 85
uip_input	uip_poll
uip_input uipdevfunc, 41	uip_poll uipappfunc, 49
uip_input uipdevfunc, 41 uip_ip6addr	uip_poll uipappfunc, 49 uip_poll_conn
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp uipconvfunc, 58	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_emp uipconvfunc, 58 uip_ipaddr_copy	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58 uip_ipaddr_mask	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr uipconffunc, 38
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58 uip_ipaddr_mask uipconvfunc, 59	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr uipconffunc, 38 uip_setethaddr
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_maskcmp	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr uipconffunc, 38 uip_setethaddr uipconffunc, 38
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_maskcmp uipconvfunc, 59	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr uipconffunc, 38 uip_setethaddr uipconffunc, 38 uip_sethostaddr
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_emp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_maskemp uipconvfunc, 59 uip_ipchksum	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr uipconffunc, 38 uip_setethaddr uipconffunc, 38 uip_sethostaddr uipconffunc, 38
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_cmp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_maskcmp uipconvfunc, 59 uip_ipchksum uip, 68	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr uipconffunc, 38 uip_setethaddr uipconffunc, 38 uip_sethostaddr uipconffunc, 38 uip_sethostaddr uipconffunc, 38 uip_setipid
uip_input uipdevfunc, 41 uip_ip6addr uipconvfunc, 56 uip_ipaddr uipconvfunc, 56 uip_ipaddr1 uipconvfunc, 56 uip_ipaddr2 uipconvfunc, 57 uip_ipaddr3 uipconvfunc, 57 uip_ipaddr4 uipconvfunc, 58 uip_ipaddr_emp uipconvfunc, 58 uip_ipaddr_copy uipconvfunc, 58 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_mask uipconvfunc, 59 uip_ipaddr_maskemp uipconvfunc, 59 uip_ipchksum	uip_poll uipappfunc, 49 uip_poll_conn uipdevfunc, 43 UIP_REASSEMBLY uipopt, 85 UIP_RECEIVE_WINDOW uipopt, 86 uip_restart uipappfunc, 50 uip_rexmit uipappfunc, 50 UIP_RTO uipopt, 86 uip_send uip, 69 uipappfunc, 53 uip_setdraddr uipconffunc, 38 uip_setethaddr uipconffunc, 38 uip_sethostaddr uipconffunc, 38

uip_setnetmask	uipopt, 87
uipconffunc, 39	uip_urgdatalen
uip_split_output	uipappfunc, 51
uipsplit, 89	uipappfunc
uip_stat	uip_abort, 47
uip, 72	uip_aborted, 48
UIP_STATISTICS	uip_acked, 48
uipopt, 86	uip_close, 48
uip_stats, 140	uip_closed, 48
uip_stats_t	uip_connect, 52
uipopt, 87	uip_connected, 48
uip_stop	uip_datalen, 49
uipappfunc, 50	uip_listen, 52
uip_tcp_appstate_t	uip_mss, 49
uipopt, 87	uip_newdata, 49
UIP_TCP_MSS	uip_poll, 49
uipopt, 86	uip_restart, 50
uip_tcpchksum	uip_rexmit, 50
uip, 69	uip_send, 53
uiparch, 75	uip_stop, 50
uip_tcpip_hdr, 142	uip_timedout, 50
UIP_TIME_WAIT_TIMEOUT	uip_udp_bind, 50
uipopt, 86	uip_udp_new, 53
uip_timedout	uip_udp_remove, 51
uipappfunc, 50	uip_udp_send, 51
UIP_TTL	uip_udpconnection, 51
uipopt, 86	uip_unlisten, 54
uip_udp_appstate_t	uip_urgdatalen, 51
uipopt, 88	uiparch
uip_udp_bind	uip_add32, 74
uipappfunc, 50	uip_chksum, 75
UIP_UDP_CHECKSUMS	uip_ipchksum, 75
uipopt, 87	uip_tcpchksum, 75
uip_udp_conn, 143	uiparp
uip_udp_new	uip_arp_arpin, 77
uip, 70	uip_arp_out, 77
uipappfunc, 53	uip_arp_timer, 78
uip_udp_periodic	uipconffunc
uipdevfunc, 43	uip_getdraddr, 37
uip_udp_periodic_conn	uip_gethostaddr, 37
uipdevfunc, 44	uip_getnetmask, 38
uip_udp_remove	uip_setdraddr, 38
uipappfunc, 51	uip_setethaddr, 38
uip_udp_send	uip_sethostaddr, 38
uipappfunc, 51	uip_setnetmask, 39
uip_udpchksum	uipconvfunc
uip, 70	HTONS, 56
uip_udpconnection	htons, 60
uipappfunc, 51	uip_ip6addr, 56
uip_udpip_hdr, 144	uip_ipaddr, 56
uip_unlisten	uip_ipaddr1, 56
uip, 70	uip_ipaddr2, 57
uipappfunc, 54	uip_ipaddr3, 57
UIP_URGDATA	uip_ipaddr4, 58
	=

uip_ipaddr_cmp, 58	Web client, 114
uip_ipaddr_copy, 58	Web server, 120
uip_ipaddr_mask, 59	webclient
uip_ipaddr_maskcmp, 59	webclient_aborted, 115
uipdevfunc	webclient_closed, 116
uip_buf, 44	webclient_connected, 116
•	webclient_datahandler, 116
uip_input, 41	
uip_periodic, 42	webclient_filename, 116 webclient_get, 117
uip_periodic_conn, 43	
uip_poll_conn, 43	webclient_hostname, 117
uip_udp_periodic, 43	webclient_mimetype, 118
uip_udp_periodic_conn, 44	webclient_port, 118
uipdrivervars	webclient_timedout, 118
uip_len, 61	webclient_aborted
uipinit	webclient, 115
uip_init, 40	webclient_closed
uip_setipid, 40	webclient, 116
uipopt	webclient_connected
u16_t, 87	webclient, 116
u8_t, 87	webclient_datahandler
UIP_ACTIVE_OPEN, 83	webclient, 116
UIP_ARP_MAXAGE, 83	webclient_filename
UIP_ARPTAB_SIZE, 83	webclient, 116
	webclient_get
UIP_BROADCAST, 83	webclient, 117
UIP_BUFSIZE, 83	webclient_hostname
UIP_BYTE_ORDER, 84	webclient, 117
UIP_CONNS, 84	webclient_mimetype
UIP_FIXEDADDR, 84	webclient, 118
UIP_FIXEDETHADDR, 84	webclient_port
UIP_LISTENPORTS, 84	webclient, 118
UIP_LLH_LEN, 85	webclient_state, 145
uip_log, 88	webclient_timedout
UIP_LOGGING, 85	
UIP_MAXRTX, 85	webclient, 118
UIP_MAXSYNRTX, 85	
UIP_PINGADDRCONF, 85	
UIP_REASSEMBLY, 85	
UIP_RECEIVE_WINDOW, 86	
UIP_RTO, 86	
UIP_STATISTICS, 86	
uip_stats_t, 87	
uip_stats_t, 87 uip_tcp_appstate_t, 87	
UIP_TCP_MSS, 86	
UIP_TIME_WAIT_TIMEOUT, 86	
UIP_TTL, 86	
uip_udp_appstate_t, 88	
UIP_UDP_CHECKSUMS, 87	
UIP_URGDATA, 87	
uipsplit	
uip_split_output, 89	
unix/uip-conf.h, 196	

Variables used in uIP device drivers, 61