# Design and Implementation of a Virtual Local Area Network with using Cisco Operating System

# Prototype I

Network Topology and Cisco IOS Configuration Commands

Özde ÖZAŞ

Buğra YILMAZ

Esra Nur YÜCEL

# Create VLAN-2 and Assign FastEthernet0/1-3 to VLAN-2

```
Switch>
Switch> enable
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config) # hostname SW1
SW1(config) # vlan 2
SW1(config-vlan) # name VLAN-2
SW1(config-vlan) # exit
SW1(config) # interface range FastEthernet0/1-3
SW1(config-if-range) # switchport mode access
SW1(config-if-range) # switchport access vlan 2
SW1(config-if-range) # end
%SYS-5-CONFIG I: Configured from console by console
SW1# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW1# exit
```

# Create VLAN-3 and Assign FastEthernet0/4-5 to VLAN-3

```
SW1>
SW1> enable
SW1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config) # vlan 3
SW1(config-vlan) # name VLAN-3
SW1(config-vlan)# exit
SW1(config) # interface range FastEthernet0/4-5
SW1(config-if-range)# switchport mode access
SW1(config-if-range) # switchport access vlan 3
SW1(config-if-range) # end
SW1#
%SYS-5-CONFIG I: Configured from console by console
SW1# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW1# exit
```

# Create VLAN-99 (Management VLAN) and Assign FastEthernet0/24 to VLAN-99

```
SW1>
SW1> enable
SW1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config) # vlan 99
SW1(config-vlan) # name VLAN-99
SW1(config-vlan) # exit
SW1(config) # interface FastEthernet0/24
SW1(config-if) # switchport mode access
SW1(config-if) # switchport access vlan 99
SW1(config-if)# end
SW1#
%SYS-5-CONFIG I: Configured from console by console
SW1# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW1# exit
```

# Assign IP Address to FastEthernet0/24 (VLAN-99) for Telnet or SSH

```
SW1> enable
SW1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config)# interface vlan 99
SW1(config-if)#
%LINK-5-CHANGED: Interface Vlan99, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan99, changed state to up
SW1(config-if)#ip address 192.168.99.2 255.255.255.0
SW1(config-if)#no shutdown
SW1(config-if)#
```

# Assign Password to VTY for Telnet Connection Assign Password for Privileged EXEC Mode

```
SW1>
SW1> enable
SW1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config) # line vty 0 15
SW1(config-line) # password cisco
SW1(config-line) # login
SW1(config-line)# end
SW1#
%SYS-5-CONFIG I: Configured from console by console
SW1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config) # enable secret cisco
SW1(config) # exit
SW1#
%SYS-5-CONFIG I: Configured from console by console
```

# Create VLAN-4 (Wireless VLAN) and assign FastEthernet0/6-7 to VLAN-4

```
Switch>
Switch> enable
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config) # vlan 4
SW1(config-vlan) # name VLAN-4
SW1(config-vlan) # exit
SW1(config) # interface range FastEthernet0/6-7
SW1(config-if-range) # switchport mode access
SW1(config-if-range) # switchport access vlan 4
SW1(config-if-range) # end
SW1#
%SYS-5-CONFIG I: Configured from console by console
SW1# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW1# exit
```

# Similar Process Repeated for Switch 2

- Switch Name Change
- Create VLAN-2 and VLAN-3
- Ports Assigned to VLANs

# Create Trunk Link Between Switches

```
SW1>
SW1> enable
Password:
SW1# configure terminal
Enter configuration commands, one per line. End with {\tt CNTL/Z}.
SW1(config)# interface GigabitEthernet0/1
SW1(config-if) # switchport mode trunk
SW1(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/1, changed
state to down
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/1, changed
state to up
SW1(config-if) # switchport trunk allowed vlan 1-99
SW1(config-if)# end
SW1#
%SYS-5-CONFIG I: Configured from console by console
```

#### Same Process Repeated for Switch 2

```
SW1>
SW1> enable
Password:
SW1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config) # vlan 90
SW1(config-vlan) # name VLAN-Native
SW1(config-vlan)#exit
SW1(config)#^Z
SW1#
%SYS-5-CONFIG I: Configured from console by console
SW1# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW1# exit
```

#### Same Process Repeated for Switch 2

```
SW1>
SW1> enable
Password:
SW1# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW1(config)# interface GigabitEthernet0/1
SW1(config-if) # switchport trunk native vlan 90
SW1(config-if)# ^Z
SW1#
%SYS-5-CONFIG I: Configured from console by console
SW1#
%CDP-4-NATIVE VLAN MISMATCH: Native VLAN mismatch discovered on
GigabitEthernet0/1 (90), with SW2 GigabitEthernet0/1 (1).
SW1# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW1# exit
```

#### Same Process Repeated for Switch 2

```
%SPANTREE-2-UNBLOCK_CONSIST_PORT: Unblocking GigabitEthernet0/1 on VLAN0090. Port consistency restored.

%SPANTREE-2-UNBLOCK_CONSIST_PORT: Unblocking GigabitEthernet0/1 on VLAN0001. Port consistency restored.
```

# VOIP Building with Switch 2 (Voice VLAN)

```
SW2>
SW2>enable
Password:
SW2# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW2(config) # vlan 5
SW2(config-vlan) # name VLAN-5-Voice
SW2 (config-vlan) #^Z
%SYS-5-CONFIG I: Configured from console by console
SW2# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW2(config) # int FastEthernet0/5
SW2(config-if) # switchport mode access
SW2(config-if) # switchport access vlan 5
SW2(config-if)#^Z
SW2#
%SYS-5-CONFIG I: Configured from console by console
SW2# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW2# exit
```

#### Trunk Link Building between Switch 2 and Router

```
SW2>
SW2> enable
Password:
SW2# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW2(config)# interface GigabitEthernet0/2
SW2(config-if) # switchport mode trunk
SW2(config-if) # switchport trunk allowed vlan 1-99
SW2(config-if) # switchport trunk native vlan 90
SW2(config-if)#exit
SW2 (config) #exit
SW2#
SYS-5-CONFIG\ I: Configured from console by console
SW2# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW2# exit
```

# **Router Configuration**

```
Router>
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) # interface FastEthernet0/0.1
Router(config-subif) # encapsulation dot1Q 1
Router(config-subif) # ip address 192.168.1.1 255.255.255.0
Router(config-subif) # interface FastEthernet0/0.2
Router(config-subif) # encapsulation dot10 2
Router(config-subif) # ip address 192.168.2.1 255.255.255.0
Router(config-subif) # interface FastEthernet0/0.3
Router(config-subif)# encapsulation dot1Q 3
Router(config-subif) # ip address 192.168.3.1 255.255.255.0
Router(config-subif) # interface FastEthernet0/0.4
Router(config-subif)# encapsulation dot1Q 4
Router(config-subif) # ip address 192.168.4.1 255.255.255.0
Router(config-subif)# interface FastEthernet0/0.5
Router(config-subif)# encapsulation dot1Q 5
Router(config-subif) # ip address 192.168.5.1 255.255.255.0
Router(config-subif)# interface FastEthernet0/0.90
Router(config-subif) # encapsulation dot1Q 90
Router(config-subif) # ip address 192.168.90.1 255.255.255.0
Router(config-subif) # interface FastEthernet0/0.99
Router(config-subif) # encapsulation dot1Q 99
Router(config-subif) # ip address 192.168.99.1 255.255.255.0
Router(config-subif) # end
Router#
%SYS-5-CONFIG I: Configured from console by console
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) # interface FastEthernet0/0
Router(config-if) # no shutdown
%SYS-5-CONFIG I: Configured from console by console
Router#
Router# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
```

#### Create VOIP Pool in Router

```
Router>
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) # ip dhcp pool VOIP
Router(dhcp-config) # network 192.168.5.0 255.255.255.0
Router(dhcp-config) # default-router 192.168.5.1
Router (dhcp-config) # option 150 ip 192.168.5.1
Router(dhcp-config)#^Z
Router#
%SYS-5-CONFIG I: Configured from console by console
Router(config) #ip dhcp excluded-address 192.168.5.1
Router(config)#^Z
Router#
%SYS-5-CONFIG I: Configured from console by console
Router# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
Router#
```

# Configure Telephony Service in Router

```
Router>
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) #telephony-service
Router(config-telephony) #max-dn 10
Router(config-telephony) #max-ephones 10
Router(config-telephony) #ip source-address 192.168.5.1 port 2000
Router(config-telephony) #auto assign 1 to 9
Router(config-telephony) #^Z
Router#
%SYS-5-CONFIG I: Configured from console by console
Router# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
Router#
```

# Configure VOIP Ports in Switch 2

```
SW2>
SW2> enable
Password:
SW2# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW2(config) # interface FastEthernet0/5
SW2(config-if) # switchport mode access
SW2(config-if) # no switchport access vlan 5
SW2(config-if) # switchport voice vlan 5
SW2(config-if) # interface FastEthernet0/6
SW2(config-if) # switchport mode access
SW2(config-if) # switchport voice vlan 5
SW2(config-if)#^Z
SW2#
%SYS-5-CONFIG I: Configured from console by console
SW2# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
SW2#
```

# Assing IP Address and Phone Number to VOIP Phones

```
Router>
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) #ephone-dn 1
Router(config-ephone-dn) #%LINK-3-UPDOWN: Interface ephone dsp DN 1.1,
changed state to up
Router(config-ephone-dn) #number 35001
Router(config-ephone-dn)#
%IPPHONE-6-REGISTER: ephone-1 IP:192.168.5.2 Socket:2 DeviceType:Phone has
registered.
Router(config-ephone-dn) #ephone-dn 2
Router(config-ephone-dn) #%LINK-3-UPDOWN: Interface ephone dsp DN 2.1,
changed state to up
Router(config-ephone-dn) #number 35002
Router(config-ephone-dn)#
%IPPHONE-6-REGISTER: ephone-2 IP:192.168.5.3 Socket:2 DeviceType:Phone has
registered.
Router(config-ephone-dn) #^Z
Router#
%SYS-5-CONFIG I: Configured from console by console
Router# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
Router#
```

# Adding New PC's on VOIP Phones Ports

```
SW2>
SW2> enable
Password:
SW2# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SW2(config) # vlan 6
SW2(config-vlan) # name VLAN-6
SW2(config-vlan)# exit
SW2(config) # interface range FastEthernet0/5-6
SW2(config-if-range) # switchport mode access
SW2(config-if-range) # switchport access vlan 6
SW2(config-if-range)#^Z
SW2#
%SYS-5-CONFIG I: Configured from console by console
SW2#copy run start
Destination filename [startup-config]?
Building configuration...
[OK]
SW2#
```

```
Router>
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.

Router(config)# interface FastEthernet0/0.6
Router(config-subif)#
%LINK-5-CHANGED: Interface FastEthernet0/0.6, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0.6, changed state to up

Router(config-subif)# encapsulation dot1Q 6
Router(config-subif)# ip address 192.168.6.1 255.255.255.0
Router(config-subif)# end
Router#
%SYS-5-CONFIG_I: Configured from console by console
```

```
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface FastEthernet0/0
Router(config-if)# no shutdown
Router(config-if)#^Z
Router#
%SYS-5-CONFIG_I: Configured from console by console

Router#copy run start
Destination filename [startup-config]?
Building configuration...
[OK]
Router#
```