

Unit 205: Cold water systems

Outcome 1 Requirements for water distribution to domestic dwellings



- The Water Regulations (1999)
- The Water Regulation Guide (WRAS)
- WRAS Water Regulation Advisory Scheme
- BS6700 Design, installation, testing and
- Maintenance
- Manufacturers' instructions









Directory of fittings (WRAS approved)

WRAS approved fittings comply with the Water Regulations are a legal requirement in the UK.

They are also quality products, corrosion resistant within their environment, and are made of materials that do not cause contamination.










The Water Regulations replaced the individual Byelaws to give a national law for England and Wales:

- Waste
- Undue consumption
- Misuse
- Contamination
- Erroneous measurement of water



Rainwater cycle






Rainwater cycle in simple terms.


Evaporation: water molecules move apart.

Precipitation: water molecules condense and fall as rain.






Plumbers have a responsibility to design, install, test and maintain cold water systems correctly. We also need to advise customers on good usage.



1. Surface water

Lakes



_ .



Reservoirs



Streams





Lakes and reservoirs

After a report in 1963 on the expanding population of North East Essex, Ardleigh Reservoir was developed.

Raw water is taken in from the River Colne, via a pumping station. Most of the pumping takes place in winter and constant monitoring ensures that levels do not harm the river environment.



At full rate, the intake can transfer 36 million litres of water per day. The normal rate is around 18 million litres.

At the intake station, the water is screened to prevent fish and other unwanted matter getting into the system. It is then pumped 5km to the reservoir.

Prior to entering the reservoir, ferric sulphate is added to reduce the phosphate levels (high phosphate levels encourage the growth of algae).



The reservoir itself covers some 57 hectares and, when full, contains 2,200 million litres.

A draw-off tower is sited at the deepest point and draws water from three different levels to ensure the most suitable water is selected.

Within the reservoir there are air pumps which turn the water over. This stops layers of different quality and temperature forming.



The reservoir itself is the initial treatment of raw water, allowing larger particles to settle. The draw off point is a 1,100mm steel main, in a reinforced concrete tunnel.

Once in the treatment plant, the sludge is drawn off and the **clarified** water is **disinfected** with **ozone** gas before filtration.

The filtration stage consists of granular activated carbon and sand filters. These filters trap any fine suspended matter and organic matter, including pesticides.



Every so often these filters need cleaning, which is carried out by an air and water flush, with the debris taken to a sludge lagoon.

The water then travels to a stage where the final pH adjustment takes place and chlorine is added. The water is then stored for long enough for the chlorine to kill off any remaining bacteria (sometimes UV treated).



Sulphur dioxide is added to reduce the chlorine levels so the water can then be distributed to the customer.

A 9 million litre tank stores the water, which has two variable speed pumps discharging through 600mm diameter mains.

Ardleigh Reservoir services about 150,000 homes. Samples are taken regularly throughout the day and have to comply with 50 standards.




The 600mm main is then divided into smaller pipes until eventually into a 100, 63, 50, 32 or 25mm pipe serving a particular area.

The pipes used to be made of cast iron but have recently been replaced with MDPE pipe (medium density polyethylene).





A typical mains distribution system



This now means a road could be served by a 25mm pipe with an individual 20mm MDPE pipe serving each house. MDPE pipe is generally fusion welded with some compression fittings.

With cast iron and MDPE pipes, a screw-down ferrule connector or service union is installed, allowing the valve to be opened or closed with a ferrule key.


















Supply pipework to domestic buildings

Communication pipe: owned and maintained by water undertaker.

Service pipe: owned and maintained by homeowner.



2. Underground sources

Wells, boreholes and springs







2. Underground sources

These are quite often **private supplies** and not provided by a water undertaker, and are not covered by the Water Regulations.

Wells: deep, shallow and Artesian wells.







2. Underground sources

Boreholes:

These are modern equivalents to wells, but are smaller, less intrusive and easier to maintain. A small, drilled hole is made in the ground and water is pumped to the surface.

Springs:

Naturally occurring sources of water that force water to the surface and sometimes cause the start of a stream.

Types of water

The type of ground that water falls onto and filters through, effects the type of water that is available to consumers. The two main types of water are **hard** and **soft**.


• 70% of the earth's surface is water

- 97% of that is salt water
- 2% is ice
- 1% is fresh


Green = soft water

Yellow = semi hard water

Red = hard water







The ability of water to absorb minerals is called **plumbosolvency**.



Permanent hard water

This contains calcium sulphates (or limestone). The hardness of this water cannot be removed by boiling. Rain has fallen to the ground and filtered through limestone and dissolved the sulphates of calcium.

This type of hardness does not cause much scaling in boilers and kettles.

Temporary hard water

This contains calcium carbonates. The hardness is removed when heated to 65° C. When heated, CO_2 is removed, as the calcium carbonate from **scale** (blockages and efficiency).



Soft water

This is water that is free from calcium carbonates and sulphates. It is easy to get a lather with soap. It is either naturally soft, having fallen on peaty ground (being mildly acidic), or can be produced by a water softener.

The acidic nature of this water also causes problems to plumbing systems through electrolytic corrosion.




Normally accepted classifications for water are as follows:

	Degrees Clark	PPMCaCO ₃
Soft Moderately soft Slightly hard Moderately hard Hard Very hard	0-3.5 3.5-7.0 7.0-10.5 10.5-14.0 14.0-21.0 over-21.0	0 - 50 50 -100 100 - 150 150 -200 200- 300 over 300
J	5 · 5 · 1 · · ·	

It is generally accepted that any water with more than 200ppm needs some treatment.

Use a test kit to gauge the water hardness in your area.





The pH scale indicates whether the water is acidic or alkaline (potential of hydrogen).

If the pH value is below 7, the water will be acidic and aggressive towards pipework.

In the worst cases, people drawing directly from a well could be changing their DHW cylinder every eight months unless the pH can be corrected.



Plumbers must be aware of the type and quality of water supplied to any property, as this could have an affect on the appliances within the property.

Under the Water Regulations, plumbers also have a responsibility to maintain the quality of water supplied by the water undertaker avoiding contamination.