

IMPORTANT – The acrylic base of the robot you are building today is different than the one shown in the instructions given. DO NOT SCREW THE 20MM SCREWS UPWARDS THROUGH THE BOTTOM OF THE BASE (SHOWN BELOW).



THIS COULD SHATTER THE ACRYLIC PLATE AND CUT OPEN YOUR HANDS. Even if it does not break the plate, the robot will not stay attached to the plate and will fall off.

Instead, screw the base to the acrylic plate like shown. NOTE – This means that you must install the base servo before attaching the base to the plate.

For the servos: red is voltage (5V), brown/black is ground, and yellow is data (the wire you connect directly to the pins on the board)



Some fitments might be tight due to printer errors like elephants' foot or warping. You can use the pliers to scrape the part to make it fit better. If the part still refuses to fit, ask either your professor or the Part Cart to supply you with a replacement.

Links to the instructions:

actually need the part.

https://www.instructables.com/Pocket-Sized-Robot-Arm-meArm-V04/

Link to a GitHub Repository with sample code in case the professor did not provide it:

https://github.com/CarsonHam1/Hackathon-Robot-Arm/tree/main

If you don't know how to use GitHub, open the sample code folder, and then download the Sample_Code_V2 file.