

Error messages for tape backup and restore of FlexVol volumes

ONTAP 9

NetApp February 26, 2022

This PDF was generated from https://docs.netapp.com/us-en/ontap/tape-backup/resource-limitation-no-available-thread-reference.html on February 26, 2022. Always check docs.netapp.com for the latest.

Table of Contents

Error messages for tape backup and restore of FlexVol v	olumes
Backup and restore error messages	
NDMP error messages	
Dump error messages	
SMTape error messages	

Error messages for tape backup and restore of FlexVol volumes

Backup and restore error messages

Resource limitation: no available thread

Message

Resource limitation: no available thread

Cause

The maximum number of active local tape I/O threads is currently in use. You can have a maximum of 16 active local tape drives.

· Corrective action

Wait for some tape jobs to finish before starting a new backup or restore job.

Tape reservation preempted

Message

Tape reservation preempted

Cause

The tape drive is in use by another operation or the tape has been closed prematurely.

Corrective action

Ensure that the tape drive is not in use by another operation and that the DMA application has not aborted the job and then retry.

Could not initialize media

Message

Could not initialize media

Cause

You might get this error for one of the following reasons:

- The tape drive used for the backup is corrupt or damaged.
- The tape does not contain the complete backup or is corrupt.
- The maximum number of active local tape I/O threads is currently in use.

You can have a maximum of 16 active local tape drives.

Corrective action

- If the tape drive is corrupt or damaged, retry the operation with a valid tape drive.
- If the tape does not contain the complete backup or is corrupt, you cannot perform the restore operation.
- If tape resources are not available, wait for some of the backup or restore jobs to finish and then retry the operation.

Maximum number of allowed dumps or restores (maximum session limit) in progress

Message

Maximum number of allowed dumps or restores (maximum session limit) in progress

Cause

The maximum number of backup or restore jobs is already running.

Corrective action

Retry the operation after some of the currently running jobs have finished.

Media error on tape write

Message

Media error on tape write

Cause

The tape used for the backup is corrupted.

Corrective action

Replace the tape and retry the backup job.

Tape write failed

Message

Tape write failed

Cause

The tape used for the backup is corrupted.

Corrective action

Replace the tape and retry the backup job.

Tape write failed - new tape encountered media error

Message

Tape write failed - new tape encountered media error

Cause

The tape used for the backup is corrupted.

Corrective action

Replace the tape and retry the backup.

Tape write failed - new tape is broken or write protected

Message

Tape write failed - new tape is broken or write protected

Cause

The tape used for the backup is corrupted or write-protected.

Corrective action

Replace the tape and retry the backup.

Tape write failed - new tape is already at the end of media

Message

Tape write failed - new tape is already at the end of media

Cause

There is not enough space on the tape to complete the backup.

Corrective action

Replace the tape and retry the backup.

Tape write error

Message

Tape write error - The previous tape had less than the required minimum capacity, size MB, for this tape operation, The operation should be restarted from the beginning

Cause

The tape capacity is insufficient to contain the backup data.

Corrective action

Use tapes with larger capacity and retry the backup job.

Media error on tape read

Message

Media error on tape read

Cause

The tape from which data is being restored is corrupted and might not contain the complete backup data.

Corrective action

If you are sure that the tape has the complete backup, retry the restore operation. If the tape does not contain the complete backup, you cannot perform the restore operation.

Tape read error

Message

Tape read error

Cause

The tape drive is damaged or the tape does not contain the complete backup.

· Corrective action

If the tape drive is damaged, use another tape drive. If the tape does not contain the complete backup, you cannot restore the data.

Already at the end of tape

Message

Already at the end of tape

Cause

The tape does not contain any data or must be rewound.

Corrective action

If the tape does not contain data, use the tape that contains the backup and retry the restore job. Otherwise, rewind the tape and retry the restore job.

Tape record size is too small. Try a larger size.

Message

Tape record size is too small. Try a larger size.

Cause

The blocking factor specified for the restore operation is smaller than the blocking factor that was used during the backup.

Corrective action

Use the same blocking factor that was specified during the backup.

Tape record size should be block_size1 and not block_size2

Message

Tape record size should be block size1 and not block size2

Cause

The blocking factor specified for the local restore is incorrect.

· Corrective action

Retry the restore job with block size1 as the blocking factor.

Tape record size must be in the range between 4KB and 256KB

Message

Tape record size must be in the range between 4KB and 256KB

Cause

The blocking factor specified for the backup or restore operation is not within the permitted range.

Corrective action

Specify a blocking factor in the range of 4 KB to 256 KB.

NDMP error messages

Network communication error

Message

Network communication error

Cause

Communication to a remote tape in an NDMP three-way connection has failed.

· Corrective action

Check the network connection to the remote mover.

Message from Read Socket: error_string

Message

Message from Read Socket: error string

Cause

Restore communication from the remote tape in NDMP 3-way connection has errors.

Corrective action

Check the network connection to the remote mover.

Message from Write Dirnet: error_string

Message

```
Message from Write Dirnet: error string
```

Cause

Backup communication to a remote tape in an NDMP three-way connection has an error.

Corrective action

Check the network connection to the remote mover.

Read Socket received EOF

Message

Read Socket received EOF

Cause

Attempt to communicate with a remote tape in an NDMP three-way connection has reached the End Of File mark. You might be attempting a three-way restore from a backup image with a larger block size.

Corrective action

Specify the correct block size and retry the restore operation.

ndmpd invalid version number: version_number ``

Message

```
ndmpd invalid version number: version number
```

Cause

The NDMP version specified is not supported by the storage system.

Corrective action

Specify NDMP version 4.

ndmpd session session ID not active

Message

ndmpd session session ID not active

Cause

The NDMP session might not exist.

Corrective action

Use the ndmpd status command to view the active NDMP sessions.

Could not obtain vol ref for Volume volume_name

Message

Could not obtain vol ref for Volume vol name

Cause

The volume reference could not be obtained because the volume might be in use by other operations.

Corrective action

Retry the operation later.

Data connection type ["NDMP4_ADDR_TCP"|"NDMP4_ADDR_TCP_IPv6"] not supported for ["IPv6"|"IPv4"] control connections

Message

Data connection type ["NDMP4_ADDR_TCP"|"NDMP4_ADDR_TCP_IPv6"] not supported for ["IPv6"|"IPv4"] control connections

Cause

In node-scoped NDMP mode, the NDMP data connection established must be of the same network address type (IPv4 or IPv6) as the NDMP control connection.

· Corrective action

Contact your backup application vendor.

DATA LISTEN: CAB data connection prepare precondition error

Message

DATA LISTEN: CAB data connection prepare precondition error

Cause

NDMP data listen fails when the backup application has negotiated the CAB extension with the NDMP server and there is a mismatch in the specified NDMP data connection address type between the NDMP_CAB_DATA_CONN_PREPARE and the NDMP_DATA_LISTEN messages.

· Corrective action

Contact your backup application vendor.

DATA CONNECT: CAB data connection prepare precondition error

Message

DATA CONNECT: CAB data connection prepare precondition error

Cause

NDMP data connect fails when the backup application has negotiated the CAB extension with the NDMP server and there is a mismatch in the specified NDMP data connection address type between the NDMP CAB DATA CONN PREPARE and the NDMP DATA CONNECT messages.

Corrective action

Contact your backup application vendor.

Error:show failed: Cannot get password for user '<username>'

Message

Error: show failed: Cannot get password for user '<username>'

Cause

Incomplete user account configuration for NDMP

· Corrective action

Ensure that the user account is associated with the SSH access method and the authentication method is user password.

Dump error messages

Destination volume is read-only

Message

Destination volume is read-only

Cause

The path to which the restore operation is attempted to is read-only.

Corrective action

Try restoring the data to a different location.

Destination qtree is read-only

Message

Destination qtree is read-only

Cause

The qtree to which the restore is attempted to is read-only.

Corrective action

Try restoring the data to a different location.

Dumps temporarily disabled on volume, try again

Message

Dumps temporarily disabled on volume, try again

Cause

NDMP dump backup is attempted on a SnapMirror destination volume that is part of either a snapmirror break or a snapmirror resync operation.

Corrective action

Wait for the snapmirror break or snapmirror resync operation to finish and then perform the dump operation.



Whenever the state of a SnapMirror destination volume changes from read/write to read-only or from read-only to read/write, you must perform a baseline backup.

NFS labels not recognized

Message

Error: Aborting: dump encountered NFS security labels in the file system

Cause

NFS security labels are supported Beginning with ONTAP 9.9.1 when NFSv4.2 is enabled. However, NFS

security labels are not currently recognized by the dump engine. If it encounters any NFS security labels on the files, directories, or any special files in any format of dump, the dump fails.

Corrective action

Verify that no files or directories have NFS security labels.

No files were created

Message

No files were created

Cause

A directory DAR was attempted without enabling the enhanced DAR functionality.

Corrective action

Enable the enhanced DAR functionality and retry the DAR.

Restore of the file <file name> failed

Message

Restore of the file file name failed

Cause

When a DAR (Direct Access Recovery) of a file whose file name is the same as that of a LUN on the destination volume is performed, then the DAR fails.

Corrective action

Retry DAR of the file.

Truncation failed for src inode <inode number>...

Message

Truncation failed for src inode <inode number>. Error <error number>. Skipping inode.

Cause

Inode of a file is deleted when the file is being restored.

· Corrective action

Wait for the restore operation on a volume to complete before using that volume.

Unable to lock a snapshot needed by dump

Message

Unable to lock a snapshot needed by dump

Cause

The Snapshot copy specified for the backup is not available.

Corrective action

Retry the backup with a different Snapshot copy.

Use the snap list command to see the list of available Snapshot copies.

Unable to locate bitmap files

Message

Unable to locate bitmap files

Cause

The bitmap files required for the backup operation might have been deleted. In this case, the backup cannot be restarted.

Corrective action

Perform the backup again.

Volume is temporarily in a transitional state

Message

Volume is temporarily in a transitional state

Cause

The volume being backed up is temporarily in an unmounted state.

Corrective action

Wait for some time and perform the backup again.

SMTape error messages

Chunks out of order

Message

Chunks out of order

Cause

The backup tapes are not being restored in the correct sequence.

Corrective action

Retry the restore operation and load the tapes in the correct sequence.

Chunk format not supported

Message

Chunk format not supported

Cause

The backup image is not of SMTape.

Corrective action

If the backup image is not of SMTape, retry the operation with a tape that has the SMTape backup.

Failed to allocate memory

Message

Failed to allocate memory

Cause

The system has run out of memory.

Corrective action

Retry the job later when the system is not too busy.

Failed to get data buffer

Message

Failed to get data buffer

Cause

The storage system ran out of buffers.

Corrective action

Wait for some storage system operations to finish and then retry the job.

Failed to find snapshot

Message

Failed to find snapshot

Cause

The Snapshot copy specified for the backup is unavailable.

Corrective action

Check if the specified Snapshot copy is available. If not, retry with the correct Snapshot copy.

Failed to create snapshot

Message

Failed to create snapshot

Cause

The volume already contains the maximum number of Snapshot copies.

Corrective action

Delete some Snapshot copies and then retry the backup operation.

Failed to lock snapshot

Message

Failed to lock snapshot

Cause

The Snapshot copy is either in use or has been deleted.

Corrective action

If the Snapshot copy is in use by another operation, wait for that operation to finish and then retry the backup. If the Snapshot copy has been deleted, you cannot perform the backup.

Failed to delete snapshot

Message

Failed to delete snapshot

Cause

The auto Snapshot copy could not be deleted because it is in use by other operations.

Corrective action

Use the snap command to determine the status of the Snapshot copy. If the Snapshot copy is not required, delete it manually.

Failed to get latest snapshot

Message

Failed to get latest snapshot

Cause

The latest Snapshot copy might not exist because the volume is being initialized by SnapMirror.

· Corrective action

Retry after initialization is complete.

Failed to load new tape

Message

Failed to load new tape

Cause

Error in tape drive or media.

Corrective action

Replace the tape and retry the operation.

Failed to initialize tape

Message

Failed to initialize tape

Cause

You might get this error message for one of the following reasons:

- The backup image is not of SMTape.
- The tape blocking factor specified is incorrect.
- The tape is corrupt or damaged.
- The wrong tape is loaded for restore.

Corrective action

- If the backup image is not of SMTape, retry the operation with a tape that has SMTape backup.
- If the blocking factor is incorrect, specify the correct blocking factor and retry the operation.

- If the tape is corrupt, you cannot perform the restore operation.
- If the wrong tape is loaded, retry the operation with the correct tape.

Failed to initialize restore stream

Message

Failed to initialize restore stream

Cause

You might get this error message for one of the following reasons:

- The backup image is not of SMTape.
- The tape blocking factor specified is incorrect.
- The tape is corrupt or damaged.
- The wrong tape is loaded for restore.

Corrective action

- If the backup image is not of SMTape, retry the operation with a tape that has the SMTape backup.
- If the blocking factor is incorrect, specify the correct blocking factor and retry the operation.
- If the tape is corrupt, you cannot perform the restore operation.
- If the wrong tape is loaded, retry the operation with the correct tape.

Failed to read backup image

Message

Failed to read backup image

Cause

The tape is corrupt.

Corrective action

If the tape is corrupt, you cannot perform the restore operation.

Image header missing or corrupted

Message

Image header missing or corrupted

Cause

The tape does not contain a valid SMTape backup.

Corrective action

Retry with a tape containing a valid backup.

Internal assertion

Message

Internal assertion

Cause

There is an internal SMTape error.

Corrective action

Report the error and send the etc/log/backup file to technical support.

Invalid backup image magic number

Message

Invalid backup image magic number

Cause

The backup image is not of SMTape.

Corrective action

If the backup image is not of SMTape, retry the operation with a tape that has the SMTape backup.

Invalid backup image checksum

Message

Invalid backup image checksum

Cause

The tape is corrupt.

Corrective action

If the tape is corrupt, you cannot perform the restore operation.

Invalid input tape

Message

Invalid input tape

Cause

The signature of the backup image is not valid in the tape header. The tape has corrupted data or does not contain a valid backup image.

Corrective action

Retry the restore job with a valid backup image.

Invalid volume path

Message

Invalid volume path

Cause

The specified volume for the backup or restore operation is not found.

Corrective action

Retry the job with a valid volume path and volume name.

Mismatch in backup set ID

Message

Mismatch in backup set ID

Cause

The tape loaded during a tape change is not a part of the backup set.

Corrective action

Load the correct tape and retry the job.

Mismatch in backup time stamp

Message

Mismatch in backup time stamp

Cause

The tape loaded during a tape change is not a part of the backup set.

Corrective action

Use the smtape restore -h command to verify the header information of a tape.

Job aborted due to shutdown

Message

Job aborted due to shutdown

Cause

The storage system is being rebooted.

Corrective action

Retry the job after the storage system reboots.

Job aborted due to Snapshot autodelete

Message

Job aborted due to Snapshot autodelete

Cause

The volume does not have enough space and has triggered the automatic deletion of Snapshot copies.

Corrective action

Free up space in the volume and retry the job.

Tape is currently in use by other operations

Message

Tape is currently in use by other operations

Cause

The tape drive is in use by another job.

Corrective action

Retry the backup after the currently active job is finished.

Tapes out of order

Message

Tapes out of order

Cause

The first tape of the tape sequence for the restore operation does not have the image header.

Corrective action

Load the tape with the image header and retry the job.

Transfer failed (Aborted due to MetroCluster operation)

Message

Transfer failed (Aborted due to MetroCluster operation)

Cause

The SMTape operation is aborted because of a switchover or switchback operation.

Corrective action

Perform the SMTape operation after the switchover or switchback operation finishes.

Transfer failed (ARL initiated abort)

Message

```
Transfer failed (ARL initiated abort)
```

Cause

While an SMTape operation is in progress if an aggregate relocation is initiated, then the SMTape operation is aborted.

· Corrective action

Perform the SMTape operation after the aggregate relocation operation finishes.

Transfer failed (CFO initiated abort)

Message

```
Transfer failed (CFO initiated abort)
```

Cause

The SMTape operation is aborted because of a storage failover (takeover and giveback) operation of a CFO aggregate.

· Corrective action

Perform the SMTape operation after the storage failover of the CFO aggregate finishes.

Transfer failed (SFO initiated abort)

Message

```
Transfer failed (SFO initiated abort)
```

Cause

The SMTape operation is aborted because of a storage failover (takeover and giveback) operation.

· Corrective action

Perform the SMTape operation after the storage failover (takeover and giveback) operation finishes.

Underlying aggregate under migration

Message

Underlying aggregate under migration

Cause

If an SMTape operation is initiated on an aggregate that is under migration (storage failover or aggregate relocation), then the SMTape operation fails.

· Corrective action

Perform the SMTape operation after the aggregate migration finishes.

Volume is currently under migration

Message

Volume is currently under migration

Cause

Volume migration and SMTape backup cannot run simultaneously.

· Corrective action

Retry the backup job after the volume migration is complete.

Volume offline

Message

Volume offline

Cause

The volume being backed up is offline.

Corrective action

Bring the volume online and retry the backup.

Volume not restricted

Message

Volume not restricted

Cause

The destination volume to which data is being restored is not restricted.

Corrective action

Restrict the volume and retry the restore operation.

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.