

## Manage and monitor the BranchCache configuration

ONTAP 9

NetApp March 26, 2022

This PDF was generated from https://docs.netapp.com/us-en/ontap/smb-admin/modify-branchcache-config-task.html on March 26, 2022. Always check docs.netapp.com for the latest.

## **Table of Contents**

M	anage and monitor the BranchCache configuration	. 1
	Modify BranchCache configurations	. 1
	Display information about BranchCache configurations	. 3
	Change the BranchCache server key	. 3
	Pre-compute BranchCache hashes on specified paths	. 4
	Flush hashes from the SVM BranchCache hash store	. 7
	Display BranchCache statistics	. 7
	Support for BranchCache Group Policy Objects	10
	Display information about BranchCache Group Policy Objects	11

# Manage and monitor the BranchCache configuration

## **Modify BranchCache configurations**

You can modify the configuration of the BranchCache service on SVMs, including changing the hash store directory path, the hash store maximum directory size, the operating mode, and which BranchCache versions are supported. You can also increase the size of the volume that contains the hash store.

#### **Steps**

1. Perform the appropriate action:

If you want to	Enter the following
Modify the hash store directory size	<pre>vserver cifs branchcache modify -vserver vserver_name -hash-store-max -size {integer[KB MB GB TB PB]}</pre>
Increase the size of the volume that contains the hash store	volume size -vserver vserver_name -volume volume_name -new-size new_size[k m g t] If the volume containing the hash store fills up, you might be able to increase the size of the volume. You can specify the new volume size as a number followed by a unit designation.  See Logical storage management for more information about increasing volume size.

If you want to	Enter the following	
Modify the hash store directory path	vserver cifs branchcache modify -vserver vserver_name -hash-store-path path -flush-hashes {true false} If the SVM is an SVM disaster recovery source, the hash path cannot be on the root volume. This is because the root volume is not replicated to the disaster recovery destination.	
	The BranchCache hash path can contain blanks and any valid file name characters.	
	If you modify the hash path, -flush-hashes is a required parameter that specifies whether you want ONTAP to flush the hashes from the original hash store location. You can set the following values for the -flush-hashes parameter:	
	<ul> <li>If you specify true, ONTAP deletes the hashes in the original location and creates new hashes in the new location as new requests are made by BranchCache-enabled clients.</li> </ul>	
	<ul> <li>If you specify false, the hashes are not flushed.</li> </ul>	
	In this case, you can choose to reuse the existing hashes later by changing the hash store path back to the original location.	
Change the operating mode	<pre>vserver cifs branchcache modify -vserver vserver_name -operating-mode {per-share all-shares disable}</pre>	
	You should be aware of the following when modifying the operating mode: - ONTAP advertises BranchCache support for a share when the SMB session is set up Clients that already have established sessions when BranchCache is enabled need to disconnect and reconnect to use cached content for this share.	
Change the BranchCache version support	<pre>vserver cifs branchcache modify -vserver vserver_name -versions {v1- enable v2-enable enable-all}</pre>	

2. Verify the configuration changes by using the <code>vserver cifs branchcache show command</code>.

## Display information about BranchCache configurations

You can display information about BranchCache configurations on storage virtual machines (SVMs), which can be used when verifying a configuration or when determining current settings before modifying a configuration.

#### Step

1. Perform one of the following actions:

If you want to display	Enter this command
Summary information about BranchCache configurations on all SVMs	vserver cifs branchcache show
Detailed information about the configuration on a specific SVM	<pre>vserver cifs branchcache show -vserver vserver_name</pre>

#### **Example**

The following example displays information about the BranchCache configuration on SVM vs1:

```
Cluster1::> vserver cifs branchcache show -vserver vs1

Vserver: vs1

Supported BranchCache Versions: enable_all

Path to Hash Store: /hash_data

Maximum Size of the Hash Store: 20GB

Encryption Key Used to Secure the Hashes: -

CIFS BranchCache Operating Modes: per_share
```

### Change the BranchCache server key

You can change the BranchCache server key by modifying the BranchCache configuration on the storage virtual machine (SVM) and specifying a different server key.

#### About this task

You can set the server key to a specific value so that if multiple servers are providing BranchCache data for the same files, clients can use hashes from any server using that same server key.

When you change the server key, you must also flush the hash cache. After flushing the hashes, ONTAP creates new hashes as new requests are made by BranchCache-enabled clients.

#### **Steps**

1. Change the server key by using the following command: vserver cifs branchcache modify

```
-vserver vserver name -server-key text -flush-hashes true
```

When configuring a new server key, you must also specify -flush-hashes and set the value to true.

2. Verify that the BranchCache configuration is correct by using the vserver cifs branchcache show command.

#### **Example**

The following example sets a new server key that contains spaces and flushes the hash cache on SVM vs1:

#### Related information

Reasons ONTAP invalidates BranchCache hashes

## Pre-compute BranchCache hashes on specified paths

You can configure the BranchCache service to pre-compute hashes for a single file, for a directory, or for all files in a directory structure. This can be helpful if you want to compute hashes on data in a BranchCache-enabled share during off, non-peak hours.

#### About this task

If you want to collect a data sample before you display hash statistics, you must use the statistics start and optional statistics stop commands.

- You must specify the storage virtual machine (SVM) and path on which you want to pre-compute hashes.
- · You must also specify whether you want hashes computed recursively.
- If you want hashes computed recursively, the BranchCache service traverses the entire directory tree under the specified path, and computes hashes for each eligible object.

#### **Steps**

1. Pre-compute hashes as desired:

If you want to pre-compute hashes on	Enter the command
A single file or directory	vserver cifs branchcache hash-create -vserver vserver_name -path path -recurse false
Recursively on all files in a directory structure	vserver cifs branchcache hash-create -vserver vserver_name -path absolute_path -recurse true

- 2. Verify that hashes are being computed by using the statistics command:
  - a. Display statistics for the hashd object on the desired SVM instance: statistics show -object hashd -instance vserver\_name
  - b. Verify that the number of hashes created is increasing by repeating the command.

#### **Examples**

The following example creates hashes on the path /data and on all contained files and subdirectories on SVM vs1:

cluster1::> vserver cifs branchcache hash-create -vserver vs1 -path /data -recurse true cluster1::> statistics show -object hashd -instance vs1 Object: hashd Instance: vs1 Start-time: 9/6/2012 19:09:54 End-time: 9/6/2012 19:11:15 Cluster: cluster1 Counter Value \_\_\_\_\_ branchcache hash created 85 branchcache hash files replaced 0 branchcache hash rejected 0 branchcache hash store bytes 0 branchcache hash store size 0 instance name vs1 node name node1 node uuid 11111111-1111-1111-1111-11111111111111 process name cluster1::> statistics show -object hashd -instance vs1 Object: hashd Instance: vs1 Start-time: 9/6/2012 19:09:54 End-time: 9/6/2012 19:11:15 Cluster: cluster1 Counter Value branchcache hash created 92 branchcache hash files replaced 0 branchcache hash rejected 0 branchcache hash store bytes 0 branchcache hash store size instance name vs1 node name node1 node uuid 11111111-1111-1111-1111-11111111111111 process\_name

#### Related information

Performance monitoring setup

### Flush hashes from the SVM BranchCache hash store

You can flush all cached hashes from the BranchCache hash store on the storage virtual machine (SVM). This can be useful if you have changed the branch office BranchCache configuration. For example, if you recently reconfigured the caching mode from distributed caching to hosted caching mode, you would want to flush the hash store.

#### About this task

After flushing the hashes, ONTAP creates new hashes as new requests are made by BranchCache-enabled clients.

#### Step

1. Flush the hashes from the BranchCache hash store: vserver cifs branchcache hash-flush -vserver vserver name

vserver cifs branchcache hash-flush -vserver vs1

## **Display BranchCache statistics**

You can display BranchCache statistics to, among other things, identify how well caching is performing, determine whether your configuration is providing cached content to clients, and determine whether hash files were deleted to make room for more recent hash data.

#### About this task

The hashd statistic object contains counters that provide statistical information about BranchCache hashes. The cifs statistic object contains counters that provide statistical information about BranchCache-related activity. You can collect and display information about these objects at the advanced-privilege level.

#### Steps

1. Set the privilege level to advanced: set -privilege advanced

```
cluster1::> set -privilege advanced  
Warning: These advanced commands are potentially dangerous; use them only when directed to do so by support personnel.  
Do you want to continue? \{y|n\}: y
```

2. Display the BranchCache-related counters by using the statistics catalog counter show command.

For more information about statistics counters, see the man page for this command.

```
cluster1::*> statistics catalog counter show -object hashd
Object: hashd
```

Counter Description BranchCache hash for a file succeeded. branchcache hash files replaced Number of times a BranchCache hash file was deleted to make room for more recent hash data. This happens if the hash store size is exceeded. branchcache hash rejected Number of times a request to generate BranchCache hash data failed. branchcache hash store bytes Total number of bytes used to store hash data. branchcache hash store size Total space used to store BranchCache hash data for the Vserver. instance name Instance Name Instance UUID instance uuid node name System node name node uuid System node id 9 entries were displayed. cluster1::\*> statistics catalog counter show -object cifs Object: cifs Description Counter active searches Number of active searches over SMB and SMB2 auth reject too many Authentication refused after too many requests were made in rapid succession avg directory depth Average number of directories crossed by SMB and SMB2 path-based commands avg junction depth Average number of junctions crossed by SMB and SMB2 path-based commands branchcache hash fetch fail Total number of times a request to fetch hash data failed. These are failures when

```
attempting to read existing hash data.
Ιt
                                does not include attempts to fetch hash
data
                                that has not yet been generated.
    branchcache hash fetch ok Total number of times a request to fetch
hash
                                data succeeded.
    branchcache hash sent bytes Total number of bytes sent to clients
                                requesting hashes.
    branchcache missing hash bytes
                                Total number of bytes of data that had
to be
                                read by the client because the hash for
that
                                content was not available on the server.
  ....Output truncated....
```

3. Collect BranchCache-related statistics by using the statistics start and statistics stop commands.

```
cluster1::*> statistics start -object cifs -vserver vs1 -sample-id 11
Statistics collection is being started for Sample-id: 11
cluster1::*> statistics stop -sample-id 11
Statistics collection is being stopped for Sample-id: 11
```

4. Display the collected BranchCache statistics by using the statistics show command.

cluster1::\*> statistics show -object cifs -counter

branchcache hash sent bytes -sample-id 11

Object: cifs
Instance: vs1

Start-time: 12/26/2012 19:50:24 End-time: 12/26/2012 19:51:01

Cluster: cluster1

Counter	Value
branchcache_hash_sent_bytes	0
branchcache_hash_sent_bytes	0
branchcache_hash_sent_bytes	0
branchcache hash sent bytes	0

cluster1::\*> statistics show -object cifs -counter
branchcache missing hash bytes -sample-id 11

Object: cifs
Instance: vs1

Start-time: 12/26/2012 19:50:24 End-time: 12/26/2012 19:51:01

Cluster: cluster1

Counter	Value
branchcache_missing_hash_bytes	0

5. Return to the admin privilege level: set -privilege admin

```
cluster1::*> set -privilege admin
```

#### **Related information**

Displaying statistics

Performance monitoring setup

## Support for BranchCache Group Policy Objects

ONTAP BranchCache provides support for BranchCache Group Policy Objects (GPOs),

which allow centralized management for certain BranchCache configuration parameters. There are two GPOs used for BranchCache, the Hash Publication for BranchCache GPO and the Hash Version Support for BranchCache GPO.

#### · Hash Publication for BranchCache GPO

The Hash Publication for BranchCache GPO corresponds to the <code>-operating-mode</code> parameter. When GPO updates occur, this value is applied to storage virtual machine (SVM) objects contained within the organizational unit (OU) to which the group policy applies.

#### Hash Version Support for BranchCache GPO

The Hash Version Support for BranchCache GPO corresponds to the -versions parameter. When GPO updates occur, this value is applied to SVM objects contained within the organizational unit to which the group policy applies.

#### Related information

Applying Group Policy Objects to CIFS servers

## Display information about BranchCache Group Policy Objects

You can display information about the CIFS server's Group Policy Object (GPO) configuration to determine whether BranchCache GPOs are defined for the domain to which the CIFS server belongs and, if so, what the allowed settings are. You can also determine whether BranchCache GPO settings are applied to the CIFS server.

#### About this task

Even though a GPO setting is defined within the domain to which the CIFS server belongs, it is not necessarily applied to the organizational unit (OU) containing the CIFS-enabled storage virtual machine (SVM). Applied GPO setting are the subset of all defined GPOs that are applied to the CIFS-enabled SVM. BranchCache settings applied through GPOs override settings applied through the CLI.

#### **Steps**

1. Display the defined BranchCache GPO setting for the Active Directory domain by using the vserver cifs group-policy show-defined command.



This example does not display all of the available output fields for the command. Output is truncated.

```
cluster1::> vserver cifs group-policy show-defined -vserver vs1
Vserver: vs1
_____
      GPO Name: Default Domain Policy
      Level: Domain
      Status: enabled
  Advanced Audit Settings:
     Object Access:
          Central Access Policy Staging: failure
  Registry Settings:
     Refresh Time Interval: 22
     Refresh Random Offset: 8
     Hash Publication Mode for BranchCache: per-share
     Hash Version Support for BranchCache: version1
  [...]
    GPO Name: Resultant Set of Policy
      Status: enabled
  Advanced Audit Settings:
      Object Access:
          Central Access Policy Staging: failure
  Registry Settings:
     Refresh Time Interval: 22
     Refresh Random Offset: 8
     Hash Publication for Mode BranchCache: per-share
     Hash Version Support for BranchCache: version1
  [...]
```

2. Display the BranchCache GPO setting applied to the CIFS server by using the vserver cifs group-policy show-applied command. ``



This example does not display all of the available output fields for the command. Output is truncated.

```
cluster1::> vserver cifs group-policy show-applied -vserver vs1
Vserver: vs1
_____
    GPO Name: Default Domain Policy
      Level: Domain
     Status: enabled
  Advanced Audit Settings:
     Object Access:
         Central Access Policy Staging: failure
  Registry Settings:
     Refresh Time Interval: 22
     Refresh Random Offset: 8
     Hash Publication Mode for BranchCache: per-share
     Hash Version Support for BranchCache: version1
  [...]
    GPO Name: Resultant Set of Policy
      Level: RSOP
  Advanced Audit Settings:
     Object Access:
         Central Access Policy Staging: failure
  Registry Settings:
     Refresh Time Interval: 22
     Refresh Random Offset: 8
     Hash Publication Mode for BranchCache: per-share
     Hash Version Support for BranchCache: version1
 [...]
```

#### **Related information**

Enabling or disabling GPO support on a CIFS server

#### **Copyright Information**

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

#### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.