

# **Protect buckets with S3 SnapMirror**

ONTAP 9

NetApp September 01, 2022

This PDF was generated from https://docs.netapp.com/us-en/ontap/s3-snapmirror/index.html on September 01, 2022. Always check docs.netapp.com for the latest.

# **Table of Contents**

Protect buckets with S3 SnapMirror	 1
S3 SnapMirror overview	 1
Mirror and backup protection on a remote cluster	 3
Mirror and backup protection on the local cluster	 11
Backup protection with cloud targets	 19
Modify a mirror policy	 26

# Protect buckets with S3 SnapMirror

# S3 SnapMirror overview

Beginning with ONTAP 9.10.1, you can protect buckets in ONTAP S3 object stores using familiar SnapMirror mirroring and backup functionality. In addition, unlike standard SnapMirror, S3 SnapMirror can have non-NetApp destinations.

S3 SnapMirror supports active mirrors and backup tiers from ONTAP S3 buckets to the following destinations:

Target	Supports active mirrors and takeover?	Supports backup and restore?
<ul> <li>ONTAP S3</li> <li>buckets in the same SVM</li> <li>buckets in different SVMs on the same cluster</li> <li>buckets in SVMs on different clusters</li> </ul>		
StorageGRID		~
AWS S3		<b>₹</b>
Cloud Volumes ONTAP for Azure		V

You can protect existing buckets on ONTAP S3 servers or you can create new buckets with data protection enabled immediately.

S3 SnapMirror supports fan-out and cascade relationships. For an overview, see Fan-out and cascade data protection deployments.

## S3 SnapMirror requirements

- ONTAP version
   ONTAP 9.10.1 or later must be running source and destination clusters.
- Licensing

The following license bundles are required on ONTAP source and destination systems:

- Core Bundle
   For ONTAP S3 protocol and storage.
- Data Protection Bundle
   For S3 SnapMirror to target other NetApp object store targets (ONTAP S3, StorageGRID, and Cloud Volumes ONTAP).
- Data Protection Bundle and Hybrid Cloud Bundle
   For S3 SnapMirror to target 3rd party object stores (AWS S3).
- ONTAP S3
  - ONTAP S3 servers must be running source and destination SVMs.
  - It is recommended but not required that CA certificates for TLS access are installed on systems that host S3 servers.

- The CA certificates used to sign the S3 servers' certificates must be installed on the admin storage VM of the clusters that host S3 servers.
- You can use a self-signed CA certificate or a certificate signed by an external CA vendor.
- If the source or destination storage VMs are not listening on HTTPS, it is not necessary to install CA certificates.
- Peering (for ONTAP S3 targets)
  - Intercluster LIFs must be configured (for remote ONTAP targets).
  - Source and destination clusters are peered (for remote ONTAP targets).
  - Source and destination storage VMs are peered (for all ONTAP targets).
- SnapMirror policy
  - An S3-specific SnapMirror policy is required for all S3 SnapMirror relationships, but you can use the same policy for multiple relationships.
  - You can create your own policy or accept the default Continuous policy, which includes the following values:
    - Throttle (upper limit on throughput/bandwidth) unlimited.
    - Time for recovery point objective: 1 hour (3600 seconds).
- Root user keys

Storage VM root user access keys are required for S3 SnapMirror relationships; ONTAP does not assign them by default. The first time you create an S3 SnapMirror relationship, you must verify that the keys exist on both source and destination storage VMs and regenerate them if they do not. If you need to regenerate them, you must ensure that all clients and all SnapMirror object-store configurations using the access and secret key pair are updated with the new keys.

For information about S3 server configuration, see the following topics:

- Enable an S3 server on a storage VM
- About the S3 configuration process

For information about cluster and storage VM peering, see the following topic:

- Prepare for mirroring and vaulting (System Manager, steps 1-6)
- Cluster and SVM peering (CLI)

### S3 SnapMirror considerations and restrictions

When you create new buckets, you can control access by creating users and groups. For more information, see the following topics:

- Add S3 users and groups (System Manager)
- Create an S3 user (CLI)
- Create or modify S3 groups (CLI)

The following standard SnapMirror functionality is not supported in the current S3 SnapMirror release:

• Fan-in deployments (data protection relationships between multiple source buckets and a single destination bucket)

S3 Snapmirror can support multiple bucket mirrors from multiple clusters to a single secondary cluster, but each source bucket must have its own destination bucket on the secondary cluster.

# Mirror and backup protection on a remote cluster

### Create a mirror relationship for a new bucket (remote cluster)

When you create new S3 buckets, you can protect them immediately to an S3 SnapMirror destination on a remote cluster.

### What you'll need

- Requirements for ONTAP versions, licensing, and S3 server configuration have been completed.
- A peering relationship exists between source and destination clusters, and a peering relationship exists between source and destination storage VMs.
- CA Certificates are needed for the source and destination VMs. You can use self-signed CA certificates or certificates signed by an external CA vendor.

#### About this task

You will need to perform tasks on both source and destination systems.

### System Manager procedure

- 1. If this is the first S3 SnapMirror relationship for this storage VM, verify that root user keys exist for both source and destination storage VMs and regenerate them if they do not:
  - a. Click **Storage > Storage VMs** and then select the storage VM.
  - b. In the **Settings** tab, click / in the **S3** tile.
  - c. In the **Users** tab, verify that there is an access key for the root user.
  - d. If there is not, click inext to root, then click Regenerate Key. Do not regenerate the key if one already exists.
- Edit the storage VM to add users, and to add users to groups, in both the source and destination storage VMs:

Click Storage > storage VMs, click the storage VM, click Settings and then click 🥕 under S3.

See Add S3 users and groups for more information.

- 3. On the source cluster, create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:
  - a. Click Protection > Overview, and then click Local Policy Settings.
  - b. Click  $\rightarrow$  next to **Protection Policies**, then click **Add**.
    - Enter the policy name and description.
    - Select the policy scope, cluster or SVM
    - Select Continuous for S3 SnapMirror relationships.
    - Enter your Throttle and Recovery Point Objective values.
- 4. Create a bucket with SnapMirror protection:

- a. Click Storage > Buckets, then click Add. Verifying permissions is optional but recommended.
- b. Enter a name, select the storage VM, enter a size, then click **More Options**.
- c. Under **Permissions**, click **Add**.
  - Principal and Effect select values corresponding to your user group settings or accept the defaults.
  - Actions- make sure the following values are shown: GetObject, PutObject, DeleteObject, ListBucket, GetBucketAcl, GetObjectAcl, ListBucketMultipartUploads, ListMultipartUploadParts
  - Resources use the defaults (bucketname, bucketname/\*) or other values you need.

See Manage user access to buckets for more information about these fields.

- d. Under Protection, check Enable SnapMirror (ONTAP or Cloud). Then enter the following values:
  - Destination
    - TARGET: ONTAP System
    - CLUSTER: Select the remote cluster.
    - STORAGE VM: Select a storage VM on the remote cluster.
    - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the source certificate.
  - Source
    - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the *destination* certificate.

Check **Use the same certificate on the destination** if you are using a certificate signed by an external CA vendor.

If you click **Destination Settings**, you can also enter your own values in place of the defaults for bucket name, capacity, and performance service level.

When you click **Save**, a new bucket is created in the source storage VM, and it is mirrored to a new bucket that is created the destination storage VM.

### **CLI** procedure

1. If this is the first S3 SnapMirror relationship for this SVM, verify that root user keys exist for both source and destination SVMs and regenerate them if they do not:

```
vserver object-store-server user show
```

Verify that there is an access key for the root user. If there is not, enter:

```
vserver object-store-server user regenerate-keys -vserver svm_name -user root
```

Do not regenerate the key if one already exists.

2. Create buckets in both the source and destination SVMs:

```
vserver object-store-server bucket create -vserver svm_name -bucket
bucket_name [-size integer[KB|MB|GB|TB|PB]] [-comment text]
[additional options]
```

3. Add access rules to the default bucket policies in both the source and destination SVMs:

```
vserver object-store-server bucket policy add-statement -vserver svm_name
-bucket bucket_name -effect {allow|deny} -action object_store_actions
-principal user_and_group_names -resource object_store_resources [-sid text]
[-index integer]
```

### **Example**

```
src_cluster::> vserver object-store-server bucket policy add-statement
-bucket test-bucket -effect allow -action
GetObject,PutObject,DeleteObject,ListBucket,GetBucketAcl,GetObjectAcl,Li
stBucketMultipartUploads,ListMultipartUploadParts -principal - -resource
test-bucket, test-bucket /*
```

4. On the source SVM, create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:

```
snapmirror policy create -vserver svm_name -policy policy_name -type
continuous [-rpo integer] [-throttle throttle_type] [-comment text]
[additional options]
```

#### Parameters:

- ° type continuous the only policy type for S3 SnapMirror relationships (required).
- -rpo specifies the time for recovery point objective, in seconds (optional).
- -throttle specifies the upper limit on throughput/bandwidth, in kilobytes/seconds (optional).

### **Example**

```
src_cluster::> snapmirror policy create -vserver vs0 -type continuous
-rpo 0 -policy test-policy
```

- 5. Install CA server certificates on the admin SVMs of the source and destination clusters:
  - a. On the source cluster, install the CA certificate that signed the *destination* S3 server certificate:
    security certificate install -type server-ca -vserver *src\_admin\_svm* -cert
    -name *dest server certificate*
  - b. On the destination cluster, install the CA certificate that signed the source S3 server certificate: security certificate install -type server-ca -vserver dest\_admin\_svm -cert -name src\_server\_certificate

If you are using a certificate signed by an external CA vendor, install the same certificate on the source and destination admin SVM.

See the security certificate install man page for details.

6. On the source SVM, create an S3 SnapMirror relationship:

snapmirror create -source-path src svm name:/bucket/bucket name -destination

```
-path dest peer svm name:/bucket/bucket name, ...} [-policy policy name]
```

You can use a policy you created or accept the default.

### **Example**

```
src_cluster::> snapmirror create -source-path vs0-src:/bucket/test-
bucket -destination-path vs1-dest:bucket/test-bucket-mirror -policy
test-policy
```

7. Verify that mirroring is active:

snapmirror show -policy-type continuous -fields status

### Create a mirror relationship for an existing bucket (remote cluster)

You can begin protecting existing S3 buckets at any time; for example, if you upgraded an S3 configuration from a release earlier than ONTAP 9.10.1.

### What you'll need

- Requirements for ONTAP versions, licensing, and S3 server configuration have been completed.
- A peering relationship exists between source and destination clusters, and a peering relationship exists between source and destination storage VMs.
- CA Certificates are needed for the source and destination VMs. You can use self-signed CA certificates or certificates signed by an external CA vendor.

#### About this task

You will need to perform tasks on both source and destination clusters.

### System Manager procedure

- 1. If this is the first S3 SnapMirror relationship for this storage VM, verify that root user keys exist for both source and destination storage VMs and regenerate them if they do not:
  - a. Click Storage > Storage VMs and then select the storage VM.
  - b. In the **Settings** tab, click / in the **S3** tile.
  - c. In the **Users** tab, verify that there is an access key for the root user.
  - d. If there is not, click next to **root**, then click **Regenerate Key.**Do not regenerate the key if one already exists.
- Verify that user and group access is correct in both the source and destination storage VMs:
   Click Storage > storage VMs, click the storage VM, click Settings and then click under S3.

See Add S3 users and groups for more information.

- 3. On the source cluster, create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:
  - a. Click Protection > Overview, and then click Local Policy Settings.
  - b. Click  $\rightarrow$  next to **Protection Policies**, then click **Add**.
  - c. Enter the policy name and description.

- d. Select the policy scope, cluster or SVM
- e. Select Continuous for S3 SnapMirror relationships.
- f. Enter your Throttle and Recovery Point Objective values.
- 4. Verify that the bucket access policy of the existing bucket still meets your needs:
  - a. Click **Storage > Buckets** and then select the bucket you want to protect.
  - b. In the **Permissions** tab, click **/ Edit**, then click **Add** under **Permissions**.
    - Principal and Effect: select values corresponding to your user group settings, or accept the defaults.
    - Actions: make sure the following values are shown:
       GetObject, PutObject, DeleteObject, ListBucket, GetBucketAcl, GetObjectAcl, ListBucketMultipartUploads, ListMultipartUploadParts
    - **Resources**: use the defaults (bucketname, bucketname/\*) or other values you need.

See Manage user access to buckets for more information about these fields.

- 5. Protect an existing bucket with S3 SnapMirror protection:
  - a. Click **Storage** > **Buckets** and then select the bucket you want to protect..
  - b. Click **Protect** and enter the following values:
    - Destination
      - TARGET: ONTAP System
      - CLUSTER: Select the remote cluster.
      - STORAGE VM: Select a storage VM on the remote cluster.
      - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the source certificate.
    - Source
      - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the *destination* certificate.

Check **Use the same certificate on the destination** if you are using a certificate signed by an external CA vendor.

If you click **Destination Settings**, you can also enter your own values in place of the defaults for bucket name, capacity, and performance service level.

When you click **Save**, the existing bucket is mirrored to a new bucket in the destination storage VM.

### **CLI** procedure

1. If this is the first S3 SnapMirror relationship for this SVM, verify that root user keys exist for both source and destination SVMs and regenerate them if they do not:

```
vserver object-store-server user show
```

Verify that there is an access key for the root user. If there is not, enter:

```
vserver object-store-server user regenerate-keys -vserver svm name -user root
```

Do not regenerate the key if one already exists.

2. Create a bucket on the destination SVM to be the mirror target:

```
vserver object-store-server bucket create -vserver svm_name -bucket
dest_bucket_name [-size integer[KB|MB|GB|TB|PB]] [-comment text]
[additional options]
```

3. Verify that the access rules of the default bucket policies are correcte in both the source and destination SVMs:

```
vserver object-store-server bucket policy add-statement -vserver svm_name
-bucket bucket_name -effect {allow|deny} -action object_store_actions
-principal user_and_group_names -resource object_store_resources [-sid text]
[-index integer]
```

### **Example**

```
src_cluster::> vserver object-store-server bucket policy add-statement
-bucket test-bucket -effect allow -action
GetObject,PutObject,DeleteObject,ListBucket,GetBucketAcl,GetObjectAcl,Li
stBucketMultipartUploads,ListMultipartUploadParts -principal - -resource
test-bucket, test-bucket /*
```

4. On the source SVM, create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:

```
snapmirror policy create -vserver svm_name -policy policy_name -type
continuous [-rpo integer] [-throttle throttle_type] [-comment text]
[additional_options]
```

### Parameters:

- ° continuous the only policy type for S3 SnapMirror relationships (required).
- -rpo specifies the time for recovery point objective, in seconds (optional).
- -throttle specifies the upper limit on throughput/bandwidth, in kilobytes/seconds (optional).

### **Example**

```
src_cluster::> snapmirror policy create -vserver vs0 -type continuous
-rpo 0 -policy test-policy
```

- 5. Install CA certificates on the admin SVMs of source and destination clusters:
  - a. On the source cluster, install the CA certificate that signed the destination S3 server certificate: security certificate install -type server-ca -vserver src\_admin\_svm -cert -name dest server certificate
  - b. On the destination cluster, install the CA certificate that signed the source S3 server certificate: security certificate install -type server-ca -vserver dest\_admin\_svm -cert -name src\_server\_certificate

If you are using a certificate signed by an external CA vendor, install the same certificate on the source and destination admin SVM.

See the security certificate install man page for details.

6. On the source SVM, create an S3 SnapMirror relationship:

```
snapmirror create -source-path src_svm_name:/bucket/bucket_name -destination
-path dest_peer_svm_name:/bucket/bucket_name, ...} [-policy_policy_name]
```

You can use a policy you created or accept the default.

### **Example**

```
src_cluster::> snapmirror create -source-path vs0:/bucket/test-bucket
-destination-path vs1:/bucket/test-bucket-mirror -policy test-policy
```

7. Verify that mirroring is active:

snapmirror show -policy-type continuous -fields status

### Takeover and serve data from the destination bucket (remote cluster)

If the data in a source bucket becomes unavailable, you can break the SnapMirror relationship to make the destination bucket writable and begin serving data.

#### About this task

When a takeover operation is performed, source bucket is converted to read-only and original destination bucket is converted to read-write, thereby reversing the S3 SnapMirror relationship.

When the disabled source bucket is available again, S3 SnapMirror automatically resynchronizes the contents of the two buckets. It is not necessary to explicitly resynchronize the relationship, as is required for volume SnapMirror deployments.

The takeover operation must be initiated from the remote cluster.

### System Manager procedure

Failover from the unavailable bucket and begin serving data:

- 1. Click **Protection > Relationships**, then select **S3 SnapMirror**.
- Click , select Failover, then click Failover.

### **CLI** procedure

- 1. Initiate a failover operation for the destination bucket:
  snapmirror failover start -destination-path svm\_name:/bucket/bucket\_name
- 2. Verify the status of the failover operation: snapmirror show -fields status

### **Example**

```
dest_cluster::> snapmirror failover start -destination-path
dest_svm1:/bucket/test-bucket-mirror
```

### Restore a bucket from the destination storage VM (remote cluster)

If data in a source bucket is lost or corrupted, you repopulate your data by restoring from a destination bucket.

### About this task

You can restore the destination bucket to an existing bucket or a new bucket. The target bucket for the restore operation must be larger than the destination bucket's logical used space.

If you use an existing bucket, it must be empty when starting a restore operation. Restore does not "roll back" a bucket in time; rather, it populates an empty bucket with its previous contents.

The restore operation must be initiated from the remote cluster.

### System Manager procedure

Restore the back-up data:

- 1. Click Protection > Relationships, then select S3 SnapMirror.
- 2. Click and then select **Restore**.
- 3. Under Source, select Existing Bucket (the default) or New Bucket.
  - To restore to an **Existing Bucket** (the default), complete these actions:
    - Select the cluster and storage VM to search for the existing bucket.
    - Select the existing bucket.
    - Copy and paste the contents of the destination S3 server CA certificate.
  - To restore to a **New Bucket**, enter the following values:
    - The cluster and storage VM to host the new bucket.
    - The new bucket's name, capacity, and performance service level. See Storage service levels for more information.
    - The contents of the destination S3 server CA certificate.
- 4. Under **Destination**, copy and paste the contents of the *source* S3 server CA certificate.
- 5. Click **Protection > Relationships** to monitor the restore progress.

### **CLI** procedure

- 1. If you are restoring to a new bucket, create the new bucket. For more information, see Create a backup relationship for a new bucket (cloud target).
- 2. Initiate a restore operation for the destination bucket: snapmirror restore -source-path svm\_name:/bucket/bucket\_name -destination-path svm\_name:/bucket/bucket\_name

### **Example**

```
dest_cluster::> snapmirror restore -source-path src_vs1:/bucket/test-
bucket -destination-path dest_vs1:/bucket/test-bucket-mirror
```

# Mirror and backup protection on the local cluster

### Create a mirror relationship for a new bucket (local cluster)

When you create new S3 buckets, you can protect them immediately to an S3 SnapMirror destination on the same cluster. You can mirror data to a bucket in a different storage VM or the same storage VM as the source.

### What you'll need

- Requirements for ONTAP versions, licensing, and S3 server configuration have been completed.
- A peering relationship exists between source and destination storage VMs.
- CA Certificates are needed for the source and destination VMs. You can use self-signed CA certificates or certificates signed by an external CA vendor.

### System Manager procedure

- 1. If this is the first S3 SnapMirror relationship for this storage VM, verify that root user keys exist for both source and destination storage VMs and regenerate them if they do not:
  - a. Click Storage > Storage VMs and then select the storage VM.
  - b. In the Settings tab, click in the S3 tile.
  - c. In the Users tab, verify that there is an access key for the root user
  - d. If there is not, click inext to **root**, then click **Regenerate Key**. Do not regenerate the key if one already exists.
- Edit the storage VM to add users, and to add users to groups, in both the source and destination storage VMs:

Click Storage > storage VMs, click the storage VM, click Settings and then click > under S3.

See Add S3 users and groups for more information.

- Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:
  - a. Click **Protection > Overview**, and then click **Local Policy Settings**.
  - b. Click  $\rightarrow$  next to **Protection Policies**, then click **Add**.
    - Enter the policy name and description.
    - Select the policy scope, cluster or SVM
    - Select Continuous for S3 SnapMirror relationships.
    - Enter your Throttle and Recovery Point Objective values.
- Create a bucket with SnapMirror protection:
  - a. Click Storage > Buckets then click Add.
  - b. Enter a name, select the storage VM, enter a size, then click More Options.
  - c. Under **Permissions**, click **Add**. Verifying permissions is optional but recommended.
    - Principal and Effect select values corresponding to your user group settings, or accept the
      defaults.
    - Actions make sure the following values are shown:

GetObject, PutObject, DeleteObject, ListBucket, GetBucketAcl, GetObjectAcl, ListBucketMultipartUploads, ListMultipartUploadParts

Resources - use the defaults (bucketname, bucketname/\*) or other values you need

See Manage user access to buckets for more information about these fields.

- d. Under Protection, check Enable SnapMirror (ONTAP or Cloud). Then enter the following values:
  - Destination
    - TARGET: ONTAP System
    - CLUSTER: Select the remote cluster.
    - STORAGE VM: Select a storage VM on the remote cluster.
    - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the source certificate.
  - Source
    - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the destination certificate.

Check **Use the same certificate on the destination** if you are using a certificate signed by an external CA vendor.

If you click **Destination Settings**, you can also enter your own values in place of the defaults for bucket name, capacity, and performance service level.

When you click **Save**, a new bucket is created in the source storage VM, and it is mirrored to a new bucket that is created the destination storage VM.

### **CLI** procedure

1. If this is the first S3 SnapMirror relationship for this SVM, verify that root user keys exist for both source and destination SVMs and regenerate them if they do not:

```
vserver object-store-server user show
```

Verify that there is an access key for the root user. If there is not, enter:

```
vserver object-store-server user regenerate-keys -vserver svm name -user root
```

Do not regenerate the key if one already exists.

2. Create buckets in both the source and destination SVMs:

```
vserver object-store-server bucket create -vserver svm_name -bucket
bucket_name [-size integer[KB|MB|GB|TB|PB]] [-comment text]
[additional options]
```

3. Add access rules to the default bucket policies in both the source and destination SVMs:

```
vserver object-store-server bucket policy add-statement -vserver svm_name
-bucket bucket_name -effect {allow|deny} -action object_store_actions
-principal user_and_group_names -resource object_store_resources [-sid text]
[-index integer]
```

### **Example**

```
src_cluster::> vserver object-store-server bucket policy add-statement
-bucket test-bucket -effect allow -action
GetObject,PutObject,DeleteObject,ListBucket,GetBucketAcl,GetObjectAcl,Li
stBucketMultipartUploads,ListMultipartUploadParts -principal - -resource
test-bucket, test-bucket /*
```

4. Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:

```
snapmirror policy create -vserver svm_name -policy policy_name -type
continuous [-rpo integer] [-throttle throttle_type] [-comment text]
[additional options]
```

### Parameters:

- ° continuous the only policy type for S3 SnapMirror relationships (required).
- -rpo specifies the time for recovery point objective, in seconds (optional).
- -throttle specifies the upper limit on throughput/bandwidth, in kilobytes/seconds (optional).

### **Example**

```
src_cluster::> snapmirror policy create -vserver vs0 -type continuous
-rpo 0 -policy test-policy
```

- 5. Install CA server certificates on the admin SVM:
  - a. Install the CA certificate that signed the *source* S3 server's certificate on the admin SVM:
    security certificate install -type server-ca -vserver *admin\_svm* -cert-name
    src server certificate
  - b. Install the CA certificate that signed the destination S3 server's certificate on the admin SVM: security certificate install -type server-ca -vserver admin\_svm -cert-name dest\_server\_certificate

If you are using a certificate signed by an external CA vendor, you only need to install this certificate on the admin SVM.

See the security certificate install man page for details.

6. Create an S3 SnapMirror relationship:

```
snapmirror create -source-path src_svm_name:/bucket/bucket_name -destination
-path dest_peer_svm_name:/bucket/bucket_name, ...} [-policy_policy_name]`
```

You can use a policy you created or accept the default.

### **Example**

src\_cluster::> snapmirror create -source-path vs0-src:/bucket/testbucket -destination-path vs1-dest:/vs1/bucket/test-bucket-mirror -policy
test-policy

 Verify that mirroring is active: snapmirror show -policy-type continuous -fields status

### Create a mirror relationship for an existing bucket (local cluster)

You can begin protecting existing S3 buckets on the same cluster at any time; for example, if you upgraded an S3 configuration from a release earlier than ONTAP 9.10.1. You can mirror data to a bucket in a different storage VM or the same storage VM as the source.

### What you'll need

- Requirements for ONTAP versions, licensing, and S3 server configuration have been completed.
- A peering relationship exists between source and destination storage VMs.
- CA Certificates are needed for the source and destination VMs. You can use self-signed CA certificates or certificates signed by an external CA vendor.

### System Manager procedure

- 1. If this is the first S3 SnapMirror relationship for this storage VM, verify that root user keys exist for both source and destination storage VMs and regenerate them if they do not:
  - a. Click Storage > Storage VMs and then select the storage VM.
  - b. In the **Settings** tab, click / in the **S3** tile.
  - c. In the **Users** tab, verify that there is an access key for the root user.
  - d. If there is not, click next to **root**, then click **Regenerate Key**. Do not regenerate the key if one already exists
- 2. Verify that user and group access is correct in both the source and destination storage VMs:
  - Click Storage > storage VMs, click the storage VM, click Settings and then click 

     under S3.

See Add S3 users and groups for more information.

- 3. Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:
  - a. Click Protection > Overview, and then click Local Policy Setting.
  - b. Click  $\rightarrow$  next to **Protection Policies**, then click **Add**.
    - Enter the policy name and description.
    - Select the policy scope, cluster or SVM
    - Select Continuous for S3 Snapmirror relationships.
    - Enter your Throttle and Recovery Point Objective values.

- 4. Verify that the bucket access policy of the existing bucket continues to meet your needs:
  - a. Click Storage > Buckets and then select the bucket you want to protect.
  - b. In the **Permissions** tab, click **/ Edit**, then click **Add** under **Permissions**.
    - Principal and Effect select values corresponding to your user group settings, or accept the
      defaults.
    - Actions make sure the following values are shown:
       GetObject, PutObject, DeleteObject, ListBucket, GetBucketAcl, GetObjectAcl, ListBucketMultipartUploads, ListMultipartUploadParts
    - Resources use the defaults (bucketname, bucketname/\*) or other values you need.

See Manage user access to buckets for more information about these fields.

- 5. Protect an existing bucket with S3 SnapMirror:
  - a. Click **Storage** > **Buckets** and then select the bucket you want to protect.
  - b. Click **Protect** and enter the following values:
    - Destination
      - TARGET: ONTAP System
      - CLUSTER: Select the local cluster.
      - STORAGE VM: Select the same or a different storage VM.
      - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the source certificate.
    - Source
      - S3 SERVER CA CERTIFICATE: Copy and paste the contents of the *destination* certificate.

Check **Use the same certificate on the destination** if you are using a certificate signed by an external CA vendor.

If you click **Destination Settings**, you can also enter your own values in place of the defaults for bucket name, capacity, and performance service level.

When you click Save, the existing bucket is mirrored to a new bucket in the destination storage VM.

### **CLI** procedure

1. If this is the first S3 SnapMirror relationship for this SVM, verify that root user keys exist for both source and destination SVMs and regenerate them if they do not:

```
vserver object-store-server user show
```

Verify that there is an access key for the root user. If there is not, enter:

```
vserver object-store-server user regenerate-keys -vserver svm name -user root
```

Do not regenerate the key if one already exists.

2. Create a bucket on the destination SVM to be the mirror target:

```
vserver object-store-server bucket create -vserver svm_name -bucket
dest_bucket_name [-size integer[KB|MB|GB|TB|PB]] [-comment text]
[additional options]
```

3. Verify that the access rules to the default bucket policies are correct in both the source and destination SVMs:

vserver object-store-server bucket policy add-statement -vserver svm\_name
-bucket bucket\_name -effect {allow|deny} -action object\_store\_actions
-principal user\_and\_group\_names -resource object\_store\_resources [-sid text]
[-index integer]`

### **Example**

clusterA::> vserver object-store-server bucket policy add-statement
-bucket test-bucket -effect allow -action
GetObject,PutObject,DeleteObject,ListBucket,GetBucketAcl,GetObjectAcl,Li
stBucketMultipartUploads,ListMultipartUploadParts -principal - -resource
test-bucket, test-bucket /\*

4. Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:

```
snapmirror policy create -vserver svm_name -policy policy_name -type
continuous [-rpo _integer] [-throttle throttle_type] [-comment text]
[additional options]
```

### Parameters:

- ° continuous the only policy type for S3 SnapMirror relationships (required).
- -rpo specifies the time for recovery point objective, in seconds (optional).
- -throttle specifies the upper limit on throughput/bandwidth, in kilobytes/seconds (optional).

#### **Example**

```
clusterA::> snapmirror policy create -vserver vs0 -type continuous
-rpo 0 -policy test-policy
```

- 5. Install CA server certificates on the admin SVM:
  - a. Install the CA certificate that signed the *source* S3 server's certificate on the admin SVM:
    security certificate install -type server-ca -vserver admin\_svm -cert-name
    src server certificate
  - b. Install the CA certificate that signed the destination S3 server's certificate on the admin SVM: security certificate install -type server-ca -vserver admin\_svm -cert-name dest\_server\_certificate

If you are using a certificate signed by an external CA vendor, you only need to install this certificate on the admin SVM.

See the security certificate install man page for details.

6. Create an S3 SnapMirror relationship:

```
snapmirror create -source-path src_svm_name:/bucket/bucket_name -destination
-path dest peer svm name:/bucket/bucket name, ...} [-policy policy name]
```

You can use a policy you created or accept the default.

### **Example**

```
src_cluster::> snapmirror create -source-path vs0-src:/bucket/test-
bucket -destination-path vs1-dest:/bucket/test-bucket-mirror -policy
test-policy
```

7. Verify that mirroring is active:
snapmirror show -policy-type continuous -fields status

### Takeover and serve data from the destination bucket (local cluster)

If the data in a source bucket becomes unavailable, you can break the SnapMirror relationship to make the destination bucket writable and begin serving data.

### About this task

When a takeover operation is performed, source bucket is converted to read-only and original destination bucket is converted to read-write, thereby reversing the S3 SnapMirror relationship.

When the disabled source bucket is available again, S3 SnapMirror automatically resynchronizes the contents of the two buckets. You don't need to explicitly resynchronize the relationship, as is required for standard volume SnapMirror deployments.

If the destination bucket is on a remote cluster, the takeover operation must be initiated from the remote cluster.

### System Manager procedure

Failover from the unavailable bucket and begin serving data:

- 1. Click **Protection > Relationships**, then select **S3 SnapMirror**.
- Click :, select Failover, then click Failover.

### **CLI** procedure

- 1. Initiate a failover operation for the destination bucket:
  snapmirror failover start -destination-path svm name:/bucket/bucket name
- Verify the status of the failover operation: snapmirror show -fields status

### **Example**

clusterA::> snapmirror failover start -destination-path vs1:/bucket/test-bucketmirror

### Restore a bucket from the destination storage VM (remote cluster)

When data in a source bucket is lost or corrupted, you repopulate your data by restoring from a destination bucket

### About this task

You can restore the destination bucket to an existing bucket or a new bucket. The target bucket for the restore operation must be larger than the destination bucket's logical used space.

If you use an existing bucket, it must be empty when starting a restore operation. Restore does not "roll back" a bucket in time; rather, it populates an empty bucket with its previous contents.

The restore operation must be initiated from the remote cluster.

### System Manager procedure

Restore the back-up data:

- 1. Click **Protection > Relationships**, then select the bucket.
- Click and then select Restore.
- 3. Under Source, select Existing Bucket (the default) or New Bucket.
  - To restore to an **Existing Bucket** (the default), complete these actions:
    - Select the cluster and storage VM to search for the existing bucket.
    - Select the existing bucket.
- 4. Copy and paste the contents of the destination S3 server CA certificate.
  - To restore to a **New Bucket**, enter the following values:
    - The cluster and storage VM to host the new bucket.
    - The new bucket's name, capacity, and performance service level. See Storage service levels for more information.
    - The contents of the destination S3 server CA certificate.
- 5. Under **Destination**, copy and paste the contents of the source S3 server CA certificate.
- 6. Click **Protection** > Relationships to monitor the restore progress.

### **CLI** procedure

- 1. If you are restoring to a new bucket, create the new bucket. For more information, see Create a backup relationship for a new bucket (cloud target).
- 2. Initiate a restore operation for the destination bucket: snapmirror restore -source-path svm\_name:/bucket/bucket\_name -destination-path svm\_name:/bucket/bucket\_name

### **Example**

```
clusterA::> snapmirror restore -source-path vs0:/bucket/test-bucket
-destination-path vs1:/bucket/test-bucket-mirror
```

# **Backup protection with cloud targets**

### Requirements for cloud target relationships

Make sure that your source and target environments meet the requirements for S3 SnapMirror backup protection to cloud targets.

You must have valid account credentials with the object store provider to access the data bucket.

Intercluster network interfaces and an IPspace should be configured on the cluster before the cluster can connect to a cloud object store. You should create enter cluster network interfaces on each node to seamlessly transfer data from the local storage to the cloud object store.

For StorageGRID targets, you need to know the following information:

- server name, expressed as a fully-qualified domain name (FQDN) or IP address
- bucket name; the bucket must already exist
- · access key
- · secret key

In addition, the CA certificate used to sign the StorageGRID server certificate needs to be installed on the ONTAP S3 cluster's admin storage VM using the security certificate install command. For more information, see Installing a CA certificate if you use StorageGRID.

For AWS S3 targets, you need to know the following information:

- server name, expressed as a fully-qualified domain name (FQDN) or IP address
- · bucket name; the bucket must already exist
- access key
- · secret key

The DNS server for the ONTAP cluster's admin storage VM must be able to resolve FQDNs (if used) to IP addresses.

## Create a backup relationship for a new bucket (cloud target)

When you create new S3 buckets, you can back them up immediately to an S3 SnapMirror target bucket on an object store provider, which can be a StorageGRID system or an AWS S3 deployment.

### What you'll need

- You have valid account credentials and configuration information for the object store provider.
- · Intercluster network interfaces and an IPspace have been configured on the source system.
- The DNS configuration for the source storage VM must be able to resolve the target's FQDN.

### System Manager procedure

1. Edit the storage VM to add users, and to add users to groups:

a. Click Storage > storage VMs, click the storage VM, click Settings and then click / under S3.

See Add S3 users and groups for more information.

- 2. Add a Cloud Object Store on the source system:
  - a. Click Protection > Overview, then select Cloud Object Stores.
  - b. Click Add, then select Amazon S3 or StorageGRID.
  - c. Enter the following values:
    - Cloud object store name
    - URL style (path or virtual-hosted)
    - storage VM (enabled for S3)
    - Object store server name (FQDN)
    - Object store certificate
    - Access key
    - Secret key
    - Container (bucket) name
- 3. Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:
  - a. Click **Protection > Overview**, and then click **Local Policy Settings**.
  - b. Click  $\rightarrow$  next to **Protection Policies**, then click **Add**.
    - Enter the policy name and description.
    - Select the policy scope, cluster or SVM
    - Select Continuous for S3 SnapMirror relationships.
    - Enter your Throttle and Recovery Point Objective values.
- Create a bucket with SnapMirror protection:
  - a. Click Storage > Buckets, then click Add.
  - b. Enter a name, select the storage VM, enter a size, then click **More Options**.
  - c. Under **Permissions**, click **Add**. Verifying permissions is optional but recommended.
    - Principal and Effect select values corresponding to your user group settings or accept the defaults.
    - Actions make sure the following values are shown:
       GetObject, PutObject, DeleteObject, ListBucket, GetBucketAcl, GetObjectAcl, ListBucketMultipartUploads, ListMultipartUploadParts
    - Resources use the defaults (bucketname, bucketname/\*) or other values you need.

See Manage user access to buckets for more information about these fields.

d. Under **Protection**, check **Enable SnapMirror (ONTAP or Cloud)**, select **Cloud Storage**, then select the **Cloud Object Store**.

When you click **Save**, a new bucket is created in the source storage VM, and it is backed up to the cloud object store.

### **CLI** procedure

1. If this is the first S3 SnapMirror relationship for this SVM, verify that root user keys exist for both source and destination SVMs and regenerate them if they do not:

```
vserver object-store-server user show
```

Confirm that there is an access key for the root user. If there is not, enter:

```
vserver object-store-server user regenerate-keys -vserver svm_name -user root
```

Do not regenerate the key if one already exists.

2. Create a bucket in the source SVM:

```
vserver object-store-server bucket create -vserver svm_name -bucket
bucket_name [-size integer[KB|MB|GB|TB|PB]] [-comment text]
[additional options]
```

3. Add access rules to the default bucket policy:

```
vserver object-store-server bucket policy add-statement -vserver svm_name
-bucket bucket_name -effect {allow|deny} -action object_store_actions
-principal user_and_group_names -resource object_store_resources [-sid text]
[-index integer]
```

### Example

```
clusterA::> vserver object-store-server bucket policy add-statement
-bucket test-bucket -effect allow -action
GetObject,PutObject,DeleteObject,ListBucket,GetBucketAcl,GetObjectAcl,Li
stBucketMultipartUploads,ListMultipartUploadParts -principal - -resource
test-bucket, test-bucket /*
```

4. Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:

```
snapmirror policy create -vserver svm_name -policy policy_name -type
continuous [-rpo integer] [-throttle throttle_type] [-comment text]
[additional options]
```

### Parameters:

- \* type continuous the only policy type for S3 SnapMirror relationships (required).
- \* -rpo specifies the time for recovery point objective, in seconds (optional).
- \* -throttle specifies the upper limit on throughput/bandwidth, in kilobytes/seconds (optional).

### **Example**

```
clusterA::> snapmirror policy create -vserver vs0 -type continuous -rpo
0 -policy test-policy
```

5. If the target is a StorageGRID system, install the StorageGRID CA server certificate on the admin SVM of the source cluster:

```
security certificate install -type server-ca -vserver src\_admin\_svm -cert-name storage\_grid\_server\_certificate
```

See the security certificate install man page for details.

### 6. Define the S3 SnapMirror destination object store:

snapmirror object-store config create -vserver svm\_name -object-store-name
target\_store\_name -usage data -provider-type {AWS\_S3|SGWS} -server target\_FQDN
-container-name remote\_bucket\_name -is-ssl-enabled true -port port\_number
-access-key target\_access\_key -secret-password target\_secret\_key

### Parameters:

- \* -object-store-name the name of the object store target on the local ONTAP system.
- \* -usage use data for this workflow.
- \* -provider-type AWS S3 and SGWS (StorageGRID) targets are supported.
- \* -server the target server's FQDN or IP address.
- \* -is-ssl-enabled -enabling SSL is optional but recommended.

See the snapmirror object-store config create man page for details.

### **Example**

```
src_cluster::> snapmirror object-store config create -vserver vs0
-object-store-name sgws-store -usage data -provider-type SGWS -server
sgws.example.com -container-name target-test-bucket -is-ssl-enabled true
-port 443 -access-key abc123 -secret-password xyz890
```

### 7. Create an S3 SnapMirror relationship:

snapmirror create -source-path svm\_name:/bucket/bucket\_name -destination-path
object\_store\_name:/objstore -policy\_policy\_name

### Parameters:

\* -destination-path - the object store name you created in the previous step and the fixed value objstore.

You can use a policy you created or accept the default.

### **Example**

```
src_cluster::> snapmirror create -source-path vs0:/bucket/test-bucket
-destination-path sgws-store:/objstore -policy test-policy
```

### 8. Verify that mirroring is active:

snapmirror show -policy-type continuous -fields status

# Create a backup relationship for an existing bucket (cloud target)

You can begin backing up existing S3 buckets at any time; for example, if you upgraded an S3 configuration from a release earlier than ONTAP 9.10.1.

### What you'll need

· You have valid account credentials and configuration information for the object store provider.

- Intercluster network interfaces and an IPspace have been configured on the source system.
- The DNS configuration for the source storage VM must be able to resolve the target's FQDN.

### System Manager procedure

Verify that the users and groups are correctly defined:
 Click Storage > storage VMs, click the storage VM, click Settings and then click under S3.

See Add S3 users and groups for more information.

- 2. Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:
  - a. Click **Protection > Overview**, and then click **Local Policy Settings**.
  - b. Click  $\rightarrow$  next to **Protection Policies**, then click **Add**.
  - c. Enter the policy name and description.
  - d. Select the policy scope, cluster or SVM
  - e. Select **Continuous** for S3 SnapMirror relationships.
  - f. Enter your Throttle and Recovery Point Objective values.
- 3. Add a Cloud Object Store on the source system:
  - a. Click **Protection > Overview**, then select **Cloud Object Store**.
  - b. Click Add, then select Amazon S3 or Others for StorageGRID Webscale.
  - c. Enter the following values:
    - Cloud object store name
    - URL style (path or virtual-hosted)
    - storage VM (enabled for S3)
    - Object store server name (FQDN)
    - Object store certificate
    - Access key
    - Secret key
    - Container (bucket) name
- 4. Verify that the bucket access policy of the existing bucket still meets your needs:
  - a. Click **Storage** > **Buckets** and then select the bucket you want to protect.
  - b. In the **Permissions** tab, click **/ Edit**, then click **Add** under **Permissions**.
    - Principal and Effect select values corresponding to your user group settings or accept the defaults.
    - Actions make sure the following values are shown:

      GetObject, PutObject, DeleteObject, ListBucket, GetBucketAcl, GetObjectAcl, ListBucketMultipartUploads, ListMultipartUploadParts
    - Resources use the defaults (bucketname, bucketname/\*) or other values you need.

See Manage user access to buckets for more information about these fields.

- 5. Back up the bucket using S3 SnapMirror:
  - a. Click **Storage** > **Buckets** and then select the bucket you want to back up.
  - b. Click Protect, select Cloud Storage under Target, then select the Cloud Object Store.

When you click Save, the existing bucket is backed up to the cloud object store.

### **CLI** procedure

1. Verify that the access rules in the default bucket policy are correct:

```
vserver object-store-server bucket policy add-statement -vserver svm_name
-bucket bucket_name -effect {allow|deny} -action object_store_actions
-principal user_and_group_names -resource object_store_resources [-sid text]
[-index integer]
```

### **Example**

```
clusterA::> vserver object-store-server bucket policy add-statement
-bucket test-bucket -effect allow -action
GetObject,PutObject,DeleteObject,ListBucket,GetBucketAcl,GetObjectAcl,Li
stBucketMultipartUploads,ListMultipartUploadParts -principal - -resource
test-bucket, test-bucket /*
```

2. Create an S3 SnapMirror policy if you don't have an existing one and you don't want to use the default policy:

```
snapmirror policy create -vserver svm_name -policy policy_name -type
continuous [-rpo integer] [-throttle throttle_type] [-comment text]
[additional options]
```

#### Parameters:

- \* type continuous the only policy type for S3 SnapMirror relationships (required).
- \* -rpo specifies the time for recovery point objective, in seconds (optional).
- \* -throttle specifies the upper limit on throughput/bandwidth, in kilobytes/seconds (optional).

### **Example**

```
clusterA::> snapmirror policy create -vserver vs0 -type continuous -rpo
0 -policy test-policy
```

3. If the target is a StorageGRID system, install the StorageGRID CA certificate on the admin SVM of the source cluster:

```
security certificate install -type server-ca -vserver src\_admin\_svm -cert-name storage grid server certificate
```

See the security certificate install man page for details.

4. Define the S3 SnapMirror destination object store:

```
snapmirror\ object-store\ config\ create\ -vserver\ svm\_name\ -object-store-name\ target\_store\_name\ -usage\ data\ -provider-type\ {AWS_S3|SGWS}\ -server\ target\_FQDN\ -container-name\ remote\_bucket\_name\ -is-ssl-enabled\ true\ -port\ port\_number
```

-access-key target access key -secret-password target secret key

#### Parameters:

- \* -object-store-name the name of the object store target on the local ONTAP system.
- \* -usage use data for this workflow.
- \* -provider-type AWS S3 and SGWS (StorageGRID) targets are supported.
- \* -server the target server's FQDN or IP address.
- \* -is-ssl-enabled -enabling SSL is optional but recommended.

See the snapmirror object-store config create man page for details.

### **Example**

```
src_cluster::> snapmirror object-store config create -vserver vs0
-object-store-name sgws-store -usage data -provider-type SGWS -server
sgws.example.com -container-name target-test-bucket -is-ssl-enabled true
-port 443 -access-key abc123 -secret-password xyz890
```

### 5. Create an S3 SnapMirror relationship:

snapmirror create -source-path svm\_name:/bucket/bucket\_name -destination-path
object\_store\_name:/objstore -policy\_policy\_name

#### Parameters:

\* -destination-path - the object store name you created in the previous step and the fixed value objstore.

You can use a policy you created or accept the default.

### **Example**

```
src_cluster::> snapmirror create -source-path vs0:/bucket/buck-evp
-destination-path sgws-store:/objstore -policy test-policy
```

### 6. Verify that mirroring is active:

snapmirror show -policy-type continuous -fields status

### Restore a bucket from a cloud target

When data in a source bucket is lost or corrupted, you repopulate your data by restoring from a destination bucket.

#### About this task

You can restore the destination bucket to an existing bucket or a new bucket. The target bucket for the restore operation must be larger than the destination bucket's logical used space.

If you use an existing bucket, it must be empty when starting a restore operation. Restore does not "roll back" a bucket in time; rather, it populates an empty bucket with its previous contents.

### System Manager procedure

Restore the back-up data:

- 1. Click **Protection > Relationships**, then select **S3 SnapMirror**.
- 2. Click and then select **Restore**.
- 3. Under Source, select Existing Bucket (the default) or New Bucket.
  - To restore to an Existing Bucket (the default), complete these actions:
    - Select the cluster and storage VM to search for the existing bucket.
    - Select the existing bucket.
    - Copy and paste the contents of the destination S3 server CA certificate.
  - To restore to a **New Bucket**, enter the following values:
    - The cluster and storage VM to host the new bucket.
    - The new bucket's name, capacity, and performance service level. See Storage service levels for more information.
    - The contents of the destination S3 server CA certificate.
- 4. Under **Destination**, copy and paste the contents of the *source* S3 server CA certificate.
- 5. Click **Protection > Relationships** to monitor the restore progress.

### **CLI** procedure

- 1. If you are restoring to a new bucket, create the new bucket. For more information, see Create a backup relationship for a bucket (cloud target).
- 2. Initiate a restore operation for the destination bucket:

```
snapmirror restore -source-path object_store_name:/objstore -destination-path
svm name:/bucket/bucket name
```

### Example

The following example restores a destination bucket to an existing bucket.

```
clusterA::> snapmirror restore -source-path sgws.store:/objstore -destination
-path vs0:/bucket/test-bucket
```

# Modify a mirror policy

You might want to modify an S3 mirror policy; for example, if you want to adjust the RPO and throttle values.

## System Manager procedure

If you want to adjust these values, you can edit an existing protection policy.

- 1. Click **Protection > Relationships**, and then select the protection policy for the relationship you want to modify.
- 2. Click inext to the policy name, then click Edit.

# **CLI** procedure

### Modify an S3 SnapMirror policy:

snapmirror policy modify -vserver svm\_name -policy policy\_name [-rpo integer] [throttle throttle type] [-comment text]

### Parameters:

- -rpo specifies the time for recovery point objective, in seconds.
- -throttle specifies the upper limit on throughput/bandwidth, in kilobytes/seconds.

### **Example**

clusterA::> snapmirror policy modify -vserver vs0 -policy test-policy -rpo
60

### **Copyright Information**

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.