Step 9: Insert programmed ATTINY85 IC into socket. Wire up Battery Box



Battery cable goes through large hole then back in to PCB. Red: +ve Black: -ve



Double check IC orientation! Does notch align?

Step 10: Attach to base plate







Step 11: Add 3 x AAA batteries and test,

Insert 3 AAA batteries into the battery box, You should see the 3mm red LED flash. This means the unit is working. It will flash for around 60 seconds and then switch off. Press the push switch button to start the sequence again. The device sends out all the TV codes in sequence. Pressing the button will cause it to start the sequence again.





Use a camera to check IR LEDs working

Note: This is viewed through a camera You would not normally see the LEDs flash.

Use a digital camera to check the IR LEDs are working. A phone camera works well for this. You should see the LEDs flashing purple, which proves the device is sending IR codes.

Note: Most popular TV codes are used first but it may take over 60 seconds to scroll through all the codes.

Step 12: Finished! Go and switch off some annoying TVs....

This kit is based upon a circuit originally produced by Mitch Altman:

http://www.tvbgone.com/cfe\_tvbg\_main.php
The circuit is based upon the kit by Adafruit Industries:
http://www.ladvada.net/make/tvbgone/index.htm

http://www.ladyada.net/make/tvbgone/index.html
Kit developed by Matt Little: www.curiouselectric.co.uk



## TV-B-Gone KIT Instructions

The TV-B-Gone switches off TVs from a distance of up to 30m. It sends out the standby command for the top 125 European and 125 US TV specifications.



It is based upon an idea and product from Mitch Altman.

In use: Point at an unwanted TV. Press the black button and the red light will flash, showing it is sending out the various TV codes. The most popular codes are sent first, but it takes over 60 seconds to run through all the codes.

## Components:





Step 1: Solder the IC socket

You will also need: 3 x AAA batteries



Step 2: Solder the resistors

