# DATA LINK LAYER

# Link layer


- understand principles behind link layer services:
  - error detection, correction
  - sharing a broadcast channel: multiple access
  - link layer addressing
  - local area networks: Ethernet, VLANs
- instantiation, implementation of various link layer technologies

# Link layer: introduction

## terminology:

- hosts and routers: nodes
- communication channels that connect adjacent nodes along communication path: links
  - wired links
  - wireless links
  - LANs
- layer-2 packet: frame, encapsulates datagram

data-link layer has responsibility of transferring datagram from one node to physically adjacent node over a link



# Data Link Layer

- Bridging Protocol
  - Network Layer
  - Physical Layer

- □ Places data (Frames) onto the Network
- Receives data from the Network

# Transit Example




## How does it work?

Data Link Layer

Logical Link Control

Media Access Control

# Medium Independent



# Link layer: context

- datagram transferred by different link protocols over different links:
  - e.g., Ethernet on first link, frame relay on intermediate links, 802.11 on last link
- each link protocol provides different services
  - e.g., may or may not provide rdt over link

## transportation analogy:

- trip from Princeton to Lausanne
  - □ limo: Princeton to JFK
  - plane: JFK to Geneva
  - □ train: Geneva to Lausanne
- □ tourist = datagram
- transport segment = communication link
- transportation mode = link layer protocol
- travel agent = routing algorithm

# Link layer services


- □ framing, link access:
  - encapsulate datagram into frame, adding header, trailer
  - channel access if shared medium
  - "MAC" addresses used in frame headers to identify source, dest
    - different from IP address!
- □ reliable delivery between adjacent nodes
  - we learned how to do this already (chapter 3)!
  - seldom used on low bit-error link (fiber, some twisted pair)
  - wireless links: high error rates
    - Q: why both link-level and end-end reliability?

# Link layer services


- □ flow control:
  - pacing between adjacent sending and receiving nodes
- □ error detection:
  - errors caused by signal attenuation, noise.
  - receiver detects presence of errors:
    - signals sender for retransmission or drops frame
- □ error correction:
  - receiver identifies and corrects bit error(s) without resorting to retransmission
- □ half-duplex and full-duplex
  - with half duplex, nodes at both ends of link can transmit, but not at same time

# Where is the link layer implemented?

- in each and every host
- link layer implemented in "adaptor" (aka network interface card NIC) or on a chip
  - Ethernet card, 802.11card; Ethernet chipset
  - implements link, physical layer
- attaches into host's system buses
- combination of hardware, software, firmware



# Adaptors communicating




- sending side:
  - encapsulates datagram in frame
  - adds error checking bits, rdt, flow control, etc.

- receiving side
  - looks for errors, rdt, flow control, etc
  - extracts datagram, passes to upper layer at receiving side

## Error detection

EDC= Error Detection and Correction bits (redundancy)


- D = Data protected by error checking, may include header fields
- Error detection not 100% reliable!
  - protocol may miss some errors, but rarely
  - larger EDC field yields better detection and correction



# Parity checking


### single bit parity:

detect single bit errors



### two-dimensional bit parity:

detect and correct single bit errors



# Internet checksum (review)

goal: detect "errors" (e.g., flipped bits) in transmitted packet (note: used at transport layer only)

### sender:


- treat segment contents as sequence of 16-bit integers
- checksum: addition (I's complement sum) of segment contents
- sender puts checksum value into UDP checksum field

#### receiver:

- compute checksum of received segment
- check if computed checksum equals checksum field value:
  - □ NO error detected
  - YES no error detected. But maybe errors nonetheless?

# Cyclic redundancy check

- more powerful error-detection coding
- view data bits, D, as a binary number
- choose r+1 bit pattern (generator), G
- goal: choose r CRC bits, R, such that
  - <D,R> exactly divisible by G (modulo 2)
  - receiver knows G, divides <D,R> by G. If non-zero remainder: error detected!
  - can detect all burst errors less than r+1 bits
- widely used in practice (Ethernet, 802.11 WiFi, ATM)



# CRC example

### want:

 $D\cdot 2^r$  XOR R = nG


equivalently:

 $D \cdot 2^r = nG XOR R$ 

## equivalently:

if we divide D.2<sup>r</sup> by G, want remainder R to satisfy:

$$R = remainder[\frac{D \cdot 2^r}{G}]$$



# Multiple access links, protocols

## two types of "links":

- point-to-point
  - PPP for dial-up access
  - point-to-point link between Ethernet switch, host
- □ broadcast (shared wire or medium)
  - old-fashioned Ethernet
  - upstream HFC
  - 802.11 wireless LAN



shared wire (e.g., cabled Ethernet)



shared RF (e.g., 802.11 WiFi)



shared RF (satellite)

# Multiple access protocols

- single shared broadcast channel
- □ two or more simultaneous transmissions by nodes: interference
  - collision if node receives two or more signals at the same time

## multiple access protocol

- distributed algorithm that determines how nodes share channel, i.e., determine when node can transmit
- communication about channel sharing must use channel itself!
  - no out-of-band channel for coordination

# An ideal multiple access protocol

# given: broadcast channel of rate R bps desiderata:

- I. when one node wants to transmit, it can send at rate R.
- 2. when M nodes want to transmit, each can send at average rate R/M
- 3. fully decentralized:
  - no special node to coordinate transmissions
  - no synchronization of clocks, slots
- 4. simple

# MAC protocols: taxonomy


### three broad classes:

- □ channel partitioning
  - divide channel into smaller "pieces" (time slots, frequency, code)
  - allocate piece to node for exclusive use
- □ random access
  - channel not divided, allow collisions
  - "recover" from collisions
- "taking turns"
  - nodes take turns, but nodes with more to send can take longer turns

## Channel partitioning MAC protocols: TDMA

## TDMA: time division multiple access


- access to channel in "rounds"
- each station gets fixed length slot (length = pkt trans time) in each round
- unused slots go idle
- example: 6-station LAN, 1,3,4 have pkt, slots
  2,5,6 idle



## Channel partitioning MAC protocols: FDMA

## FDMA: frequency division multiple access

- channel spectrum divided into frequency bands
- each station assigned fixed frequency band
- unused transmission time in frequency bands go idle
- example: 6-station LAN, 1,3,4 have pkt, frequency bands 2,5,6 idle



# Random access protocols

- when node has packet to send
  - transmit at full channel data rate R.
  - no a priori coordination among nodes
- $\square$  two or more transmitting nodes  $\rightarrow$  "collision",
- random access MAC protocol specifies:
  - how to detect collisions
  - how to recover from collisions (e.g., via delayed retransmissions)
- examples of random access MAC protocols:
  - slotted ALOHA
  - ALOHA
  - CSMA, CSMA/CD, CSMA/CA

## Slotted ALOHA


### assumptions:

- □ all frames same size
- time divided into equal size slots (time to transmit I frame)
- nodes start to transmit only slot beginning
- nodes are synchronized
- if 2 or more nodes transmit in slot, all nodes detect collision

### operation:

- when node obtains fresh frame, transmits in next slot
  - if no collision: node can send new frame in next slot
  - if collision: node retransmits frame in each subsequent slot with prob. p until success

## Slotted ALOHA



### **Pros:**

- single active node can continuously transmit at full rate of channel
- highly decentralized: only slots in nodes need to be in sync
- simple

### Cons:

- collisions, wasting slots
- idle slots
- nodes may be able to detect collision in less than time to transmit packet
- clock synchronization

# Slotted ALOHA: efficiency

efficiency: long-run fraction of successful slots (many nodes, all with many frames to send)

- suppose: N nodes with many frames to send, each transmits in slot with probability p
- prob that given node has success in a slot =  $p(1-p)^{N-1}$
- prob that any node has a success =  $Np(1-p)^{N-1}$

- max efficiency: find p\* that maximizes
  Np(I-p)<sup>N-I</sup>
- for many nodes, take limit of Np\*(I-p\*)<sup>N-I</sup> as N goes to infinity, gives:


max efficiency = 1/e = .37

at best: channel used for useful transmissions 37% of time!



# Pure (unslotted) ALOHA

- unslotted Aloha: simpler, no synchronization
- when frame first arrives
  - transmit immediately
- collision probability increases:
  - $\blacksquare$  frame sent at  $t_0$  collides with other frames sent in



# Pure ALOHA efficiency

P(success by given node) = P(node transmits) ·

P(no other node transmits in  $[t_0-I,t_0]$ .

P(no other node transmits in  $[t_0-I,t_0]$ 

$$= p \cdot (I-p)^{N-1} \cdot (I-p)^{N-1}$$
$$= p \cdot (I-p)^{2(N-1)} \longrightarrow \infty$$

... choosing optimum p and then letting n

$$= 1/(2e) = .18$$

even worse than slotted Aloha!

# CSMA (carrier sense multiple access)

### **CSMA:** listen before transmit:


if channel sensed idle: transmit entire frame

if channel sensed busy, defer transmission

human analogy: don't interrupt others!

## **CSMA** collisions

- collisions can still occur:
  propagation delay means
  two nodes may not hear
  each other's
  transmission
- collision: entire packet transmission time wasted
  - distance & propagation delay play role in in determining collision probability






t.

# CSMA/CD (collision detection)

## CSMA/CD: carrier sensing, deferral as in CSMA

- collisions detected within short time
- colliding transmissions aborted, reducing channel wastage
- collision detection:
  - easy in wired LANs: measure signal strengths, compare transmitted, received signals
  - difficult in wireless LANs: received signal strength overwhelmed by local transmission strength
- human analogy: the polite conversationalist

# CSMA/CD (collision detection)



# Ethernet CSMA/CD algorithm

- I. NIC receives datagram from network layer, creates frame
- 2. If NIC senses channel idle, starts frame transmission. If NIC senses channel busy, waits until channel idle, then transmits.
- 3. If NIC transmits entire frame without detecting another transmission, NIC is done with frame!

- 4. If NIC detects another transmission while transmitting, aborts and sends jam signal
- 5. After aborting, NIC enters binary (exponential) backoff:
  - □ after *m*th collision, NIC chooses *K* at random from {0,1,2,..., 2<sup>m</sup>-1}. NIC waits K·512 bit times, returns to Step 2
  - longer backoff interval with more collisions

# CSMA/CD efficiency

- $\Box$   $T_{prop}$  = max prop delay between 2 nodes in LAN
- $\Box$  t<sub>trans</sub> = time to transmit max-size frame

$$efficiency = \frac{1}{1 + 5t_{prop}/t_{trans}}$$

- efficiency goes to I
  - $\square$  as  $t_{prop}$  goes to 0
  - as t<sub>trans</sub> goes to infinity
- better performance than ALOHA: and simple, cheap, decentralized!