


### Overview

- Pipeline data-path
- Challenges in ILP realization
- Data-dependence
- Pipeline hazards and their solutions
- Out-of-order execution
- Branch prediction
- Dynamic scheduling
- VLIW and superscalar processors

### Building a Car


- Non pipeline example car assembly line
  - Note that in each time unit, only one sub-task is active (other 4 sub-tasks are idle)



Advantage: Low CPI(1)

Disadvantage: Long clock period(to accommodate slowest instruction)

### Single cycle and multi-cycle




Advantage: Short clock period


Disadvantage: High CPI

### Pipeline datapath (Part 1/3)


- Pipelining allows multiple sub-tasks to be carried out simultaneously using independent resources
- Need to balance time taken by each sub-task




### Pipeline datapath (Part 2/3)



### Pipeline datapath (Part 3/3)



### Ideal Pipelining




- So an n-stage pipeline means that the CPU can operate at a maximum of n times faster than without a pipeline (ideally!).
- There is an increase in latency due to register delays.

### Pipelined datapath – example 1 (Part 1/5)


LDUR X0, [X1,#100]

Representation scheme: write on first half cycle of clock and read on second half cycle of clock




### Pipelined datapath – example 1 (Part 2/5)

LDUR X0, [X1,#100]




### Pipelined datapath – example 1 (Part 3/5)

LDUR X0, [X1,#100]




### Pipelined datapath – example 1 (Part 4/5)


LDUR X0, [X1,#100]




### Pipelined datapath – example 1 (Part 5/5)




### Example of ideal pipelining






### Example of ideal pipelining




Each row of **reservation table** corresponds to a **pipeline** stage and each column represents a clock cycle.

### Pipelined datapath – example 2

ADD X14, X5, X6	LDUR X13, [X1,48]	ADD X12, X3, X4	SUB X11, X2, X3	LDUR X10, [X1,40]
Instruction fetch	Instruction decode	Execution	Memory	Write-back




# Synchronization of the control signals in pipelined datapath



	Instruction decode stage control lines	calc	ution/add ulation sta ontrol line	ige		Memory acc tage control	Write-back stage control lines		
Instruction	Reg2Loc	ALUOp1	ALUOp0	ALUSrc	Branch	MemRead	MemWrite	RegWrite	MemtoReg
R-format	0	1	0	0	0	0	0	1	0
LDUR	X	0	0	1	0	1	0	1	1
STUR	1	0	0	1	0	0	1	0	Х
CBZ	1	0	1	0	1	0	0	0	X

### Pipelined datapath and control



### Challenges in instruction pipelining realisation

#### Ideal pipeline

- Identical task of all instructions
- Uniform decomposition of task
- Independent computations

# So is pipeline always moving?

#### Real pipeline

- Except load instruction all other instructions do not need all stages
- Not all pipeline stages involve the same time to complete their respective sub-tasks
- The execution of one instruction may depend on one of the preceding instructions

#### **Complications**

- Datapath
  - Many instructions in flight
- Control
  - Must correspond to multiple instructions
- Instructions may have
  - data and control flow dependences
  - One may have to stall and wait for another

### Fundamental issues in pipelining

- Balancing work in pipeline stages
  - How many stages and what is done in each stage
- Keeping the pipeline correct, moving, and full in the presence of events that disrupt pipeline flow
  - Handling dependences
    - Data
    - Control
  - Handling resource contention
  - Handling resource contention
- Advanced: Improving pipeline throughput
  - Minimizing stalls

### Pipeline Hazards (Part 1/2)

- Stalling of the pipeline drop in efficiency (hazard).
- Various types of hazards are data hazard, control/instruction hazard and structural hazard.
- Structural hazard: If two instructions require to use of a given hardware resource at the same time that will lead to a stall in the pipeline (one instruction has to wait at least for a clock cycle).

Example: Consider we have only one memory. For a case when write stage access the memory for writing the result and the instruction fetch stage tries to fetch the instruction from the memory at the same time.


Without two memories –structural hazard.

 Data hazard: either the source or destination register of an instruction are not available at the time expected in the pipeline. Hence results in pipeline stalls.

### Pipeline Hazards (Part 2/2)

 Control/Instruction hazard: Conditional and unconditional jumps, subroutine calls, and other program control instructions can stall a pipeline because of a delay in the availability of an instruction.

If missed, the instruction has to be fetched from main memory which introduces delay in the instruction fetch and the pipeline stalls.



### Solutions to solve pipeline hazard

#### Structural hazard

Can be solved by additional hardware elements

#### Data hazard

 Need to know the dependencies between data in the program and eliminate them

#### Control Hazard

 Need to predict the location of conditional /unconditional branch to avoid stalling

### Data Dependencies

#### Types of data dependences

 True/flow dependence (RAW – read after write) – j cannot execute until i produces its result

( i and j are two different instructions)

- Output dependence (WAW write after write) j cannot write its result until i has written its result
- Anti dependence (WAR write after read) j cannot write its result until i has read its sources

### Data Dependencies (example-1)

True/RAW (read-after-write) dependency arise when one instruction relies upon the output from the previous instruction:

```
11: SUB X3, X2, X1; X3 \leftarrow X2 - X1 12: AND X5, X3, X4; X5 \leftarrow X3 & X4
```

Output/WAW (write-after-write) dependency arise when two nearby instructions must write to the same location:

```
11: ADD X0, X2, X1; X0 \leftarrow X2 + X1
12: SUBI X0, X3, X1; X0 \leftarrow X3 - 1
```

The SUBI must wait until ADD finishes writing.

Anti/WAR (write-after-read) dependency in the bellow example, because the ANDI must not change the value of X1 before the ADD has used the value that is in X1.

11:	ADD	X0, X2, <b>X1</b> ;	$X0 \leftarrow X2 + X1$
12:	ADDI	X1, X3, #2;	X1 ← X3 + 2


### How to handle data dependencies

- Anti and output dependences are easier to handle
- True (Flow or RAW) dependences are more difficult to handle as they constitute true dependence on a value

#### Five fundamental ways of handling True dependences

- Detect and wait until value is available in register file
  - Stall the program. (HARDWARE)
  - Compiler can also plug in the NOP instructions in between. (SOFTWARE)
- Detect and forward / bypass data to dependent instruction
- Detect and eliminate the dependence at the software level
  - No need for the hardware to detect dependence
- Predict the needed value(s), execute "speculatively", and verify
- Do something else (fine-grained multithreading)
  - No need to detect

### Detect and wait




#### Hardware stall

Instr.	1	2	3	4	5	6	7	8	9
I1	IF	ID	EX	M	WB				
12		IF	S	S	S	ID	EX	M	WB

#### **Software inserting NOPs**

Instr.	1	2	3	4	5	6	7	8	9
I1	IF	ID	EX	M	WB				
3NOPs									
12					IF	ID	EX	M	WB

### Data Forwarding – through register



Solution: write and read in the same cycle Most processors have this as it is easy to implement


# What happens when same register is read and written during same clock cycle?

#### Slide from last module

- The register read happens combinational (no clock)
- The register will be valid during the time it is read.
- The value returned will be the value written in the earlier clock cycle.
- The write of the register file occurs on the clock edge.
- If we want to read to return the value currently being written- we need additional logic.

## Regfile program from lab2

```
reg ['DSIZE-1:0] regdata [0:'NREG-1];
integer i;
     always@(posedge clk)
           begin
                if(rst)
                      begin
                           for (i=0; i<`NREG; i=i+1)
                           regdata[i] <=0;
                      end
                else
           regdata[waddr] <=((wen == 1)) ? wdata : regdata[waddr];
           end
assign rdata1 = ((wen) && (waddr == raddr1)) ? wdata : regdata[raddr1];
assign rdata2 = ((wen) && (waddr == raddr2)) ? wdata : regdata[raddr2];
```



### Data forwarding – example 2

## Without forwarding (writeback and decode can happen simultaneously)

11: ADD X1, X2, X3

12: SUB X2, X1, X2

13: AND X6, X7, X1

									, ,		
	Clocks	1	2	3	4	5	6	7	8	9	10
	l1	IF	ID	EX	M	WB					
	12		IF	S	S	ID	EX	M	WB		
	13					IF	ID	EX	M	WB	

#### With forwarding

Clock cycle	1	2	3	4	5	6	7
l1	IF	ID	EX	M	WB		
12		IF	ID	EX	M	WB	
13			IF	ID	EX	M	WB

Steady state CPI = (No of instructions + no of stalls ) / No of instructions Steady state CPI (no forwarding) = (3 + 2)/3 = 5/3 Steady state CPI (forwarding) = 3/3 = 1

#### In-order and out of order execution

- In-order instruction execution
  - instructions are fetched, executed & completed in compiler generated order
  - one stalls, they all stall
  - instructions are statically scheduled
- Out-of-order instruction execution
  - instructions are fetched in compiler-generated order
  - but they may be executed in some other order
  - independent instructions behind a stalled instruction may pass it
  - instructions are dynamically scheduled during run time

### Dynamic Scheduling

#### Out-of-order processors:

#### After instruction decode

- check for structural hazards:-
  - an instruction can be issued when a functional unit is available
  - an instruction stalls if no appropriate functional unit is free in that clock cycle
- check for data hazards:-
  - an instruction can execute if its operand has been loaded in the register
  - an instruction stalls if operands are not available
- don't wait for previous instructions to execute if this instruction does not depend on them,
   i.e., independent ready instructions can execute before earlier instructions that are stalled

#### in-order processors

LDUR X1, [X4, #100] ADD X2, X1, X4 (need to wait till the value is loaded) SUB X5, X6, X7 out-of-order processors LDUR X1, [X4, #100] SUB X5, X6, X7 ADD X2, X1, X4(no stalls)

### Instruction Reordering

LDUR	X1, [X0, #0]	LDUR	X1, [X0, #0]
LDUR	<b>X2</b> , [X0, #4]	LDUR	X2, [X0, #4]
ADD	X3, X1, <b>X2</b>	LDUR	X4, [X0, #8]
STUR	X3, [X0, #12]	ADD 🥌	X3, X1, X2
LDUR	<b>X4</b> , [X0, #8]	STUR	X3, [X0, #12]
ADD	X5, X1, <b>X4</b>	ADD	X5, X1, X4
STUR	X5, [X0, #16]	STUR	X5, [X0, #16]

ready instructions can execute before earlier instructions that are stalled – Key idea behind out of order execution

Any other techniques to reduce stalling?

### Register Renaming

```
X4, X2, X1;
         ADD
                                   X4 \leftarrow X2 + X1
WAR
                   X1, X0, #2;    X1 \leftarrow X0 & 2
         ANDI
                  Rename X1 to X3
                   X4, X2, X1; X4 \leftarrow X2 + X1
         ADD
         AND
                   X3, X0, #2; X3 ← X0 & 2
WAW
                   X0, X2, X1;
        ADD
                               X0 ← X2 + X1
                   X0, X3, X5; X0 \leftarrow X3 - X5
         SUB
                  Rename X0 to X4
                   X0, X2, X1; X0 \leftarrow X2 + X1
         ADD
         SUB
                   X4, X3, X5: X4 \leftarrow X3 - X5
```

More register resources will be needed

#### Loop unrolling

- loop unrolling leads to multiple replications of the loop body
  - unrolling creates longer code sequences
  - goal is to execute iterations in parallel
- Example

```
for (i=0: i < 16; i++) {
c[i] = a[i]+ b[i];
}
```



```
for (i=0: i < 8; i++) {
c[2 * i] = a[2 * i] + b[2 * i];
c[2 * i+1] = a[2 * i+1] + b[2 * i+1];
}
```

- greater demand for registers
  - higher register pressure: more concurrency demands for more resources
     How can loop unrolling help us to reduce the stalls and to improve CPI?

## Loop unrolling example (Part 1/3)

```
X0, [X1, #0];
Loop:
        LDUR
                                   load to X0 from mem[0+X1]
        ADD
                 X4, X0, X2;
                                   add [X0]+[X2]
        STUR
                 X4, [X1, #0];
                                   store X4 to mem[0+X1]
        SUBI
                 X1, X1, #8;
                                   decrement pointer 8
        CBNZ
                                    branch X1!=zero
                 X1,Loop;
```

```
X0, [X1, #0]
1. Loop: LDUR
2.
         stall
                                       If full data forwarding is
3.
         ADD
                  X4, X0, X2
                                   allowed then we will have one
4.
         STUR
                  X4, [X1, #0]
                                     stall for data dependency
5.
         SUBI
                  X1, X1, #8;
6.
         CBNZ
                  X1,Loop;
```

CPI = (No of instructions + no of stall) / No. of instruction = (5 + 1) / 5 = 1.2

## Loop unrolling example (Part 2/3)

I Loop:	LDUR	<b>X0</b> , [X1, #0] <b>1 stall here</b>	
2	ADD	<b>X4</b> , <b>X0</b> , X2	
3	STUR	<b>X4</b> , [X1, #0] ;drop \$UB1 & CBNZ	
4	LDUR	<b>X6</b> , [X1, #-8]	
5	ADD	X8, X6, X2	
6	STUR	<b>X8</b> , [X1, #-8] ;drop SUBI & BNEZ	full data forw
7	LDUR	<b>X10</b> , [X1,#-16]	
8	ADD	X12, X10, X2	is allowed
9	STUR	<b>X12</b> , [X1, #-16] / ;drop SUBI & BNEZ	
10	LDUR	<b>X14</b> , [X1, #-24]	
11	ADD	X16, X14, X2	
12	STUR	<b>X16, [X1, #</b> -24]	
13	SUBI	<b>X1</b> , X1, #32 ;alter to 4*8	Rewrite loop to mini
14	CBNZ	X1,LOOP	

STRAIGHT FORWARED UNROLLING, CPI= (14+4)/14=1.286

warding

imize stalls?

## Loop unrolling example (Part 3/3)

# Branch is not handled here

1 Loop:	LDUR	<b>X0</b> , [X1, #0]	(°)		
2	ADD	<b>X4</b> , <b>X0</b> , X2	1 Loop:	LDUR	X0, [X1, #0]
2			2	LDUR	X6, [X1, #-8]
3	STUR	<b>X4</b> , [X1, #0]	3	LDUR	X10, [X1,#-16]
4	LDUR	<b>X6</b> , [X1, #-8]	3		
5	ADD	<b>X8, X6,</b> X2	4	LDUR	X14, [X1,#-24]
			5	ADD 📥	X4, X0, X2
6	STUR	<b>X8</b> , [X1, #-8]	6	ADD	X8, X6, X2
7	LDUR	<b>X10</b> , [X1,#-16]	7		
8	ADD	X12, X10, X2	/	ADD	X12, X10, X2
9	STUR		8	ADD	X16, X14, X2
·		<b>X12</b> , [X1, #-16]	9	STUR	X4, [X1, 0]
10	LDUR	<b>X14</b> , [X1,#-24]			· • · •
11	ADD	<b>X16, X14</b> , X2	10	STUR	X8, [X1, #-8]
12	STUR		11	STUR	X12, [X1, #-16]
		X16, [X1, #-24]	12	STUR	X16, [X1, #-24]
13	SUBI	<b>X1</b> , X1, #32	<del></del>		•
14	CBNZ	X1,LOOP	13	SUBI	X1, X1, #32
	J = . \ <b>=</b>	211,200	14	CBNZ	X1,LOOP

STRAIGHT FORWARED UNROLLING, CPI= (14+4)/14=1.286

Rearranging after unrolling, CPI=(14/14)=1

Full dataforwarding

#### How data hazards can be eliminated?

#### Summary

- Detect and wait (stalling unnecessarily)
- Data forwarding
- Reordering (out of order)
- Renaming (to remove WAR and WAW hazard)
- Loop unrolling and reordering

#### Control Hazards

- Branching instructions
  - pipeline to stall as it changes the execution sequence of instructions.
- Unconditional and conditional branches: In decode stage of branch the decoding unit comes to know that there is an alteration in the program control flow.
  - Incorrectly fetched instruction by the instruction fetch unit must be discarded.
  - New instruction specified by the conditional or unconditional branch must be fetched by the instruction fetch unit. This causes stalls (bubble) in the pipeline. Example: B, CBZ
- The time lost as a result of a branch instruction is often referred to as the branch penalty.

#### How to tackle control hazards

#### Conservative way

- Stall the pipeline immediately after we fetch a branch instruction, waiting until the pipeline determines the outcome of the branch and knows the address of next instruction to be fetched
- 3 stalls without forwarding and 2 stalls with forwarding

#### Branch prediction

- Simple way is to predict always that the branches will be untaken
- Only when branches are taken does the pipeline stall


### Control Hazards (stall)

**Example** 

CBZ X1, loop

Loop: LDUR X3, [X0, #30]

Clock	1	2	3	4	5	6	7	8	9
I1	IF	ID	EX	M	WB				
12		nop	nop	nop	nop	nop			
13			nop	nop	nop	nop	nop		
14				nop	nop	nop	nop	nop	
15					IF	ID	EX	M	WB



CBZ updating PC in MEM stage
Branch penalty=
3 stalls

If data forwarding allowed:
Then CBZ can update PC in EXE stage.
Branch penalty=
2 stalls

44


## Early Evaluation of PC for reducing branch stalls

Example CBZ X1, loop

.....

Loop: LDUR X3, [X0, #30]

Clock	1	2	3	4	5	6	7	8	9	10	11
<b>I</b> 1	IF	ID	EX	M	WB						
12		nop	nop	nop	nop	nop					
15			IF	ID	EX	M	WB				



#### Need for branch prediction

# Modified LEGv8 pipeline with branch address and outcome calculated in second stage. (needs only one stall)

- With the branch decision made during ID stage, there is a reduction of the cost associated with each branch (branch penalty):
- We need only one-clock-cycle stall after each branch
- Or a flush of only one instruction following the branch
- One-cycle-delay for every branch still yields a performance loss of 10% to 30% depending on the branch frequency:
- Pipeline Stall Cycles per Instruction due to Branches = Branch frequency x Branch Penalty

#### Branch Prediction

**Branch prediction** deals with branch penalty by continuing executing the instructions following the branch <u>speculatively</u>.

- If the branch does not occur then there was no pipeline stall.
- If, however, the branch does occur, the pipeline must be flushed of the speculative instructions.
- On average, this reduces pipeline stalls by 50%.

**Static branch prediction** techniques:- The actions for the branch are fixed for each branch during the entire execution. (when behaviour is highly predictable).

**Dynamic branch prediction techniques:**- The prediction decision may change depending on the execution history (when behaviour is not predictable).

## Static Prediction (Part 1/2)

**Static branch prediction** is used in processors where the expectation is that the branch behaviour is highly predictable at compile time.

#### a) Branch Always Not Taken – Predict-Not-Taken (Speculation)

- Execute successive instructions in sequence.
- Flush the pipeline and read correct instructions if branch actually taken.

#### b) Branch Always Taken – Predict-Taken

- The predicted-taken scheme makes sense for pipelines where the branch target address is known before the branch outcome.
- But in LEGv8 pipeline we haven't calculated yet branch target address, still incurs branch penalty.

#### c) Delayed branch

## Static Prediction (Part 2/2)

Example with <u>speculative execution</u> (predict not taken):

```
i1:
            ADD
                         X3, X1, #2
i2:
            CBZ
                         X3, L1
i3:
                         X1, X0, X0
            ADD
                         X4, X1, X2
i4:
            AND
                         X4,[X5,#0]
i5:
      L1
            SW
```

(Assume branch solved in ID stage)

Instr.	1	2	3	4	5	6	7	8
I1	IF	ID	EX	M	WB			
12		IF	ID					
13			IF	F	F	F	F	
15				IF	ID	EX	M	WB

Instr.	1	2	3	4	5	6	7	8
I1	IF	ID	EX	M	WB			
12		IF	ID					
13			IF	ID	EX	М	WB	
14				IF	ID	EX	М	WB
15					IF	ID	EX	M

#### Branch taken


- 1. Need to **flush** the next instruction already fetched.
- 2. Restart the execution by fetching the instruction at the branch target address **One-cycle penalty.**

#### Branch not taken

### Static Prediction – Delayed Branch (Part 1/3)

- The compiler statically schedules an independent instruction in the branch delay slot.
- The instruction in the branch delay slot is executed whether or not the branch is taken.
- If we assume a branch delay of one-cycle (as for modified LEGV8) ->we have only one-delay slot.
- The LEGv8 compiler always schedules a branch independent instruction after the branch.

### Static Prediction – Delayed Branch (Part 2/3)




A previous **add** instruction with no effects on the branch is scheduled in the **Branch Delay Slot**.

### Static Prediction – Delayed Branch (Part 3/3)


 The behaviour of the delayed branch is the same whether or not the branch is taken.

If the branch is untaken → execution continues with the instruction.

after the branch.



If the branch is taken → execution continues at the branch target.



### Dynamic Prediction


**Dynamic branch prediction** usually relies on some measure of past behaviour to predict the future.

- When CPU sees a branch, it uses the hardware predictor to make a decision of which path to speculate on.
- Later on when the branch outcome is known, it updates the predictor.

#### Dynamic Prediction (One bit)

#### **Scheme 1: Single T bit** (Last time predictor)

T is set to 1 when a branch is confirmed taken, 0 when not.



#### **Example:**

Assume single bit predictor for branch b1. Initial value of predictor to be 0. Then  $T_{b1}$  predicts that the branch is not taken.

branch b1 taken,  $T_{b1} = 1$  (predict next branch taken) branch b1 not taken,  $T_{b1} = 0$  (predict next branch not taken)

## Dynamic Prediction (One bit predictor)


- T is set to 1 when a branch is confirmed taken, 0 when not.
- Consider that you start from predict not taken
- Always mis-predicts the last iteration and the first iteration of a loop branch
- TNTNTNTNTNTNTNTNTN  $\rightarrow$  0% accuracy

#### Improving one bit predictor

- Problem: A last-time predictor changes its prediction from Taken(T)→Not taken (N) or N→T too quickly
  - even though the branch may be mostly taken or mostly not taken.
- Solution Idea: Add hysteresis to the predictor so that prediction does not change on a single different outcome
   Use two bits to track the history of predictions for a branch instead of a single bit
  - Can have 2 states for T or N instead of 1 state for each.

Ref: Smith, "A Study of Branch Prediction Strategies," ISCA 1981.

## Dynamic Prediction (Part 1/2)



**Scheme 2: 2 bit prediction** uses the result of last two branches to predict instead of just the last branch.

- TNTNTNTNTNTNTNTNTN → 50% accuracy
- (assuming initial to probable (weakly taken)
- Disadvantage: More hardware

#### Dynamic Prediction (Part 2/2)

- Scheme 3: Bimodal prediction uses a counter and the state of that counter determines the prediction.
- Generalized scheme of 3 bit predictor.
- The counter is incremented if branch is taken.
- The counter is decremented if branch not taken.
- Counters saturate (no wraparound). The speculation decision is based on the most significant bit: if MSB is 1, then counter is above half way.


$$000 \rightarrow 001 \rightarrow 010 \rightarrow 011 \rightarrow 100 \rightarrow 101 \rightarrow 110 \rightarrow 111$$

## Instruction-level parallelism (ILP)

- Execution of more than one instruction at the same time (in parallel)
   => Instruction Level Parallelism (ILP)
- Multi-issue datapath => Datapath that allow execution of two or more instructions in parallel
- N-issue architecture => Executes 'N' instructions at the same time


#### ILP and Multi-issue processors

1 instruction issued in a clock cycle
=> single-issue processor



Pipelined processor

Scalar processor



Multi-issue/super scalar processor =>2 or more instructions are issued in a clock cycle

## Instruction-level parallelism (ILP) (Part 1/2)

Parallel execution of instructions requires 3 major tasks:

- Which instructions should be executed in parallel?
   Checking the data dependence between instructions to identify the instructions which can be grouped together for parallel execution.
- 2. Where to be executed?
  Assigning instructions to different functional units in the processor.
- 3. When to be executed?


  Determining when instruction execution is to be initiated.

## Instruction-level parallelism (ILP) (Part 2/2)

#### Two approaches to achieve ILP

- Hardware Approach: Superscalar Processor
  - P5 Pentium, the first superscalar X86 processor
  - Most general purpose CPU's developed since 1998 are superscalar
- Software (or compiler-based) Approach: Very Long Instruction
   Word(VLIW) processor
  - VLIW CPU's contain multiple RISC like Functional Units(FUs). Typically have 4 to 8 FUs.


#### Hardware and Software Approaches



FU: Functional unit

EPIC: Explicitly parallel instruction computing


# Concept of Superscalar Processing



#### Requirement of superscalar processing


- Multiple functional units (FU) in a CPU are used to execute more than one instructions concurrently in a clock cycle.
- More than 1 independent instructions need to be available to be executed. (Makes use of ILP)
- Use specialized hardware to issue multiple independent instructions that can be executed simultaneously.

#### Scalar vs Superscalar



#### Out-of-order execution in SS pipeline

- Instructions are fetched in compiler-generated order (in-order).
- Instruction completion may be also in order.
- Instructions are executed in some other order: independent instructions behind a stalled instruction can be executed prior to the stalled instruction.
- Dynamically scheduled: the order of execution of instructions is changed.



#### Methods to extract more parallelism

- 1. Instruction reordering and out-of-order execution,
- 2. Speculative execution with dynamic scheduling,
- 3. Loop unrolling
- Instruction Reordering: Change the order of execution of instruction if it does not violate the data dependence.
- Speculative Execution: To execute a instruction without exactly knowing if that need to be executed: ahead of branch outcome.
- Dynamic Scheduling: Execute instructions as soon as dependencies are satisfied and functional units are available.

#### Loop unrolling for ILP

- loop unrolling leads to multiple replications of the loop body
  - Multiple independent instructions that can be executed in parallel
- Example

```
for (i=0: i < 16; i++) {
c[i] = a[i]+ b[i];
}
```



Original loop

```
for (i=0: i < 8; i++) {
c[2 * i] = a[2 * i] + b[2 * i];
c[2 * i+1] = a[2 * i+1] + b[2 * i+1];
}
```

Unrolled by a factor 2

How can loop unrolling help us to produce multiple independent instructions?

### Example: Scheduling for superscalar (Part 1/2)

LOOP: LDUR X0, [X1, #0]
ADDI X0, X0, #25
STUR X0, [X1, #0]
ADDI X1, X1, #8
SUBI X2, X2, #1
CNBZ X2, Loop

# load an array element
# add that with 25
# store back the result
# find address of the next element in dmem
# find the remaining no. of iterations
# continue iterations if x2!= 0

## Example: Scheduling for superscalar (Part 2/2)

Loop: LDUR X0, [X1, #0] (2 stalls)

ADDI X0, X0, #25 (2 stalls)

STUR X0, [X1, #0]

ADDI X1, X1, #8

SUBI X2, X2, #1 (2 stalls)

CBNZ X2, Loop (1 stall)

Control hazard is removed in decode stage (1 stall cycle)

CPI = (6+7)/6=2.17 without reordering in a scalar processor


2-way super-scalar after instruction reordering CPI = 7/6 (No data-

forwarding is done)

	Way-1	Way-2	Cycle
Loop	SUBI X2, X2, #1	LDUR X0, [X1, #0]	1
	nop	nop	2
	nop	nop	3
	ADDI X0, X0, #25	nop	4
	ADDI X1, X1, #8	nop	5
	CBNZ X2, Loop	nop	6
	nop	STUR XO, [X1, #0]	7

# Loop unrolling and instruction reordering (Part 1/3)

Loop: LDUR X0, [X1, #0]
ADDI X0, X0, #25
STUR X0, [X1, #0]
ADDI X1, X1, #8
SUBI X2, X2, #1
CBNZ X2, Loop



```
Loop:
            LDUR X0, [X1, #0]
            LDUR X3, [X1, #8]
            LDUR X4, [X1, #16]
            LDUR X5, [X1, #24]
            ADDI X0, X0, #25
            ADDI X3, X3, #25
            ADDI X4, X4, #25
            ADDI X5, X5, #25
            SUBI X2, X2, #4
            STUR X0, [X1, #0]
            STUR X3, [X1, #8]
            STUR X4, [X1, #16]
            STUR X5, [X1, #24]
            ADDI X1,X1, #32
      CBNZ X2, Loop
```


after loop unrolling by 4 and instruction reordering

# Loop unrolling and instruction reordering (Part 2/3)


	Way-1	Way-2	Cycle
Loop	SUBI X2, X2, #4	LDUR X0, [X1, #0]	1
	nop	LDUR X3, [X1, #8]	2
	nop	LDUR X4, [X1, #16]	3
	ADDI X0, X0, #25	LDUR X5, [X1, #24]	4
	ADDI X3, X3, #25	nop	5
	ADDI X4, X4, #25	nop	6
	ADDI X5, X5, #25	STUR X0, [X1, #0]	7
	ADDI X1,X1, #32	STUR X3, [X1, #8]	8
	CBNZ X2, Loop	STUR X4, [X1, #16]	9
	nop	STUR X5, [X1, #24]	10

2-way super-scalar after 4-unrolling and reordering : CPI = 10/15 = 2/3

Loop unrolling and instruction reordering



## Different stages in superscalar pipeline



Fetch multiple instructions in every clock cycle and store in instruction buffer(IB)

Decode the instructions available in the instruction buffer.


Instructions are issued into functional units as and when their operands and respective functional units are available.

Instructions are marked 'finished' when executed, and enter the reorder buffer (in out-of-order)

Instructions exit the ROB (in order). Results are written in the processor registers in order.

performs memory update if any (usually D-cache).

### Superscalar execution




Superscalar processor solves the data hazard, control hazard, and memory-latency problems

#### VLIW processing strategy

- Packs multiple independent operations into one instruction.
- VLIW processor needs a compiler to break the program instructions down into basic operations that can be performed by the processor in parallel.
- These operations are put into a very long instruction word which the processor (consisting of multiple functional units (FU)) gets executed in appropriate FUs.
- There must be enough parallelism in the program code to fill the available slots, to reduce the CPI significantly.

#### VLIW architecture



- Multiple operation execution.
- Many functional units: each is executing its own instruction.
- Typically maximum of 4 or 8 instructions per cycle are issued.

# Advantage and disadvantage of VLIW (Part 1/2)

- Compiler prepares fixed packets of multiple operations: gives the complete plan of execution.
  - Dependencies are determined by compiler and that is used to schedule according to the latencies of corresponding functional units.
  - Functional units are assigned by compiler, they correspond to the position within the instruction packet or instruction slot.
  - Compiler produces fully-scheduled, hazard-free code => hardware need not check dependencies for scheduling.

# Advantage and disadvantage of VLIW (Part 2/2)

- Compatibility across implementations is a major problem.
  - VLIW code cannot run properly with different number of functional units or functional units with different latencies.
  - Unscheduled events (e.g., cache miss) can stall the entire processor.
- Code density is an important concern.
  - Slot utilization varies: nops increase with branching (control).
  - Reduce nops by compression ("flexible/variable-length VLIW").

#### Conclusions

- Basic of multi-issue processing.
- Limitation of scalar pipeline and Motivation for superscalar processors.
- Concept of superscalar processing.
- Basics of superscalar pipeline.
- Instruction execution in a superscalar processor.
- Basics of VLIW processors.