# Unofficial Nord Lead A1 File Structure Documentation

## christian.florentz@gmail.com

# Nord Lead A1 Program File Structure

This mapping corresponds to the Nord Lead A1 program file (file extension nlas).

offset	bits	description
0x0000	ссссссс	ascii C - 0x43, 4-byte Clavia ID
0x0001	ccccccc	ascii B - $0x42$
0x0002	ccccccc	ascii I - 0x49
0x0003	ccccccc	ascii N - 0x4E
0x0004	ffffffff	(f) file format
0x0005		0
0x0006		0
0x0007		0
8000x0	ccccccc	ascii n - 0x6E, 4-byte NLA1 Program file ID
0x0009	ccccccc	ascii l - 0x6c,
A000x0	ccccccc	ascii a - 0x61,
0x000B	ccccccc	ascii s - $0x73$ ,
0x000C	bb	(b) bank $(0 = A, 1 = B \dots)$
0x000D		0
0x000E	111111	(1) location lsb $(0 = 01:1, 1 = 01:2)$
0x000F		0
0x0010	ccccccc	(c) program category
0x0011		
0x0012		
0x0013		
0x0014	iiiiiiii	(i) file version (16-bit)
0x0015	iiiiiiii	
0x0016		
0x0017		
0x0018	ccccccc	CRC1 (32-bit)
0x0019	ccccccc	
0x001A	ccccccc	
0x001B	ccccccc	
0x001C		
0x001D		
0x001E		
0x001F		
0x0020		
0x0021		
0x0022		
0x0023		
0x0024		
0x0025		
0x0026		
0x0027		
0x0028		
0x0029		
0x002A		
0x002B		
0x002C		
0x002D		

offset	bits	description
0x002E		
0x002F		
0x0030		
0x0031		
0x0032		
0x0033		
0x0034		
0x0035		
0x0036		
0x0037		
0x0038		
0x0039		
0x003A		
0x003B		
0x003C		
0x003D		
0x003E		
0x003F		
0x0040		
0x0041 0x0042		
0x0042 0x0043		
0x0043		
0x0044		
0x0046		
0x0047		
0x0048		
0x0049		
0x004A		
0x004B		
0x004C		
0x004D		
0x004E		
0x004F		
0x0050		
0x0051		
0x0052		
0x0053		
0x0054		
0x0055		
0x0056		
0x0057		
0x0058		
0x0059 0x005A		
0x005A 0x005B		
0x005B		
0x005C		
0x005E		
0x005F		
0x0060		
0x0061		
0x0062		
0x0063		
0x0064		
0x0065		
0x0066		
0x0067		
0x0068		

offset	bits	description
0x0069		
0x006A		
0x006B		
0x006C		
0x006D		
0x006E		
0x006F		
0x0070		
0x0071		
0x0072		
0x0073		
0x0074		
0x0075		
0x0076		
0x0077		
0x0078		
0x0079		
0x007A		
0x007B		
0x007C		
0x007D		
0x007E		
0x007F		
0x0080		
0x0081		
0x0082		
0x0083		
0x0084		
0x0085	0-	(o) reverb on
0x0086		
0x0087		
0x0088		
0x0089		
A800x0		
0x008B		
0x008C		

#### NLA1 Reverb On

```
Offset in file: 0x85 (b2)

0 = off, 1 = on
```

### **NLA1 File Version**

```
Offset in file: 0x14 and 0x15

See: Nord Lead A1 - Update History

Nord Lead A1 - 0S Update
v1.02 (2014-03-10)
v1.12 (2014-04-02)
v1.14 (2014-04-04)
v1.20 (2014-04-25)
v1.24 (2014-04-28)
v1.30 (2014-05-12)
v1.32 (2014-05-22)
v1.34 (2015-10-07)
```

16-bit integer value in Little Endian format current supported version are 6 and  $7\,$ 

#### **NLA1** File Format

```
Offset in file: 0x04
0 = header type 0 - legacy format no CRC (Byte 0x18 to 0x2B are missing)
1 = header type 1 - new format with additional bytes 0x18 to 0x2B (20 bytes).

All files exported with Nord Sound Manager v7.40 (2018-12-18) or later are in type 1.
```

### **NLA1 Program Category**

```
Offset in file: 0x10
  0 = Acoustic
  1 = Bass
 2 = Wind
  4 = Fantasy
 5 = FX
  6 = Lead
  7 = Organ
 8 = Pad
  10 = Pluck
 11 = String
  12 = Synth
  13 = Vocal
  14 = User
  17 = None
  21 = Grand
  22 = Upright
 23 = EPiano1
 24 = EPiano2
  27 = Clavinet
  28 = Harpsi
  30 = Arpeggio
```

255 = Undefined