

BINARY-WATCH assembly cheat sheet





BinaryWatch PCB is made with small SMT components.

There are several ways how to assemble the SMT components, the harder one requires no extra tools bit experience with soldering iron, good eyesight. You hold the components with tweezers then solder the legs one by one.

Easier assembly process for SMT components requires some tools and preparation and follows these steps:

- 1. Apply solder paste
- 2. Place the components
- 3. Reflow

Capacitors:

Name	Size	Value
C1	0603	100nF, 50VDC, 10%
C2, C3	0603	10pF, 50VDC, 10%

Resistor matrices:

Name	Size	Value
RM1, RM2, RM3	4×0603	4.7K, 5%

LEDs:

Warning! They have polarity! Green mark indicates cathode and should be facing top!

Name	Size	Value
LED1LED6	0603	GREEN 100mCd
LED7LED11	0603	RED 100 mCd

Buttons:

Name	Value
BUT1, BUT2	WTCM-TR

MCU:

Warning first pin is marked with DOT!

Name	Size	Value
U1	SSOP28	PIC16F722A-I/SS

Quartz:

Name	Size	Value
Q1		CM7V-T1A 32.768kHz 12.5pF 20ppm

BAT holder:

Name	Value
3V-LI_BAT	BC2001