

### 6. Data transmission

- \* digital representation
- \* digital and analog transmission
- \* asynchronous and synchronous communications
- \* transmission media

## 7-Layer OSI Reference Model



## Digital transmission enables networks to support many services



## 6.1 Digital representation

- Bit: number with value 0 or 1
  - *n* bits: digital representation for  $0, 1, ..., 2^n$
  - byte or octet, n = 8
  - computer word, n = 16, 32, or 64
- n bits allows enumeration of  $2^n$  possibilities
  - *n*-bit field in a header
  - *n*-bit representation of a voice sample
  - message consisting of n bits
- The number of bits required to represent a message is a measure of its information content
  - more bits  $\rightarrow$  more content

#### **Block**


- Information that occurs in a single block
  - text message
  - data file
  - JPEG image
- size = bits / blockor bytes/block
  - 1 Kbyte =  $2^{10}$  bytes
  - 1 Mbyte =  $2^{20}$  bytes
  - 1 Gbyte =  $2^{30}$  bytes

#### **Stream**

- Information that is produced
   & transmitted *continuously*
  - real-time voice
  - MP3 audio
  - streaming video (H.261, MPEG-2)
- Bit rate = bits / second (bps)
  - 1 Kbps =  $10^3$  bps
  - 1 Mbps =  $10^6$  bps
  - 1 Gbps =  $10^9$  bps


### **Stream information**

- a real-time voice signal must be digitized & transmitted as it is produced
- analog signal level varies continuously in time



## Digitization of analog signal


- sample analog signal in time
- find closest approximation quantization



 $R_s$  = bit rate = # bits/sample x # samples/second


## Video signal

- sequence of picture frames
  - each picture digitized & compressed
- frame repetition rate
  - 10-30-60 frames/second (fps), depending on quality
- frame resolution
  - small frames for videoconferencing
  - standard frames for conventional broadcast TV
  - HDTV frames



Rate = M bits/pixel x (WxH) pixels/frame x F frames/second

### Video frames



# Digital video signals

Type	Method	Format	Original	Compressed
Video Conference	H.261	176x144 or 352x288 pix @10-30 fps	2-36 Mbps	64-1544 Kbps
Full Motion	MPEG-2	720x480 pix @30 fps	249 Mbps	2-6 Mbps
HDTV	MPEG-2	1920x1080 @30 fps	1.6 Gbps	19-38 Mbps

### Transmission of stream information

- Constant bit-rate
  - Signals such as digitized telephone voice produce a steady stream: e.g. 64 Kbps
  - Network must support steady transfer of signal, e.g. 64
     Kbps circuit
- Variable bit-rate
  - Signals such as digitized video produce a stream that varies in bit rate, e.g. according to motion and detail in a scene
  - Network must support variable transfer rate of signal, e.g. packet switching or rate-smoothing with constant bit-rate circuit

## 6.2 Digital and analog transmission



#### Transmitter

- converts information into *signal* suitable for transmission
- injects energy into communications medium or channel
  - telephone converts voice into electric current
  - modem converts bits into tones

#### Receiver

- receives energy from medium
- converts received signal into form suitable for delivery to user
  - telephone converts current into voice
  - modem converts tones into bits



### **Communication Channel**

- Pair of copper wires
- Coaxial cable
- Radio
- Light in optical fiber
- Light in air
- Infrared

### Transmission Impairments

- Signal attenuation
- Signal distortion
- Spurious noise
- Interference from other signals

### **Analog long-distance communication**

Transmission segment

Source

Repeater


Repeater

Destination


- Each repeater attempts to restore analog signal to its original form
- Restoration is imperfect
  - Distortion is not completely eliminated
  - Noise and interference is only partially removed
- Signal quality decreases with number of repeaters
- Communication is distance-limited
- Analogy: copy a song using a cassette recorder

## Analog vs. digital transmission

Analog transmission: all details must be reproduced accurately



**Digital transmission**: only discrete levels need to be reproduced



### **Digital long-distance communication**

Transmission segment

Source Regenerator Regenerator Destination


- Regenerator recovers original data sequence and retransmits on next segment
- Each regeneration is like the first time!
- Can design a transmission system with very low bit error rate
- Analogy: copy an MP3 file
- Communication is possible over very long distances
- Digital systems vs. analog systems
  - Less power, longer distances, lower system cost
  - Monitoring, multiplexing, coding, encryption, protocols...

## Digitization of analog signals

- 1. Sampling: obtain samples of x(t) at uniformly spaced time intervals
- 2. Quantization: map each sample into an approximation value of finite precision
  - Pulse Code Modulation (PCM): telephone speech
  - CD audio
- 3. Compression: to lower bit rate further, apply additional compression method
  - Differential coding: cellular telephone speech
  - Subband coding: MP3 audio

### Sampling rate and bandwidth


- A signal that varies faster needs to be sampled more frequently
- Bandwidth measures how fast a signal varies



- What is the bandwidth of a signal?
- How is bandwidth related to sampling rate?


### **Periodic signals**

• A periodic signal with period *T* can be represented as sum of sinusoids using Fourier Series:



- $|a_k|$  determines amount of power in kth harmonic
- Amplitude spectrum  $|a_0|$ ,  $|a_1|$ ,  $|a_2|$ , ...

### **Example - Fourier series**




$$x_{1}(t) = 0 + \frac{4}{\pi}\cos(2\pi 4000t)$$

$$x_{2}(t) = 0 + \frac{4}{\pi}\cos(2\pi 1000t)$$

$$+ \frac{4}{3\pi}\cos(2\pi 3(4000)t)$$

$$+ \frac{4}{5\pi}\cos(2\pi 5(4000)t) + \dots$$

$$+ \frac{4}{5\pi}\cos(2\pi 5(1000t)t)$$




$$x_2(t) = 0 + \frac{4}{\pi} \cos(2\pi 1000t) + \frac{4}{3\pi} \cos(2\pi 3(1000)t) + \frac{4}{5\pi} \cos(2\pi 5(1000)t) + \dots$$


## **Spectrum and bandwidth**

- Spectrum of a signal: magnitude of amplitudes as a function of frequency
- $x_1(t)$  varies faster in time and has more high frequency content than  $x_2(t)$
- Bandwidth  $W_s$  is defined as range of frequencies where a signal has non-negligible power, e.g. range of band that contains 99% of total signal power


#### Spectrum of $x_1(t)$




#### Spectrum of $x_2(t)$



## **Bandwidth of general signals**




- Not all signals are periodic
  - e.g. voice signal varies according to sound
  - vowels are periodic, "s" is noise-like
- Spectrum of long-term signal
  - averages over many sounds, many speakers
  - involves Fourier transform
- Telephone speech: 4 KHz
- CD Audio: 22 KHz




## Sampling theorem


Nyquist: Perfect reconstruction if sampling rate  $1/T > 2W_s$ 



### Digital transmission of analog information




## **Quantization of analog samples**



Quantizer maps input into closest of 2<sup>m</sup> representation values

Quantization error: "noise" = x(nT) - y(nT)



## Example: voice and audio

### **Telephone voice**


- $W_s = 4 \text{ KHz} \rightarrow 8000 \text{ samples/sec}$
- 8 bits/sample
- $R_s = 8 \times 8000 = 64 \text{ Kbps}$
- Cellular phones use more powerful compression algorithms: 8-12 Kbps

#### **CD** Audio

- $W_s = 22 \text{ KHz} \rightarrow 44,000 \text{ samples/sec}$
- 16 bits/sample
- $R_s = 16 \times 44000 = 704 \text{ Kbps per}$  audio channel
- MP3 uses more powerful compression algorithms: 50
   Kbps per audio channel

## Quantizer performance

 $M = 2^m$  levels, Dynamic range  $(-V, V) \Delta = 2V/M$ 



If the number of levels M is large, then the error is approximately uniformly distributed between  $(-\Delta/2, \Delta2)$ 

Average Noise Power = Mean Square Error:

$$\sigma_{\rm e}^2 = \int_{\frac{\Delta}{2}}^{\frac{\Delta}{2}} x^2 \frac{1}{\Delta} dx = \frac{\Delta^2}{12}$$

Figure of merit:

Signal-to-Noise Ratio (SNR) = average signal power / average noise power Let  $\sigma_x^2$  be the signal power, then

$$SNR = \frac{\sigma_x^2}{\Delta^2/12} = \frac{12\sigma_x^2}{4V^2/M^2} = 3(\frac{\sigma_x}{V})^2 M^2 = 3(\frac{\sigma_x}{V})^2 2^{2m}$$

The ratio  $V/\sigma_x \approx 4$ 

The SNR is usually stated in decibels:

SNR dB = 10 
$$\log_{10} \sigma_x^2 / \sigma_e^2 = 6m + 10 \log_{10} 3\sigma_x^2 / V^2$$
  
SNR dB =  $6m - 7.27$  dB for  $V / \sigma_x = 4$ 

### **Example: telephone speech**

W = 4 KHz, so Nyquist sampling theorem  $\Rightarrow 2W = 8000$  samples/second Suppose error requirement = 1% error SNR = 10 log(1/.01)<sup>2</sup> = 40 dB Assume  $V/\sigma_x = 4$ , then 40 dB = 6m - 7 $\Rightarrow m = 8 \text{ bits/sample}$ 

PCM telephone speech:
Bit rate= 8000 x 8 bits/sec= 64 Kbps

### **Communication channel**

- A *physical medium* is an inherent part of a communications system
  - copper wires, radio medium, or optical fiber
- Communications system includes electronic or optical devices that are part of the path followed by a signal
  - equalizers, amplifiers, signal conditioners
- By *communication channel* we refer to the combined end-to-end physical medium and attached devices
- Sometimes we use the term *filter* to refer to a channel especially in the context of a specific mathematical model for the channel



### **Signal Bandwidth**

 In order to transfer data faster, a signal has to vary more quickly.


#### **Channel Bandwidth**

- A channel or medium has an inherent limit on how fast the signals it passes can vary
- Limits how tightly input pulses can be packed

### **Transmission Impairments**

- Signal attenuation
- Signal distortion
- Spurious noise
- Interference from other signals
- Limits accuracy of measurements on received signal

### Frequency domain channel characterization




- Apply sinusoidal input at frequency f
  - Output is sinusoid at same frequency, but attenuated & phase-shifted
  - Measure amplitude of output sinusoid (of same frequency f)
  - Calculate amplitude response
    - A(f) = ratio of output amplitude to input amplitude
  - If  $A(f) \approx 1$ , then input signal passes readily
  - If  $A(f) \approx 0$ , then input signal is blocked
- Bandwidth  $W_c$  is range of frequencies passed by channel


### **Ideal Low-Pass Filter**

• Ideal filter: all sinusoids with frequency  $f < W_c$  are passed without attenuation and delayed by  $\tau$  seconds; sinusoids at other frequencies are blocked


$$y(t) = A_{in}\cos(2\pi f t - 2\pi f \tau) = A_{in}\cos(2\pi f (t - \tau)) = x(t - \tau)$$



Phase Response




### Time-domain characterization



- Time-domain characterization of a channel requires finding the *impulse response* h(t)
- Apply a very narrow pulse to a channel and observe the channel output
  - h(t) typically a delayed pulse with ringing
- Interested in system designs with h(t) that can be packed closely without interfering with each other

## Nyquist pulse with zero InterSymbol Interference (ISI)

• For channel with ideal low pass amplitude response of bandwidth  $W_c$ , the impulse response is a Nyquist pulse  $h(t)=s(t-\tau)$ , where  $T=1/2W_c$ , and



- s(t) has zero crossings at t = kT,  $k = \pm 1$ ,  $\pm 2$ , ...
- Pulses can be packed every T seconds with zero interference

## Example - composite waveform

Three Nyquist pulses shown separately

$$\bullet$$
 +  $S(t)$ 

- $\bullet$  + s(t-T)
- s(t-2T)

### **Composite waveform**

$$r(t) = s(t) + s(t-T) - s(t-2T)$$


Samples at kT


$$r(0)=s(0)+s(-T)-s(-2T)=+1$$

$$r(T)=s(T)+s(0)-s(-T)=+1$$


$$r(2T)=s(2T)+s(T)-s(0)=-1$$

Zero ISI at sampling times *kT* 





## Digital binary signal




Bit rate = 1 bit / T seconds

For a given communications medium:

- How do we increase transmission speed?
- How do we achieve reliable communications?
- Are there limits to speed and reliability?


## Signaling with Nyquist pulses

- p(t) pulse at receiver in response to a single input pulse (takes into account pulse shape at input, transmitter and receiver filters, and communications medium)
- r(t) waveform that appears in response to sequence of pulses
- If p(t) is a Nyquist pulse, then r(t) has zero intersymbol interference (ISI) when sampled at multiples of T



#### **Pulse transmission rate**

• Objective: maximize pulse rate through a channel, that is, make *T* as small as possible



- If input is a narrow pulse, then typical output is a spread-out pulse with ringing
- Question: How frequently can these pulses be transmitted without interfering with each other?
- Answer:  $2 \times W_c$  pulses/second where  $W_c$  is the bandwidth of the channel


# **Multilevel signaling**

- Nyquist pulses achieve the maximum signalling rate with zero ISI,  $2W_c$  pulses per second or  $2W_c$  pulses /  $W_c$  Hz = 2 pulses / Hz
- With two signal levels, each pulse carries one bit of information Bit rate =  $2W_c$  bits/second
- With  $M = 2^m$  signal levels, each pulse carries m bits

  Bit rate =  $2W_c$  pulses/sec. \* m bits/pulse =  $2W_c$  m bps
- Bit rate can be increased by increasing number of levels
- r(t) includes additive noise, that limits number of levels that can be used reliably.


# Example

- Four levels {-1, -1/3, 1/3, +1} for {00, 01, 10, 11}
- Waveform for 11, 10, 01 sends +1, +1/3, -1/3
- Zero ISI at sampling instants




### **Noise limits accuracy**

- Receiver makes decision based on transmitted pulse level + noise
- Error rate depends on relative value of noise amplitude and spacing between signal levels
- Large (positive or negative) noise values can cause wrong decision
- Noise level below impacts 8-level signaling more than 4-level signaling




#### **Noise distribution**

- Noise is characterized by probability density of amplitude samples
- Likelihood that certain amplitude occurs
- Thermal electronic noise is inevitable (due to vibrations of electrons)
- Noise distribution is Gaussian (bell-shaped) as below




## **Probability of error**

- Error occurs if noise value exceeds certain magnitude
- Probability of large values drops quickly with Gaussian noise
- Target probability of error achieved by designing system so separation between signal levels is appropriate relative to average noise power



## Channel noise affects reliability



- If transmitted power is limited, then as *M* increases spacing between levels decreases
- Presence of noise at receiver causes more frequent errors to occur as M is increased

#### **Shannon channel capacity:**

The maximum reliable transmission rate over an ideal channel with bandwidth *W* Hz, with Gaussian distributed noise, and with SNR *S/N* is

$$C = W \log_2 (1 + S/N) \text{ bps}$$

• Reliable means error rate can be made arbitrarily small by proper coding

## Example

- Consider a 3 KHz channel with 8-level signaling. Compare bit rate to channel capacity at 20 dB SNR
- 3KHz telephone channel with 8 level signaling
  Bit rate = 2\*3000 pulses/sec \* 3 bits/pulse = 18 Kbps
- 20 dB SNR means  $10 \log_{10} S/N = 20$ Implies S/N = 100
- Shannon channel capacity is then  $C = 3000 \log (1 + 100) = 19,974 \text{ bps}$


# Bit rates of digital transmission systems

System	Bit Rate	Observations
Telephone twisted pair	33.6-56 Kbps	4 KHz telephone channel
Ethernet twisted pair	10 Mbps, 100 Mbps	100 meters of unshielded twisted copper wire pair
Cable modem	500 Kbps-4 Mbps	Shared CATV return channel
ADSL twisted pair	64-640 Kbps in, 1.536- 6.144 Mbps out	Coexists with analog telephone signal
2.4 GHz radio	2-11 Mbps	IEEE 802.11 wireless LAN
28 GHz radio	1.5-45 Mbps	5 Km multipoint radio
Optical fiber	2.5-10 Gbps	1 wavelength
Optical fiber	>1600 Gbps	Many wavelengths

## Line coding


- Mapping of binary information sequence into the digital signal that enters the channel
  - Example "1" maps to +A square pulse; "0" to -A pulse
- Line code selected to meet system requirements:
  - *Transmitted power*: Power consumption = \$
  - *Bit timing*: Transitions in signal help timing recovery
  - Bandwidth efficiency: Excessive transitions wastes bandwidth
  - Low frequency content: Some channels block low frequencies
    - Waveform should not have low-frequency content
  - Error detection: Ability to detect errors helps
  - *Complexity/cost*: Is code implementable in chip at high speed?


# **Examples**



# **Spectrum of line codes**

Assume 1s and 0s independent and equiprobable






#### **Unipolar NRZ**


- "1" maps to +A pulse
- "0" maps to no pulse
- High Average Power
   0.5\*A² +0.5\*0²=A²/2
- Long strings of A or 0
  - Poor timing
  - Low-frequency content
- Simple

#### **Polar NRZ**

- "1" maps to +A/2 pulse
- "0" maps to –A/2 pulse
- Better Average Power
   0.5\*(A/2)² +0.5\*(-A/2)²=A²/4
- Long strings of +A/2 or -A/2
  - Poor timing
  - Low-frequency content
- Simple




- Three signal levels:  $\{-A, 0, +A\}$
- "1" maps to +A or –A in alternation
- "0" maps to no pulse
  - Every +pulse matched by –pulse so little content at low frequencies
- String of 1s produces a square wave
  - Spectrum centered at T/2
- Long string of 0s causes receiver to lose synchronization
- Zero-substitution codes



- "1" maps into A/2 first T/2, -A/2 last T/2
- "0" maps into -A/2 first *T*/2, A/2 last *T*/2
- Every interval has transition in middle
  - Timing recovery easy
  - Uses double the minimum bandwidth
- Simple to implement
- Used in 10-Mbps Ethernet and other LAN standards


- mBnB line code
- Maps block of *m* bits into *n* bits
- Manchester code is 1B2B code
- 4B5B code used in FDDI LAN
- 8B10B code used in Gigabit Ethernet
- 64B66B code used in 10G Ethernet




- Errors in some systems cause transposition in polarity, +A become –A and vice versa
  - All subsequent bits in Polar NRZ coding would be in error
- Differential line coding provides robustness to this type of error
- "1" mapped into transition in signal level
- "0" mapped into no transition in signal level
- Same spectrum as NRZ
- Errors occur in pairs
- Also used with Manchester coding

## 6.3 Asynchronous and synchronous communications


- Recommended Standard (RS) 232
- serial line interface between computer and modem or similar device
- Data Terminal Equipment (DTE): computer
- Data Communications Equipment (DCE): modem
- mechanical and electrical specification







# **Synchronization**

- Synchronization of clocks in transmitters and receivers.
  - clock drift causes a loss of synchronization
- Example: assume '1' and '0' are represented by V volts and 0 volts respectively
  - Correct reception
  - Incorrect reception due to incorrect clock (slower clock)






- Incorrect reception
- How to avoid a loss of synchronization?
  - Asynchronous transmission
  - Synchronous transmission




### **Asynchronous transmission**

• Avoids synchronization loss by specifying a short maximum length for the bit sequences and resetting the clock in the beginning of each bit sequence.




### Synchronous transmission

- Sequence contains data + clock information (line coding)
  - i.e. Manchester encoding, self-synchronizing codes, is used.
- R transition for R bits per second transmission




### 6.4 Transmission media



- Information bearing capacity
  - Amplitude response and bandwidth
    - depend on distance
  - Susceptibility to noise and interference
    - error rates and SNRs
- Propagation speed of signal
  - $c = 3 \times 10^8 \text{ m/s in vacuum}$
  - $n = c/\sqrt{e}$  speed of light in medium where e > 1 is the dielectric constant of the medium
  - $n = 2.3 \times 10^8 \text{ m/s}$  in copper wire;  $n = 2.0 \times 10^8 \text{ m/s}$  in optical fiber

## frequency of communication signals



#### Wireless Media

- Signal energy propagates in space, limited directionality
- Interference possible, so spectrum regulated
- Limited bandwidth
- Simple infrastructure: antennas & transmitters
- No physical connection between network & user
- Users can move


#### Wired Media

- Signal energy contained & guided within medium
- Spectrum can be re-used in separate media (wires or cables), more scalable
- Extremely high bandwidth
- Complex infrastructure: ducts, conduits, poles, right-of-way

- Attenuation varies with media
  - Dependence on distance of central importance
- Wired media has exponential dependence
  - Received power at d meters proportional to 10-kd
  - Attenuation in dB = k d, where k is dB/meter
- Wireless media has logarithmic dependence
  - Received power at d meters proportional to  $d^{-n}$
  - Attenuation in dB =  $n \log d$ , where n is path loss exponent; n=2 in free space
  - Signal level maintained for much longer distances
  - Space communications possible

# Twisted pair


- Two insulated copper wires arranged in a regular spiral pattern to minimize interference
- Various thicknesses, e.g. 0.016 inch (24 gauge)
- Low cost
- Telephone subscriber loop from customer to CO
- Old trunk plant connecting telephone COs
- Intra-building telephone from wiring closet to desktop
- In old installations, loading coils added to improve quality in 3 KHz band, but more attenuation at higher frequencies



Standard	Data Rate	Distance
T-1	1.544 Mbps	18,000 feet, 5.5 Km
DS2	6.312 Mbps	12,000 feet, 3.7 Km
1/4 STS-1	12.960 Mbps	4500 feet, 1.4 Km
1/2 STS-1	25.920 Mbps	3000 feet, 0.9 Km
STS-1	51.840 Mbps	1000 feet, 300 m

- Twisted pairs can provide high bit rates at short distances
- Asymmetric Digital Subscriber Loop (ADSL)
  - High-speed Internet Access
  - Lower 3 KHz for voice
  - Upper band for data
  - 64 Kbps inbound
  - 640 Kbps outbound
- Much higher rates possible at shorter distances
  - Strategy for telephone companies is to bring fiber close to home and then twisted pair
  - Higher-speed access + video


#### **Ethernet LAN**




- Category 3 unshielded twisted pair (UTP): ordinary telephone wires
- Category 5 UTP: tighter twisting to improve signal quality
- Shielded twisted pair (STP): to minimize interference; costly
- 10BASE-T Ethernet
  - 10 Mbps, Baseband, Twisted pair
  - Two Cat3 pairs
  - Manchester coding, 100 meters
- 100BASE-T4 Fast Ethernet
  - 100 Mbps, Baseband, Twisted pair
  - Four Cat3 pairs
  - Three pairs for one direction at-a-time
  - 100/3 Mbps per pair;
  - 3B6T line code, 100 meters
- Cat5 and STP provide other options

### Coaxial cable


- Cylindrical braided outer conductor surrounds insulated inner wire conductor
- High interference immunity
- Higher bandwidth than twisted pair
- Hundreds of MHz
- Cable TV distribution
- Long distance telephone transmission
- Original Ethernet LAN medium




## **Optical fiber**



- Light sources (lasers, LEDs) generate pulses of light that are transmitted on optical fiber
  - Very long distances (>1000 Km)
  - Very high speeds (>40 Gbps/wavelength)
  - Nearly error-free (BER of 10<sup>-15</sup>)
- Profound influence on network architecture
  - Dominates long distance transmission
  - Distance less of a cost factor in communications
  - Plentiful bandwidth for new services




Total Internal Reflection in optical fiber



- Very fine glass cylindrical core surrounded by concentric layer of glass (cladding)
- Core has higher index of refraction than cladding
- Light rays incident at less than critical angle  $\theta_c$  is completely reflected back into the core

Multimode fiber: multiple rays follow different paths



- Multimode: thicker core, shorter reach
  - Rays on different paths interfere causing dispersion and limiting bit rate
- Single mode: very thin core supports only one mode (path)
  - More expensive lasers, but achieves very high speeds

#### **Radio transmission**

- Radio signals: antenna transmits sinusoidal signal ("carrier") that radiates in air/space
- Information embedded in carrier signal using modulation, e.g. Quadrature Amplitude Modulation (QAM)
- Communications without tethering
  - cellular phones, satellite transmissions, wireless LANs
- Multipath propagation causes fading
- Interference from other users
- Spectrum regulated by national and international regulatory organizations

#### Frequency (Hz) 1012 10<sup>5</sup> $10^{7}$ 10<sup>8</sup> 10<sup>4</sup> $10^6$ 10<sup>11</sup> 10<sup>9</sup> 10<sup>10</sup> FM radio and TV Wireless cable AM radio Cellular and PCS Satellite and terrestrial microwave LF MF HF VHF UHF SHF EHĖ 10-1 10-2 10<sup>2</sup> **10**-3 10<sup>3</sup> 10<sup>1</sup> 10

Wavelength (meters)

Omni-directional applications

Point-to-Point applications

## **Examples**

#### **Cellular Phone**

- Allocated spectrum
- First generation:
  - 800, 900 MHz
  - Initially analog voice
- Second generation:
  - 1800-1900 MHz
  - Digital voice, messaging

#### Wireless LAN

- Unlicenced ISM spectrum
  - Industrial, Scientific, Medical
  - 902-928 MHz, 2.400-2.4835 GHz, 5.725-5.850 GHz
- IEEE 802.11 LAN standard
  - 11-54 Mbps

#### **Satellite Communications**

- Geostationary satellite @ 36,000 Km above equator
- Relays microwave signals from uplink frequency to downlink frequency
- Long distance telephone
- Satellite TV broadcast

# **Chapter Summary**

- ♦ digital representation of information
- ◆ digital transmission digitization of analog signal, characterization of communication channel, limitations, line coding
- ♦ asynchronous and synchronous communications
- ♦ transmission media

### Reference

Chapter 3, Communication
Networks: Fundamental Concepts
and Key Architectures

