

VL53L0X Sensors Expansion Deck

Please note the following about the Crazyflie expansion connectors:
* VCOM is power directly from the battery/USB and is not regulated
* VCC is regulated to 3.0V
* VUSB is connected directly to the USB which means this will supply at 4.5–5.5V when the USB is connected and can be used for charging the battery when the USB is not connected

Sheet: /
File: CustomBoard.sch

Title: CrazyFlie2.0

Size: A4	Date: 2018-07-24	Rev:
KiCad E.D.A. kicad 4.0.7-e2-637658ubuntu16.04.1		Id: 1/1