
# Terms: Word Size, Word Alignment

#### The Word Size of a computer

The size of an integer or pointer on the computer 32b (4B) on many machines



### Word Alignment

`Integer variable X is not word aligned'

The data item is not located at a word boundary

Word boundaries: addresses 0, 4, 8, 12, ...

# Instruction Set Architecture (ISA)

View of the computer that is visible to the programmer (or compiler)

There are 2 styles of instruction set design

#### 1. CISC

- Complex Instruction Set Computer
- A single instruction performs a complex operation involving several actions

#### 2. RISC

- Reduced Instruction Set Computer
- Each instruction performs only a simple operation

### Instruction Set Architecture

- Description of machine from view of the programmer/compiler
  - Example: Intel® x86 Instruction Set Architecture
- Includes specification of
  - The different kinds of instructions available (instruction set)
  - How operands are specified (addressing modes)
  - What each instruction looks like (instruction format)

#### 1. Arithmetic/logical instructions

- add, subtract, multiply, divide, compare (int/fp)
- or, and, not, xor
- shift (left/right, arithmetic/logical), rotate

- 1. Arithmetic/logical instructions
- Data transfer instructions
  - load (copy data to a register from memory)
  - store (copy data to a memory location from a register)
  - move

- 1. Arithmetic/logical instructions
- Data transfer instructions
- 3. Control transfer instructions
  - jump, conditional branch, function call, return

- 1. Arithmetic/logical instructions
- Data transfer instructions
- 3. Control transfer instructions
- 4. Other instructions
  - e.g., halt

# Operand Addressing Modes

- Operands to an instruction
  - Source: input value to instruction
  - Destination: where result is to go
- Addressing Mode
  - How the location of an operand to an instruction is specified
- An operand can be either
  - in a memory location
  - in a register

## Addressing Modes: Operand in Register

Register Direct Addressing Mode

Operand is in the specified general purpose register

Example

Suppose that the General Purpose Registers numbered as R0, R1, R2, etc

Registers R2 24

R1

67

$$/R1 = R2 + R3$$

destination operand

source operands

Information that must be present in the instruction:

Operation (e.g., add)

Identities of source and destination registers

## Addressing Modes: Operand in Register

- Register Direct Addressing Mode
- 2. Immediate Addressing Mode

Operand is included in the instruction ADD R1, R2, 7 /R1 = R2 + 7

Information that must be present in the instruction:
The "immediate operand" value

## Addressing Modes: Operand in Memory

3. Register Indirect Addressing Mode

Memory address of operand is in the specified general purpose register

R1 **32**R2 100

ADD R1, R1, (R2)

Address	96	100	104	108
Value	0	10	35	-17

MAIN MEMORY

Information that must be present in the instruction: Identity of register which contains the operand address

### Addressing Modes: Operand in Memory

- 3. Register Indirect Addressing Mode
- 4. Base-Displacement Addressing Mode

Memory address of operand is calculated as the sum of value in specified register and specified displacement

ADD R1, R1, 4(R2)

Address	96	100	104	108
Value	0	10	35	-17

MAIN MEMORY

Information that must be present in instruction:

Identity of base register (e.g., R2)

Value of displacement to be added (e.g. 4)

**67** 

100

R2

### Addressing Modes: Operand in Memory

- 3. Register Indirect Addressing Mode
- 4. Base-Displacement Addressing Mode
- 5. Absolute Addressing Mode

Memory address of operand is specified directly in the instruction

ADD R1, R2, #100