# Dynastat Embedded Systems Manual

### **Table of Contents**

Control and Power Cape	
Connectors	
Power Supply	
Motors	3
Control Switches	3
Sensor Chain	∠
Real Time Clock	∠
Linux Notes	
Programming Registers	6
Sensor Interface (Array)	
Programming Registers	
Sensor Interface (Satellite)	
Programming Registers	

### **Control and Power Cape**

The BeagleBone Control Cape is a board that fits on top of the Beagle Bone Black or Beagle Bone Green embedded boards.

The cape provides the following features:

- Regulated 5V power supply for BBB, Remote boards and motors.
- Provides connectors for 10x RMCS-220X motors.
   I2C and 12V are present on the connectors (no UART).
- 5 connectors to 10x Control switches for a homing sequence.
- 2 connectors for a remote chain of pressure sensor boards.
- An I2C Real Time Clock (DS3231).

#### **Connectors**

#### **Power Supply**

Power is provided via a 2-way screw terminal block.

Expected supply is 12V DC, 10A; however the regulator is capable of a wide input range (6V to 25V).

Polarity is marked on the PCB.

#### **Motors**

The motor connectors are a 6-pin JST, labelled P7,P8,P10,P11,P13,P14,P16,P17,P20,P21 on the schematic.

All of these are connected to the 12V screw terminal power input via a trace capable of carrying approximately 10A. As such, only one motor may be operated at a time.

Pin	Description
1	Ground
2	I2C2 Clock
3	I2C2 Data
4	N/C
5	N/C
6	+12V

#### **Control Switches**

The control switch connectors have provision for 2 switches on each connector. They also provide +5V should a proximity switch or other active device be required in the future.

The connector is a wire insertion type to allow solder less assembly. The outer diameter of each wire (including insulation) should be less than 1.5mm.

Pin	Description
1	+5V
2	Input 1 (10K Pull up to +5V)
3	Ground
4	+5V
5	Input 2 (10K Pull up to +5V)
6	Ground

#### **Sensor Chain**

There are two sensor connectors on the board to allow connection to one or more remote sensor boards.

The suggested configuration is to have two chains, each containing 1 pressure array board and 1 satellite sensor board.

Pin	Description
1	+5V
2	I2C1 Clock
3	I2C2 Data
4	Ground

#### **Real Time Clock**

The RTC connector is designed to accept an off the shelf RTC module based on the DS3231 chip.

This will be connected to I2C2 and can be accessed via I2C2 (i2c-1 under Linux) at address 0x68.

It may be used by the kernel with the following command:

echo ds3231 0x68 >/sys/bus/i2c/devices/i2c-1/new\_device

#### **Linux Notes**

The BBB by default has the I2C1 bus disabled. It can be enabled by issuing the following command:

```
echo BB-I2C1 > /sys/devices/bone_capemgr.9/slots
```

Note that the bus numbering under Linux is dependent on the order in which the buses are initialised so doesn't always match the schematics.

The following command can be used to check the actual bus ordering:

```
ls -l/sys/bus/i2c/devices/i2c-*
```

The lower the HEX address towards the end of the location, the lower the I2C bus:

```
44e0b000 = I2C0
4802a000 = I2C1
4819c000 = I2C2
```

In all cases so far, I2C1 and I2C2 have been swapped around on my system.

An example /etc/rc.local is as follows:

```
#!/bin/sh -e

#
# rc.local

#
# This script is executed at the end of each multiuser runlevel.

# Make sure that the script will "exit 0" on success or any other

# value on error.

#
# In order to enable or disable this script just change the execution

# bits.

#
# By default this script does nothing.

echo ds3231 0x68 >/sys/bus/i2c/devices/i2c-1/new_device

echo BB-I2C1 > /sys/devices/bone_capemgr.9/slots

sleep 1

hwclock -f /dev/rtc1 -s

exit 0
```

# **Programming Registers**

The control board contains an MCU that is capable of monitoring the state of the control switches.

The micro controller is connected to I2C1 and the IRQ line is connected to GPIO1\_16 of the BBB.

The default I2C slave address of the MCU is 0x20.

All registers are 16-bits wide. The following I2C registers are available:

Address	Description	Read	Write
0x00	ID Register	0xFE00	N/A
0x01	Interrupt Status Each bit corresponding to inputs 1-10 will be set if an input has gone low since the last clear. Writing a bit will clear the status (write 0x3FF to clear all).	0x0000	0x03FF
0x02	Interrupt Enable For each input that you wish to cause an interrupt (set the IRQ line low), set the corresponding bit.	0x0000 (default)	0x03FF
0x03	Control Switch Values 1-10 Bits 0-9 will represent the raw logic state of each input 1-10. The default is high (1) due to the 10K pull up.	0x03FF	N/A
0x0F	Set Device Address This will set the device's I2C address after the next chip reset.	Current Address	0x00-0x7F

# **Sensor Interface (Array)**

The sensor interface board provides a localised system capable of measuring a 16x10 grid pressure sensor and up to 2 individual pressure sensors.

Linearity is achieved by using an inverting amplifier to perform a 1/x in the analogue domain. This avoids losing resolution in the ADC and doing conversion in software.

### **Programming Registers**

The sensor board contains an MCU that continuously scans the sensors.

The default I2C slave address of the MCU is 0x21.

All registers are 16-bits wide. The following I2C registers are available:

Address	Description	Read	Write
0x00	ID Register	0xFE01	N/A
0x01	Sensor 1 Value	0x0000 (default)	N/A
0x02	Sensor 2 Value	0x0000 (default)	N/A
0x03	Reserved	0x0000 (default)	N/A
0x04	Reserved	0x0000 (default)	N/A
0x0F	Set Device Address This will set the device's I2C address after the next chip reset.	Current Address	0x00-0x7F
0x10- 0xAF	160 Registers in a Column (16) x Row (10) Array	0x0000 (default)	N/A

# **Sensor Interface (Satellite)**

The satellite sensor interface board provides a localised system capable of measuring up to 4 individual pressure sensors.

Linearity is achieved by using an inverting amplifier to perform a 1/x in the analogue domain. This avoids losing resolution in the ADC and doing conversion in software.

### **Programming Registers**

The satellite sensor board contains an MCU that continuously scans the sensors.

The default I2C slave address of the MCU is 0x22.

All registers are 16-bits wide. The following I2C registers are available:

Address	Description	Read	Write
0x00	ID Register	0xFE02	N/A
0x01	Sensor 1 Value	0x0000 (default)	N/A
0x02	Sensor 2 Value	0x0000 (default)	N/A
0x03	Sensor 3 Value	0x0000 (default)	N/A
0x04	Sensor 4 Value	0x0000 (default)	N/A
0x0F	Set Device Address This will set the device's I2C address after the next chip reset.	Current Address	0x00-0x7F