ELECTRICAL, CONTROLS, INSTRUMENTATION RICKY NGUYEN'S KNOWLEDGE BANK

EC&I Knowledge Encyclopedia

Changed by:	Date	Comment
Ricky N.	16/07/2022	

Contents

1	$\mathbf{U}\mathbf{Q}$	Subjects	3
	1.1	CSSE2002 - Java Language	3
	1.2	CSSE2010 - Embedded Programming	4
	1.3	CSSE2310 - C Language	5
	1.4	CSSE3010 - Advanced Embedded	6
	1.5	MATH1051 - Linear Calculus	7
	1.6	MATH2001 - Advanced Calculus	8
	1.7	MATH2010 - Partial Differential Equations	9
	1.8	STAT2202 - Advanced Statistics	10
	1.9	ELEC2003 - Electronics & Circuits Pt.1	11
	1.10	ELEC2004 - Electronics & Circuits Pt.2	12
		1.10.1 LEC01: Capacitors and Inductors, RL and RC Circuits	12
		1.10.2 LEC02: Nodal & Mesh Analysis and Network Theorems	14
	1.11	ELEC3100 - Advanced Electrical Theory	18
	1.12	ELEC3300 - Motors & Electrical Energy	19
	1.13	ELEC3400 - Amplifiers & Electronics	20
	1.14	ELEC4300 - Power System Analysis	21
	1.15	ELEC4302 - Power System Protection	22
	1.16	ELEC4620 - Signal Processing	23
	1.17	ELEC4630 - Image Processing	24
	1.18	ENGG4800 - Project Management	25
	1.19	METR4201 - Control System Analysis	26

List of Figures

1	Snapshot - Super-Nodes in Circuit Analysis (Nodal)	15
2	Snapshot - Super-Mesh in Circuit Analysis (Mesh)	16

List of Tables

1 UQ Subjects

This chapter goes through the UQ courses that was undertaken from 2016-2019. The format will be as follows, for each section, where possible:

- 1. Lecture notes (Use "LEC##: TITLE HERE" for each heading)
- 2. Tutorial questions (Use "TUT##: TITLE HERE" for each heading)
- 3. Summary of all equations used (Use "EQU##: TITLE HERE" for each heading)
- 4. References & other helping material (Use "REF##: TITLE HERE" for each heading)
- 5. Australian Standards (Use "STD##: TITLE HERE" for each heading)

In terms of text colour and highlights, the format will be as follows where possible:

- 1. Black = normal text
- 2. Red = Important
- 3. Blue = References
- 4. Green = Key Takeaways

1.1 CSSE2002 - Java Language

1.2 CSSE2010 - Embedded Programming

1.3 CSSE2310 - C Language

1.4 CSSE3010 - Advanced Embedded

1.5 MATH1051 - Linear Calculus

1.6 MATH2001 - Advanced Calculus

1.7 MATH2010 - Partial Differential Equations

$1.8 \quad {\rm STAT2202} \ \hbox{--} \ {\rm Advanced} \ {\rm Statistics}$

1.9 ELEC2003 - Electronics & Circuits Pt.1

1.10 ELEC2004 - Electronics & Circuits Pt.2

1.10.1 LEC01: Capacitors and Inductors, RL and RC Circuits

CAPACITORS

Capacitors and inductors are linear circuit elements that can store electrical energy. The ideal capacitor stores energy in the form of **charge**.

$$C = \frac{\epsilon A}{d} \tag{1}$$

Where:

- C = capacitance in Farads (F)
- A = conductor plates area (both top and bottom) (mm^2)
- ϵ = dielectric of permittivity (constant)
- d = plate separation distance (m)

$$Q = CV (2)$$

Where:

- Q = stored charge
- C = capacitance(F)
- V = applied voltage (V)

In DC, a capacitor is effectively an open circuit; when a steady voltage is applied. When the voltage changes, the stored charge changes also as per equation (2) by taking the derivative. Thus,

$$i(t) = \frac{dq(t)}{dt} = C\frac{dv(t)}{dt} \tag{3}$$

KEY TAKEAWAY: Change in voltage induces a current because there are charges moving. This electrical energy is stored in "capacitance" in the form of an electric field.

Energy storage in capacitors is calculated by integrating the instantaneous power P(t). Thus,

$$P(t) = v(t)i(t) = Cv(t)\frac{dv(t)}{dt}$$
(4)

Integrating the instanteous power:

$$W(t) = \frac{1}{2}Cv^2(t) \tag{5}$$

Capacitors can be combined in series and in parallel to yield a single equivalent capacitance. Note: the behaviour of equivalent capacitance is the opposite of resistors. Series:

$$C_{EQ} = \frac{1}{\frac{1}{C_1} + \frac{1}{C_2} + \frac{1}{C_3} \dots} \tag{6}$$

Parallel:

$$C_{EO} = C_1 + C_2 + C_3 \dots (7)$$

Inductors

The ideal inductor stores energy in an induced magnetic field.

$$\phi = LI \tag{8}$$

Where:

- ϕ = induced magnetic flux
- L = inductance in Henrys (H)
- I = applied current(A)

In DC, an inductor is effectively a short circuit (i.e. a wire with no resistance). When the current changes, the induced field also changes. Thus,

$$v(t) = \frac{d\phi(t)}{dt} = L\frac{di(t)}{dt} \tag{9}$$

KEY TAKEAWAY: The rate of change in magnetic flux induces a voltage. Thus, alternating current (AC) induces a change in magnetic field and thus produces a voltage. Inductance is the tendency of an electrical conductor to oppose a change in the electric current flowing through it.

Energy storage in inductors is calculated by integrating the instantaneous power P(t). Thus,

$$P(t) = v(t)i(t) = Li(t)\frac{di(t)}{dt}$$
(10)

Integrating the instanteous power:

$$W(t) = \frac{1}{2}Li^{2}(t) \tag{11}$$

Inductors can be combined in series and in parallel to yield a single equivalent inductance. Note: the behaviour of equivalent inductance is the same as resistors. Series:

$$L_{EQ} = L_1 + L_2 + L_3... (12)$$

Parallel:

$$L_{EQ} = \frac{1}{\frac{1}{L_1} + \frac{1}{L_2} + \frac{1}{L_3} \dots}$$
 (13)

Other topics found:

- Solving RC Circuits & Forced responses & Transient analysis
- Approaches to solve circuits
- Class exercises

1.10.2 LEC02: Nodal & Mesh Analysis and Network Theorems

THE BASICS

These are the fundamental electrical basics:

- V = IR (Ohm's Law)
- $P = VI = \frac{V^2}{R} = I^2 R$
- Kirchhoff's current law (KCL): Sum of currents into a node = 0
- Kirchhoff's voltage law (KVL): Sum of voltages around a loop = 0
- Series and parallel circuits (voltage and current dividers)
- $R_{series} = R_1 + R_2 + R_3$; $R_{parallel} = \frac{1}{\frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_2}}$

Node and Mesh Analysis

Note: For a network with n nodes, both methods will result in n independent equations, with n unknown variables.

- Nodal analysis: Set voltages at each node as the unknown variables, apply KCL. Note: Currents going into the node are positive, and currents going out of the node are negative. Use KCL when the source is a current source; typically.
- Mesh analysis: set the current through each branch as the unknown variables, apply KVL; Note: choose a direction for a loop and stick to that direction for all loops. Voltages going from negative to positive (e.g. Voltage Sources) are positive and voltages going from positive to negative (e.g. resistors) are impedances. Use KVL when the source is a voltage source; typically.

PROCEDURE: NODAL (KCL) The below steps for the method to use Nodal Analysis:

- 1. Label all circuit parameters identify the unknown parameters (voltages and currents).
- 2. Identify all essential nodes.
- 3. Select a node as the reference node (ground node). Assign it a potential of 0 volts. All other voltages are measured with respect to the reference node.
- 4. Label the voltages at all other nodes.
- 5. Apply KCL at each node and express currents in terms of node voltages.
- 6. Solve the resulting equations for node voltages.
- 7. WHAT HAPPENS IF THERE ARE V AND I SOURCES? We may need to define a 'super-node' (this is where a voltage source connects two nodes; thus, like a node, Current in = Current out) See Figure 1

PROCEDURE: MESH (KVL) The below steps for the method to use Mesh Analysis:

- 1. Label all circuit parameters and identify unknown parameters (voltages and currents).
- 2. Identify all meshes of the circuit.
- 3. Assign mesh currents and label polarities.

Nodal analysis with V and I sources

If a voltage source connects two nodes, it's necessary to define a *super-node*.

Like a node, current in = current out.


$$\cdot \text{ So } \frac{v_{\rm a}}{R_1} + \frac{v_{\rm b}}{R_2} = i_{\rm s}$$
 Supernode
$$\cdot \text{ and } v_{\rm a} = v_{\rm b} + v_{\rm s}.$$

$$\cdot \text{ Thus, } \frac{v_{\rm a}}{R_1} + \frac{v_{\rm a} - v_{\rm s}}{R_2} = i_{\rm s}.$$

$$\stackrel{\downarrow}{\geqslant} R_1$$

Figure 1: Snapshot - Super-Nodes in Circuit Analysis (Nodal)

Mesh analysis with V and I sources



When a current source is common to both meshes, form a *super-mesh*.


- We know from Node a that $i_2 = i_s + i_1$.
- So again only one mesh equation, $R_1i_1 + (R_2 + R_3)i_2 = v_s$.
- Rearranging, $R_1 i_1 + (R_2 + R_3)(i_s + i_1) = v_s$.

Figure 2: Snapshot - Super-Mesh in Circuit Analysis (Mesh)

- 4. Apply KVL at each mesh and express voltages in terms of the mesh currents.
- 5. Solve the resulting simultaneous equations for the mesh currents.
- 6. Now that the mesh currents are known, the voltages may be obtained from Ohm's law.
- 7. WHAT HAPPENS IF THERE ARE V AND I SOURCES? We may need to define a 'super-mesh' (this is where the current is found common to both meshes) See Figure 2

Kirchhoff-based solution strategy

How to obtain a solvable case with KCL and KVL?



KCL gives

$$i_{s} = i_{1} = i_{2} = i_{3}.$$

Using Ohm's law gives

$$i_{\rm S} = \frac{v_1}{R_1} = \frac{v_2}{R_2} = \frac{v_3}{R_3}.$$

KCL:

$$i_{s} - i_{1} = 0$$
 $i_{1} - i_{2} = 0$
 $i_{2} - i_{3} = 0$
 $i_{3} - i_{s} = 0$

KVL:

$$v_s - v_1 - v_2 - v_3 = 0$$
Branch v - i :
 $v_1 = R_1 i_1$
 $v_2 = R_2 i_2$
 $v_3 = R_3 i_3$

KVL gives

$$v_1 = v_s - v_2 - v_3$$

$$\Rightarrow i_s = \frac{1}{R_1}(v_s - R_2i_2 - R_3i_3)$$

$$\Leftrightarrow i_s = \frac{v_s}{R_1 + R_2 + R_3}$$

Nodal (KCL) Procedure (pg 11)

Other topics found:

- Definitions: Ideal Sources (Voltage, Current), Independent vs Dependent Sources
- Approaches to solve circuits
- Class exercises

$1.11\quad \textbf{ELEC3100 - Advanced Electrical Theory}$

 $1.12\quad {\tt ELEC3300 - Motors \& Electrical \ Energy}$

1.13 ELEC3400 - Amplifiers & Electronics

1.14 ELEC4300 - Power System Analysis

$1.15\quad {\bf ELEC4302 \text{ - Power System Protection}}$

1.16 ELEC4620 - Signal Processing

1.17 ELEC4630 - Image Processing

${\bf 1.18}\quad {\bf ENGG4800 \text{ - Project Management}}$

1.19 METR4201 - Control System Analysis