



INTEL-IRRIS

Intelligent Irrigation System for Low-cost Autonomous Water Control
in Small-scale Agriculture



Intelligent Irrigation System for Low-cost Autonomous Water Control in Small-scale Agriculture



Wireless Communication Essentials Understanding radio & LoRa technologies in IoT



Prof. Congduc Pham
<http://www.univ-pau.fr/~cpham>
Université de Pau, France



Wireless networks: WiFi



Wireless networks: 2G/3G/4G/5G/...




Wireless networks: Bluetooth



How Bluetooth is Transforming Consumer Electronics



Wireless networks: Satellites




Iridium, 66 satellites
 Initially 77




© Pearson Education France

Wireless networks: Laser/Optical



Wireless networks: Visible Light



Visible Light Communications, con't

- High throughput is "easy"
- Bi-directionality is still an issue
- VR is a perfect application for VL

How li-fi sends data

The visible light spectrum is 10,000 times larger than the radio waves we use for wi-fi today. Information can be encoded in light pulses, just like in traditional TV remote controls.



Modern LEDs, however, could transmit enough data for a stable broadband connection - but still look like normal white light





*bits per second

Source: Professor Harald Haas

BBC




Wireless radio transmission basics




Antenna types





Omni-directional antennas




Directional antenna



PCB, patch, ceramic,...






Antennas in a smartphones!



Testing antennas




- Source: F. Ferrero,
University of Nice



Antenna gain (1)

- Antenna gain

- Directional antennas FOCUS energy:
they DO NOT ADD energy



- Antenna Gain

- Omni-directional antennas FOCUS energy:
they DO NOT ADD energy



Antenna gain (2)


- Antenna gain and its effective surface

$$G = \frac{4\pi A_e}{\lambda^2} = \frac{4\pi f A_e}{c^2}$$

- with

- G = gain
- A_e = effective surface
- f = signal frequency
- c = light speed in space $3 \cdot 10^8$ m/s
- λ = wave length of the signal = c/f

1st challenge: signal attenuation



Attenuation limits the range!

- Attenuation depends mainly on distance

$$P_r = P_e d^{-\alpha}$$

- with :

- P_e = transmitted power
- P_r = received power
- d = distance between antennas
- α from 2 to 4

Attenuation in practice


- For an ideal antenna (theoretic)

$$\frac{P_e}{P_r} = \frac{(4\pi d)^2}{\lambda^2} = \frac{(4\pi f d)^2}{c^2}$$

- P_e = transmitted power
- P_r = received power
- P_e / P_r is high when P_r is small → high attenuation
- d = distance between antennas
- c = light speed in space 3.10^8 m/s
- λ = wave length of the signal = c/f
- Higher frequencies f means higher attenuation!


Attenuation, values in watts

- Free Space Path Loss model



Attenuation, values in watts


- Free Space Path Loss model



Link budget in wireless system – (simplified)

$$P_{RX} = P_{TX} + G_{TX} - L_{TX} - L_{FS} - L_M + G_{RX} - L_{RX}$$

Adapted from Peter R. Egli, INDIGOOCOM



P_{RX} = Received power (dBm)

P_{TX} = Sender output power (dBm)

G_{TX} = Sender antenna gain (dBi)

L_{TX} = Sender losses (connectors etc.) (dB)

L_{FS} = Free space loss (dB)

L_M = Misc. losses (multipath etc.) (dB)



G_{RX} = Receiver antenna gain (dBi)

L_{RX} = Receiver losses (connectors etc.) (dB)

S_{RX} = Receiver sensitivity (dBm)

Shadow fading & Multi-path fading

- ➊ Things are getting even worse!
- ➋ Shadow fading by obstacles
- ➌ Multi-path fading
- ➍ ...




How can we increase range?



I'm not fluent in idiot
 could you please speak




- Increase TX power and/or improve RX sensitivity
- Generally, RX sensitivity (~robustness) can be increased when transmitting (much) slower (**like speaking slower!**)
- LoRa uses spread spectrum approach to increase RX sensitivity
 - Spreading Factor defines how many chips will be used to code a symbol.
More chip/symbol=longer transmission time ➔ more robustness
- **The price to pay for LPWAN**
 - LoRa has **very low** throughput: **200bps-37500bps (0.2-37.5kbps)**



- WiFi 802.11n: 450 000 000 bps (450Mbps)
- WiFi 802.11g: 54 000 000 bps (54Mbps)
- Bluetooth3&4: 25 000 000 bps (25Mbps)
- Bluetooth BLE: 2 000 000 bps (2Mbps)
- 3G/4G : 20Mbps-200Mbps
- **LoRa**: **200bps-37500bps (0.0002-0.0375Mbps)**
- **3G/LoRa ratio: 20,000,000bps/200bps=100000!**

Line-of-Sight & Fresnel zone


- LoS means clear Fresnel zone
- Football (american) shape
- Acceptable = 60% of zone 1 + 3m



In real environment!




Clearing the Fresnel zone? Raise antennas!




$$r_n = \sqrt{\frac{d_1 d_2}{d_1 + d_2}}$$

Range Distance	900 MHz Modems Required Fresnel Zone Diameter	2.4 GHz Modems Required Fresnel Zone Diameter
1000 ft. (300 m)	16 ft. (5 m)	11 ft. (3.4 m)
1 Mile (1.6 km)	32 ft. (10 m)	21 ft. (6.4 m)
5 Miles (8 km)	68 ft. (21 m)	43 ft. (13 m)
10 Miles (16 km)	95 ft. (29 m)	59 ft. (18 m)



Coverage test by Fabien Ferrero on March 21-22, 2019



- LoRaWAN gateway on top of Danang's DSP building by Fabien, U. Danang and DSP team. Almost 26kms! Congrats Fabien!



Coverage test by Fabien Ferrero on Intel-Irris

June 11th, 2019

- ➊ High Altitude Ballon




- ➊ 31kms high
- ➋ Reception at 642km (Udine, Italy)!
- ➌ Current record at 702km with balloon at 38kms

https://github.com/FabienFerrero/HAB_Relay_STM32Contest

Clearing the Fresnel zone? Let's use satellite!

- Low-orbit, low-cost; compact satellite for global coverage



<https://lacuna.space/first-successful-lacunasat-launch-in-2021/>

LPWAN=star topology, gateway centric





Figure from Siradel

LoRaWAN IoT networks


- LoRaWAN specifications/protocols run on top of LoRa physical networks. It is defined and managed by the [LoRa Alliance](#)
- Make possible to run large-scale, public LoRa networks



Understanding LoRa vs LoRaWAN

- The physical layer, thus the long-range radio technology, is called LoRa
- A so-called 1-byte sync word is used to add a "filtering" level
- You can decide to transmit using only the LoRa physical layer and then define our own packet format
- With pure LoRa you can transmit from any device to any other device with same LoRa datarate, frequency and sync word
- LoRaWAN uses LoRa physical layer but defines its own packet format and uses sync word of 0x34 (public LoRaWAN)
- "In LoRaWAN, a gateway applies I/Q inversion on TX, and nodes do the same on RX. This ensures that gateways can talk to nodes and vice-versa, but gateways will not hear other gateways and nodes will not hear other nodes" [LMIC Arduino]


LoRaWAN gateway



- ➊ A full LoRaWAN gateway should be able to listen on multiple channels and spreading factors




- ➋ They are mostly based on the Semtech SX1301 radio concentrator



LoRaWAN gateway software

- Most of LoRaWAN gateways run the following software
 - the Semtech's concentrator gateway at the lowest level (https://github.com/Lora-net/lora_gateway)
 - The Semtech's LoRa packet forwarder on top of the low-level concentrator gateway (https://github.com/Lora-net/packet_forwarder)
- "*A LoRa packet forwarder is a program running on the host of a LoRa gateway that forwards RF packets receive by the concentrator to a server through a IP/UDP link, and emits RF packets that are sent by the server.*"
- The server is the so-called LoRaWAN Network Server (LNS) as described in the next slides
- The Network Server is usually linked to the Application Server which can be seen as a LoRaWAN cloud

LoRaWAN Network Server (LNS)



- LNS manages the state of the network, has knowledge of devices active on the network and is able to handle over-the-air-activation procedure (OTAA)
- When data is received by multiple gateways, the LNS can also de-duplicate this data
- When a message needs to be sent back to a device, the LNS forwards it to one of the gateways
- Currently, each LoRaWAN network provider will have their own LNS
 - The Packet Forwarder run on deployed gateways needs to identify an LNS
 - Therefore users need to be "bounded" to a particular LoRa network provider because end-devices need to be registered

TheThingNetwork (TTN)

- Popular LoRa Network Provider
- Provides the TTN Network Server



- Community-based deployment of LoRa gateways
 - User A can buy a LoRa gateway, register it and deploy it
 - User B then creates an account on TTN to register its devices
 - Messages from registered devices received by a TTN gateway will be made available for users on the TTN console



TTN user console

The image displays two screenshots of the TTN User Console interface.

Screenshot 1: Application Overview

This screenshot shows the application details for "pau_lorawan_testing".

- Application ID:** pau_lorawan_testing
- Description:** Pau LoRaWAN testing
- Created:** 9 months ago
- Handler:** ttu-handler-eu (current handler)

APPLICATION EUIS

Shows the EUIS of the application, with the value 12AA34BB56CC78CC highlighted.

DEVICES

Shows 2 registered devices.

Screenshot 2: Device List

This screenshot shows the device list for the "pau_lorawan_testing" application.

Device ID	Device Name	EUI	Status
pau_testing_device	Pau testing device	xxxxxxxxxxxxxx	•
pau_testing_otaa_device		xxxxxxxxxxxxxx	•