

# INTEL-IRRIS

Intelligent Irrigation System for Low-cost Autonomous Water Control  
in Small-scale Agriculture



# Intelligent Irrigation System for Low-cost Autonomous Water Control in Small-scale Agriculture



## Wireless Communication Essentials Understanding radio & LoRa technologies in IoT



Prof. Congduc Pham  
<http://www.univ-pau.fr/~cpham>  
Université de Pau, France



# Wireless networks: WiFi



# Wireless networks: 2G/3G/4G/5G/...




# Wireless networks: Bluetooth



## How Bluetooth is Transforming Consumer Electronics



# Wireless networks: Satellites





Iridium, 66 satellites  
 Initially 77




© Pearson Education France

# Wireless networks: Laser/Optical



# Wireless networks: Visible Light



# Visible Light Communications, con't

- High throughput is "easy"
- Bi-directionality is still an issue
- VR is a perfect application for VL

## How li-fi sends data

The visible light spectrum is 10,000 times larger than the radio waves we use for wi-fi today. Information can be encoded in light pulses, just like in traditional TV remote controls.



Modern LEDs, however, could transmit enough data for a stable broadband connection - but still look like normal white light





\*bits per second

Source: Professor Harald Haas

BBC




# Wireless radio transmission basics




# Antenna types





Omni-directional antennas




Directional antenna



# PCB, patch, ceramic,...






# Antennas in a smartphones!



# Testing antennas




- Source: F. Ferrero,  
University of Nice



# Antenna gain (1)

- Antenna gain

- Directional antennas FOCUS energy:  
they DO NOT ADD energy



- Antenna Gain

- Omni-directional antennas FOCUS energy:  
they DO NOT ADD energy



# Antenna gain (2)


- Antenna gain and its effective surface

$$G = \frac{4\pi A_e}{\lambda^2} = \frac{4\pi f A_e}{c^2}$$

- with

- G = gain
- $A_e$  = effective surface
- f = signal frequency
- c = light speed in space  $3 \cdot 10^8$  m/s
- $\lambda$  = wave length of the signal =  $c/f$

# 1st challenge: signal attenuation



# Attenuation limits the range!

- Attenuation depends mainly on distance

$$P_r = P_e d^{-\alpha}$$

- with :

- $P_e$  = transmitted power
- $P_r$  = received power
- $d$  = distance between antennas
- $\alpha$  from 2 to 4

# Attenuation in practice


- For an ideal antenna (theoretic)

$$\frac{P_e}{P_r} = \frac{(4\pi d)^2}{\lambda^2} = \frac{(4\pi f d)^2}{c^2}$$

- $P_e$  = transmitted power
- $P_r$  = received power
- $P_e / P_r$  is high when  $P_r$  is small → high attenuation
- $d$  = distance between antennas
- $c$  = light speed in space  $3.10^8$  m/s
- $\lambda$  = wave length of the signal =  $c/f$
- Higher frequencies  $f$  means higher attenuation!


# Attenuation, value in watts

- Free Space Path Loss model



# Attenuation in decibel (dB)


- Decibel uses logarithmic scale as attenuation values can be very large
- Attenuation in dB:  $10\log_{10}(P_e/P_r)$ ,  $P_e$  and  $P_r$  in watts
  - So  $P_e/P_r = 10^{dB/10}$
  - Difference of 3dB≈half (divided by 2) as  $P_e/P_r = 10^{3/10} = 10^{0.3} = 1.99526\dots$
- → Gain =  $10\log_{10}(P_r/P_e)$
- We can add various sections with attenuation or gain



$-16\text{dB} + 20\text{dB} - 10\text{dB} = -6\text{dB}$ , so it is an attenuation  
 $P_e/P_r = 10^{-6/10} = 10^{-0.6} = 3.98 \rightarrow P_r = P_e/3.98 \approx 100\text{mW}$

# dB, dBm, ...

- Total net output power of transmitter
- Typically measured in dBm or mW



- **mW:** milliwatts are a measurement of power ( $1000 \text{ mW} = 1 \text{ Watt}$ ).
- **dB:** decibel is a unit for expressing the ratio of two amounts of signal power equal to 10 times the common logarithm of this ratio. So, a power measurement in dB has to be relative to something.
- **dBm:** dB(mW) is power relative to 1 milliwatt ( $\text{mW to dBm} = 10\log_{10}(\text{mW}/1000) + 30$ ).  

$$P(\text{dBm}) = 10 \cdot \log_{10}(P(\text{mW}) / 1\text{mW})$$
- **dB<sub>i</sub>:** dB(isotropic) is the forward gain of an antenna compared to the hypothetical isotropic antenna, which uniformly distributes energy in all directions.

# dBm to mW conversion

$$P(\text{dBm}) = 10 \cdot \log_{10}(P(\text{mW})/1\text{mW})$$

$$P(\text{mW}) = 10^{\frac{P(\text{dBm})}{10}}$$

Ex:


$$P(\text{mW}) = 10^{\frac{14\text{dBm}}{10}} = 10^{1.4} = 25.118\text{mW}$$

| dBm | Watts  |
|-----|--------|
| 0   | 1.0 mW |
| 1   | 1.3 mW |
| 2   | 1.6 mW |
| 3   | 2.0 mW |
| 4   | 2.5 mW |
| 5   | 3.2 mW |
| 6   | 4 mW   |
| 7   | 5 mW   |
| 8   | 6 mW   |
| 9   | 8 mW   |
| 10  | 10 mW  |
| 11  | 13 mW  |
| 12  | 16 mW  |
| 13  | 20 mW  |
| 14  | 25 mW  |
| 15  | 32 mW  |

| dBm | Watts  |
|-----|--------|
| 16  | 40 mW  |
| 17  | 50 mW  |
| 18  | 63 mW  |
| 19  | 79 mW  |
| 20  | 100 mW |
| 21  | 126 mW |
| 22  | 158 mW |
| 23  | 200 mW |
| 24  | 250 mW |
| 25  | 316 mW |
| 26  | 398 mW |
| 27  | 500 mW |
| 28  | 630 mW |
| 29  | 800 mW |
| 30  | 1.0 W  |
| 31  | 1.3 W  |

| dBm | Watts |
|-----|-------|
| 32  | 1.6 W |
| 33  | 2.0 W |
| 34  | 2.5 W |
| 35  | 3.2 W |
| 36  | 4.0 W |
| 37  | 5.0 W |
| 38  | 6.3 W |
| 39  | 8.0 W |
| 40  | 10 W  |
| 41  | 13 W  |
| 42  | 16 W  |
| 43  | 20 W  |
| 44  | 25 W  |
| 45  | 32 W  |
| 46  | 40 W  |
| 47  | 50 W  |

# Attenuation, using dBm & dB



# Impact of signal frequency

- Free Space Path Loss model


$$\text{FSPL} = \left( \frac{4\pi d}{\lambda} \right)^2 \quad FSPL = \frac{P_t}{P_r} G_t G_r$$

$$= \left( \frac{4\pi df}{c} \right)^2$$

FSPL assume Gt=Gr=1

$$L_{(dB)} = 10 \log \left( \frac{P_t}{P_r} \right) = 20 \log \left( \frac{4\pi d}{\lambda} \right) = 20 \log \left( \frac{4\pi fd}{c} \right)$$


$$L_{(dB)} = 20 \log(f) + 20 \log(d) - 147,55 \text{ dB}$$



# Link budget in wireless system

$$P_{RX} = P_{TX} + G_{TX} - L_{TX} - L_{FS} - L_M + G_{RX} - L_{RX}$$

Adapted from Peter R. Egli, INDIGOOCOM



$P_{RX}$  = Received power (dBm)

$P_{TX}$  = Sender output power (dBm)

$G_{TX}$  = Sender antenna gain (dBi)

$L_{TX}$  = Sender losses (connectors etc.) (dB)

$L_{FS}$  = Free space loss (dB)

$L_M$  = Misc. losses (multipath etc.) (dB)

$G_{RX}$  = Receiver antenna gain (dBi)

$L_{RX}$  = Receiver losses (connectors etc.) (dB)

$S_{RX}$  = Receiver sensitivity (dBm)



# Receiver's sensitivity

- Receiver's sensitivity is a measure of how well the receiver performs and is defined as the power of the weakest signal the receiver can detect
- How low can you go?




# Shadow fading & Multi-path fading

- ➊ Things are getting even worse!
- ➋ Shadow fading by obstacles
- ➌ Multi-path fading
- ➍ ...





# Frequency re-use




# 2<sup>nd</sup> challenge: energy cost

Moisture/  
Temperature of  
storage areas




| Technology                     | 2G        | 3G         | LAN               |
|--------------------------------|-----------|------------|-------------------|
| Range<br>(I=Indoor, O=Outdoor) | N/A       | N/A        | O: 300m<br>I: 30m |
| Tx current consumption         | 200-500mA | 500-1000mA | 100-300mA         |
| Standby current                | 2.3mA     | 3.5mA      | NC                |

# Low-power, long-range radios for IoT systems: LPWAN networks



# Energy consumption comparaison



| 2G        | 3G         | LAN               | ZigBee           | Lo Power WAN  |
|-----------|------------|-------------------|------------------|---------------|
| N/A       | N/A        | O: 300m<br>I: 30m | O: 90m<br>I: 30m | Same as 2G/3G |
| 200-500mA | 500-1000mA | 100-300mA         | 18mA             | 18mA-40mA     |
| 2.3mA     | 3.5mA      | NC                | 0.003mA          | 0.001mA       |



TX power: 500mA. Mean consumption:  $(8s \times 500 + 3592s \times 0.005)/3600 = 1.11mA$

$2500/1.11 = 2252h = 93 \text{ days} = 3 \text{ months } \ominus$

2500mA


In most cellular networks, the device is still maintaining communication with BS even if it is inactive

TX power: 40mA. Mean consumption:  $(2s \times 40 + 3598s \times 0.005)/3600 = 0.027mA$

$2500/0.027 = 92592h = 3858 \text{ days} = 10 \text{ y. } \oplus$

LPWAN does not need to maintain connection if not in use

# Expected range?




# How can we increase range?



I'm not fluent in idiot  
 could you please speak




- Increase TX power and/or improve RX sensitivity
- Generally, RX sensitivity (~robustness) can be increased when transmitting (much) slower (**like speaking slower!**)
- LoRa uses spread spectrum approach to increase RX sensitivity
  - Spreading Factor defines how many chips will be used to code a symbol.  
 More chip/symbol=longer transmission time → more robustness
- **The price to pay for LPWAN**
  - LoRa has **very low** throughput: **200bps-37500bps (0.2-37.5kbps)**



- WiFi 802.11n: 450 000 000 bps (450Mbps)
- WiFi 802.11g: 54 000 000 bps (54Mbps)
- Bluetooth3&4: 25 000 000 bps (25Mbps)
- Bluetooth BLE: 2 000 000 bps (2Mbps)
- 3G/4G : 20Mbps-200Mbps
- **LoRa**: **200bps-37500bps (0.0002-0.0375Mbps)**
- **3G/LoRa ratio: 20,000,000bps/200bps=100000!**

# Chirp Spread Spectrum in LoRa

- Compressed High Intensity Radar Pulse (CHIRP) is a signal which frequency either increases or decreases in time, in a deterministic way



- Can be very low power, but then low data rate!
- Very high interference immunity
  - Thus adapted to very large distances
  - Better resistance to frequency shift (e.g. Doppler shift, low-cost oscillator)

# LoRa spreading factor in image

- Higher spreading factor means lower data rate but increased receiver sensitivity




Figure from "All About LoRa and LoRaWAN", <https://www.sghosly.com>

# LoRa modules with Semtech's SX127x



DORJI DRF1278DM is based on Semtech SX1278 LoRa 433MHz



Libelium LoRa is based on Semtech SX1272 LoRa 863-870 MHz for Europe



inAir9 based on SX1276



Eggy Factory LoRa module (Arduino)



HopeRF  
RFM  
series

## KEY PRODUCT FEATURES

- ◆ LoRa® Modem
- ◆ 168 dB maximum link budget
- ◆ +20 dBm - 100 mW constant RF output vs. V supply
- ◆ +14 dBm high efficiency PA
- ◆ Programmable bit rate up to 300 kbps
- ◆ High sensitivity: down to -148 dBm



Multi-Tech  
MultiConnect mDot



ARM-Nano N8 LoRa module from ATIM



SODAQ LoRaBee  
Embit




LoRa™ Long-Range Sub-GHz Module  
(Part # RN2483)

Microchip RN2483



SODAQ LoRaBee  
RN2483


# What distance for -148dBm?



|      |         |
|------|---------|
| -26  | 1       |
| -32  | 2       |
| -38  | 4       |
| -44  | 8       |
| -50  | 16      |
| -56  | 32      |
| -62  | 64      |
| -68  | 128     |
| -74  | 256     |
| -80  | 512     |
| -86  | 1024    |
| -92  | 2048    |
| -98  | 4096    |
| -104 | 8192    |
| -110 | 16384   |
| -116 | 32768   |
| -122 | 65536   |
| -128 | 131072  |
| -134 | 262144  |
| -140 | 524288  |
| -146 | 1048576 |
| -152 | 2097152 |

# Line-of-Sight & Fresnel zone


- LoS means clear Fresnel zone
- Football (american) shape
- Acceptable = 60% of zone 1 + 3m



# In real environment!




# Clearing the Fresnel zone? Raise antennas!




$$r_n = \sqrt{\frac{d_1 d_2}{d_1 + d_2}}$$

| Range Distance   | 900 MHz Modems Required Fresnel Zone Diameter | 2.4 GHz Modems Required Fresnel Zone Diameter |
|------------------|---|---|
| 1000 ft. (300 m) | 16 ft. (5 m)                                  | 11 ft. (3.4 m)                                |
| 1 Mile (1.6 km)  | 32 ft. (10 m)                                 | 21 ft. (6.4 m)                                |
| 5 Miles (8 km)   | 68 ft. (21 m)                                 | 43 ft. (13 m)                                 |
| 10 Miles (16 km) | 95 ft. (29 m)                                 | 59 ft. (18 m)                                 |



# Clearing the Fresnel zone? Let's use satellite!

- Low-orbit, low-cost; compact satellite for global coverage



<https://lacuna.space/first-successful-lacunasat-launch-in-2021/>