
This document explains the function of the Comms, its schematic level design, its board level design, and its functional testing

# Comms

In-Orbit Communication Subsystem Design

Revision: 1.0.2

Bradley Davis



## **Table of Contents**

1	Intro	oduct	tion5
	1.1	Fund	ction5
	1.2	Req	uirements5
	1.3	Ope	n Systems Interconnection (OSI) Model5
	1.3.	1	Layers5
	1.3.	2	CougSat Communication Subsystem6
	1.4	Link	Budget6
2	Deta	ailed	Description
	2.1	Fund	ctional Block Diagram7
	2.1.	1	Comms µController
	2.1.	2	RF Clock Generators
	2.1.	3	700mm Receiver Radio
	2.1.	4	700mm Transmitter Radio
	2.1.	5	230mm Transmitter Radio8
	2.1.	6	5V & 9V Boost Converters8
	2.2	Sche	ematic8
	2.2.	1	Isolated Grounds8
	2.2.	2	Power Rails8
	2.2.	3	Comms µController8
	2.2.	4	I <sup>2</sup> C Bus9
	2.2.	5	SPI Bus9
	2.2.	6	Current Monitoring
	2.2.	7	Voltage Monitoring
	2.2.	8	Temperature Monitoring
	2.2.	9	Analog Voltage Reference and Supply10
	2.2.	10	5.0V Regulation11
	2.2.	11	9.0V Regulation11
	2.2.	12	Low Drop-Out Regulators
	2.2.	13	RF Clock Generators
	2.2.	14	Differential Drivers





	2.2	2.15	RF Modulators	12
		2.16	RF Demodulator	
		2.17	Low Noise Amplifier	
		2.18	Power Amplifiers	
		2.19	Mechanical Features	
	2.3	Boa	ırd	
	2.3		Layer Stack-Up	
	2.3	3.2	Layout Constraints	14
3	Tes	sting	· · · · · · · · · · · · · · · · · · ·	
	3.1	Befo	ore First Power-On Check	16
	3.1	1	Test Instructions	16
	3.1	2	Test Data	16
	3.1	3	Test Notes	17
	3.2	Pow	ver Rail Switching	17
	3.2	2.1	Test Instructions	17
	3.2	2.2	Test Data	17
	3.2	2.3	Test Notes	17
	3.3	I <sup>2</sup> C I	Bus	17
	3.3	3.1	Test Instructions	18
	3.3	3.2	Test Data	18
	3.3	3.3	Test Notes	19
	3.4	SPI	Bus	19
	3.4	1.1	Test Instructions	19
	3.4	1.2	Test Data	19
	3.4	1.3	Test Notes	20
	3.5	Curi	rent Monitoring	20
	3.5	5.1	Test Instructions	20
	3.5	5.2	Test Data	20
	3.5	5.3	Test Notes	21
	3.6	Volt	tage Monitoring	21
	3.6	5.1	Test Instructions	21
	3.6	5.2	Test Data	21





3.6.3	Test Notes	21
3.7 Ter	mperature Monitoring	21
3.7.1	Test Instructions	21
3.7.2	Test Data	22
3.7.3	Test Notes	22
3.8 Ana	alog Voltage Reference	22
3.8.1	Voltage	22
3.8.2	Ripple	22
3.8.3	Noise	23
3.9 μC	ontroller Programming	23
3.9.1	Test Instructions	24
3.9.2	Test Data	24
3.9.3	Test Notes	24
3.10 5.0	V and 9.0V Regulator	24
3.10.1	Output Voltage	24
3.10.2	Output Ripple	25
3.10.3	Output Noise	25
3.10.4	Output Efficiency	25
3.10.5	Current Limit	27
3.10.6	Load Response	28
3.11 Lov	w Drop-Out Regulators	30
3.11.1	Output Voltage	30
3.11.2	Output Ripple	30
3.11.3	Output Noise	31
3.12 RF	Clock Generators	31
3.12.1	Reference Clock Supply	31
3.12.2	Reference Clock Frequency	31
3.12.3	Output Frequency	32
3.13 Dif	ferential Drivers	32
3.13.1	Test Instructions	32
3.13.2	Test Data	33
3.13.3	Test Notes	33





3.14	Pow	ver Amplifier Bias	33
3.14	4.1	Test Instructions	33
3.14	4.2	Test Data	33
3.14	4.3	Test Notes	33
3.15	RF C	Chain – 230mm Downlink	33
3.15	5.1	Test Instructions	33
3.15	5.2	Test Data	34
3.15	5.3	Test Notes	34
3.16	RF C	Chain – 700mm Downlink	34
3.16	5.1	Isolation Switch	34
3.16	6.2	Digital Modulation	35
3.16	6.3	Analog Modulation	35
3.17	RF C	Chain – 700mm Uplink	36
3.17	7.1	Test Instructions	36
3.17	7.2	Test Data	36
3.17	7.3	Test Notes	37





## 1 Introduction

This document explains how the Comms will fulfil the following Functions and conform to the following Requirements. This document refers to the Comms version 1.0, +X Panel version 1.0, and -Z Panel version 1.0.

## 1.1 Function

The In-Orbit Communication Subsystem (Comms) is responsible for the following:

- Transferring telemetry to the ground station
- Transferring payload data to the ground station
- Transferring commands from the ground station
- Transmitting a locating beacon

## 1.2 Requirements

The system requirements and Comms design requirements can be found on GitHub.

## 1.3 Open Systems Interconnection (OSI) Model

The OSI model<sup>1</sup> is a conceptual model that can be applied to any communication system. It has eight layers; each layer serves the layer above it and is served by the layer below it.

## 1.3.1 Layers

	Layer		Protocol Data Unit	Function
	7	Application		High-level APIs
Host	6	Presentation	Data	Translation of data between a networking service and an application
layers	5	Session		Managing communication sessions
	4	Transport	Segment	Reliable transmission of data segments between points on a network
	3	Network	Packet	Structuring and managing a multi- node network
Media layers	2	Data link	Frame	Reliable transmission of data frames between two nodes connected by a physical layer
tayers	1	Physical	Symbol	Transmission and reception of raw bit streams over a physical medium
	0	Medium	Electrons, Photons	The physical medium: copper, fiber, wireless

<sup>&</sup>lt;sup>1</sup> For more information, read Wikipedia's article on the OSI model





## 1.3.2 CougSat Communication Subsystem

The communication subsystem, formed from the in-orbit and ground subsystems, fulfils layers 0 through 2 of the OSI model. The Comms serves the Command and Data Handling (C&DH) subsystem which fulfils layers 3 and up. The Ground serves itself for layers 3 and up which results in a graphical representation of the exchanged information. The in-orbit and ground subsystems are very similar as they are required to be compatible. For details on the ground subsystem, see its <u>design document</u>.

#### 1.3.2.1 Layer 0

The communication subsystem is using wireless transmission, in the radio frequency band. There are two bands utilized: 700mm and 230mm. The 700mm radio is the primary radio used for telemetry and beacon. The 230mm radio is the secondary radio used for payload data transfers and only operates in downlink mode.

#### 1.3.2.2 Layer 1

The modulation scheme used is Quadrature Phase Shift Keying (QPSK)<sup>2</sup>. Each symbol is a change in the phase constant of the RF wave. The radios are software defined radios which allows reconfiguration of this layer if necessary. Other modulation schemes can be developed if the hardware supports it.

#### 1.3.2.3 Layer 2

See the Comms µController's Framing Protocol.

#### 1.3.2.4 Layer 3 and Up

See the Ground's Communication Protocol.

## 1.4 Link Budget

A <u>link budget</u> for downlink and uplink was tabulated indicating a transmit power of 1W is sufficient for up to 500kbps on the 230mm band. The 700mm band transmitter will incur less loses<sup>3</sup> and send slower data<sup>4</sup> so 1W is also sufficient. Uplink has no problems thanks to access to high gain and high-power transmitters on the ground.

<sup>&</sup>lt;sup>4</sup> A slower data rate has looser requirements for signal-to-noise ratio because there is more time to decode the symbol





<sup>&</sup>lt;sup>2</sup> For more information, read Wikipedia's article on Phase Shift Keying (PSK)

<sup>&</sup>lt;sup>3</sup> <u>Free-space path loss</u> is proportional to frequency squared

## 2 Detailed Description

This section references the Comms <u>schematic</u>. Page numbers will be listed and may have coordinates listed (number and letter combination found around the frame).

## 2.1 Functional Block Diagram

The block diagram can be found on the first page of the schematic.

## Comms µController

The Comms µController is responsible for interfacing the radio signals and the Command and Data Handling subsystem<sup>5</sup>. This fulfils OSI model<sup>6</sup> layers 1 and 2. It samples and synthesizes the baseband signals which are mixed with the carrier wave. This constitutes a software defined radio. The µController has nonvolatile storage in the form of SPI Flash to store configurations and reference waveforms

#### **RF Clock Generators** 2.1.2

Each radio has a configurable clock generator used to synthesize the carrier waves. For the transmission of the beacon, the generator is the direct source without any modulation to the antenna<sup>7</sup>.

#### 2.1.3 700mm Receiver Radio

Its RF diagram is the top row on page 2. The RF signal from the antenna is connected to the receiver radio via a high isolation RF switch. This switch prevents the transmitter from overdriving the sensitive receiver components and inducing damage. The signal is then amplified by low noise amplifiers which add very little noise to the signal to maintain the highest signal to noise ratio. The signal is then connected to the demodulator which removes the carrier frequency and splits that baseband signal into its in-phase and quadraturephase signals which are then sampled by the Comms µController and demodulated into binary. The receiver radio is designed for continuous operation and low power8.

#### 2.1.4 700mm Transmitter Radio

Its RF diagram is the middle row on page 2. The Comms µController generates in-phase and quadrature-phase baseband signals using its digital to analog converter. This allows arbitrary waveform including voice signals9. These signals feed the modulator which puts the baseband signals on the carrier wave. This modulated RF gets amplified with a power amplifier to transmit the desired 1W, see the Link Budget.

<sup>9</sup> Requirement COMMS-006





<sup>&</sup>lt;sup>5</sup> Requirements COMMS-008, COMMS-009

<sup>&</sup>lt;sup>6</sup> Open Systems Interconnection (OSI) Model

Requirements COMMS-001
 Requirement COMMS-005

## 2.1.5 230mm Transmitter Radio

Its RF diagram is the bottom row on page 2. The Comms µController generates in-phase and quadrature-phase baseband signals using fast GPIO. This only allows each signal to be discrete positive or negative as found in QPSK modulation. If arbitrary waveforms are desired, an external DAC is needed. These signals feed the modulator which puts the baseband signals on the carrier wave. This modulated RF gets amplified with a power amplifier to transmit the desired 1W, see the Link Budget.

## 2.1.6 5V & 9V Boost Converters

The RF chains require 5V and 9V supplies which come from boost converters. The converters are sourced from the battery rail.

## 2.2 Schematic

## 2.2.1 Isolated Grounds

On page 3 of the schematic (D1 & D2), are the six isolated grounds found on the Comms. Power ground (PGND) is directly connected to the backplane and the boost converters. Most of the other grounds are shorted to PGND using a 0\Omega resistor rated up to 2A, the expected current is less than 500mA each. Digital ground (DGND) connects to the digital circuity including the Comms \(\mu\)Controller. Analog ground (AGND) connects to analog circuits including the ADCs, the voltage references, the thermistors, and the operational amplifiers. AGND connects to DGND. Chassis ground (CHASSIS) is connected to the Mechanical Features including bolt holes and the card rails. The 230mm RF chain and the 700 RF chains each have their own RF grounds (RFGND-0 and RFGND-1, respectively).

## 2.2.2 Power Rails

Page 3 of the schematic illustrates all the power rails on the Comms. Each RF chain can be turned off to save power and as a radio inhibit<sup>10</sup>.

## 2.2.3 Comms µController

The Comms µController (page 4, A3, C1, C2, & C4) is a microcontroller from the STM32 low power family<sup>11</sup>. It was chosen for its ease of programming, and low power consumption. It needed fast ADCs and DACs for sampling and synthesizing the baseband signals.

The µController's reset pin is connected to the backplane such that if it or any subsystem needs to reset itself, all the subsystems reset. This is to put all the subsystems in a known state which reduces cause for error.

#### 2.2.3.1 Programming Connections

During testing, the Comms µController is programmed via Serial Wire Debug<sup>12</sup> (SWD, page 4, A1). The process of programming is made simple with just a

<sup>&</sup>lt;sup>12</sup> For more information, see <u>ARM's article</u> on SWD





<sup>&</sup>lt;sup>10</sup> Requirement REQ-005

<sup>&</sup>lt;sup>11</sup> STM32L476RG

single six pin header and a robust software utility. In orbit, the µController can be programmed via JTAG<sup>13</sup>. The <u>In-Flight JTAG Reprogrammer</u> (IFJR) connects via the backplane, through tri-state buffers/logic level converters<sup>14</sup> (page 4, C1:D2). The IFJR can enable or disable the tri-state buffer which essentially disconnects the JTAG interface from the Comms µController (it outputs high impedance), allowing the SWD to program. The logic level conversion feature is not used.

## 2.2.4 I<sup>2</sup>C Bus

The Comms µController has one I<sup>2</sup>C bus (page 4, C4). It connects to the monitoring ADCs.

#### 2.2.4.1 ADCs

There are 3 ADCs<sup>15</sup> connected to the Comms µController, each with 16 single-ended inputs or eight differential inputs or a combination. The ADC was chosen for its low power, differential inputs, small package, and up to 27 addresses. The list of address follow:

- [0xEE] Global ADC address
- [0x28] ADC-0 (page 10, A2), voltage and current
- [0x2A] ADC-1 (page 10, A4), voltage and current
- [0x2E] ADC-2 (page 10, C2), voltage and current

The ADCs' mux output and ADC input have voltage dividers (page 10, B2, B4, & D2) that reduces the voltage of every input to place their level within the sensing range. Using paired resistors helps match the source impedance to the ADC across temperature. A mismatch results in an offset. The input range is  $\frac{Vref}{2}*$   $\frac{25k\Omega}{5k\Omega}=4.5V$  but is limited by the IC's ESD diodes<sup>16</sup> to the supply rail of 3.3V. To allow even high input voltages, those nets have series resistors (page 10, C1 & C3). With  $20k\Omega, V=3.3V*\frac{45k\Omega}{25k\Omega}=5.9V$ . With  $50k\Omega, V=3.3V*\frac{75k\Omega}{25k\Omega}=9.9V$ .

## 2.2.5 SPI Bus

The Comms  $\mu$ Controller has three SPI buses<sup>17</sup>. One connects to the C&DH to transfer packets and telemetry. One connects to the RF Clock Generators. One connects to the  $\mu$ SD cards.

#### 2.2.5.1 Backplane to the C&DH

The Comms µController is a slave to the C&DH, see the <u>interface document</u> for details.

<sup>&</sup>lt;sup>17</sup> For more information, see Wikipedia's article on SPI





<sup>&</sup>lt;sup>13</sup> For more information, see Wikipedia's article on JTAG

<sup>&</sup>lt;sup>14</sup> TXS0102

<sup>15</sup> TC2499

<sup>&</sup>lt;sup>16</sup> ESD diodes are reversed biased diodes between every pin and VCC and GND. When a pin is above VCC or below GND, these diodes conduct. The intent is to prevent ESD transients from harming the device, they are not designed for continuous conduction

#### 2.2.5.2 RF Clock Generators

The Comms µController is a transmit only master to the RF Clock Generators. Each generator has a tri-state buffer (page 8, A2, & C2; page 9, B2) which only connects the bus if the generator's rail is on. Without this, when the generator is turned off, its ESD diodes would prevent the bus from moving above GND effectively disabling the bus.

#### 2.2.5.3 SPI Flash

The Comms µController is a master to two SPI Flash chips<sup>18</sup> (page 15) that provides 16Mb of mirrored storage or 32Mb of striped storage.

## 2.2.6 Current Monitoring

At various locations, the power chain has shunt resistors connected to ADCs in differential mode to monitor the current. Those locations are:

- 5V Regulator output (page 6, B6)
- 9V Regulator output (page 6, C6)
- Each RF chain input (page 7)

## 2.2.7 Voltage Monitoring

At various locations, the power chain is probed for the voltage using the ADCs in single ended mode. Those locations are:

- 5V Regulator output (page 6, B6)
- 9V Regulator output (page 6, C6)

## 2.2.8 Temperature Monitoring

At various locations, the temperature is monitored using thermistors and the ADCs in single ended mode. Those locations are:

- 5V Regulator (page 6, A3)
- 9V Regulator (page 6, C3)
- Comms µController (page 4, B4)
- RF clock generators (page 8, A4, C4; page 9, B4)
- 230mm downlink RF chain (page 11, B3, B5, & D4)
- 700mm downlink RF chain (page 12, B3, B5, & D5)
- 700mm uplink RF chain (page 13, B4 & C4; page 14, C4)

## 2.2.9 Analog Voltage Reference and Supply

The Comms has a precision voltage reference<sup>19</sup> (page 5, B6) for calibrating the ADCs. This is inputted into the ADCs' reference input.

The Comms has an analog voltage supply (page 5, C6) which is fed by the 3.3V rail filtered with a ferrite bead and capacitors. Precision is not required as all ADCs use the precision voltage reference for calibration. This is the source for the Temperature Monitoring thermistors and operational amplifiers. A negative





<sup>&</sup>lt;sup>18</sup> <u>IS25LP016D</u> <sup>19</sup> <u>MCP1501</u>

voltage supply<sup>20</sup> for the op-amps takes the 3.3V rail and inverts it (page 10, C4:C6) to supply the op-amps' negative supply.

## 2.2.10 5.0V Regulation

The 5.0V regulator (page 6, B1:B6) is switching mode, boost topology. The converter<sup>21</sup> automatically senses the output voltage and adjusts the switching parameters to keep the output at 5.0V. The converter has an integrated switching MOSFET. The converter was chosen for its small size and high efficiency. The output voltage is tuned to 5.1V to allow enough head room for the 5.0V Low Drop-Out Regulators to properly regulate.

The large package Multi-Layer Ceramic Capacitors (MLCC, input and output filtering) are placed in series such that one was to fail short, they would not compromise the power chain. The small package and tantalum capacitors are not likely to fail due to mechanical vibration.

The converter and inductor (page 6, B2:B3) are thermally connected to a thermistor for Temperature Monitoring and an optional heatsink if a thermal test indicates they need additional heat dissipation.

## 2.2.11 9.0V Regulation

The 9.0V regulator (page 6, C1:C6) is switching mode, boost topology. The converter<sup>22</sup> automatically senses the output voltage and adjusts the switching parameters to keep the output at 9.0V. The converter has an integrated switching MOSFET. The converter was chosen for its small size and high efficiency.

The large package Multi-Layer Ceramic Capacitors (MLCC, input and output filtering) are placed in series such that one was to fail short, they would not compromise the power chain. The small package and tantalum capacitors are not likely to fail due to mechanical vibration.

The converter and inductor (page 6, C2:C3) are thermally connected to a thermistor for Temperature Monitoring and an optional heatsink if a thermal test indicates they need additional heat dissipation.

## 2.2.12 Low Drop-Out Regulators

The sensitive RF components are supplied through low drop-out (LDO) regulators<sup>23</sup> (page 7, B2, B4, B6, C2, C4, & C6). These are linear regulators that require a small drop-out<sup>24</sup> for proper regulation. They are used to reject the switching noise from the switching mode power supplies. The "3.3V" LDO regulators are might require the Electrical Power Subsystem to tune its 3.3V regulator to a higher voltage to allow enough head room for proper regulation.

<sup>20</sup> LM2776 and <u>TPS732</u>
<sup>21</sup> TPS61236
<sup>22</sup> TPS61089
<sup>23</sup> TPS73250 and LP5907

<sup>&</sup>lt;sup>24</sup> Voltage difference between input and output





## 2.2.13 RF Clock Generators

The RF Clock Generators<sup>25</sup> (page 8, A3, & C3; page 9, B3) have a voltage-controlled oscillator and a phase-locked loop to take a reference clock and synthesize a RF wave. The reference clocks<sup>26</sup> (page 8, A3, & C3; page 9, C3) have high frequency stability and are supplied with ferrite beads to further increase frequency stability. The supporting circuitry for the generators was created using Analog Device's <u>ADIsimPLL</u>. The design files can be found under the <u>documentation folder</u>. The output of the generators is designed to drive a 50 $\Omega$  load.

The 700mm Receiver Radio's demodulator divides its clock input by two, so the RF clock generator needs to output double the carrier frequency.

## 2.2.14 Differential Drivers

The Comms µController outputs its basebands signals 0 to 3.3V single ended. The modulators' baseband signals are differential with a different amplitude. The differential output op-amps<sup>27</sup> (page 10, A1:D3) are used to perform this translation. The µController input is subtracted from a 1.65V reference (page 10, A4:A6) then multiplied by the proper gain to have the 3.3Vpp signal reduced to 1.0Vpp or 0.6Vpp as the modulator desires. This signal is then added to the proper common mode voltage reference (page 10, B4:B6, C4:C6). This circuit was simulated in LTSpice and can be found under electrical design. Precision resistors are used to reduce any common mode offset or gain imbalance.

## 2.2.15 RF Modulators

The 700mm Transmitter Radio's modulator (page 12, B3) and the 230mm Transmitter Radio's modulator (page 11, B3) have the RF Clock Generators AC coupled into their local oscillator input, and the Differential Drivers are directly connected to the baseband inputs. The RF output is AC coupled to the next element in the RF chain.

## 2.2.16 RF Demodulator

The 700mm Receiver Radio's demodulator (page 14, B3:B4) has the RF Clock Generators AC coupled into its local oscillator input. The  $60.4\Omega$  termination resistor is used to match a  $50\Omega$  input into the demodulator. The RF signal is connected to the modulator's input through a 1:4 balun (page 13, B2) to match a  $50\Omega$  input into the demodulator. The gain of the demodulator is set by a voltage divider (page 14, B2) which is initially set to maximum gain.

The demodulator outputs differential baseband signals  $1.0V \pm 500mV$ . this amplified and translated to  $1.65V \pm 1V$  single ended for input to the Comms





<sup>&</sup>lt;sup>25</sup> ADF4360

<sup>26</sup> ECS-TXO-3225

µController's ADC by op-amps<sup>28</sup> (page 13, C2 & C5). This circuit was simulated in LTSpice and can be found under <u>electrical design</u>.

## 2.2.17 Low Noise Amplifier

The low noise amplifiers (LNA)<sup>29</sup> (page 11, B5; page 12, B5; page 13, B3 & C3) amplify the RF signal for the next component in the RF chain. They were chosen for their low noise figure, broadband response, and high gain. The gain is set by the bias voltage and is 19dB. For the 700mm Receiver Radio's LNAs, the bias voltage can be shorted to ground which disables the amplifier. This is required, along with toggling the RF switch, when transmitting on 700mm to not damage the demodulator. The output is biased via a ferrite bead to provide power yet decouple the RF signal from the power supply. The output is AC coupled to feed into the next component.

## 2.2.18 Power Amplifiers

The power amplifiers<sup>30</sup> (page 10, C4; page 11, C4) are the final amplifiers for the RF signal. They drive the antennas and output the desired 1W, see the Link Budget. They were chosen for the output power, linearity, and broadband response. The gain is set by the bias voltage of -4 to 0V. The Comms  $\mu$ Controller outputs a PWM signal which is filtered and inverted to achieve an adjustable range of -3.3V to 0V. This is achieved by op-amps<sup>31</sup>. This circuit was simulated in LTSpice and can be found under <u>electrical design</u>. The output is biased via an inductor to provide power yet decouple the RF signal from the power supply. The output is AC coupled to feed into the antennae.

## 2.2.19 Mechanical Features

The 5V & 9V Boost Converters heatsink (page 6, D1:D2) and RF chain heatsinks (page 11, D1; page 12, A1) mount directly to the Comms board using bolts. These holes are conductive and connected directly to *CHASSIS*, see Isolated Grounds. The Comms also slots into the structure using rails<sup>32</sup> which are also conductive and connected directly to *CHASSIS*. Each of the holes have a capacitor and resistor connecting to power ground which will absorb and dissipate transients.

## 2.3 Board

The board shall also conform to the dimensions specified by the <u>CougSat Module Standard</u>.

<sup>&</sup>lt;sup>32</sup> See <u>backplane documentation</u> for details





<sup>&</sup>lt;sup>28</sup> <u>AD8515</u>

<sup>&</sup>lt;sup>29</sup> MAAP-011229

<sup>30</sup> MAAP-011232

<sup>31</sup> AD8515

## 2.3.1 Layer Stack-Up

The board shall be four layered with ENIG finish, see Figure 1. Only through vias shall be used. The external copper weight shall be  $35\mu m$  and the internal copper weight shall be  $18\mu m$ .

Layer	Thickness	Primary Function
1 (top)	35μm (1 <i>oz</i> )	SMD components, RF & signal traces
Prepreg	200μm	
2	18μm (0.5 <i>oz</i> )	Ground planes
Core	$500\mu m$	
3	$18\mu m (0.5oz)$	Power planes
Prepreg	200μm	
4 (bottom)	35μm (1 <i>oz</i> )	Signal traces

Figure 1: Stack-Up

## 2.3.2 Layout Constraints

Unless specified in the following subsections, all signals shall use the default parameters below. Signals in the following subsections do not include their sense signals unless otherwise specified. Trace width can be broken if a trace needs to bottleneck down to a pin, the bottleneck shall be minimized.

Trace width: 0.16mm

Vias:  $\emptyset 0.3mm$ , unlimited count

Separation: 0.16mm Length: unlimited

Devices with specific placement and routing considerations are called out on the schematic, see "CAD Note:"

## 2.3.2.1 All $50\Omega$ Impedance Traces

This applies to all RF traces expect the demodulator's RF input. These traces shall be a coplanar waveguide with ground<sup>33</sup>.

Trace width: 0.35mm

Gap width: 0.16mm

Vias: none

Length: minimize

#### 2.3.2.2 All 200 $\Omega$ Impedance Traces

This applies to the demodulator's RF input. These traces shall be an edge coupled microstrip<sup>34</sup> with differential impedance of  $200\Omega$ . Ground located on second layer below (0.8mm substrate thickness).

Trace width: 0.16mm

Gap width: 0.4mm

Vias: none

Length: minimize

<sup>&</sup>lt;sup>34</sup> For more information, see <u>Microwaves101's article</u> on microstrips





<sup>33</sup> For more information, read Microwaves101's article on CPW

## 2.3.2.3 All Differential Signals

This applies to the modulators' inputs. Single ended to/from differential shall occur as close to the single ended side as possible.

Trace width: 0.16mm Gap width: 0.16mm

Length: Length match  $\pm 1.0mm$ 

Vias: minimize

## 2.3.2.4 Regulator Inputs - VBATT, PGND

This applies to *VBATT* and *PGND* between the backplane and the inputs to the regulators and their input capacitors.

Trace width: 1.0mm (2.0mm on internal layers)

## 2.3.2.5 Regulator Outputs - 5.0V, 9.0V, PGND

*PGND* applies to between the regulators, their output capacitors, and the backplane.

Trace width: 0.5mm (1.0mm on internal layers)

## 2.3.2.6 Regulator Channels - 3.3V\_[0:3], 5.0V\_[0:3], 9.0V\_[0:1], PGND

*PGND* applies to between the regulators, their loads, and the backplane.

Trace width: 0.5mm (1.0mm on internal layers)

## 2.3.2.7 SPI Buses - SPL [SCK, MOSI, MISO, CS], RFCLK\_[SCK, MOSI, CS], COM\_SPL [SCK, MOSI, MISO, CS]

Length: Each node shall be length matched  $\pm 1.0mm$ 

Stubs: < 10.0*mm* 

## 2.3.2.8 JTAG-JTAG\_[TCK, TDI, TDO, TMS], BUS\_JTAG-[TCK, TDI, TDO, TMS]

Length: Each node shall be length matched  $\pm 1.0mm$ 

Stubs: < 10.0*mm* 

## 

Length: Each node shall be length matched  $\pm 1.0mm$ 

Stubs: < 10.0*mm* 





## 3 Testing

All tests shall be performed at room temperature and not under vacuum unless otherwise specified. If any modifications are performed, take note. Include enough information to understand circuit behavior and for others to replicate the results. Include any software written to execute the test and link it in the test notes section. Save all software, waveforms, etc. in a subfolder of the board's test folder for each test<sup>35</sup>.

- Waveforms shall be captured whenever appropriate
- Have the event take fill the screen (for fast events, zoom in; for slow events, zoom out)
- Label each channel accurately
- Only have bandwidth limiting if necessary for the test (this applies to the oscilloscope and probe settings)
- If ringing or overshoot occurs, use a ground spring or differential probe

Results location: <a href="https://github.com/CougsInSpace/CougSat1-">https://github.com/CougsInSpace/CougSat1-</a> Hardware/tree/master/CougSat1-PowerBoard/Testing/Comms.1.0

Common test instructions can be found on the wiki.

## 3.1 Before First Power-On Check

This test is required to be executed before any external power is applied to the Comms.

#### 3.1.1 Test Instructions

Measure the resistance of various points in reference to *PGND* located at the backplane. Measure the resistance across each current shunt resistor. This is informational only; the resistance of the current shunt resistor is used to calibrate the Current Monitoring.

#### 3.1.2 Test Data

Node	Resistance	Node	Resistance
VBATT		3.3V	
3.3V-0		3.3V-1	
3.3V-2		5.0V	
5.0V-0		5.0V-1	
5.0V-2		9.0V	
9.0V-0		9.0V-1	
I2C_SCL		I2C_SDA	

Net	Resistor	Value	Net	Resistor	Value
3.3V-0	R4		3.3V-1	R113	
3.3V-2	R37		5.0V Output	R1	
5.0V-0	R5		5.0V-1	R114	
5.0V-2	R38		9.0V Output	R15	

<sup>35</sup> For test 3.1, place files in the subfolder "3.1" and so on





Net	Resistor	Value	Net	Resistor	Value
9.0V-0	R27		9.0V-1	R39	

## 3.1.3 Test Notes

Delete me if no notes are required.

## 3.2 Power Rail Switching

Results: Pass / Fail

This test evaluates the circuit described in Power Rails.

## 3.2.1 Test Instructions

Hold the µController in reset or program a blank image, verify the power rails are powered off. Have the µController enable the power rail, verify the power rails are powered on, ensuring the rail turns on only with its control signal.

## 3.2.2 Test Data

Hold the µControlle	Hold the µController in reset, measure the voltage of each power rail						
Rail	Voltage	Passing Criteria	Pass / Fail				
3.3V-0		Voltage < 50mV					
3.3V-1		Voltage < 50mV					
3.3V-2		Voltage < 50mV					
5.0V-0		Voltage < 50mV					
5.0V-1		Voltage < 50mV					
5.0V-2		Voltage < 50mV					
9.0V-0		Voltage < 50mV					
9.0V-1		Voltage < 50mV					

	Have the µController enable the power rail, measure the voltage of each power rail. Ensure the rail turns on only with its control signal							
Rail	Control Signal		Passing Criteria	Pass / Fail				
3.3V-0	PC_LDO_3.3V		Voltage > 3V					
3.3V-1	PC_LDO_3.3V		Voltage > 3V					
3.3V-2	PC_LDO_3.3V		Voltage > 3V					
5.0V-0	PC_MOD_230		Voltage > 4V					
5.0V-1	PC_MOD_700		Voltage > 4V					
5.0V-2	PC_DEMOD		Voltage > 4V					
9.0V-0	PC_MOD_230		Voltage > 8V					
9.0V-1	PC_MOD_700		Voltage > 8V					

## 3.2.3 Test Notes

Delete me if no notes are required.

## 3.3 **I**<sup>2</sup>C Bus

Results: Pass / Fail

This test evaluates the circuit described in I<sup>2</sup>C Bus.





## 3.3.1 Test Instructions

At the pull up resistors of the *I2C* bus, validate the following timing parameters, see Test Data table for the valid range for each parameter. Refer to Figure 2 for a definition of the timing parameters.

- V<sub>H</sub> Logic high level
- V<sub>L</sub> Logic low level
- f<sub>SDA</sub> Clock frequency
- t<sub>HD(SDA)</sub> Hold time for (repeated) start condition
- t<sub>LOW</sub> Low period of *SCL*
- t<sub>HIGH</sub> High period of *SCL*
- t<sub>SU(STA)</sub> Setup time for a repeated start condition
- t<sub>HD(SDA)</sub> Data hold time
- t<sub>SU(SDA)</sub> Data setup time
- t<sub>r</sub> Rise time for *SDA*
- t<sub>f</sub> Fall time for *SDA*
- t<sub>SU(STO)</sub> Setup time for stop condition
- t<sub>BUE</sub> Bus free time between a second start condition




Figure 2: Definition of timing parameters for Fast mode on the I<sup>2</sup>C bus

Note: The µController should generate random I2C traffic on the bus.

## 3.3.2 Test Data

A								
At the p	At the pull up resistors of the <i>I2C</i> bus, validate the following timing parameters							
Symbol	Capture the <i>SDA</i> and <i>SCL</i> lines	Value	Passing Criteria	Pass / Fail				
V <sub>H</sub>			V > 2.45V					
$V_L$			<i>V</i> < 990 <i>mV</i>					
f <sub>SDA</sub>			f < 400kHz					
t <sub>HD(SDA)</sub>			t > 600ns					
t <sub>LOW</sub>			$t > 1.3 \mu s$					
t <sub>HIGH</sub>			t > 600ns					
t <sub>SU(STA)</sub>			t > 600ns					
t <sub>HD(SDA)</sub>			0 < t < 900 ns					
t <sub>SU(SDA)</sub>			t > 600ns					
t <sub>r</sub>			30ns < t < 300ns					
t <sub>f</sub>			30ns < t < 300ns					





At the pull up resistors of the <i>I2C</i> bus, validate the following timing parameters					
Symbol	Symbol Capture the SDA and SCL lines Value Passing Criteria Pass / Fail				
t <sub>SU(STO)</sub>			t > 600ns		
t <sub>BUF</sub>			$t > 1.3 \mu s$		

## 3.3.3 Test Notes

Delete me if no notes are required.

## 3.4 SPI Bus

Results: Pass / Fail

This test evaluates the circuit described in SPI Bus.

## 3.4.1 Test Instructions

At the end (furthest away from the  $\mu$ Controller) of each SPI bus, validate the following timing parameters, see Test Data table for the valid range for each parameter.

- V<sub>H</sub> Logic high level
- V<sub>L</sub> Logic low level
- f<sub>SCK</sub> Clock frequency
- t<sub>LOW</sub> Low period of *SCK*
- t<sub>HIGH</sub> High period of *SCK*
- $t_{HD(CS)}$  Data hold time of CS
- $t_{SU(CS)}$  Data setup time of CS
- t<sub>HD(MOSI)</sub> Data hold time of *MOSI*
- t<sub>SU(MOSI</sub> Data setup time of *MOSI*

Note: The µController should generate random SPI traffic on the bus.

## 3.4.2 Test Data

At the backplane end of the COM_SPI bus, validate the following timing parameters				
Symbol Capture the SCK, MOSI, and CS Value Passing Criteria Politices				
V <sub>H</sub>			<i>V</i> > 2.30 <i>V</i>	
$V_L$			V < 990mV	
f <sub>SCK</sub>			f < 20MHz	
$t_{LOW}$			t > 25ns	
t <sub>HIGH</sub>			t > 25ns	
t <sub>HD(CS)</sub>			t > 20ns	
t <sub>SU(CS)</sub>			t > 20ns	
t <sub>HD(MOSI)</sub>			t > 10ns	
t <sub>SU(MOSI)</sub>			t > 10ns	





At t	At the U8 end of the SPI bus, validate the following timing parameters				
Symbol	Capture the <i>SCK, MOSI</i> , and <i>CS</i> lines	Value	Passing Criteria	Pass / Fail	
$V_{H}$			<i>V</i> > 2.30 <i>V</i>		
VL			V < 990mV		
$f_{SCK}$			f < 20MHz		
t <sub>LOW</sub>			t > 25ns		
t <sub>HIGH</sub>			t > 25ns		
t <sub>HD(CS0)</sub>			t > 20ns		
t <sub>SU(CS0)</sub>			t > 20ns		
t <sub>HD(MOSI)</sub>			t > 10ns		
t <sub>SU(MOSI)</sub>			t > 10ns		

At the	At the U36 end of the RFCLK bus, validate the following timing parameters				
Symbol	Capture the <i>SCK, MOSI</i> , and <i>CS</i> lines	Value	Passing Criteria	Pass / Fail	
VH			<i>V</i> > 1.5 <i>V</i>		
$V_L$			V < 600 mV		
$f_{\sf SCK}$			f < 20MHz		
t <sub>LOW</sub>			t > 25ns		
t <sub>HIGH</sub>			t > 25 ns		
t <sub>HD(CS)</sub>			t > 20ns		
t <sub>SU(CS)</sub>			t > 20ns		
t <sub>HD(MOSI)</sub>			t > 10ns		
t <sub>SU(MOSI)</sub>			t > 10 ns		

## 3.4.3 Test Notes

Delete me if no notes are required.

## 3.5 Current Monitoring

Results: Pass / Fail

This test evaluates the circuit described in Current Monitoring.

## 3.5.1 Test Instructions

Apply a 10mA to 250mA resistive load to a 9.0V-0. Compare the current measured by the Comms and a DMM.

Note: 
$$Error = \frac{|I_{Comms} - I_{DMM}|}{I_{DMM}}$$

## 3.5.2 Test Data

Apply	Apply a $10mA$ to $250mA$ resistive load to a single output channel. Compare the current measured by the Comms and a DMM					
Load	Load EPS Current DMM Current Error Passing Pass /					
10mA   Error < 1.0%						
25 <i>mA</i>				<i>Error</i> < 1.0%		





Apply	Apply a $10mA$ to $250mA$ resistive load to a single output channel. Compare the current measured by the Comms and a DMM					
Load	Load EPS Current DMM Current Error Passing Pass / Criteria Fail					
50 <i>mA</i>	50mA					
100mA	100mA					
250 <i>mA</i>				<i>Error</i> < 1.0%		

## 3.5.3 Test Notes

Delete me if no notes are required.

## 3.6 Voltage Monitoring

Results: Pass / Fail

This test evaluates the circuit described in Voltage Monitoring.

## 3.6.1 Test Instructions

Compare the voltage measured by the Comms and a DMM on the following signals:

- /\_3.3V-0N
- /\_3.3V-1P
- 5.0V

Note:  $Error = \frac{|V_{Comms} - V_{DMM}|}{V_{DMM}}$ 

## 3.6.2 Test Data

Compare the voltage measured by the Comms and a DMM					
Signal	Comms Voltage	DMM Voltage	Error	Passing Criteria	Pass / Fail
<i>I_3.3V-0N</i>				<i>Error</i> < 1.0%	
<i>L_3.3V-1P</i>				<i>Error</i> < 1.0%	
5.0V				<i>Error</i> < 1.0%	

## 3.6.3 Test Notes

Delete me if no notes are required.

## 3.7 Temperature Monitoring

Results: Pass / Fail

This test evaluates the circuit described in Temperature Monitoring.

## 3.7.1 Test Instructions

Compare the temperature measured by the Comms and a thermometer on the following temperature sensors:

- 5.0V Regulator
- µController
- +X+Y





Note:  $Error = |T_{Comms} - T_{THERMOMETER}|$ 

#### 3.7.2 Test Data

Compare the temperature measured by the Comms and a thermometer					
Sensor	Comms	Thermometer	Error	Passing	Pass /
Serisor	Temperature	Temperature	LITOI	Criteria	Fail
5.0V Regulator				Error < 2°C	
μController				Error < 2°C	
+X+Y				Error < 2°C	

## 3.7.3 Test Notes

Delete me if no notes are required.

## 3.8 Analog Voltage Reference

Results: Pass / Fail

This test evaluates the circuit described in Analog Voltage Reference and Supply and Differential Drivers. More information on measuring noise/ripple as well as using an oscilloscope can be found on the Electrical Systems Team page of the Wiki under Tutorials and Resources.

## 3.8.1 Voltage

#### 3.8.1.1 Test Instructions

Measure the voltage of the following signals:

- AVREF
- VREF\_CM\_IN
- VREF\_CM\_OUT\_230
- VREF\_CM\_OUT\_700

Note: Measure the DC component with f < 0.1Hz

## 3.8.1.2 Test Data

Measure the voltage of the following signals					
Signal	Voltage	Passing Criteria	Pass / Fail		
AVREF		1.7982V < V < 1.8018V			
VREF_CM_IN		1.635V < V < 1.665V			
VREF_CM_OUT_300		1.215V < V < 1.225V			
VREF_CM_OUT_700		0.695V < V < 0.705V			

#### *3.8.1.3 Test Notes*

Delete me if no notes are required.

## 3.8.2 Ripple

#### 3.8.2.1 Test Instructions

Measure the ripple of the following signals:

AVREF





- VREF\_CM\_IN
- VREF\_CM\_OUT\_230
- VREF\_CM\_OUT\_700

Note: Measure the AC component with 0.1Hz < f < 100Hz

#### 3.8.2.2 Test Data

Measure the voltage ripple of the following signals					
Signal	Capture the Ripple	Voltage	Passing Criteria	Pass / Fail	
AVREF			$ V_{ripple}  < 180 \mu V$		
VREF_CM_IN			$\left V_{ripple}\right  < 16nV$		
VREF_CM_OUT_300			$\left V_{ripple}\right  < 12nV$		
VREF_CM_OUT_700			$ V_{ripple}  < 7nV$		

#### *3.8.2.3 Test Notes*

Delete me if no notes are required.

## 3.8.3 Noise

## 3.8.3.1 Test Instructions

Measure the noise of the following signals:

- AVREF
- VREF\_CM\_IN
- VREF\_CM\_OUT\_230
- VREF\_CM\_OUT\_700

Note: Measure the AC component with 100Hz < f

## 3.8.3.2 Test Data

Measure the voltage noise of the following signals						
Signal	Capture the Ripple	Voltage	Passing Criteria	Pass / Fail		
AVREF			$ V_{noise}  < 90 \mu V$			
VREF_CM_IN			$ V_{noise}  < 8nV$			
VREF_CM_OUT_300			$ V_{noise}  < 6nV$			
VREF_CM_OUT_700			$ V_{noise}  < 3nV$			

#### *3.8.3.3 Test Notes*

Delete me if no notes are required.

## 3.9 µController Programming

Results: Pass / Fail

This test evaluates the circuit described in Programming Connections.





## 3.9.1 Test Instructions

Connect a SWD programmer to the SWD header and upload an image, validate the  $\mu$ Controller is properly programmed. Connect a JTAG programmer to the backplane and upload an image, validate the  $\mu$ Controller is properly programmed.

Note: Follow the programming instructions on the wiki.

#### 3.9.2 Test Data

Program the µController via SWD and JTAG, validate the µController is properly				
programmed				
Programmer	Passing Criteria	Pass / Fail		
SWD	μController properly programmed			
JTAG	μController properly programmed			

#### 3.9.3 Test Notes

Delete me if no notes are required.

## 3.10 5.0V and 9.0V Regulator

Results: Pass / Fail

This test evaluates the circuit described in 5.0V Regulation and 9.0V Regulation. More information on measuring noise/ripple as well as using an oscilloscope can be found on the Electrical Systems Team page of the Wiki under Tutorials and Resources

## 3.10.1 Output Voltage

#### 3.10.1.1 Test Instructions

Apply 3.7V to VBATT. Measure the voltage of the 5.0V and 9.0V regulators under no load and under a 200mA resistive load.

Note: Measure the DC component with f < 0.1Hz

#### 3.10.1.2 Test Data

١	Measure the voltage of the 5.0V and 9.0V regulators under no load and under a								
	200mA resistive load								
F	Regulator	No Load Voltage	200 <i>mA</i> Load Voltage	Passing Criteria	Pass / Fail				
	5.0V			5.05V < V < 5.25V					
	9.0V			8.55V < V < 9.45V					

## *3.10.1.3 Test Notes*

Delete me if no notes are required.





## 3.10.2 Output Ripple

## 3.10.2.1 Test Instructions

Apply 3.7V to VBATT. Measure the ripple of the 5.0V and 9.0V regulators whilst under a 200mA resistive load.

Note: Measure the AC component with 0.1Hz < f < 100Hz

#### 3.10.2.2 Test Data

Measure the ripple of the $5.0 \mathrm{V}$ and $9.0 \mathrm{V}$ regulators whilst under a $200 mA$ resistive load.							
Regulator	Capture the ripple	Passing Criteria	Pass / Fail				
5.0V		$\left V_{ripple}\right  < 25mV$					
9.0V		$ V_{ripple}  < 45mV$					

#### *3.10.2.3 Test Notes*

Delete me if no notes are required.

## 3.10.3 Output Noise

## 3.10.3.1 Test Instructions

Apply 3.7V to VBATT. Measure the noise of the 5.0V and 9.0V regulators whilst under a 200mA resistive load. Measure at the test point; if the noise is too excessive, measure across the output capacitor.

Note: Measure the AC component with 100Hz < f

## 3.10.3.2 Test Data

Measure th	Measure the noise of the 5.0V and 9.0V regulators whilst under a 200 <i>mA</i> resistive load.							
Regulator	Capture the noise	Passing Criteria	Pass / Fail					
5.0V		$ V_{noise}  < 50mV$						
9.0V		$ V_{noise}  < 90mV$						

## 3.10.3.3 Test Notes

Delete me if no notes are required.

## 3.10.4 Output Efficiency

#### 3.10.4.1 Test Instructions

Measure the efficiency of the 5.0V and 9.0V regulators whilst under a  $10mA\ to\ 200mA$  resistive loads and with  $3.3V\ to\ 4.1V$  input voltage on VBATT.

Note:  $Efficiency = \frac{P_{out}}{P_{in}}$ , measure the power across the input and output current shunt resistors.





## 3.10.4.2 Test Data - 5.0V

Measure the	Measure the efficiency of the 5.0V regulator whilst under a $10mA$ resistive load							
	and 3.3V to 4.1V input voltage.							
Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail			
3.3V				Efficiency > 50%				
3.7V				Efficiency > 50%				
4.1V				Efficiency > 50%				

Measure the	Measure the efficiency of the 5.0V regulator whilst under a 20mA resistive load							
	and 3.3V to 4.1V input voltage.							
Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail			
3.3V				Efficiency > 50%				
3.7V				Efficiency > 50%				
4.1V				Efficiency > 50%				

Measure the	Measure the efficiency of the 5.0V regulator whilst under a $50mA$ resistive load							
	and 3.3V to 4.1V input voltage.							
Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail			
3.3V				Efficiency > 50%				
3.7V				Efficiency > 50%				
4.1V				Efficiency > 50%				

Measure the	Measure the efficiency of the 5.0V regulator whilst under a 100mA resistive load							
	and 3.3V to 4.1V input voltage.							
Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail			
3.3V				Efficiency > 70%				
3.7V				Efficiency > 70%				
4.1V				Efficiency > 70%				

Measure the	Measure the efficiency of the 5.0V regulator whilst under a 200mA resistive load and 3.3V to 4.1V input voltage.							
Input Voltage	Input Voltage   Power In   Power Out   Efficiency   Passing Criteria   Pass / Fail							
3.3V				<i>Efficiency</i> > 90%				
3.7V				Efficiency > 90%				
4.1V				Efficiency > 90%				

## 3.10.4.3 Test Data - 9.0V

Measure the	Measure the efficiency of the 9.0V regulator whilst under a 10mA resistive load							
	and 3.3V to 4.1V input voltage.							
Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail			
3.3V				Efficiency > 50%				
3.7V				Efficiency > 50%				
4.1V				Efficiency > 50%				

	Measure the efficiency of the 9.0V regulator whilst under a 20mA resistive load							
	and 3.3V to 4.1V input voltage.							
ſ	Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail		
	3.3V				Efficiency > 50%			





Ī	Measure the efficiency of the 9.0V regulator whilst under a 20mA resistive load							
	and 3.3V to 4.1V input voltage.							
ĺ	Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail		
ĺ	3.7V				Efficiency > 50%			
	4.1V				Efficiency > 50%			

Measure the	Measure the efficiency of the 9.0V regulator whilst under a 50mA resistive load							
	and 3.3V to 4.1V input voltage.							
Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail			
3.3V				Efficiency > 50%				
3.7V				Efficiency > 50%				
4.1V				Efficiency > 50%				

Measure the	Measure the efficiency of the 9.0V regulator whilst under a $100mA$ resistive load				
	and 3.3V to 4.1V input voltage.				
Input Voltage	Power In	Power Out	Efficiency	Passing Criteria	Pass / Fail
3.3V	3.3V <i>Efficiency</i> > 80%				
3.7V <i>Efficiency</i> > 80%					
4.1V				Efficiency > 80%	

Measure the	Measure the efficiency of the 9.0V regulator whilst under a 200 <i>mA</i> resistive load					
	and 3.3V to 4.1V input voltage.					
Input Voltage   Power In   Power Out   Efficiency   Passing Criteria   Pass / Fail				Pass / Fail		
3.3V	3.3V <i>Efficiency</i> > 90%					
3.7V <i>Efficiency</i> > 90%						
4.1V				Efficiency > 90%		

## 3.10.4.4 Efficiency Plot

Create a plot of current versus efficiency with each input voltage.

## *3.10.4.5 Test Notes*

Delete me if no notes are required.

## 3.10.5 Current Limit

#### 3.10.5.1 Test Instructions

Apply 3.7V to VBATT. For each regulator, apply an increasing load to its output until the current no longer increases. Measure voltage and current of the rail.

Note: The load will likely be increased by adding more resistors in parallel or decrease the load resistance.

## 3.10.5.2 Test Data

Apply an increasing load to 3.3V outputs until the current no longer increases					
Regulator	Max Current	Passing Criteria	Pass / Fail		
5.0V		500mA < I < 1A			
9.0V		500mA < I < 1A			





#### *3.10.5.3 Test Notes*

Delete me if no notes are required.

## 3.10.6 Load Response

## 3.10.6.1 Test Instructions

Apply 3.7V to VBATT. Apply the following loads to the both regulator outputs:

- No load to 200mA resistive load
- 200mA resistive load to no load
- No load to 10µF MLCC
- 200mA resistive load adding 10μF MLCC
- No load to short circuit
- Short circuit to no load
- 200mA resistive load to short circuit
- Short circuit to 200mA resistive load
- Short circuit continuous

Capture the voltage, and current of the rail under test and the voltage of *VBATT*. Validate the Comms does not misoperate in any way.

#### 3.10.6.2 Test Data

То	To each regulator output, apply no load to 200mA resistive load				
Regulator	Capture voltage and current of the rail and the voltage of <i>VBATT</i>	Passing Criteria	Pass / Fail		
5.0V		No misoperation			
9.0V		No misoperation			

То	To each regulator output, apply 200 <i>mA</i> resistive load to no load				
Regulator	Capture voltage and current of the rail and the voltage of <i>VBATT</i>	Passing Criteria	Pass / Fail		
5.0V		No misoperation			
9.0V		No misoperation			

	To each regulator output, apply no load to 10μF MLCC				
Regulator	Capture voltage and current of the rail and the voltage of <i>VBATT</i>	Passing Criteria	Pass / Fail		
5.0V		No misoperation			
9.0V		No misoperation			





To each	To each regulator output, apply $200mA$ resistive load and add $10\mu F$ MLCC				
Regulator	Capture voltage and current of the rail and the voltage of <i>VBATT</i>	Passing Criteria	Pass / Fail		
5.0V	and reading or reading	No misoperation	. 200		
9.0V		No misoperation			

	To each regulator output, apply no load to short circuit				
Regulator	Capture voltage and current of the rail and the voltage of <i>VBATT</i>	Passing Criteria	Pass / Fail		
5.0V		No misoperation			
9.0V		No misoperation			

	To each regulator output, apply short circuit to no load				
Regulator	Capture voltage and current of the rail and	Passing	Pass /		
ricgulator	the voltage of <i>VBATT</i>	Criteria	Fail		
5.0V		No			
3.0 V		misoperation			
9.0∨		No			
7.00		misoperation			

To ed	To each regulator output, apply 200 <i>mA</i> resistive load to short circuit				
Regulator	Capture voltage and current of the rail and the voltage of <i>VBATT</i>	Passing Criteria	Pass / Fail		
5.0V		No misoperation			
9.0V		No misoperation			

To ed	To each regulator output, apply short circuit to 200mA resistive load				
Regulator	Capture voltage and current of the rail and	Passing	Pass /		
Regulator	the voltage of <i>VBATT</i>	Criteria	Fail		
5.0V		No			
3.0 V		misoperation			
9.0∨		No			
9.00		misoperation			

To	To each regulator output, apply short circuit continuous load				
Regulator	Capture voltage and current of the rail and the voltage of <i>VBATT</i>	Passing Criteria	Pass / Fail		
5.0V		No misoperation			
9.0V		No misoperation			

## *3.10.6.3 Test Notes*

Delete me if no notes are required.





## 3.11 Low Drop-Out Regulators

Results: Pass / Fail

This test evaluates the circuit described in Low Drop-Out Regulators. More information on measuring noise/ripple as well as using an oscilloscope can be found on the Electrical Systems Team page of the Wiki under Tutorials and Resources

## 3.11.1 Output Voltage

#### 3.11.1.1 Test Instructions

Apply 3.7V to VBATT. Measure the voltage of the 3.3V-0 and 5.0V-0 LDO regulators under no load and under an 50mA resistive load.

Note: Measure the DC component with f < 0.1Hz

#### 3.11.1.2 Test Data

Measure	Measure the voltage of the 3.3V-0 and 5.0V-0 LDO regulators under no load				
	and un	der a 50mA resistive l	1000		
Regulator No Load Voltage 50mA Load Voltage Passing Criteria Pass / Fail					
3.3V-0			3.25V < V < 3.35V		
5.0V-0			4.95V < V < 5.05V		

#### 3.11.1.3 Test Notes

Delete me if no notes are required.

## 3.11.2 Output Ripple

#### 3.11.2.1 Test Instructions

Apply 3.7V to VBATT. Measure the ripple of the 3.3V-0 and 5.0V-0 LDO regulators whilst under a 50mA resistive load.

Note: Measure the AC component with 0.1Hz < f < 100Hz

#### 3.11.2.2 Test Data

Measure t	Measure the ripple of the 3.3V-0 and 5.0V-0 LDO regulators whilst under a 50mA resistive load.				
Regulator Capture the ripple Passing Criteria Fa					
3.3V-0		$\left V_{ripple}\right  < 25mV$			
5.0V-0		$\left V_{ripple}\right  < 45mV$			

## 3.11.2.3 Test Notes

Delete me if no notes are required.





## 3.11.3 Output Noise

## 3.11.3.1 Test Instructions

Apply 3.7V to VBATT. Measure the noise of the 3.3V-0 and 5.0V-0 LDO regulators whilst under a 50mA resistive load.

Note: Measure the AC component with 100Hz < f

#### 3.11.3.2 Test Data

Measure t	Measure the noise of the 3.3V-0 and 5.0V-0 LDO regulators whilst under a 50mA resistive load.				
Regulator Capture the noise Passing Pass Fail					
3.3V-0		$ V_{noise}  < 50mV$			
5.0V-0		$ V_{noise}  < 90mV$			

#### *3.11.3.3 Test Notes*

Delete me if no notes are required.

## 3.12 RF Clock Generators

Results: Pass / Fail

This test evaluates the circuit described in RF Clock Generators.

## 3.12.1 Reference Clock Supply

#### 3.12.1.1 Test Instructions

Measure the voltage of each reference clock's supply. Ensure the voltage, including noise and ripple, is  $3.3V \pm 0.5\%$ .

## 3.12.1.2 Test Data

Meas	Measure the voltage of each reference clock's supply.				
RF Chain Capture the voltage Passing Criteria					
700mm Uplink		3.28V < V < 3.32V			
700mm Downlink		3.28V < V < 3.32V			
230mm Downlink		3.28V < V < 3.32V			

## 3.12.1.3 Test Notes

Delete me if no notes are required.

## 3.12.2 Reference Clock Frequency

#### 3.12.2.1 Test Instructions

Measure the frequency of each reference clock. Ensure the frequency is  $20MHz \pm 5ppm$ .





#### 3.12.2.2 Test Data

Measure the frequency of each reference clock output				
RF Chain Capture the oscillator output Passing Criteria Fai				
700mm Uplink		$f = 20MHz \pm 5ppm$		
700mm Downlink		$f = 20MHz \pm 5ppm$		
230mm Downlink		$f = 20MHz \pm 5ppm$		

#### *3.12.2.3 Test Notes*

Delete me if no notes are required.

## 3.12.3 Output Frequency

## 3.12.3.1 Test Instructions

Configure each generator to output its frequency as follows. Use a spectrum analyzer to measure the output. Ensure the frequency is within 10ppm and bandwidth is less than 200ppm.

700mm Uplink: 880MHz
 700mm Downlink: 440MHz
 230mm Downlink: 1.25GHz

Note: Measure the bandwidth at the -3dB point

#### 3.12.3.2 Test Data

Measure the frequency of each generator output with a spectrum analyzer				
RF Chain			Pass / Fail	
700mm Uplink		$f = 880MHz \pm 10ppm$ $B < 176kHz$		
700mm Downlink		$f = 440MHz \pm 10ppm$ $B < 88kHz$		
230mm Downlink		$f = 1.25GHz \pm 10ppm$ $B < 250kHz$		

#### 3.12.3.3 Test Notes

Delete me if no notes are required.

## 3.13 Differential Drivers

Results: Pass / Fail

This test evaluates the circuit described in Differential Drivers.

## 3.13.1 Test Instructions

Have the  $\mu$ Controller generate a square wave on each modulator input with a frequency of 250kHz. Validate the waveform and voltage levels.





## 3.13.2 Test Data

Have the µCo	Have the $\mu$ Controller generate a square wave on each modulator input with a frequency of 250 $kHz$ .					
Signal	Capture the single ended and differential signals	Passing Criteria	Pass / Fail			
MOD_230_ID		$V = 1.2V \pm 0.5V$ Signal Integrity				
MOD_230_QD		$V = 1.2V \pm 0.5V$ Signal Integrity				
MOD_700_ID		$V = 0.7V \pm 0.3V$ Signal Integrity				
MOD_700_QD		$V = 0.7V \pm 0.3V$ Signal Integrity				

## 3.13.3 Test Notes

Delete me if no notes are required.

## 3.14 Power Amplifier Bias

Results: Pass / Fail

This test evaluates the circuit described in Power Amplifiers.

## 3.14.1 Test Instructions

Have the  $\mu$ Controller sweep each power amplifier bias from 0% to 100% duty cycle. Validate the output sweeps from -3.3V to 0V.

## 3.14.2 Test Data

Have the µController sweep each power amplifier bias from 0% to 100% duty cycle. Validate the output sweeps from -3.3V to 0V.						
RF Chain	Duty Cycle Doss /					
230mm $V(0 \to 1) = -3.3V \to 0V$						
700mm	700mm $V(0 \to 1) = -3.3V \to 0V$					

## 3.14.3 Test Notes

Delete me if no notes are required.

## 3.15 RF Chain – 230mm Downlink

Results: Pass / Fail

This test evaluates the circuit described in RF Modulators, Low Noise Amplifier, and Power Amplifiers.

## 3.15.1 Test Instructions

Have the  $\mu$ Controller generate a QPSK modulated signal with pattern 00 01 11 10 with a data rate of 500kbps. Validate the following parameters:

- Power output of 1W when power amplifier bias is set to maximum
- Spectral bandwidth of less than 250kHz





• Distinct separation of symbols

## 3.15.2 Test Data

Have the µController generate a QPSK modulated signal with pattern 00 01 11 10 with a data rate of 500kbps on the 230mm radio.				
Parameter Value Passing Pass (Scope or Spectrum Analyzer Capture) Criteria Fai				
Output Power		$P = 1W \pm 0.2W$		
Spectral Bandwidth		B < 250kHz		

Have the µController generate a QPSK modulated signal with pattern 00 01 11 10 with a data rate of $500kbps$ on the $230mm$ radio. Use an SDR to demodulate into symbols				
Capture the I/Q signals (waveforms and constellation)  Passing Criteria Fail				
	Distinct Symbols			

## 3.15.3 Test Notes

Delete me if no notes are required.

## 3.16 RF Chain - 700mm Downlink

Results: Pass / Fail

This test evaluates the circuit described in RF Modulators, Low Noise Amplifier, and Power Amplifiers.

## 3.16.1 Isolation Switch

## 3.16.1.1 Test Instructions

Have the  $\mu$ Controller gradually increase the power output of the 700mm downlink radio while the RF switch is set to downlink. Measure the power on the 700mm uplink radio input. Ensure this power does not exceed 0dBm.

## 3.16.1.2 Test Data

Have the µController gradually increase the power output of the 700mm						
downlink radio while the R	downlink radio while the RF switch is set to downlink. Measure the power on the					
700mm uplink radio input. Ensure this power does not exceed $0dBm$ .						
Max power Passing Criteria Pass / Fail						
	P < 0dBm					

## *3.16.1.3 Test Notes*

Delete me if no notes are required





## 3.16.2 Digital Modulation

## 3.16.2.1 Test Instructions

Have the  $\mu$ Controller generate a QPSK modulated signal with pattern 00 01 11 10 with a data rate of 50kbps on the 700mm radio. Validate the following parameters:

- Power output of 1W when power amplifier bias is set to maximum
- Spectral bandwidth of less than 25kHz
- Distinct separation of symbols

## 3.16.2.2 Test Data

Have the µController generate a QPSK modulated signal with pattern 00 01 11 10					
	with a data rate of 50kbps on the 700mm	radio.			
Parameter	Value	Passing	Pass /		
Furumeter	(Scope or Spectrum Analyzer Capture)	Criteria	Fail		
Output Power		$P = 1W \pm 0.2W$			
Spectral Bandwidth		B < 25kHz			

Have the µController generate a QPSK modulated signal with pattern 00 01 11 10 with a data rate of $50kbps$ on the $700mm$ radio. Use an SDR to demodulate into symbols		
Capture the I/Q signals (waveforms and constellation)	Passing Criteria	Pass / Fail
	Distinct Symbols	

#### 3.16.2.3 Test Notes

Delete me if no notes are required.

## 3.16.3 Analog Modulation

## 3.16.3.1 Test Instructions

Have the  $\mu$ Controller generate an amplitude modulated audio signal on the 700mm radio. Validate the following parameters:

- Power output of 1W when power amplifier bias is set to maximum
- Spectral bandwidth of less than 20kHz
- Recognizable demodulated audio

#### 3.16.3.2 Test Data

Have the µ	Have the µController generate an amplitude modulated audio signal on the			
	700mm radio.			
Parameter	Value (Scope or Spectrum Analyzer Capture)	Passing Criteria	Pass / Fail	
Output Power		$P = 1W \pm 0.2W$		





Have the µ	Have the µController generate an amplitude modulated audio signal on the		
700mm radio.			
Parameter	Value (Scope or Spectrum Analyzer Capture)	Passing Criteria	Pass / Fail
Spectral Bandwidth		B < 20kHz	

Have the $\mu$ Controller generate an amplitude modulated audio signal on the $700mm$ radio. Use an SDR to demodulate into audio.		
Capture the I/Q signals (waveforms)	Passing Criteria	Pass / Fail
	Recognizable audio	

#### 3.16.3.3 Test Notes

Delete me if no notes are required.

## 3.17 RF Chain - 700mm Uplink

Results: Pass / Fail

This test evaluates the circuit described in RF Demodulator, and Low Noise Amplifier.

## 3.17.1 Test Instructions

Have a radio generate a QPSK modulated signal with pattern  $00\ 01\ 11\ 10$  with a data rate of 50kbps to transmit to the 700mm radio with a received power of -150dBm. Validate the following parameters:

- Signal to noise ratio (SNR) > 30dBm
- Output voltage of  $1.65V \pm 1V$
- Distinct separation of symbols

## 3.17.2 Test Data

	Have a radio generate a QPSK modulated signal with pattern 00 01 11 10 with a			
data rate d	data rate of $50kbps$ to transmit to the $700mm$ radio with a received power of			
	-150dBm.			
Parameter	Value	Passing	Pass /	
or Signal	(Scope or Spectrum Analyzer Capture)	Criteria	Fail	
SNR		SNR > 30dBm		
DEMOD_ID		$V = 1.65V \pm 1V$		
DEMOD_QD		$V = 1.65V \pm 1V$		

Have a radio generate a QPSK modulated signal with pattern 00 01 11 10 with a data rate of $50kbps$ to transmit to the $700mm$ radio with a received power of		
-150dBm.		
Capture the I/Q signals (waveforms and constellation)	Passing Criteria	Pass / Fail
	Distinct	
	Symbols	





3.17.3 Test Notes

Delete me if no notes are required.



