

NOTE: 1. CHECK ROTATION OF UNIT IS AS PER LABEL ON FAN (OR WARRANTY IS VOID)

2. CHANGE ROTATION OF DIRECTION BY INTERCHANGING 2 PHASES

REV.	DESCRIPTION	DATE	BY	106 FAIRBANK ROAD	MAT'L / F	NISH: N/A	MODEL:
A ISSUE	D FOR CONSTRUCTION	04.10.2020	CFM	CEMAIRSYSTEMS CLAYTON SOUTH, VICTORIA 3169 ph: +61 3 9551 4878 email: mail@cfmairsystems.com.au web: www.cfmairsystems.com.au	DRAWN:	CFM Airsystems	DIAGRAM # 2
				THE INFORMATION CONTAINED HEREIN IS CONFIDENTIAL TO CFM FANS AND SHALL NOT BR REPRODUCED, COPIED OR DISCLOSED IN WHOLE OR IN PART, OR USED FOR MANUFACTURE OR FOR ANY OTHER PURPOSE	DATE:	October 2020	''
				WITHOUT THE WRITTEN PERMISSION OF CFM FANS. THIS PRINT IS TO BE RETURNED UPON DEMAND DESTROY OLD REVISIONS		M.KOTSIKAS	DESCRIPTION:  ELECTRICAL DIAGRAM No.2  REV A
				UNLESS OTHERWISE STATED DIMENSIONS ARE OUTSIDE DIMS, IN MILIMETRES AND TO TOLERANCE	SCALE:	NTS	
				LINEAR: ±1 ANGLE: ±10' (MIN) HOLES: WITHIN 0.5 OF TRUE POSITION	SHEET:	A4	