

# Packet Tracer - Configure Router-on-a-Stick Inter-VLAN Routing

# Addressing Table

Device	Interface	IPv4 Address	Subnet Mask	Default Gateway
R1	G0/0.10	172.17.10.1	255.255.255.0	N/A
	G0/0.30	172.17.30.1	255.255.255.0	
PC1	NIC	172.17.10.10	255.255.255.0	172.17.10.1
PC2	NIC	172.17.30.10	255.255.255.0	172.17.30.1

# **Objectives**

Part 1: Add VLANs to a Switch

Part 2: Configure Subinterfaces

Part 3: Test Connectivity with Inter-VLAN Routing

### Scenario

In this activity, you will configure VLANs and inter-VLAN routing. You will then enable trunk interfaces and verify connectivity between VLANs.

#### Instructions

#### Part 1: Add VLANs to a Switch

#### Step 1: Create VLANs on S1.

Create VLAN 10 and VLAN 30 on S1.

### Step 2: Assign VLANs to ports.

- a. Configure interfaces F0/6 and F0/11 as access ports and assign VLANs.
  - Assign the port connected to PC1 to VLAN 10.
  - Assign the port connected to PC3 to VLAN 30.
- b. Issue the **show vlan brief** command to verify VLAN configuration.

#### S1# show vlan brief

VLAN Name	Status	Ports
1 default	active	Fa0/1, Fa0/2, Fa0/3, Fa0/4
		Fa0/5, Fa0/7, Fa0/8, Fa0/9
		Fa0/10, Fa0/12, Fa0/13, Fa0/14
		Fa0/15, Fa0/16, Fa0/17, Fa0/18

```
Fa0/19, Fa0/20, Fa0/21, Fa0/22
                                                Fa0/23, Fa0/24, Gig0/1, Gig0/2
10 VLAN0010
                                      active
                                                Fa0/11
30 VLAN0030
                                               Fa0/6
                                      active
1002 fddi-default
                                      active
1003 token-ring-default
                                      active
1004 fddinet-default
                                      active
1005 trnet-default
                                      active
```

# Step 3: Test connectivity between PC1 and PC3.

From PC1, ping PC3.

Were the pings successful? Why did you get this result?

Não tivemos sucesso no ping, porque o roteador não esta configurado para fazer a ponte entre os PCs

# Part 2: Configure Subinterfaces

### Step 1: Configure subinterfaces on R1 using the 802.1Q encapsulation.

- a. Create the subinterface G0/0.10.
  - Set the encapsulation type to 802.1Q and assign VLAN 10 to the subinterface.
  - Refer to the Address Table and assign the correct IP address to the subinterface.

```
R1(config)# int g0/0.10
R1(config-subif)# encapsulation dot1Q 10
R1(config-subif)# ip address 172.17.10.1 255.255.255.0
```

b. Repeat for the G0/0.30 subinterface.

#### Step 2: Verify Configuration.

- a. Use the **show ip interface brief** command to verify subinterface configuration. Both subinterfaces are down. Subinterfaces are virtual interfaces that are associated with a physical interface. Therefore, in order to enable subinterfaces, you must enable the physical interface that they are associated with.
- b. Enable the G0/0 interface. Verify that the subinterfaces are now active.

# Part 3: Test Connectivity with Inter-VLAN Routing

### Step 1: Ping between PC1 and PC3.

From PC1, ping PC3. The pings should still fail. Explain.

Agora não, pois atribuimos as subinterfaces do roteador

#### Step 2: Enable trunking.

a. On **\$1**, issue the **show vlan** command.

What VLAN is G0/1 assigned to?

A interface G0/1 é atribuido a Vlan nativa, pois ela se encontra em uma porta trunk

b. Because the router was configured with multiple subinterfaces assigned to different VLANs, the switch port connecting to the router must be configured as a trunk. Enable trunking on interface G0/1.

How can you determine that the interface is a trunk port using the **show vlan** command?

Ao executar o comando podemos notar o Gig0/1 não se encontra atribuido ao Vlan 1

c. Issue the show interface trunk command to verify that the interface is configured as a trunk.

# **Step 3: Test Connectivity**

If the configurations are correct, PC1 and PC3 should be able to ping their default gateways and each other.

What addresses do PC1 and PC3 use as their default gateway addresses?

PC1 - gateway padrão: 172.17.10.1 PC2 - gateway padrão: 172.17.30.1