FPGA Development for Radar, Radio-Astronomy and Communications MASTERS COURSE





Dept. Electrical Engineering, University of Cape Town Private Bag, Rondebosch, 7701, South Africa http://www.rrsg.uct.ac.za



Presented by John-Philip Taylor Convened by Dr Stephen Paine

Day 4 - 2 May 2022

Outline 1 of 34

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration

Caching Systems

Flow Control

Practical - NCO and DDC

Numerically-controlled Oscillator





Outline

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration

Caching Systems


Flow Control

Practical – NCO and DDC

Numerically-controlled Oscillator















- Useful for generating a range of related clocks
- Output clock rising and falling edges can be set, independently, to a resolution equal to the VCO period, which is typically about 1 ns ± 500 ps
- ► All output clocks can be considered to be in the same clock domain
- Noise sensitive applications should avoid PLLs due to high phase noise








- Useful for generating a range of related clocks
- ▶ Output clock rising and falling edges can be set, independently, to a resolution equal to the VCO period, which is typically about 1 ns \pm 500 ps
- All output clocks can be considered to be in the same clock domain
- Noise sensitive applications should avoid PLLs due to high phase noise








- ► Useful for generating a range of related clocks
- Output clock rising and falling edges can be set, independently, to a resolution equal to the VCO period, which is typically about 1 ns ± 500 ps
- ► All output clocks can be considered to be in the same clock domain
- Noise sensitive applications should avoid PLLs due to high phase noise








- Useful for generating a range of related clocks
- ▶ Output clock rising and falling edges can be set, independently, to a resolution equal to the VCO period, which is typically about 1 ns \pm 500 ps
- ► All output clocks can be considered to be in the same clock domain
- Noise sensitive applications should avoid PLLs due to high phase noise








- Direct: No compensation, which results in better jitter performance
- ► Normal: The clock at the register is phase-aligned with the input clock pin
- ➤ Source Synchronous: The PLL ensures that the data delay from pin to register and the apparent clock delay from pin to register is the same
- ➤ Zero-Delay Buffer: The output clock pin is phase-aligned with the input clock pin








- Direct: No compensation, which results in better jitter performance
- ► **Normal**: The clock at the register is phase-aligned with the input clock pin
- ➤ Source Synchronous: The PLL ensures that the data delay from pin to register and the apparent clock delay from pin to register is the same
- ➤ Zero-Delay Buffer: The output clock pin is phase-aligned with the input clock pin








- Direct: No compensation, which results in better jitter performance
- ► **Normal**: The clock at the register is phase-aligned with the input clock pin
- ► Source Synchronous: The PLL ensures that the data delay from pin to register and the apparent clock delay from pin to register is the same
- ➤ Zero-Delay Buffer: The output clock pin is phase-aligned with the input clock pin








- Direct: No compensation, which results in better jitter performance
- ► **Normal**: The clock at the register is phase-aligned with the input clock pin
- ► Source Synchronous: The PLL ensures that the data delay from pin to register and the apparent clock delay from pin to register is the same
- ➤ Zero-Delay Buffer: The output clock pin is phase-aligned with the input clock pin













- Useful for performing phase compensation when interfacing to fast peripherals
- All output clocks can be considered to be in the same clock domain as the input clock








- Useful for performing phase compensation when interfacing to fast peripherals
- All output clocks can be considered to be in the same clock domain as the input clock















- ► Useful when mixing fast and slow systems
- Potential to reduce overall device power usage
- Cannot be used for clocking external devices
- The multi-cycle timing requirements must be manually specified








- ► Useful when mixing fast and slow systems
- Potential to reduce overall device power usage
- Cannot be used for clocking external devices
- ➤ The multi-cycle timing requirements must be manually specified








- ► Useful when mixing fast and slow systems
- ► Potential to reduce overall device power usage
- Cannot be used for clocking external devices
- The multi-cycle timing requirements must be manually specified








- ► Useful when mixing fast and slow systems
- ► Potential to reduce overall device power usage
- Cannot be used for clocking external devices
- ► The multi-cycle timing requirements must be manually specified















- Unrelated to all other clocks in the system, including the parent clock
- Often necessitates complex clock-domain crossing schemes to the general system clock
- Useful when:
 - Requiring very low power usage
 - ► The frequency must change often
 - The clock must drive an external devices
 - ▶ etc








- Unrelated to all other clocks in the system, including the parent clock
- Often necessitates complex clock-domain crossing schemes to the general system clock
- Useful when:
 - Requiring very low power usage
 - The frequency must change often
 - The clock must drive an external device
 - etc








- Unrelated to all other clocks in the system, including the parent clock
- Often necessitates complex clock-domain crossing schemes to the general system clock
- ▶ Useful when:
 - Requiring very low power usage
 - ► The frequency must change often
 - ▶ The clock must drive an external device
 - etc.








- Unrelated to all other clocks in the system, including the parent clock
- Often necessitates complex clock-domain crossing schemes to the general system clock
- ▶ Useful when:
 - ► Requiring very low power usage
 - ► The frequency must change often
 - ► The clock must drive an external device
 - etc.








- Unrelated to all other clocks in the system, including the parent clock
- Often necessitates complex clock-domain crossing schemes to the general system clock
- ▶ Useful when:
 - ► Requiring very low power usage
 - ► The frequency must change often
 - ► The clock must drive an external device
 - etc.








- Unrelated to all other clocks in the system, including the parent clock
- Often necessitates complex clock-domain crossing schemes to the general system clock
- ▶ Useful when:
 - ► Requiring very low power usage
 - ► The frequency must change often
 - ► The clock must drive an external device
 - etc.








- Unrelated to all other clocks in the system, including the parent clock
- Often necessitates complex clock-domain crossing schemes to the general system clock
- ▶ Useful when:
 - ► Requiring very low power usage
 - ► The frequency must change often
 - ► The clock must drive an external device
 - ► etc.












Clock Regions



- ► FPGAs are generally organised into regions, each with its own PLL and I/O bank
- The local clock network is more efficient (and faster) than the global network
- ► When laying out the PCB, keep fast I/O in the same region as their clock





Clock Regions




- ► FPGAs are generally organised into regions, each with its own PLL and I/O bank
- ► The local clock network is more efficient (and faster) than the global network
- ► When laying out the PCB, keep fast I/O in the same region as their clock





Clock Regions



- ► FPGAs are generally organised into regions, each with its own PLL and I/O bank
- ► The local clock network is more efficient (and faster) than the global network
- ► When laying out the PCB, keep fast I/O in the same region as their clock





Outline

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration

Caching Systems

Flow Control

Practical – NCO and DDC

Numerically-controlled Oscillator






Common Mistake

```
module RS232 (
  input ipClk, ipReset,
  input ipRS232_Rx, // Asynchronous external signal
  output [7:0]opData
);
... // Definitions, state machine boilerplate, etc.
  Idle: begin
    if(!ipRS232_Rx) begin
      State <= Receiving;
    end
  end
  Receiving: begin
```














































- Essential for crossing asynchronous external signals
- Only useful for crossing one bit at a time (unless the system is tolerant to temporary errors)
- Often used to cross hand-shaking signals
- ► Works in both directions (fast to slow / slow to fast)








- ► Essential for crossing asynchronous external signals
- Only useful for crossing one bit at a time (unless the system is tolerant to temporary errors)
- Often used to cross hand-shaking signals
- Works in both directions (fast to slow / slow to fast)








- Essential for crossing asynchronous external signals
- Only useful for crossing one bit at a time (unless the system is tolerant to temporary errors)
- Often used to cross hand-shaking signals
- Works in both directions (fast to slow / slow to fast)








- ► Essential for crossing asynchronous external signals
- Only useful for crossing one bit at a time (unless the system is tolerant to temporary errors)
- ► Often used to cross hand-shaking signals
- ► Works in both directions (fast to slow / slow to fast)












Gray Coding




- Encoded such that only one bit changes at a time
- Only works for counter data (FIFO queue pointers, rotary encoders, etc.)
- ► Works in both directions (fast to slow / slow to fast)





Gray Coding




- Encoded such that only one bit changes at a time
- Only works for counter data (FIFO queue pointers, rotary encoders, etc.)
- ► Works in both directions (fast to slow / slow to fast)






Gray Coding



- Encoded such that only one bit changes at a time
- Only works for counter data (FIFO queue pointers, rotary encoders, etc.)
- ► Works in both directions (fast to slow / slow to fast)



















Hand-Shaking




- Source must guarantee data stability while the handshaking is taking place
- Not time-efficient: need to wait for the entire transaction sequence to finish before starting the next one
- ▶ Use only for data that does not need to be crossed often
- ► Works in both directions (fast to slow / slow to fast)






Hand-Shaking



- Source must guarantee data stability while the handshaking is taking place
- ► Not time-efficient: need to wait for the entire transaction sequence to finish before starting the next one
- Use only for data that does not need to be crossed often
- Works in both directions (fast to slow / slow to fast)








- Source must guarantee data stability while the handshaking is taking place
- ► Not time-efficient: need to wait for the entire transaction sequence to finish before starting the next one
- ▶ Use only for data that does not need to be crossed often
- ► Works in both directions (fast to slow / slow to fast)








- Source must guarantee data stability while the handshaking is taking place
- ► Not time-efficient: need to wait for the entire transaction sequence to finish before starting the next one
- ▶ Use only for data that does not need to be crossed often
- ► Works in both directions (fast to slow / slow to fast)






















- ► The data is valid for as long as the strobe is high
- As fast as the source clock
- ► The strobe edges can be used to perform flow-control
- ► Only works when the destination clock is much faster than the source clock
- ▶ Note that the source "clock" can be a strobe signal generated by the source state machine...








- ► The data is valid for as long as the strobe is high
- As fast as the source clock
- The strobe edges can be used to perform flow-control
- ► Only works when the destination clock is much faster than the source clock
- ▶ Note that the source "clock" can be a strobe signal generated by the source state machine...








- ► The data is valid for as long as the strobe is high
- As fast as the source clock
- ► The strobe edges can be used to perform flow-control
- Only works when the destination clock is much faster than the source clock
- ▶ Note that the source "clock" can be a strobe signal generated by the source state machine...








- ► The data is valid for as long as the strobe is high
- As fast as the source clock
- ► The strobe edges can be used to perform flow-control
- Only works when the destination clock is much faster than the source clock
- ▶ Note that the source "clock" can be a strobe signal generated by the source state machine...







- The data is valid for as long as the strobe is high
- As fast as the source clock
- ► The strobe edges can be used to perform flow-control
- Only works when the destination clock is much faster than the source clock
- ► Note that the source "clock" can be a strobe signal generated by the source state machine...





FIFO Queues



- Flow-control signals are crossed separately
- Control signal crossing latency can be hidden in the length of the queue
- Mixed-width RAM can be used to keep the data-rate constant across different frequencies (especially useful in DDR-based external memory)





FIFO Queues



- ► Flow-control signals are crossed separately
- Control signal crossing latency can be hidden in the length of the queue
- Mixed-width RAM can be used to keep the data-rate constant across different frequencies (especially useful in DDR-based external memory)







- ► Flow-control signals are crossed separately
- Control signal crossing latency can be hidden in the length of the queue
- Mixed-width RAM can be used to keep the data-rate constant across different frequencies (especially useful in DDR-based external memory)







- ► Flow-control signals are crossed separately
- Control signal crossing latency can be hidden in the length of the queue
- Mixed-width RAM can be used to keep the data-rate constant across different frequencies (especially useful in DDR-based external memory)





- Unrelated clock domains must be kept separate in the timing constraints as well
- ► Remember clock groups from Day 2?





Clock Groups

- Unrelated clock domains must be kept separate in the timing constraints as well
- ► Remember clock groups from Day 2?

```
set_clock_groups -asynchronous \
  -group [get_clocks ADC_Clk] \
  -group [get_clocks Clk1] \
  -group [get_clocks Clk2] \
  -group [get_clocks {SRAM_CLK *altpll_0*}]
```





Outline

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration

Caching Systems

Flow Control


Practical - NCO and DDC

Numerically-controlled Oscillator





Sharing Resources




- Often many modules need access to the same resource, but only one module can interface with it at a time
- ► Examples include:
 - External memory (SDRAM, SD-card, etc.)
 - ► I²C bus
 - etc.






Sharing Resources



- Often many modules need access to the same resource, but only one module can interface with it at a time
- ► Examples include:
 - External memory (SDRAM, SD-card, etc.)
 - ► I²C bus
 - ► etc.








- ▶ Uses "Request" and "Grant" control lines
- ► The module would raise a request and then wait until it has been granted access before using the resource
- ► All the request lines go to a central control module that administers the granting of the resource








- ► Uses "Request" and "Grant" control lines
- ► The module would raise a request and then wait until it has been granted access before using the resource
- ► All the request lines go to a central control module that administers the granting of the resource








- ► Uses "Request" and "Grant" control lines
- ► The module would raise a request and then wait until it has been granted access before using the resource
- ► All the request lines go to a central control module that administers the granting of the resource








- ► Uses "Request" and "Grant" control lines
- ► The module would raise a request and then wait until it has been granted access before using the resource
- ► All the request lines go to a central control module that administers the granting of the resource








- The requests are serviced in a circular order
- Guaranteed no starvation
- ▶ Does not scale well (in the case of many modules, many clock-cycles must be wasted checking each module's request line)








- ► The requests are serviced in a circular order
- Guaranteed no starvation
- ▶ Does not scale well (in the case of many modules, many clock-cycles must be wasted checking each module's request line)








- ► The requests are serviced in a circular order
- Guaranteed no starvation
- Does not scale well (in the case of many modules, many clock-cycles must be wasted checking each module's request line)








- ► The requests are serviced in a circular order
- Guaranteed no starvation
- Does not scale well (in the case of many modules, many clock-cycles must be wasted checking each module's request line)








- When more that one module requests access, the one with higher priority always receives the grant
- Can result in starvation of low-priority modules
- ► Fast (implementation can be a combinational circuit, providing a response within the same clock cycle)
- ▶ Scales well








- When more that one module requests access, the one with higher priority always receives the grant
- Can result in starvation of low-priority modules
- ► Fast (implementation can be a combinational circuit, providing a response within the same clock cycle)
- Scales well








- ▶ When more that one module requests access, the one with higher priority always receives the grant
- ► Can result in starvation of low-priority modules
- ► Fast (implementation can be a combinational circuit, providing a response within the same clock cycle)
- Scales well








- ▶ When more that one module requests access, the one with higher priority always receives the grant
- ► Can result in starvation of low-priority modules
- ► Fast (implementation can be a combinational circuit, providing a response within the same clock cycle)
- ▶ Scales well








- ▶ When more that one module requests access, the one with higher priority always receives the grant
- ► Can result in starvation of low-priority modules
- ► Fast (implementation can be a combinational circuit, providing a response within the same clock cycle)
- ▶ Scales well















- ➤ The arbiter makes it look as if the resource has multiple independent interfaces. There are no control lines other than the interface itself.
- Often implemented by means of an embedded mutual exclusion unit (round-robin or priority based)
- ► The I²C standard implements arbitration by collision-detection and random back-off: the modules monitor their own output, and when there is a mismatch, the module waits and tries again later.








- ► The arbiter makes it look as if the resource has multiple independent interfaces. There are no control lines other than the interface itself.
- ► Often implemented by means of an embedded mutual exclusion unit (round-robin or priority based)
- ► The I²C standard implements arbitration by collision-detection and random back-off: the modules monitor their own output, and when there is a mismatch, the module waits and tries again later.








- ► The arbiter makes it look as if the resource has multiple independent interfaces. There are no control lines other than the interface itself.
- ► Often implemented by means of an embedded mutual exclusion unit (round-robin or priority based)
- ► The I²C standard implements arbitration by collision-detection and random back-off: the modules monitor their own output, and when there is a mismatch, the module waits and tries again later.

















Outline

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration

Caching Systems


Flow Control

Practical – NCO and DDC

Numerically-controlled Oscillator








- ► Lines are typically one page in size (4 kiB in modern PCs, typically smaller on embedded systems)
- ► The controller does address translation between the external and cache line addresses
- Read is on-demand, flushing the least recently used line and loading the content into it
- Controller blocks the user module when a cache miss occurs








- ► Lines are typically one page in size (4 kiB in modern PCs, typically smaller on embedded systems)
- ➤ The controller does address translation between the external and cache line addresses
- Read is on-demand, flushing the least recently used line and loading the content into it
- Controller blocks the user module when a cache miss occurs








- ► Lines are typically one page in size (4 kiB in modern PCs, typically smaller on embedded systems)
- ► The controller does address translation between the external and cache line addresses
- Read is on-demand, flushing the least recently used line and loading the content into it
- Controller blocks the user module when a cache miss occurs







- ► Lines are typically one page in size (4 kiB in modern PCs, typically smaller on embedded systems)
- ► The controller does address translation between the external and cache line addresses
- Read is on-demand, flushing the least recently used line and loading the content into it
- Controller blocks the user module when a cache miss occurs







- ► Reading is continuous, and the user module is only blocked when the queue is empty
- The queue is typically multiple pages in size
- New data is fetched as soon as there is one page open on the queue







- ► Reading is continuous, and the user module is only blocked when the queue is empty
- ► The queue is typically multiple pages in size
- New data is fetched as soon as there is one page open on the queue








- ► Reading is continuous, and the user module is only blocked when the queue is empty
- ► The queue is typically multiple pages in size
- New data is fetched as soon as there is one page open on the queue








- Writing is continuous, and the user module is only blocked when the queue is full
- Alternatively, the user module is never blocked, and data is lost when the queue is full
- ► The flush unit automatically flushes the queue when there is one page of data in it
- The user module can also manually flush the queue if required








- Writing is continuous, and the user module is only blocked when the queue is full
- ► Alternatively, the user module is never blocked, and data is lost when the queue is full
- ► The flush unit automatically flushes the queue when there is one page of data in it
- ► The user module can also manually flush the queue if required








- Writing is continuous, and the user module is only blocked when the queue is full
- ► Alternatively, the user module is never blocked, and data is lost when the queue is full
- ➤ The flush unit automatically flushes the queue when there is one page of data in it
- The user module can also manually flush the queue if required








- Writing is continuous, and the user module is only blocked when the queue is full
- ► Alternatively, the user module is never blocked, and data is lost when the queue is full
- ➤ The flush unit automatically flushes the queue when there is one page of data in it
- The user module can also manually flush the queue if required








- ► Two independent cache system can potentially refer to the same place in external storage
- ▶ When the one user module reads what the other is writing, the two cache system must remain up to date with each other
- ► When the two user modules write to different places in the same page, a flush must not overwrite the other's data
- Many schemes exist to mitigate these and other issues, which are outside the scope of this course








- Two independent cache system can potentially refer to the same place in external storage
- ► When the one user module reads what the other is writing, the two cache system must remain up to date with each other
- ► When the two user modules write to different places in the same page, a flush must not overwrite the other's data
- Many schemes exist to mitigate these and other issues which are outside the scope of this course








- ➤ Two independent cache system can potentially refer to the same place in external storage
- ▶ When the one user module reads what the other is writing, the two cache system must remain up to date with each other
- ► When the two user modules write to different places in the same page, a flush must not overwrite the other's data
- Many schemes exist to mitigate these and other issues which are outside the scope of this course







- ➤ Two independent cache system can potentially refer to the same place in external storage
- ► When the one user module reads what the other is writing, the two cache system must remain up to date with each other
- ► When the two user modules write to different places in the same page, a flush must not overwrite the other's data
- Many schemes exist to mitigate these and other issues,
 which are outside the scope of this course





Outline

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration

Caching Systems

Flow Control

Practical – NCO and DDC

Numerically-controlled Oscillator





Fire and Forget



- No feedback from the destination to the source
- Assumes that the destination will handle the data, or
- ► The application can accept data loss





Fire and Forget



- ▶ No feedback from the destination to the source
- Assumes that the destination will handle the data, or
- ► The application can accept data loss





Fire and Forget



- ▶ No feedback from the destination to the source
- Assumes that the destination will handle the data, or
- ► The application can accept data loss







- ▶ No feedback from the destination to the source
- Assumes that the destination will handle the data, or
- ► The application can accept data loss







- No feedback from the destination to the source
- Assumes that the destination will handle the data, or
- ► The application can accept data loss







- No feedback from the destination to the source
- Assumes that the destination will handle the data, or
- ► The application can accept data loss





Source

- No feedback from the destination to the source
- Assumes that the destination will handle the data, or
- ► The application can accept data loss







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ► The source sends one packet at a time
- ► And waits for the response from the destination







- ▶ The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ▶ The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ▶ The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols








- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ▶ The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols








- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols








- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ► The destination advertises a window
- ► The source aims to fill the window with data
- ► This is used in TCP, among other protocols







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- ► Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- The source sends packets aiming to keep the credit on zero
- Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- ► Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- ► Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- The source sends packets aiming to keep the credit on zero
- Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- ► Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- The source sends packets aiming to keep the credit on zero
- Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- The source sends packets aiming to keep the credit on zero
- Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- ► Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- ► Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- The source sends packets aiming to keep the credit on zero
- Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- ► The source sends packets aiming to keep the credit on zero
- Works best when the credit is large enough to keep both directions full at all times







- ► The source assumes that the destination has a certain space
- ► The destination acknowledges all incoming packets
- The source sends packets aiming to keep the credit on zero
- ► Works best when the credit is large enough to keep both directions full at all times







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols







- Instead of the source starting with credit, an alternative algorithm lets the destination provide credit to the source
- ► This is used in PCle, among other protocols





Outline

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration


Caching Systems

Flow Control

Practical - NCO and DDC


















Outline

Advanced Clocking

Clock Domains

Mutual Exclusion and Arbitration


Caching Systems

Flow Control

Practical – NCO and DDC








- Integrate frequency to obtain phase
- Use on-chip memory blocks as a look-up table to convert phase to the intended waveform
- ► Use dual-port ROM to obtain sine and cosine from the same LUT
- ► Higher resolution can be obtained with a CORDIC-based sine-cosine module








- ► Integrate frequency to obtain phase
- Use on-chip memory blocks as a look-up table to convert phase to the intended waveform
- Use dual-port ROM to obtain sine and cosine from the same LUT
- ► Higher resolution can be obtained with a CORDIC-based sine-cosine module








- Integrate frequency to obtain phase
- Use on-chip memory blocks as a look-up table to convert phase to the intended waveform
- Use dual-port ROM to obtain sine and cosine from the same LUT
- ► Higher resolution can be obtained with a CORDIC-based sine-cosine module








- Integrate frequency to obtain phase
- Use on-chip memory blocks as a look-up table to convert phase to the intended waveform
- Use dual-port ROM to obtain sine and cosine from the same LUT
- ► Higher resolution can be obtained with a CORDIC-based sine-cosine module








- Integrate frequency to obtain phase
- Use on-chip memory blocks as a look-up table to convert phase to the intended waveform
- Use dual-port ROM to obtain sine and cosine from the same LUT
- ► Higher resolution can be obtained with a CORDIC-based sine-cosine module







$$f_{out} = f_s \cdot \frac{f_{in}}{2^N}, \quad N = 32, \quad f_s = 50 \text{ MHz}$$





Select References

- Stephen Brown and Zvonko Vranesic Fundamentals of Digital Logic with Verilog Design, 2nd Edition ISBN 978-0-07-721164-6
- Merrill L Skolnik Introduction to RADAR Systems ISBN 978-0-07-288138-7
- Mark A. Richards and James A. Scheer Principles of Modern Radar: Basic Principles ISBN 978-1-89-112152-4
- Deepak Kumar Tala
 World of ASIC
 http://www.asic-world.com/
- Jean P. Nicolle
 FPGA 4 Fun
 http://www.fpga4fun.com/





FPGA Development for Radar, Radio-Astronomy and Communications MASTERS COURSE





Dept. Electrical Engineering, University of Cape Town Private Bag, Rondebosch, 7701, South Africa http://www.rrsg.uct.ac.za



Presented by John-Philip Taylor Convened by Dr Stephen Paine

Day 4 - 2 May 2022