Eambricon 寒 武

CNStream-Developer-Guide-EN

Release 6.2.0



Table of Contents

Та	Table of Contents							
1	Copy	right						
2	Data	types Reference	3					
	2.1	enum EventType	3					
	2.2	enum EventHandleFlag	4					
	2.3	enum CNFrameFlag	4					
	2.4	enum CNDataFormat	5					
	2.5	enum StreamMsgType	6					
	2.6	struct CNConfigBase	8					
	2.7	struct ProfilerConfig	9					
	2.8	struct CNModuleConfig	10					
	2.9	struct CNSubgraphConfig	11					
	2.10	struct CNGraphConfig	12					
		struct Event						
	2.12	struct DevContext	15					
	2.13	struct CNInferBoundingBox	15					
	2.14	struct CNInferAttr	16					
	2.15	struct CNInferObjs	17					
	2.16	struct InferData	17					
	2.17	struct CNInferData	18					
	2.18	struct StreamMsg	19					
	2.19	struct ESPacket	20					
	2.20	struct MaximumVideoResolution	20					
	2.21	struct StreamProfile	21					
	2.22	struct ProcessProfile	23					
	2.23	struct ModuleProfile	25					
	2.24	struct PipelineProfile	26					
	2.25	struct TraceElem	28					
	2.26	struct PipelineTrace	29					
	2.27	typedef ModuleParamSet	31					

Cambricon®

	2.28	typede	f BusWatcher	31
	2.29	typede	f CNFrameInfoPtr	31
	2.30	typede	f CNInferFeature	31
	2.31	typede	f CNInferFeatures	32
	2.32	typede	f StringPairs	32
	2.33	typede	f CNInferObjectPtr	32
	2.34	typede	f CNDataFramePtr	32
	2.35	typede	f CNInferObjsPtr	32
	2.36	typede	f CNObjsVec	33
	2.37	typede	f CNInferDataPtr	33
	2.38	typede	f Clock	33
	2.39	typede	f Duration	33
	2.40	typede	f Time	33
	2.41	typede	f RecordKey	34
	2.42	typede	f ProcessTrace	34
	2.43	typede	f ModuleTrace	34
2	Class	_		25
3	Class		and a	35
	3.1		work	
		3.1.1	Class Collection	
		3.1.2		
		3.1.3	Class ParamRegister	
		3.1.4	Class EventBus	
		3.1.5	Class CNFrameInfo	
		3.1.6	Class IModuleObserver	
		3.1.7	Class Module	
		3.1.8	Class ModuleEx	
		3.1.9	Class Pipeline	
			Class StreamMsgObserver	
			Class SourceHandler	
			Class SourceModule	
			Class CNSyncedMemory	
	3.2		r	
		3.2.1	Class ModuleProfiler	
		3.2.2	Class PipelineProfiler	
		3.2.3	Class PipelineTracer	
		3.2.4	Class ProcessProfiler	
		3.2.5	Class StreamProfiler	
		3.2.6	Class TraceSerializeHelper	

		3.2.7	Class TraceEvent			
	3.3	Video A	Analysis			
		3.3.1	Class CNDataFrame			
		3.3.2	Class CNInferObject			
		3.3.3	Class DataSource			
		3.3.4	Class ESJpegMemHandler			
		3.3.5	Class ESMemHandler			
		3.3.6	Class FileHandler			
		3.3.7	Class RawImgMemHandler			
		3.3.8	Class RtspHandler			
		3.3.9	Class ObjPostproc			
		3.3.10	Class Postproc			
		3.3.11	Class ObjPreproc			
		3.3.12	Class Preproc			
		3.3.13	Class VideoPostproc			
		3.3.14	Class VideoPreproc			
_						
4		Referen				
	4.1		work Function			
		4.1.1	GetPathRelativeToTheJSONFile			
		4.1.2	GetMaxModuleNumber			
		4.1.3	GetMaxStreamNumber			
		4.1.4	VersionString			
		4.1.5	MajorVersion			
		4.1.6	MinorVersion			
		4.1.7	PatchVersion			
	4.2		Analysis Function			
		4.2.1	CNGetPlanes			
		4.2.2	GetCNDataFramePtr			
		4.2.3	GetCNInferObjsPtr			
		4.2.4	GetCNInferDataPtr			
5	Rele	ase Not	tes 125			
	5.1		am Release Version 6.1.0			
		5.1.1	API Updates			
	5.2		am Release Version 6.0.0			
		5.2.1	API Updates			
	5.3		am Release 2021-01-25 (Version 5.3.0)			
	0.0	5.3.1	API Updates			
	5.4		am Release 2020-09-18 (Version 5.2.0)			
	J.T	5.4 CNStream Retease 2020-03-10 (Version 3.2.0)				

Cambricon®

	5.4.1	API Updates	8
5.5	CNStre	eam Release 2020-07-10 (Version 5.0.0)	9
	5.5.1	API Updates	9
5.6	CNStre	eam Release 2020-05-25 (Version 4.5.0)	2
	5.6.1	API Updates	2
5.7	Releas	e 2020-04-16 (Version 4.4.0)	3
	5.7.1	API Updates	3
	5.7.2	Doc Updates	3
5.8	Releas	e 2020-02-24	4
	5.8.1	API Updates	4
5.9	Releas	e 2019-12-31	4
	5.9.1	API Updates	4



1 Copyright

DISCLAIMER

CAMBRICON MAKES NO REPRESENTATION, WARRANTY (EXPRESS, IMPLIED, OR STATUTORY) OR GUARANTEE REGARDING THE INFORMATION CONTAINED HEREIN, AND EXPRESSLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY, TITLE, NONINFRINGEMENT OF INTELLECTUAL PROPERTY OR FITNESS FOR A PARTICULAR PURPOSE, AND CAMBRICON DOES NOT ASSUME ANY LIABILITY ARISING OUT OF THE APPLICATION OR USE OF ANY PRODUCT OR SERVICES. CAMBRICON SHALL HAVE NO LIABILITY RELATED TO ANY DEFAULTS, DAMAGES, COSTS OR PROBLEMS WHICH MAY BE BASED ON OR ATTRIBUTABLE TO: (I) THE USE OF THE CAMBRICON PRODUCT IN ANY MANNER THAT IS CONTRARY TO THIS GUIDE, OR (II) CUSTOMER PRODUCT DESIGNS.

LIMITATION OF LIABILITY

In no event shall Cambricon be liable for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption and loss of information) arising out of the use of or inability to use this guide, even if Cambricon has been advised of the possibility of such damages. Notwithstanding any damages that customer might incur for any reason whatsoever, Cambricon's aggregate and cumulative liability towards customer for the product described in this guide shall be limited in accordance with the Cambricon terms and conditions of sale for the product.

ACCURACY OF INFORMATION

Information provided in this document is proprietary to Cambricon, and Cambricon reserves the right to make any changes to the information in this document or to any products and services at any time without notice. The information contained in this guide and all other information contained in Cambricon documentation referenced in this guide is provided "AS IS." Cambricon does not warrant the accuracy or completeness of the information, text, graphics, links or other items contained within this guide. Cambricon may make changes to this guide, or to the products described therein, at any time without notice, but makes no commitment to update this guide.

Performance tests and ratings set forth in this guide are measured using specific chips or computer systems or components. The results shown in this guide reflect approximate performance of Cambricon products as measured by those tests. Any difference in system hardware or software design or configuration may affect actual performance. As set forth above, Cambricon makes no

representation, warranty or guarantee that the product described in this guide will be suitable for any specified use. Cambricon does not represent or warrant that it tests all parameters of each product. It is customer's sole responsibility to ensure that the product is suitable and fit for the application planned by the customer and to do the necessary testing for the application in order to avoid a default of the application or the product.

Weaknesses in customer's product designs may affect the quality and reliability of Cambricon product and may result in additional or different conditions and/or requirements beyond those contained in this guide.

IP NOTICES

Cambricon and the Cambricon logo are trademarks and/or registered trademarks of Cambricon Corporation in China and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

This guide is copyrighted and is protected by worldwide copyright laws and treaty provisions. This guide may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without Cambricon's prior written permission. Other than the right for customer to use the information in this guide with the product, no other right or license, either express or implied, is granted by Cambricon under this guide. For the avoidance of doubt, Cambricon does not grant any right or license (express or implied) to customer under any patents, copyrights, trademarks, trade secret or any other intellectual property or proprietary rights of Cambricon.

- Copyright
- © 2022 Cambricon Corporation. All rights reserved.



2 Datatypes Reference

2.1 enum EventType

```
enum EventType {
    EVENT_INVALID = 0,
    EVENT_ERROR = 1,
    EVENT_WARNING = 2,
    EVENT_EOS = 3,
    EVENT_STOP = 4,
    EVENT_STREAM_ERROR = 5,
    EVENT_TYPE_END = 6,
};
enum cnstream::EventType
    Enumeration variables describing the type of event.
    Values:
     enumerator EVENT_INVALID
         An invalid event type.
     enumerator EVENT_ERROR
         An error event.
     enumerator EVENT_WARNING
         A warning event.
     enumerator EVENT_EOS
         An EOS event.
     enumerator EVENT_STOP
         A stop event.
```

```
enumerator EVENT_STREAM_ERROR

A stream error event.

enumerator EVENT_TYPE_END

Reserved for users custom events.
```

2.2 enum EventHandleFlag

```
enum EventHandleFlag {
     EVENT_HANDLE_NULL = 0,
     EVENT_HANDLE_INTERCEPTION = 1,
     EVENT_HANDLE_SYNCED = 2,
     EVENT_HANDLE_STOP = 3,
};
enum cnstream::EventHandleFlag
     Enumeration variables describing the way how bus watchers handle an event.
     Values:
     enumerator EVENT_HANDLE_NULL
         The event is not handled.
     enumerator EVENT_HANDLE_INTERCEPTION
         The event has been handled and other bus watchers needn't to handle it.
     enumerator EVENT_HANDLE_SYNCED
         The event has been handled and other bus watchers are going to handle it.
     enumerator EVENT_HANDLE_STOP
         The event has been handled and bus watchers stop all other events' processing.
```

2.3 enum CNFrameFlag

```
enum CNFrameFlag {
    CN_FRAME_FLAG_EOS = 1 << 0,
    CN_FRAME_FLAG_INVALID = 1 << 1,
    CN_FRAME_FLAG_REMOVED = 1 << 2,
};</pre>
```

```
enum cnstream::CNFrameFlag
    Enumeration variables describing the mask of CNDataFrame.
    Values:
     enumerator CN_FRAME_FLAG_EOS
         This enumeration indicates the end of data stream.
     enumerator CN_FRAME_FLAG_INVALID
         This enumeration indicates an invalid frame.
     enumerator CN_FRAME_FLAG_REMOVED
         This enumeration indicates that the stream has been removed.
2.4 enum CNDataFormat
enum CNDataFormat {
     CN_INVALID = - 1,
     CN_PIXEL_FORMAT_YUV420_NV21 = 0
     CN_PIXEL_FORMAT_YUV420_NV12 = 1,
     CN_PIXEL_FORMAT_BGR24 = 2,
    CN_PIXEL_FORMAT_RGB24 = 3,
     CN_PIXEL_FORMAT_ARGB32 = 4,
     CN_PIXEL_FORMAT_ABGR32 = 5,
     CN_PIXEL_FORMAT_RGBA32 = 6,
     CN_PIXEL_FORMAT_BGRA32 = 7,
};
enum cnstream::CNDataFormat
     Enumeration variables describling the pixel format of the data in CNDataFrame.
    Values:
     enumerator CN INVALID
         This frame is invalid.
     enumerator CN_PIXEL_FORMAT_YUV420_NV21
         This frame is in the YUV420SP(NV21) format.
     enumerator CN_PIXEL_FORMAT_YUV420_NV12
         This frame is in the YUV420sp(NV12) format.
```

```
enumerator CN_PIXEL_FORMAT_BGR24
This frame is in the BGR24 format.
enumerator CN_PIXEL_FORMAT_RGB24
This frame is in the RGB24 format.
enumerator CN_PIXEL_FORMAT_ARGB32
This frame is in the ARGB32 format.
enumerator CN_PIXEL_FORMAT_ABGR32
This frame is in the ABGR32 format.
enumerator CN_PIXEL_FORMAT_RGBA32
This frame is in the RGBA32 format.
enumerator CN_PIXEL_FORMAT_RGBA32
This frame is in the BGRA32 format.
```

2.5 enum StreamMsgType

```
enum StreamMsgType {
    EOS_MSG = 0,
    ERROR_MSG = 1,
    STREAM_ERR_MSG = 2,
    FRAME_ERR_MSG = 3,
    USER_MSG0 = 32,
    USER_MSG1 = 33,
    USER_MSG2 = 34,
    USER_MSG3 = 35,
    USER_MSG4 = 36,
    USER_MSG5 = 37,
    USER_MSG6 = 38,
    USER_MSG7 = 39,
    USER_MSG8 = 40,
    USER_MSG9 = 41,
```

};

enum cnstream::StreamMsgType

Enumeration variables describing the data stream message type.

Values:

enumerator EOS_MSG

The end of a stream message. The stream has received EOS message in all modules.

enumerator ERROR_MSG

An error message. The stream process has failed in one of the modules.

enumerator STREAM_ERR_MSG

Stream error message.

enumerator FRAME_ERR_MSG

Frame error message.

enumerator USER_MSG0

Reserved message. You can define your own messages.

enumerator USER_MSG1

Reserved message. You can define your own messages.

enumerator USER_MSG2

Reserved message. You can define your own messages.

enumerator USER_MSG3

Reserved message. You can define your own messages.

enumerator USER_MSG4

Reserved message. You can define your own messages.

 ${\tt enumerator~USER_MSG5}$

Reserved message. You can define your own messages.

enumerator USER_MSG6

Reserved message. You can define your own messages.

enumerator USER_MSG7

Reserved message. You can define your own messages.

enumerator USER_MSG8

Reserved message. You can define your own messages.

enumerator USER_MSG9

Reserved message. You can define your own messages.

2.6 struct CNConfigBase

```
struct CNConfigBase {
    std::string config_root_dir = "";
};
struct cnstream::CNConfigBase
    CNConfigBase is a base structure for configurations.
Subclassed by cnstream::CNGraphConfig, cnstream::CNModuleConfig, cnstream::CNSubgraphConfig, cnstream::ProfilerConfig
```

Public Functions

bool ParseByJSONFile(const std::string &jfname)

Parses members from a JSON file.

Parameters jfname -- [in] JSON configuration file path.

Returns Returns true if the JSON file has been parsed successfully. Otherwise, returns false.

virtual bool ParseByJSONStr(const std::string &jstr) = 0

Parses members from JSON string.

Parameters jstr -- [in] JSON string of a configuration.

Returns Returns true if the JSON string has been parsed successfully. Otherwise, returns false.

Public Members

```
std::string config_root_dir = ""
```

The directory where a configuration file is stored.

2.7 struct ProfilerConfig

```
struct ProfilerConfig {
    bool enable_profiling = false;
    bool enable_tracing = false;
    size_t trace_event_capacity = 100000;
};
struct cnstream::ProfilerConfig: public cnstream::CNConfigBase
    ProfilerConfig is a structure for profiler configuration.
```

The profiler configuration can be a JSON file.

```
{
   "profiler_config" : {
      "enable_profiling" : true,
      "enable_tracing" : true
}
```

Note:

It will not take effect when the profiler configuration is in the subgraph configuration.

Public Functions

virtual bool ParseByJSONStr(const std::string &jstr) override

Parses members from JSON string.

Parameters jstr -- [in] JSON configuration string.

Returns Returns true if the JSON string has been parsed successfully. Otherwise, returns false.

Public Members

```
bool enable_profiling = false

Whether to enable profiling.

bool enable_tracing = false

Whether to enable tracing.

size_t trace_event_capacity = 100000

The maximum number of cached trace events.
```

2.8 struct CNModuleConfig

};

```
struct CNModuleConfig {
    std::string name;
    std::map<std::string, std::string> parameters;
    int parallelism;
    int maxInputQueueSize;
    std::string className;
    std::set<std::string> next;
```

struct cnstream::CNModuleConfig:publiccnstream::CNConfigBase

CNModuleConfig is a structure for module configuration. The module configuration can be a JSON file.

```
}
}
```

Public Functions

virtual bool ParseByJSONStr(const std::string &jstr) override

Parses members except CNModuleConfig::name from the JSON file.

Parameters jstr -- [in] JSON string of a configuration.

Returns Returns true if the JSON string has been parsed successfully. Otherwise, returns false.

Public Members

std::string name

The name of the module.

std::map<std::string, std::string> parameters

The key-value pairs. The pipeline passes this value to the CNModuleConfig::name module.

int parallelism

Module parallelism. It is equal to module thread number or the data queue of input data.

int maxInputQueueSize

The maximum size of the input data queues.

std::string className

The class name of the module.

std::set<std::string> next

The name of the downstream modules/subgraphs.

2.9 struct CNSubgraphConfig

```
struct CNSubgraphConfig {
    std::string name;
    std::string config_path;
    std::set<std::string> next;
};
```

struct cnstream::CNSubgraphConfig:public cnstream::CNConfigBase CNSubgraphConfig is a structure for subgraph configuration.

The subgraph configuration can be a JSON file.

Public Functions

virtual bool ParseByJSONStr(const std::string &jstr) override

Parses members except CNSubgraphConfig::name from the JSON file.

Parameters jstr -- [in] JSON string of a configuration.

Returns Returns true if the JSON string has been parsed successfully. Otherwise, returns false.

Public Members

```
std::string name
```

The name of the subgraph.

std::string config_path

The path of configuration file.

std::set<std::string> next

The name of the downstream modules/subgraphs.

2.10 struct CNGraphConfig

```
struct CNGraphConfig {
    std::string name = "";
    ProfilerConfig profiler_config;
    std::vector<CNModuleConfig> module_configs;
    std::vector<CNSubgraphConfig> subgraph_configs;
```

};

You can use CNGraphConfig to initialize a CNGraph instance. The graph configuration can be a JSON file.

```
{
 "profiler_config" : {
    "enable_profiling" : true,
    "enable_tracing" : true
 },
  "module1": {
   "parallelism": 3,
    "max_input_queue_size": 20,
    "class_name": "cnstream::DataSource",
    "next_modules": ["subgraph:subgraph1"],
    "custom_params" : {
      "param_name" : "param_value",
      "param_name" : "param_value",
    }
 },
 "subgraph:subgraph1" : {
    "config_path" : "/your/path/to/subgraph_config_file.json"
 }
```

Public Functions

virtual bool ParseByJSONStr(const Std::String &jstr) override

Parses members except CNGraphConfig::name from the JSON file.

Parameters jstr -- [in] Json configuration string.

Returns Returns true if the JSON string has been parsed successfully. Otherwise, returns false.

};

```
Public Members
     std::string name = ""
         Graph name.
     ProfilerConfig profiler_config
         Configuration of profiler.
     std::vector<CNModuleConfig>module_configs
         Configurations of modules.
     std::vector<CNSubgraphConfig> subgraph_configs
         Configurations of subgraphs.
2.11 struct Event
struct Event {
     EventType type;
     std::string stream_id;
     std::string message;
     std::string module_name;
     std::thread::id thread_id;
struct cnstream::Event
     The Event is a structure describing the event information.
     Public Members
     EventType type
         The event type.
     std::string stream_id
         The stream that posts this event.
     std::string message
         More detailed messages describing the event.
     std::string module_name
         The module that posts this event.
```

```
std::thread::id thread_id
```

The thread ID from which the event is posted.

2.12 struct DevContext

```
struct DevContext {
     enum class DevType{
         INVALID = - 1,
         CPU = 0,
          MLU = 1,
     } dev_type;
     int dev_id = 0;
     int ddr_channel = 0;
};
struct cnstream::DevContext
     DevContext is a structure holding the information that CNDataFrame data is allocated by CPU
     or MLU.
     Public Members
     enum cnstream::DevContext::DevType dev_type = DevType::INVALID
          Device type. The default value is INVALID.
     int dev_id = 0
          Ordinal device ID.
     int ddr_channel = 0
          Ordinal channel ID for MLU. The value should be in the range [0, 4).
```

2.13 struct CNInferBoundingBox

```
struct CNInferBoundingBox {
    float x;
    float y;
    float w;
```

float h;

};

struct cnstream::CNInferBoundingBox

CNInferBoundingBox is a structure holding the bounding box information of a detected object in normalized coordinates.

Public Members

float x

The x-axis coordinate in the upper left corner of the bounding box.

float y

The y-axis coordinate in the upper left corner of the bounding box.

float w

The width of the bounding box.

float h

The height of the bounding box.

2.14 struct CNInferAttr

```
typedef struct {
```

int id = - 1;

int value = - 1;

float score = 0;

} CNInferAttr;

struct cnstream::CNInferAttr

CNInferAttr is a structure holding the classification properties of an object.

Public Members

int id = -1

The unique ID of the classification. The value -1 means invalid.

int value = -1

The label value of the classification.

float score = 0

The label score of the classification.

2.15 struct CNInferObjs

```
struct CNInferObjs {
    std::vector<std::shared_ptr<CNInferObject>> objs_;
    std::mutex mutex_;
};
struct cnstream::CNInferObjs: public NonCopyable
    CNInferObjs is a structure holding inference results.

Public Members

std::mutex mutex_
    The objects storing inference results.
```

2.16 struct InferData

```
struct InferData {
    CNDataFormat input_fmt_;
    int input_width_;
    int input_height_;
    std::shared_ptr<void> input_cpu_addr_;
    size_t input_size_;
    std::vector<std::shared_ptr<void>> output_cpu_addr_;
    std::vector<size_t> output_sizes_;
    size_t output_num_;
};
struct cnstream::InferData
    InferData is a structure holding the information of raw inference input & outputs.
```

Public Members

```
CNDataFormat input_fmt_
    The input image's pixel format.
int input_width_
    The input image's width.
int input_height_
    The input image's height.
std::shared_ptr<void>input_cpu_addr_
    The input data's CPU address.
Size_t input_size_
    The input data's size.
std::vector<std::shared_ptr<void>> output_cpu_addr_
    The corresponding inference outputs to the input data.
std::vector<size_t> output_sizes_
    The inference outputs' sizes.
size_t output_num_
    The inference output count.
```

2.17 struct CNInferData

```
struct CNInferData {
    std::map<std::string, std::vector<std::shared_ptr<InferData>>> datas_map_;
    std::mutex mutex_;
};
struct cnstream::CNInferData: public NonCopyable
    CNInferData is a structure holding a map between module name and InferData.
```

Public Members

```
std::map<std::string, std::vector<std::shared_ptr<InferData>>> datas_map_
The map between module name and InferData.

std::mutex_mutex_
Inference data mutex.
```

2.18 struct StreamMsg

```
struct StreamMsg {
     StreamMsgType type;
     std::string stream_id;
     std::string module_name;
     int64_t pts = - 1;
};
struct cnstream::StreamMsg
     The StreamMsg is a structure holding the information of a stream message.
     See StreamMsgType.
     Public Members
     StreamMsgType type
         The type of a message.
     std::string stream_id
         Stream ID, set in CNFrameInfo::stream_id.
     std::string module_name
         The module that posts this event.
     int64_t pts = -1
         The PTS (Presentation Timestamp) of this frame.
```

2.19 struct ESPacket

```
struct ESPacket {
     unsigned char * data = nullptr;
     int size = 0;
     uint64_t pts = 0;
     uint32_t flags = 0;
     enum class FLAG{
         FLAG_KEY_FRAME = 1,
         FLAG_EOS = 2,
     };
};
struct cnstream::ESPacket
     The ESPacket is a structure describing the elementary stream data packet.
     Public Members
     unsigned char *data = nullptr
         The video data.
     int size = 0
         The size of the data.
     uint64_tpts = 0
         The presentation time stamp of the data.
     uint32_tflags = 0
         The flags of the data.
```

2.20 struct MaximumVideoResolution

```
struct MaximumVideoResolution {
   bool enable_variable_resolutions = false;
   uint32_t maximum_width;
   uint32_t maximum_height;
```

```
};
```

struct cnstream::MaximumVideoResolution

The MaximumVideoResolution (not supported on MLU220/MLU270) is a structure describing the maximum video resolution parameters.

Public Members

```
bool enable_variable_resolutions = false
    Whether to enable variable resolutions.

uint32_t maximum_width
    The maximum video width.

uint32_t maximum_height
    The maximum video height.
```

2.21 struct StreamProfile

```
struct StreamProfile {
    std::string stream_name;
    uint64_t counter = 0;
    uint64_t completed = 0;
    int64_t dropped = 0;
    double latency = 0.0;
    double maximum_latency = 0.0;
    double minimum_latency = 0.0;
    double fps = 0.0;
};
```

The StreamProfile is a structure describing the performance statistics of streams.

Public Functions

```
StreamProfile() = default
```

Constructs a StreamProfile object with default constructor.

Returns No return value.

StreamProfile(const StreamProfile &it) = default

Constructs a StreamProfile object with the copy of the contents of another object.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

StreamProfile & operator = (const StreamProfile & it) = default

Replaces the contents with a copy of the contents of another StreamProfile object.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

inline StreamProfile (StreamProfile &&it)

Constructs a StreamProfile object with the contents of another object using move semantics.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

inline StreamProfile &operator=(StreamProfile &&it)

Replaces the contents with those of another StreamProfile object using move semantics.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

Public Members

std::string stream_name

The stream name.

uint64_t counter = 0

The frame counter, it is equal to completed plus dropped.

 $uint64_t completed = 0$

The completed frame counter.

 $int64_t dropped = 0$

```
The dropped frame counter.

double latency = 0.0

The average latency. (unit:ms)

double maximum_latency = 0.0

The maximum latency. (unit:ms)

double minimum_latency = 0.0

The minimum latency. (unit:ms)

double fps = 0.0

The throughput.
```

2.22 struct ProcessProfile

```
struct ProcessProfile {
    std::string process_name;
    uint64_t counter = 0;
    uint64_t completed = 0;
    int64_t dropped = 0;
    int64_t ongoing = 0;
    double latency = 0.0;
    double maximum_latency = 0.0;
    double minimum_latency = 0.0;
    double fps = 0.0;
    std::vector<StreamProfile> stream_profiles;
};
```

The ProcessProfile is a structure describing the performance statistics of process.

Public Functions

ProcessProfile() = default

Constructs a ProcessProfile object with default constructor.

Returns No return value.

ProcessProfile(const ProcessProfile &it) = default

Constructs a ProcessProfile object with the copy of the contents of another object.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

ProcessProfile & operator = (const ProcessProfile & it) = default

Replaces the contents with a copy of the contents of another ProcessProfile object.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

inline ProcessProfile (ProcessProfile &&it)

Constructs a ProcessProfile object with the contents of another object using move semantics.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

inline ProcessProfile &operator=(ProcessProfile &&it)

Replaces the contents with those of another ProcessProfile object using move semantics.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

Public Members

std::string process_name

The process name.

uint64_t counter = 0

The frame counter, it is equal to completed plus dropped frames.

uint64_t completed = 0

The completed frame counter.

 $int64_t dropped = 0$

The dropped frame counter.

int64_t ongoing = 0

The number of frame being processed.

double latency = 0.0

The average latency. (unit:ms)

double maximum_latency = 0.0

The maximum latency. (unit:ms)

double minimum_latency = 0.0

The minimum latency. (unit:ms)

double fps = 0.0

The throughput.

std::vector<StreamProfile> stream_profiles

2.23 struct ModuleProfile

The stream profiles.

```
struct ModuleProfile {
    std::string module_name;
    std::vector<ProcessProfile> process_profiles;
};
```

struct cnstream::ModuleProfile

The ModuleProfile is a structure describing the performance statistics of module.

Public Functions

ModuleProfile() = default

Constructs a ModuleProfile object with default constructor.

Returns No return value.

ModuleProfile(const ModuleProfile &it) = default

Constructs a ModuleProfile object with the copy of the contents of another object.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

ModuleProfile & operator = (const ModuleProfile & it) = default

Replaces the contents with a copy of the contents of another ModuleProfile object.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lvalue reference to the current instance.

inline ModuleProfile (ModuleProfile &&it)

Constructs a ModuleProfile object with the contents of another object using move semantics.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

```
inline ModuleProfile &operator=(ModuleProfile &&it)
```

Replaces the contents with those of another ModuleProfile object using move semantics.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lvalue reference to the current instance.

Public Members

```
std::string module_name
     The module name.
std::vector<ProcessProfile> process_profiles
     The process profiles.
```

2.24 struct PipelineProfile

```
struct PipelineProfile {
    std::string pipeline_name;
    std::vector<ModuleProfile> module_profiles;
    ProcessProfile overall_profile;
};
struct cnstream::PipelineProfile
```

The PipelineProfile is a structure describing the performance statistics of pipeline.

Public Functions

PipelineProfile() = default

Constructs a PipelineProfile object with default constructor.

Returns No return value.

PipelineProfile(const PipelineProfile &it) = default

Constructs a PipelineProfile object with the copy of the contents of another object.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

PipelineProfile & operator = (const PipelineProfile & it) = default

Replaces the contents with a copy of the contents of another PipelineProfile object.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

inline PipelineProfile (PipelineProfile &&it)

Constructs a PipelineProfile object with the contents of another object using move semantics.

Parameters it -- [in] Another object used to initialize an object.

Returns No return value.

inline PipelineProfile & operator = (PipelineProfile & & it)

Replaces the contents with those of another PipelineProfile object using move semantics.

Parameters it -- [in] Another object used to initialize the current object.

Returns Returns a lvalue reference to the current instance.

Public Members

std::string pipeline_name

The pipeline name.

std::vector<ModuleProfile> module_profiles

The module profiles.

ProcessProfile overall_profile

The profile of the whole pipeline.

2.25 struct TraceElem

```
struct TraceElem {
    pair<std::string, int64_t> key;
    time_point time;
    TraceEvent::Type type;
};
struct cnstream::TraceElem
    The TraceElem is a structure describing a trace element used by profilers.
```

Public Functions

```
TraceElem() = default
```

Constructs a TraceElem object by using default constructor.

Returns No return value.

```
TraceElem(const TraceElem &other) = default
```

Constructs a TraceElem object with the copy of the contents of another object.

Parameters other -- [in] Another object used to initialize an object. **Returns** No return value.

```
TraceElem &operator=(const TraceElem &other) = default
```

Replaces the contents with a copy of the contents of another TraceElem object.

Parameters other -- [in] Another object used to initialize the current object. **Returns** Returns a lyalue reference to the current instance.

```
inline TraceElem(TraceElem &&other)
```

Constructs a TraceElem object with the contents of another object using move semantics.

Parameters other -- [in] Another object used to initialize an object. **Returns** No return value.

```
inline TraceElem &operator=(TraceElem &&other)
```

Replaces the contents with those of another TraceElem object using move semantics.

Parameters other -- [in] Another object used to initialize the current object.

Returns Returns a lvalue reference to the current instance.

inline explicit TraceElem(const TraceEvent &event)

Constructs a TraceElem object with a trace event.

Parameters event -- [in] A specific trace event instance.

Returns No return value.

inline explicit TraceElem(TraceEvent &&event)

Constructs a TraceElem object with a trace event using move semantics.

Parameters event -- [in] A specific trace event instance.

Returns No return value.

Public Members

RecordKey key

The unique identification of a frame.

Time time

The timestamp of an event.

TraceEvent::Type type

The type of an event. It could be START or END.

2.26 struct PipelineTrace

```
struct PipelineTrace {
```

```
std::map<std::string, ProcessTrace> process_traces;
```

std::map<std::string, ModuleTrace> module_traces;

};

struct cnstream::PipelineTrace

The PipelineTrace is a structure describing the trace data of a pipeline.

Public Functions

PipelineTrace() = default

Constructs a PipelineTrace object by using default constructor.

Returns No return value.

PipelineTrace(const PipelineTrace &other) = default

Constructs a PipelineTrace object with the copy of the contents of another object.

Parameters other -- [in] Another object used to initialize an object.

Returns No return value.

PipelineTrace & operator = (const PipelineTrace & other) = default

Replaces the contents with a copy of the contents of another PipelineTrace object.

Parameters other -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

inline PipelineTrace (PipelineTrace &&other)

Constructs a PipelineTrace object with the contents of another object using move semantics.

Parameters other -- [in] Another object used to initialize an object.

Returns No return value.

inline PipelineTrace &operator=(PipelineTrace &&other)

Replaces the contents with those of another PipelineTrace object using move semantics.

Parameters other -- [in] Another object used to initialize the current object.

Returns Returns a lvalue reference to the current instance.

Public Members

std::map<std::string, ProcessTrace> process_traces

The trace data of processes.

std::map<std::string, ModuleTrace> module_traces

The trace data of modules.

2.27 typedef ModuleParamSet

typedef std::map<std::string, std::string> cnstream::ModuleParamSet;

using cnstream::ModuleParamSet = std::map<std::string, std::string>

Defines an alias for std::map<std::string, std::string>. ModuleParamSet now denotes an unordered map which contains the pairs of parameter name and parameter value.

2.28 typedef BusWatcher

typedef std::function<EventHandleFlag (const Event &)> cnstream::BusWatcher;

using cnstream::BusWatcher = Std::function<EventHandleFlag(const Event&)>

Defines an alias of bus watcher function.

Parameters event -- [in] The event is polled from the event bus.

Returns Returns the flag that specifies how the event is handled.

2.29 typedef CNFrameInfoPtr

typedef std::shared_ptr<CNFrameInfo> cnstream::CNFrameInfoPtr;

using cnstream::CNFrameInfoPtr = std::shared_ptr<CNFrameInfo>

Defines an alias for the std::shared_ptr<CNFrameInfo>. CNFrameInfoPtr now denotes a shared pointer of frame information.

2.30 typedef CNInferFeature

typedef std::vector<float> cnstream::CNInferFeature;

using cnstream::CNInferFeature = std::vector<float>

Defines an alias for std::vector<float>. CNInferFeature contains one kind of inference feature.

2.31 typedef CNInferFeatures

typedef std::vector<std::pair<std::string, CNInferFeature>> cnstream::CNInferFeatures;

using cnstream::CNInferFeatures = std::vector<std::pair<std::string, CNInferFeature>>

Defines an alias for std::vector<std::pair<std::string, std::vector<float>>>. CNInferFeatures
contains all kinds of features for one object.

2.32 typedef StringPairs

typedef std::vector<std::pair<std::string, std::string>> cnstream::StringPairs;

using cnstream::StringPairs = std::vector<std::pair<std::string, std::string>>
 Defines an alias for std::vector<std::pair<std::string, std::string>>.

2.33 typedef CNInferObjectPtr

typedef std::shared_ptr<CNInferObject> cnstream::CNInferObjectPtr;

using cnstream::CNInferObjectPtr = std::shared_ptr<CNInferObject>
 Defines an alias for the std::shared_ptr<CNInferObject>. CNInferObjectPtr now denotes a shared pointer of inference objects.

2.34 typedef CNDataFramePtr

typedef std::shared_ptr<CNDataFrame> cnstream::CNDataFramePtr;

using cnstream::CNDataFramePtr = std::shared_ptr<CNDataFrame>
 Defines an alias for the std::shared_ptr<CNDataFrame>.

2.35 typedef CNInferObjsPtr

typedef std::shared_ptr<CNInferObjs> cnstream::CNInferObjsPtr;

using cnstream::CNInferObjsPtr = std::shared_ptr<CNInferObjs>
 Defines an alias for the std::shared_ptr<CNInferObjs>.

2.36 typedef CNObjsVec

typedef std::vector<std::shared_ptr<CNInferObject>> cnstream::CNObjsVec;

using cnstream::CNObjsVec = std::vector<std::shared_ptr<CNInferObject>>
 Defines an alias for the std::vector<std::shared_ptr<CNInferObject>>.

2.37 typedef CNInferDataPtr

typedef std::shared_ptr<CNInferData> cnstream::CNInferDataPtr;

using cnstream::CNInferDataPtr = std::shared_ptr<CNInferData>
 Defines an alias for the std::shared_ptr<CNInferData>.

2.38 typedef Clock

typedef std::chrono::steady_clock cnstream::Clock;

using cnstream::Clock = std::chrono::steady_clock
 Defines an alias for the std::chrono::steady_clock.

2.39 typedef Duration

typedef std::chrono::duration<double, std::milli> cnstream::Duration;

using cnstream::Duration = std::chrono::duration<double, std::milli>
 Defines an alias for the std::chrono::duration<double, std::milli>.

2.40 typedef Time

typedef Clock::time_point cnstream::Time;

using cnstream::Time = Clock::time_point
 Defines an alias for the std::chrono::steady_clock::timepoint.

2.41 typedef RecordKey

typedef std::pair<std::string, int64_t> cnstream::RecordKey;

using cnstream::RecordKey = std::pair<std::string, int64_t>

Defines an alias for the std::pair<std::string, int64_t>. RecordKey now denotes a pair of the stream name <code>CNFrameInfo::stream_id</code> and pts <code>CNFrameInfo::timestamp</code>.

2.42 typedef ProcessTrace

typedef std::vector<TraceElem> cnstream::ProcessTrace;

using cnstream::ProcessTrace = std::vector<TraceElem>

Defines an alias for the std::vector<TraceElem>. ProcessTrace now denotes a vector which contains trace elements for a process.

2.43 typedef ModuleTrace

typedef std::map<std::string, ProcessTrace> cnstream::ModuleTrace;

using cnstream::ModuleTrace = std::map<std::string, ProcessTrace>

Defines an alias for the std::map<std::string, ProcessTrace>. ModuleTrace now denotes an unordered map which contains the pairs of the process name and the ProcessTrace object for a module.



3 Class

3.1 Framework

3.1.1 Class Collection

class Collection: public NonCopyable

Collection is a class storing structured data of variable types.

Note:

This class is thread safe.

API Reference

Collection

```
cnstream::Collection::Collection() = default
```

Constructs an instance with empty value.

Returns No return value.

~Collection

```
cnstream::Collection::~Collection() = default
```

Destructs an instance.

Get

template<typename ValueT>

```
ValueT &cnstream::Collection::Get(const std::string &tag)
```

Gets the reference to the object of typename ValueT if it exists, otherwise crashes.

Parameters tag -- [in] The unique identifier of the data.

Returns Returns the reference to the object of typename ValueT which is tagged by tag.

Add

template<typename ValueT>

Adds data tagged by tag. Crashes when there is already a piece of data tagged by tag.

Parameters

- tag -- [in] The unique identifier of the data.
- value -- [in] Value to be add.

Returns Returns the reference to the object of typename ValueT which is tagged by tag.

template<typename ValueT>

Adds data tagged by tag using move semantics. Crashes when there is already a piece of data tagged by tag.

Parameters

- tag -- [in] The unique identifier of the data.
- value -- [in] Value to be add.

Returns Returns the reference to the object of typename ValueT which is tagged by tag.

AddIfNotExists

Adds data tagged by tag, only if there is no piece of data tagged by tag.

Parameters

- tag -- [in] The unique identifier of the data.
- value -- [in] Value to be add.

Returns Returns true if the data is added successfully, otherwise returns false.

Adds data tagged by tag using move semantics, only if there is no piece of data tagged by tag.

Parameters

- tag -- [in] The unique identifier of the data.
- value -- [in] Value to be add.

Returns Returns true if the data is added successfully, otherwise returns false.

HasValue

```
bool cnstream::Collection::HasValue(const Std::String &tag)
```

Checks whether there is the data tagged by tag.

Parameters tag -- [in] The unique identifier of the data.

Returns Returns true if there is already a piece of data tagged by tag, otherwise returns false.

Type

```
const std::type_info &cnstream::Collection::Type(const std::string &tag)
```

Gets type information for data tagged by tag.

Parameters tag -- [in] The unique identifier of the data.

Returns Returns type information of the data tagged by tag.

TaggedIsOfType

template<typename ValueT>

inline bool cnstream::Collection::TaggedIsOfType(const std::string &tag)

Checks if the type of data tagged by tag is ValueT or not.

Parameters tag -- The unique identifier of the data.

Returns Returns true if the type of data tagged by tag is ValueT, otherwise returns false.

3.1.2 Class ParametersChecker

class ParametersChecker

ParameterChecker is a class used to check module parameters.

API Reference

CheckPath

Checks if a path exists.

Parameters

- path -- [in] The path relative to JSON file or an absolute path.
- paramSet -- [in] The module parameters. The JSON file path is one of the parameters.

Returns Returns true if the path exists. Otherwise, returns false.

IsNum

Checks if the parameters are number, and the value is specified in the correct range.

Parameters

• check_list -- [in] A list of parameter names.

- paramSet -- [in] The module parameters.
- err_msg -- [out] The error message.
- greater_than_zero -- [in] If this parameter is set to true, the parameter set should be greater than or equal to zero. If this parameter is set to false, the parameter set is less than zero.

Returns Returns true if the parameters are number and the value is in the correct range. Otherwise, returns false.

3.1.3 Class ParamRegister

class ParamRegister

ParamRegister is a class for module parameter registration.

Each module registers its own parameters and descriptions. This is used in CNStream Inspect tool to detect parameters of each module.

API Reference

Register

Registers a paramter and its description.

This is used in CNStream Inspect tool.

Parameters

- key -- [in] The parameter name.
- desc -- [in] The description of the paramter.

Returns Void.

GetParams

```
\verb|inline| std::vector < std::pair < std::string>> \verb|cnstream|::ParamRegister|::GetParams()| \\
```

Gets the registered paramters and the parameter descriptions.

This is used in CNStream Inspect tool.

Returns Returns the registered paramters and the parameter descriptions.

IsRegisted

inline bool cnstream::ParamRegister::IsRegisted(const std::String &key) const

Checks if the paramter is registered.

This is used in CNStream Inspect tool.

Parameters key -- [in] The parameter name.

Returns Returns true if the parameter has been registered. Otherwise, returns false.

SetModuleDesc

inline void cnstream::ParamRegister::SetModuleDesc(const std::string &desc)

Sets the description of the module.

This is used in CNStream Inspect tool.

Parameters desc -- [in] The description of the module.

Returns Void.

GetModuleDesc

inline std::string cnstream::ParamRegister::GetModuleDesc()

Gets the description of the module.

This is used in CNStream Inspect tool.

Returns Returns the description of the module.

3.1.4 Class EventBus

class EventBus: private NonCopyable

EventBus is a class that transmits events from modules to a pipeline.

API Reference

~EventBus

```
cnstream::EventBus::~EventBus()
```

Destructor. A destructor to destruct event bus.

Returns No return value.

Start

```
bool cnstream::EventBus::Start()
```

Starts an event bus thread.

Returns Returns true if start successfully, otherwise false.

Stop

```
void cnstream::EventBus::Stop()
```

Stops an event bus thread.

Returns No return values.

AddBusWatch

```
uint32_t cnstream::EventBus::AddBusWatch(BusWatcher func)
```

Adds a watcher to the event bus.

Parameters func -- [in] The bus watcher to be added.

Returns The number of bus watchers that has been added to this event bus.

PostEvent

```
bool cnstream::EventBus::PostEvent(Event event)
```

Posts an event to a bus.

Parameters event -- [in] The event to be posted.

Returns Returns true if this function run successfully. Otherwise, returns false.

3.1.5 Class CNFrameInfo

```
class CNFrameInfo: private NonCopyable
```

CNFrameInfo is a class holding the information of a frame.

Variables

stream_id

```
std::string cnstream::CNFrameInfo::stream_id
```

The data stream aliases where this frame is located to.

timestamp

```
int64_t cnstream::CNFrameInfo::timestamp = -1
```

The time stamp of this frame.

flags

```
size_t cnstream::CNFrameInfo::flags = 0
```

The mask for this frame, CNFrameFlag.

datas

```
std::map<int, any> cnstream::CNFrameInfo::datas
```

(Deprecated) Uses CNFrameInfo::collection instead.

datas_lock

```
std::mutex cnstream::CNFrameInfo::datas_lock_
(Deprecated) Uses CNFrameInfo::collection instead.
```

collection

```
Collection cnstream:: CNFrameInfo::collection
Stored structured data.
```

payload

```
std::shared_ptr<cnstream::CNFrameInfo> cnstream::CNFrameInfo::payload = nullptr
CNFrameInfo instance of parent pipeline.
```

API Reference

Create

Creates a CNFrameInfo instance.

Parameters

- stream_id -- [in] The data stream alias. Identifies which data stream the frame data comes from.
- eos -- [in] Whether this is the end of the stream. This parameter is set to false
 by default to create a CNFrameInfo instance. If you set this parameter to true,
 CNDataFrame::flags will be set to CN_FRAME_FLAG_EOS. Then, the modules do
 not have permission to process this frame. This frame should be handed over
 to the pipeline for processing.

Returns Returns shared_ptr of *CNFrameInfo* if this function has run successfully. Otherwise, returns NULL.

CNFrameInfo

```
cnstream::CNFrameInfo::CNFrameInfo() = default
```

~CNFrameInfo

```
cnstream::CNFrameInfo::~CNFrameInfo()
```

Destructs CNFrameInfo object.

Returns No return value.

IsEos

```
inline bool cnstream::CNFrameInfo::IsEos()
```

Checks whether DataFrame is end of stream (EOS) or not.

Returns Returns true if the frame is EOS. Returns false if the frame is not EOS.

IsRemoved

```
inline bool cnstream::CNFrameInfo::IsRemoved()
```

Checks whether DataFrame is removed or not.

Returns Returns true if the frame is EOS. Returns false if the frame is not EOS.

IsInvalid

```
inline bool cnstream::CNFrameInfo::IsInvalid()
```

Checks if DataFrame is valid or not.

Returns Returns true if frame is invalid, otherwise returns false.

SetStreamIndex

```
inline void cnstream::CNFrameInfo::SetStreamIndex(uint32_t index)
```

Sets index (usually the index is a number) to identify stream.

Parameters index -- [in] Number to identify stream.

Note:

This is only used for distributing each stream data to the appropriate thread. We do not recommend SDK users to use this API because it will be removed later.

GetStreamIndex

inline uint32_t cnstream::CNFrameInfo::GetStreamIndex() const

Gets index number which identifies stream.

Returns Index number.

Note:

This is only used for distributing each stream data to the appropriate thread. We do not recommend SDK users to use this API because it will be removed later.

3.1.6 Class IModuleObserver

class IModuleObserver

IModuleObserver is an interface class. Users need to implement an observer based on this, and register it to one module.

API Reference

notify

virtual void cnstream:: IModuleObserver::notify(std::shared_ptr<CNFrameInfo> data) = 0

Notifies "data" after being processed by this module.

Parameters data -- [in] The frame that is notified to observer.

Returns No return value.

~IModuleObserver

```
virtual cnstream::IModuleObserver::~IModuleObserver() = default
```

Default destructor. A destructor to destruct module observer.

3.1.7 Class Module

class Module: private NonCopyable

Module is the parent class of all modules. A module could have configurable number of upstream links and downstream links. Some modules are already constructed with a framework, such as source, inferencer, and so on. You can also design your own modules.

Subclassed by cnstream::ModuleEx, cnstream::SourceModule

Variables

param_register

ParamRegister cnstream:: Module::param_register_

Each module registers its own parameters and descriptions. CNStream Inspect tool uses this class to detect parameters of each module.

API Reference

Module

inline explicit cnstream::Module(const std::string &name)

Constructor. A constructor to construct module object.

Parameters name -- [in] The name of a module. Modules defined in a pipeline must have different names.

Returns No return value.

~Module

virtual cnstream::Module::~Module()

Destructor. A destructor to destruct module instance.

SetObserver

```
inline void cnstream::Module::SetObserver(IModuleObserver*observer)
```

Registers an observer to the module.

Parameters observer -- [in] An observer you defined.

Returns No return value.

Open

```
virtual bool cnstream::Module::Open(ModuleParamSet param_set) = 0
```

Opens resources for a module.

Parameters param_set -- [in] A set of parameters for this module.

Returns Returns true if this function has run successfully. Otherwise, returns false.

Note:

You do not need to call this function by yourself. This function is called by pipeline automatically when the pipeline is started. The pipeline calls the Process function of this module automatically after the Open function is done.

Close

```
virtual void cnstream::Module::Close() = 0
```

Closes resources for a module.

Returns No return value.

Note:

You do not need to call this function by yourself. This function is called by pipeline automatically when the pipeline is stopped. The pipeline calls the Close function of this module automatically after the Open and Process functions are done.

Process

```
virtual int cnstream::Module::Process(std::shared_ptr<CNFrameInfo> data) = 0
```

Processes data.

Parameters data -- [in] The data to be processed by the module.

Returns >= 0 The data is processed successfully.

Returns < 0 Pipeline will post an event with the EVENT_ERROR event type and the return number.

OnEos

```
inline virtual void cnstream::Module::OnEos(const std::string &stream_id)
```

Notifies flow-EOS arriving, the module should reset internal status if needed.

Parameters stream_id -- [in] The stream identification.

Note:

This function will be invoked when flow-EOS is forwarded by the framework.

GetName

```
inline std::string cnstream::Module::GetName() const
```

Gets the name of this module.

Returns Returns the name of this module.

PostEvent

Posts an event to the pipeline.

Parameters

- type -- [in] The type of an event.
- msg -- [in] The event message string.

Returns Returns true if this function has run successfully. Returns false if this module has not been added to the pipeline.

bool cnstream::Module::PostEvent(Evente)

Posts an event to the pipeline.

Parameters Event -- with event type, stream_id, message, module name and thread_id.

Returns Returns true if this function has run successfully. Returns false if this module has not been added to the pipeline.

TransmitData

bool cnstream::Module::TransmitData(std::shared_ptr<CNFrameInfo> data)

Transmits data to the following stages.

Valid when the module has permission to transmit data by itself.

Parameters data -- [in] A pointer to the information of the frame.

Returns Returns true if the data has been transmitted successfully. Otherwise, returns false.

CheckParamSet

Checks parameters for a module, including parameter name, type, value, validity, and so on.

Parameters paramSet -- [in] Parameters for this module.

Returns Returns true if this function has run successfully. Otherwise, returns false.

GetContainer

```
inline Pipeline *cnstream::Module::GetContainer() const
```

Gets the pipeline this module belongs to.

Returns Returns the pointer to pipeline instance.

GetProfiler

```
ModuleProfiler *cnstream::Module::GetProfiler()
```

Gets module profiler.

Returns Returns a pointer to the module's profiler.

HasTransmit

```
inline bool cnstream::Module::HasTransmit() const
```

Checks if this module has permission to transmit data by itself.

See Process

Returns Returns true if this module has permission to transmit data by itself. Otherwise, returns false.

3.1.8 Class ModuleEx

class ModuleEx:public cnstream::Module

ModuleEx is the base class of the modules who have permission to transmit processed data by themselves.

API Reference

ModuleEx

```
inline explicit cnstream::ModuleEx::ModuleEx(const std::string &name)
```

Constructor. A constructor to construct the module which has permission to transmit processed data by itself.

Parameters name -- [in] The name of a module. Modules defined in a pipeline must have different names.

Returns No return value.

3.1.9 Class Pipeline

class Pipeline:private NonCopyable

Pipeline is the manager of the modules, which manages data transmission between modules and controls messages delivery.

API Reference

Pipeline

```
explicit cnstream::Pipeline::Pipeline(const std::string &name)
```

A constructor to construct one pipeline.

Parameters name -- [in] The name of the pipeline.

Returns No return value.

\sim Pipeline

```
virtual cnstream::Pipeline::~Pipeline()
```

A destructor to destruct one pipeline.

Parameters name -- [in] The name of the pipeline.

GetName

```
inline const std::string &cnstream::Pipeline::GetName() const
```

Gets the pipeline's name.

Returns Returns the pipeline's name.

BuildPipeline

Builds a pipeline by module configurations.

Parameters

- module_configs -- [in] The configurations of a module.
- profiler_config -- [in] The configuration of a profiler.

Returns Returns true if this function has run successfully. Otherwise, returns false.

```
bool cnstream::Pipeline::BuildPipeline(const CNGraphConfig &graph_config)
```

Builds a pipeline by graph configuration.

Parameters graph_config -- [in] The configuration of a graph.

Returns Returns true if this function has run successfully. Otherwise, returns false.

BuildPipelineByJSONFile

```
inline bool cnstream::Pipeline::BuildPipelineByJSONFile(const std::string &config_file)
```

Builds a pipeline from a JSON file. You can learn to write a configuration file by looking at the description of CNGraphConfig.

See CNGraphConfig

Parameters config_file -- [in] The configuration file in JSON format.

Returns Returns true if this function has run successfully. Otherwise, returns false.

Start

```
bool cnstream::Pipeline::Start()
```

Starts a pipeline. Starts data transmission in a pipeline. Calls the 0pen function for all modules. See Module::Open.

Returns Returns true if this function has run successfully. Returns false if the Open function did not run successfully in one of the modules, or the link modules failed.

Stop

```
bool cnstream::Pipeline::Stop()
```

Stops data transmissions in a pipeline.

Returns Returns true if this function has run successfully. Otherwise, returns false.

IsRunning

```
inline bool cnstream::Pipeline::IsRunning() const
```

The running status of a pipeline.

Returns Returns true if the pipeline is running. Returns false if the pipeline is not running.

GetModule

```
Module *cnstream::Pipeline::GetModule(const std::string &module_name) const
```

Gets a module in current pipeline by name.

Parameters module_name

-- **[in]** The module name specified in the module configuration. If you specify a module name written in the module configuration, the first module with the same name as the specified module name in the order of DFS will be returned. When there are modules with the same name as other graphs in the subgraph, you can also find the module by adding the graph name prefix divided by slash. eg. pipeline_name/subgraph1/module1.

Returns Returns the module pointer if the module has been added to the current pipeline. Otherwise, returns nullptr.

GetModuleConfig

Gets the module configuration by the module name.

Parameters module_name -- [in] The module name specified in module configuration. The module name can be specified by two ways, see Pipeline::GetModule for detail.

Returns Returns module configuration if this function has run successfully. Returns NULL if the module specified by module_name has not been added to the current pipeline.

IsProfilingEnabled

```
inline bool cnstream::Pipeline::IsProfilingEnabled() const
```

Checks if profiling is enabled.

Returns Returns true if profiling is enabled.

IsTracingEnabled

```
inline bool cnstream::Pipeline::IsTracingEnabled() const
```

Checks if tracing is enabled.

Returns Returns true if tracing is enabled.

ProvideData

```
bool cnstream::Pipeline::ProvideData(const Module *module,

std::shared_ptr<CNFrameInfo> data)
```

Provides data for the pipeline that is used in source module or the module transmitted by itself.

See Module::Process.

Parameters

- module -- [in] The module that provides data.
- data -- [in] The data that is transmitted to the pipeline.

Returns Returns true if this function has run successfully. Returns false if the module is not added in the pipeline or the pipeline has been stopped.

Note:

ProvideData can be only called by the head modules in pipeline. A head module means the module has no parent modules.

GetEventBus

```
inline EventBus *cnstream::Pipeline::GetEventBus() const
```

Gets the event bus in the pipeline.

Returns Returns the event bus.

SetStreamMsgObserver

```
inline void cnstream::Pipeline::SetStreamMsgObserver(StreamMsgObserver*observer)
```

Binds the stream message observer with a pipeline to receive stream message from this pipeline.

See StreamMsgObserver.

Parameters observer -- [in] The stream message observer. **Returns** No return value.

GetStreamMsgObserver

```
inline StreamMsgObserver *cnstream::Pipeline::GetStreamMsgObserver() const
```

Gets the stream message observer that has been bound with this pipeline.

See Pipeline::SetStreamMsgObserver.

Returns Returns the stream message observer that has been bound with this pipeline.

GetProfiler

```
inline PipelineProfiler *cnstream::Pipeline::GetProfiler() const
```

Gets this pipeline's profiler.

Returns Profiler.

GetTracer

```
inline PipelineTracer *cnstream::Pipeline::GetTracer() const
```

Gets this pipeline's tracer.

Returns Returns tracer.

IsRootNode

```
bool cnstream::Pipeline::IsRootNode(const Std::String &module_name) const
```

Checks if module is root node of pipeline or not. The module name can be specified by two ways, see Pipeline::GetModule for detail.

Parameters module_name -- [in] module name.

Returns Returns true if it's root node, otherwise returns false.

IsLeafNode

```
bool cnstream:: Pipeline:: IsLeafNode(const std:: String & module_name) const
```

Checks if module is leaf node of pipeline. The module name can be specified by two ways, see Pipeline::GetModule for detail.

Parameters module_name -- [in] module name.

Returns Returns true if it's leaf node, otherwise returns false.

Register Frame Done Call Back

```
inline VOid cnstream::Pipeline::RegisterFrameDoneCallBack(const
```

std::function<void)std::shared_ptr<CNFrameInfo

> &callback

Registers a callback to be called after the frame process is done. The callback will be invalid when Pipeline::Stop is called.

Parameters callback -- [in] The call back function. **Returns** No return value.

3.1.10 Class StreamMsgObserver

class StreamMsgObserver

Receives stream messages from a pipeline. To receive stream messages from the pipeline, you can define a class to inherit the StreamMsgObserver class and call the Update function. The observer instance is bounded to the pipeline using the Pipeline::SetStreamMsgObserver function.

See Pipeline::SetStreamMsgObserver StreamMsg StreamMsgType.

API Reference

Update

```
virtual void cnstream::StreamMsgObserver::Update(const StreamMsg &msg) = 0
```

Receives stream messages from a pipeline passively.

Parameters msg -- [in] The stream message from a pipeline. **Returns** No return value.

~StreamMsgObserver

```
virtual cnstream::StreamMsgObserver() = default
```

Default destructor to destruct stream message observer.

Returns No return value.

3.1.11 Class SourceHandler

class SourceHandler: private NonCopyable

SourceHandler is a class that handles various sources, such as RTSP and video file.

Subclassed by cnstream::ESJpegMemHandler, cnstream::ESMemHandler, cnstream::RawImgMemHandler, cnstream::RtspHandler

API Reference

SourceHandler

Constructs a source handler.

Parameters

- module -- [in] The source module this handler belongs to.
- stream_id -- [in] The name of the stream.

Returns No return value.

~SourceHandler

```
inline virtual cnstream::SourceHandler::~SourceHandler()
```

Destructs a source module.

Returns No return value.

Open

```
virtual bool cnstream::SourceHandler::Open() = 0
```

Opens a decoder.

Returns Returns true if a decoder is opened successfully, otherwise returns false.

Close

```
virtual Void cnstream::SourceHandler::Close() = 0
```

Closes a decoder.

Stop

```
inline virtual VOid cnstream::SourceHandler::Stop()
```

Stops a decoder. The Close() function should be called afterwards.

Returns No return value.

GetStreamId

```
inline Std::string cnstream::SourceHandler::GetStreamId() const
```

Gets the stream identification.

Returns Returns the name of stream.

CreateFrameInfo

Creates the context of CNFameInfo.

Parameters

- eos -- [in] The flag marking the frame is end of stream.
- payload -- [in] The payload of CNFameInfo. It's useless now.

Returns Returns the context of CNFameInfo.

SendData

```
inline bool cnstream::SourceHandler::SendData(std::shared_ptr<CNFrameInfo> data)
```

Sends data to next module.

Parameters data -- [in] The data need to be sent to next modules.

Returns Returns true if send data successfully, otherwise returns false.

3.1.12 Class SourceModule

class SourceModule: public Cnstream::Module

SourceModule is the base class of source modules.

Subclassed by cnstream::DataSource

API Reference

SourceModule

```
inline explicit cnstream::SourceModule::SourceModule(const Std::String &name)
```

Constructs a source module.

Parameters name -- [in] The name of the source module.

Returns No return value.

~SourceModule

```
inline virtual cnstream::SourceModule::~SourceModule()
```

Destructs a source module.

Returns No return value.

AddSource

```
int cnstream::SourceModule::AddSource(std::shared_ptr<SourceHandler> handler)
```

Adds one stream to DataSource module. This function should be called after pipeline starts.

Parameters handler -- [in] The source handler

Returns Returns 0 for success, otherwise returns -1.

GetSourceHandler

Destructs a source module.

Parameters stream_id -- [in] The stream identifier.

Returns Returns the handler of the stream.

RemoveSource

Removes one stream from ::DataSource module with given handler. This function should be called before pipeline stops.

Parameters

- handler -- [in] The handler of one stream.
- force -- [in] The flag describing the removing behaviour.

Returns 0 success (always success by now).

Note:

If force sets to true, the stream will be removed immediately, otherwise the stream will be removed after all cached frames are processed.

Removes one stream from DataSource module with given the stream identification. This function should be called before pipeline stops.

Parameters

- stream_id -- [in] The stream identification.
- force -- [in] The flag describing the removing behaviour.

Returns 0 success (always success by now).

Note:

If force sets to true, the stream will be removed immediately, otherwise the stream will be removed after all cached frames are processed.

RemoveSources

int cnstream::SourceModule::RemoveSources(bool force = false)

Removes all streams from DataSource module.

Parameters force -- [in] The flag describing the removing behaviour. **Returns 0** success (always success by now).

Note:

If force sets to true, the stream will be removed immediately, otherwise the stream will be removed after all cached frames are processed.

3.1.13 Class CNSyncedMemory

 ${\tt class} \ {\tt CNSyncedMemory:private\ NonCopyable}$

CNSyncedMemory is a class synchronizing memory between CPU and MLU.

If the data on MLU is the latest, the data on CPU should be synchronized before processing the data on CPU. Vice versa, if the data on CPU is the latest, the data on MLU should be synchronized before processing the data on MLU.

Note:

CNSyncedMemory::Head() always returns SyncedHead::UNINITIALIZED when memory size is 0.

Datatypes Reference

```
enum SyncedHead {
    UNINITIALIZED = 0,
    HEAD_AT_CPU = 1,
    HEAD_AT_MLU = 2,
    SYNCED = 3,
};
enum cnstream:: CNSyncedMemory::SyncedHead
    An enumerator describing the synchronization status.
    Values:
    enumerator UNINITIALIZED
        The memory is not allocated.
    enumerator HEAD_AT_CPU
        The data is updated to CPU but is not synchronized to MLU yet.
    enumerator HEAD_AT_MLU
```

The data is updated to MLU but is not synchronized to CPU yet.

enumerator SYNCED

The data is synchronized to both CPU and MLU.

API Reference

CNSyncedMemory

```
explicit cnstream::CNSyncedMemory::CNSyncedMemory(size_t size)
```

Constructor to construct synchronized memory object.

Parameters size -- [in] The size of the memory.

Returns No return value.

Constructor to construct synchronized memory object.

Parameters

- size -- [in] The size of the memory.
- mlu_dev_id -- [in] MLU device ID that is incremented from 0.
- mlu_ddr_chn -- [in] The MLU DDR channel that is greater than or equal to 0, and is less than 4. It specifies which piece of DDR channel the memory allocated on.

Returns No return value.

\sim CNSyncedMemory

```
cnstream::CNSyncedMemory::~CNSyncedMemory()
```

Destructor to destruct synchronized memory object.

Returns No return value.

GetCpuData

```
const VOid *cnstream::CNSyncedMemory::GetCpuData()
```

Gets the CPU data.

Parameters No -- return value.

Returns Returns the CPU data pointer.

Note:

If the size is 0, nullptr is always returned.

SetCpuData

```
void cnstream::CNSyncedMemory::SetCpuData(void *data)
```

Sets the CPU data.

Parameters data -- [in] The data pointer on CPU. Returns Void.

GetMluData

```
const VOid *cnstream::CNSyncedMemory::GetMluData()
```

Gets the MLU data.

Returns Returns the MLU data pointer.

Note:

If the size is 0, nullptr is always returned.

SetMluData

```
void cnstream::CNSyncedMemory::SetMluData(void *data)
```

Sets the MLU data.

Parameters data -- [out] The data pointer on MLU.

Returns No return value.

SetMluDevContext

Sets the MLU device context.

Parameters

- dev_id -- [in] The MLU device ID that is incremented from 0.
- ddr_chn -- [in] The MLU DDR channel ID that is greater than or equal to 0, and less than

a. It specifies which piece of DDR channel the memory is allocated on.

Returns No return value.

Note:

You need to call this API before all getters and setters.

GetMluDevId

```
int cnstream::CNSyncedMemory::GetMluDevId() const
```

Gets the MLU device ID.

Returns Returns the ID of the device that the MLU memory is allocated on.

GetMluDdrChnld

```
int cnstream::CNSyncedMemory::GetMluDdrChnId() const
```

Gets the channel ID of the MLU DDR.

Returns Returns the DDR channel ID that the MLU memory is allocated on.

GetMutableCpuData

```
void *cnstream::CNSyncedMemory::GetMutableCpuData()
```

Gets the mutable CPU data.

Returns Returns the CPU data pointer.

3. CLASS 3.2. PROFILER

GetMutableMluData

```
void *cnstream::CNSyncedMemory::GetMutableMluData()
```

Gets the mutable MLU data.

Returns Returns the MLU data pointer.

GetHead

```
{\tt inline SyncedHead cnstream:: \it CNSyncedMemory:: GetHead() const}
```

Gets synchronization status.

See SyncedHead.

Returns Returns synchronization status.

GetSize

```
inline SiZe_t cnstream::CNSyncedMemory::GetSize() const
```

Gets data bytes.

Returns Returns data bytes.

3.2 Profiler

3.2.1 Class ModuleProfiler

class ModuleProfiler:private NonCopyable

ModuleProfiler is a class of the performance statistics of a module. It contains multiple cnstream::ProcessProfiler instances to support multiple process profilings.

The trace events of each process will be recorded when ProfilerConfig::enable_tracing is true. Profiling

and tracing of customized process is supported. See ModuleProfiler::RegisterProcessName for details.

Note:

This class is thread safe.

3. CLASS 3.2. PROFILER

API Reference

ModuleProfiler

Constructs a ModuleProfiler object.

Parameters

- config -- [in] The configuration of the profiler.
- module_name -- [in] The name of the module.
- tracer -- [in] The tracer for tracing events.

Returns No return value.

RegisterProcessName

bool cnstream:: ModuleProfiler::RegisterProcessName(const std::string &process_name)

Registers process named by process_name for this profiler.

Parameters process_name -- [in] The process name is the unique identification of a function or a piece of code that needs to do profiling.

Returns Returns true if the registration is successful. Returns false if the process name has been registered.

RecordProcessStart

Records the start of a process named process_name.

See cnstream::ModuleProfiler::RegisterProcessName

See cnstream::ModuleProfiler::RecordKey

Parameters

- process_name -- [in] The name of the process. It should be registed by RegisterProcessName.
- key -- [in] The unique identifier of a CNFrameInfo instance.

Returns Returns true if recording is successful. Returns false if the process named by process_name is not registered by RegisterProcessName.

RecordProcessEnd

 ${\tt bool\ cnstream::} \textit{ModuleProfiler::} \textbf{RecordProcessEnd(const\ std::} \textbf{string\ \&process_name,} \\ \\ {\tt const\ RecordKey\ \&key)}$

Records the end of a process named process_name.

See cnstream::ModuleProfiler::RegisterProcessName

See cnstream::ModuleProfiler::RecordKey

Parameters

- process_name -- [in] The name of the process. It should be registed by RegisterProcessName.
- key -- [in] The unique identifier of a CNFrameInfo instance.

Returns Returns true if record successfully. Returns false if the process named by process_name has not been registered by RegisterProcessName.

OnStreamEos

void cnstream::ModuleProfiler::OnStreamEos(const std::string &stream_name)

Clears profiling data of the stream named by stream_name, as the end of the stream is reached.

Parameters stream_name -- [in] The name of the stream, usually the CNFrameInfo::stream_id.

Returns No return value.

GetName

inline std::string cnstream::ModuleProfiler::GetName() const

Gets the name of the module.

Returns Returns the name of the module.

GetProfile

ModuleProfile cnstream::ModuleProfiler::GetProfile()

Gets profiling results of the module during the execution of the program.

Returns Returns the profiling results.

ModuleProfile cnstream:: ModuleProfiler::GetProfile(const ModuleTrace &trace)

Gets profiling results according to the trace data.

Parameters trace -- [in] Gets profiling results according to the trace data. **Returns** Returns the profiling results.

3.2.2 Class PipelineProfiler

class PipelineProfiler: private NonCopyable

PipelineProfiler is responsible for the performance statistics of a pipeline. It contains multiple cnstream::ModuleProfiler instances to support multiple module profilings.

By default, it will perform profiling of two processes for all modules. They are named kPROCESS_PROFILER_NAME and kINPUT_PROFILER_NAME. The start of the first process is before cnstream::Module::Process being called, and the end is before cnstream::Module::Transmit being called. The time when data is pushed into the data queue of the module is the start of the second process and the end is when data starts to be processed by the module.

It also does profiling of the data processing process from entering to exiting the pipeline.

The start and end trace events of each process are recorded when the config.enable_tracing is true.

Note:

This class is thread safe.

API Reference

PipelineProfiler

Constructs a PipelineProfiler object.

Parameters

- config -- [in] The configuration of the profiler.
- pipeline_name -- [in] The name of the pipeline.

• modules -- [in] All modules of the pipeline named pipeline_name.

Returns No return value.

GetName

```
inline Std::string cnstream::PipelineProfiler::GetName() const
```

Gets the name of the pipeline.

Returns Returns the name of the pipeline.

GetConfig

```
inline ProfilerConfig cnstream::PipelineProfiler::GetConfig() const
```

Gets profiler configuration.

Returns Returns profiler configuration.

GetTracer

```
inline PipelineTracer *cnstream::PipelineProfiler::GetTracer() const
```

Gets tracer.

Returns Returns the tracer of the pipeline.

GetModuleProfiler

```
\label{thm:moduleProfiler*const} {\tt ModuleProfiler}::{\tt GetModuleProfiler}({\tt const} & {\tt std}::{\tt string} \\ & {\tt \&module\_name}) \ {\tt const} \\
```

Gets the module profiler by the name of the module.

Parameters module_name -- [in] The name of the module.

Returns Returns the module profiler.

GetProfile

```
PipelineProfile cnstream::PipelineProfiler::GetProfile()
```

Gets profiling results of the pipeline during the execution of the program.

Returns Returns the profiling results.

```
PipelineProfile cnstream::PipelineProfiler::GetProfile(const Time &start, const Time &end)
```

Gets profiling results between the start time and the end time.

Parameters

- start -- [in] The start time.
- end -- [in] The end time.

Returns Returns the profiling results.

GetProfileBefore

Gets profiling results during a specified period time.

Parameters

- end -- [in] The end time.
- duration -- [in] The duration in milliseconds. The start time is the end time minus duration.

Returns Returns the profiling results.

GetProfileAfter

Gets profiling results for a specified period time.

Parameters

- start -- [in] The start time.
- duration -- [in] The duration in milliseconds. The end time is the start time plus duration.

Returns Returns the profiling results.

RecordInput

```
inline void cnstream::PipelineProfiler::RecordInput(const RecordKey &key)
```

Records the time when the data enters the pipeline.

See cnstream::RecordKey

Parameters key -- [in] The unique identifier of a CNFrameInfo instance.

Returns No return value.

RecordOutput

```
inline void cnstream::PipelineProfiler::RecordOutput(const RecordKey &key)
```

Records the time when the data exits the pipeline.

See cnstream::RecordKey

Parameters key -- [in] The unique identifier of a CNFrameInfo instance.

Returns No return value.

OnStreamEos

```
inline Void cnstream::PipelineProfiler::OnStreamEos(const Std::String &Stream_name)
```

Clears profiling data of the stream named by stream_name, as the end of the stream is reached.

Parameters stream_name -- [in] The name of the stream, usually the CNFrameInfo::stream_id.

Returns No return value.

3.2.3 Class PipelineTracer

class PipelineTracer: private NonCopyable

PipelineTracer is a class for recording trace events of the pipeline.

API Reference

PipelineTracer

```
explicit cnstream::PipelineTracer::PipelineTracer(size_t capacity = 100000)
```

Constructs a PipelineTracer object.

Parameters capacity -- [in] The capacity to store trace events.

Returns No return value.

~PipelineTracer

```
cnstream::PipelineTracer::~PipelineTracer()
```

Destructs a PipelineTracer object.

Returns No return value.

RecordEvent

```
void cnstream::PipelineTracer::RecordEvent(const TraceEvent &event)
```

Records a trace event using value reference semantics.

Parameters event -- [in] The trace event.

Returns No return value.

```
void cnstream::PipelineTracer::RecordEvent(TraceEvent &&event)
```

Records a trace event using move semantics.

Parameters event -- [in] The trace event.

Returns No return value.

GetTrace

```
PipelineTrace cnstream::PipelineTracer::GetTrace(const Time &start, const Time &end) const
```

Gets the trace data of the pipeline for a specified period of time.

Parameters

- start -- [in] The start time.
- end -- [in] The end time.

Returns Returns the trace data of the pipeline.

GetTraceBefore

Gets the trace data of the pipeline for a specified period of time.

Parameters

- end -- [in] The end time
- duration -- [in] The duration in milliseconds. The start time is the end time minus duration.

Returns Returns the trace data of the pipeline.

GetTraceAfter

Gets the trace data of the pipeline for a specified period of time.

Parameters

- start -- [in] The start time.
- duration -- [in] The duration in milliseconds. The end time is the start time plus duration.

Returns Returns the trace data of the pipeline.

3.2.4 Class ProcessProfiler

class ProcessProfiler: private NonCopyable

ProcessProfiler is the profiler for a process. A process can be a function call or a piece of code.

Note:

This class is thread safe.

API Reference

ProcessProfiler

Constructs a ProcessProfiler object.

Parameters

- config -- [in] The configuration of the profiler.
- process_name -- [in] The name of the process.
- tracer -- [in] The tracer for tracing events.

Returns No return value.

~ProcessProfiler

```
cnstream::ProcessProfiler::~ProcessProfiler()
```

Destructs a ProcessProfiler object.

Returns No return value.

SetModuleName

Sets the module name to identify which module this profiler belongs to. The module name takes effect when the trace level is TraceEvent::MODULE. The trace level can be set by cnstream::ProcessProfiler::SetTraceLevel.

Parameters module_name -- [in] The name of the module. **Returns** Returns this profiler itself.

SetTraceLevel

```
inline ProcessProfiler &cnstream::ProcessProfiler::SetTraceLevel(const
```

TraceEvent::Level

&level)

Set the trace level for this profiler. Trace level identifies whether this profiler belongs to a module or a pipeline.

See cnstream::TraceEvent::Level.

Parameters level -- [in] Trace level.

Returns Returns the ProcessProfiler object itself.

RecordStart

```
void cnstream::ProcessProfiler::RecordStart(const RecordKey &key)
```

Records the start of the process.

See cnstream::RecordKey.

Parameters key -- [in] The unique identifier of a CNFrameInfo instance.

Returns No return value.

RecordEnd

```
void cnstream::ProcessProfiler::RecordEnd(const RecordKey &key)
```

Records the end of the process.

See cnstream::RecordKey.

Parameters key -- [in] The unique identifier of a CNFrameInfo instance.

Returns No return value.

GetName

```
inline std::string cnstream::ProcessProfiler::GetName() const
```

Gets the name of the process.

Returns The name of the process.

GetProfile

```
ProcessProfile cnstream::ProcessProfiler::GetProfile()
```

Gets profiling results of the process during the execution of the program.

Returns Returns the profiling results.

```
ProcessProfile cnstream::ProcessProfiler::GetProfile(const ProcessTrace &trace) const
```

Gets profiling results according to the trace data.

Parameters trace -- [in] The trace data of the process.

Returns Returns the profiling results.

OnStreamEos

```
void cnstream::ProcessProfiler::OnStreamEos(const std::string &stream_name)
```

Clears profiling data of the stream named by stream_name, as the end of the stream is reached.

Parameters stream_name -- [in] The name of the stream, usually the CNFrameInfo::stream_id.

Returns No return value.

3.2.5 Class StreamProfiler

class StreamProfiler

StreamProfiler is responsible for the performance statistics of a certain processing process of a stream. It is used by ProcessProfiler.

See cnstream::ProcessProfiler.

Datatypes Reference

typedef Duration

typedef std::chrono::duration<double, std::milli> cnstream::Duration;

using cnstream::StreamProfiler::Duration = std::chrono::duration < double, std::milli>

API Reference

StreamProfiler

explicit cnstream::StreamProfiler::StreamProfiler(const std::string &stream_name)

Constructs a StreamProfiler object.

Parameters stream_name -- [in] The name of a stream.

Returns No return value.

AddLatency

inline StreamProfiler &cnstream::StreamProfiler::AddLatency(const Duration &latency)

Accumulates latency to total latency.

Parameters latency -- [in] The latency to be added. The latency will be accumulated to total latency.

Returns Returns a lvalue reference to the current instance.

UpdatePhysicalTime

Updates physical time that a stream costs.

Parameters time -- [in] The physical time a stream costs.

Returns Returns a lyalue reference to the current instance.

AddDropped

inline StreamProfiler &cnstream::StreamProfiler::AddDropped(uint64_t dropped)

Accumulates dropped frame count.

Parameters dropped -- [in] The dropped frame count.

Returns Returns a lvalue reference to the current instance.

AddCompleted

```
inline StreamProfiler &cnstream::StreamProfiler::AddCompleted()
```

Accumulates completed frame count with 1.

Returns Returns a lvalue reference to the current instance.

GetName

```
inline std::string cnstream::StreamProfiler::GetName() const
```

Gets the name of the stream.

Returns Returns the name of the stream.

GetProfile

```
StreamProfile cnstream::StreamProfiler::GetProfile()
```

Gets the performance statistics for this stream.

Returns Returns the performance statistics for this stream.

3.2.6 Class TraceSerializeHelper

class TraceSerializeHelper

Serializes trace data into JSON format. You can load JSON file by chrome-tracing to show the trace data.

API Reference

Deservative From JSONStr

Deserializes a JSON string.

Parameters

- jsonstr -- [in] The JSON string.
- pout -- [out] The output pointer stores the results.

Returns Returns true if the JSON string is deserialized successfully, otherwise returns false.

Deservative From JSON File

Deserializes a JSON file.

Parameters

- jsonstr -- [in] The JSON file path.
- pout -- [out] The output pointer stores the results.

Returns Returns true if the JSON string is deserialized successfully, otherwise returns false.

TraceSerializeHelper

```
cnstream::TraceSerializeHelper::TraceSerializeHelper()
```

Constructs a TraceSerializeHelper object.

Returns No return value.

Constructs a TraceSerializeHelper object with the copy of the contents of another object.

Parameters other -- [in] Another object used to initialize an object. **Returns** No return value.

```
cnstream::TraceSerializeHelper::TraceSerializeHelper(TraceSerializeHelper &&other)
```

Constructs a TraceSerializeHelper object with the contents of another object using move semantics.

Parameters other -- [in] Another object used to initialize an object. **Returns** No return value.

operator=

```
\label{thm:constrain} {\it TraceSerializeHelper::operator=(const} $$ TraceSerializeHelper::operator=(const & Constraints) $$ (a) $$ (b) $$ (b) $$ (b) $$ (c) $$ (c)
```

Replaces the contents with a copy of the contents of another TraceSerializeHelper object.

Parameters other -- [in] Another object used to initialize the current object. **Returns** Returns a lyalue reference to the current instance.

```
TraceSerializeHelper &cnstream:: TraceSerializeHelper::operator=(TraceSerializeHelper &constream)
```

Replaces the contents with those of another TraceSerializeHelper object using move semantics.

Parameters other -- [in] Another object used to initialize the current object. **Returns** Returns a lvalue reference to the current instance.

~TraceSerializeHelper

```
cnstream::TraceSerializeHelper::~TraceSerializeHelper() = default
```

Destructs a TraceSerializeHelper object by using default constructor.

Returns No return value.

Serialize

```
void cnstream::TraceSerializeHelper::Serialize(const PipelineTrace &pipeline_trace)
```

Serializes trace data.

Parameters pipeline_trace -- [in] The trace data. Get it by
 pipeline.GetTracer()->GetTrace().

Returns No return value.

Merge

```
void cnstream::TraceSerializeHelper::Merge(const TraceSerializeHelper &t)
```

Merges another trace serialization helper tool data.

Parameters t -- [in] The trace serialization helper tool to be merged.

Returns No return value.

ToJsonStr

```
std::string cnstream::TraceSerializeHelper::ToJsonStr() const
```

Serializes to a JSON string.

Returns Returns a JSON string.

ToFile

```
inline bool cnstream::TraceSerializeHelper::ToFile(const Std::String &filename) const
```

Serializes to a JSON file.

Parameters filename -- [in] The JSON file name.

Returns Returns true if the serialization is successful, otherwise returns false.

Note:

the possible reason of serialization failure is that writing to the file is not permitted.

Reset

```
void cnstream::TraceSerializeHelper::Reset()
```

Resets serialization helper. Clears data and frees up memory.

Returns No return value.

3.2.7 Class TraceEvent

```
class TraceEvent
     TraceEvent is a class representing a trace event used by Profile.
Datatypes Reference
enum Level
enum Level {
     PIPELINE = 0,
     MODULE = 1,
};
enum cnstream::TraceEvent::Level
     Enumeration variables describing the level of an event. The default level is 0 (pipeline's event).
     Values:
     enumerator PIPELINE
         A event of a pipeline.
     enumerator MODULE
         An event of a module.
enum Type
enum Type {
     START = 1 << 0,
     END = 1 << 1,
};
enum cnstream::TraceEvent::Type
     Enumeration variables describing the type of an event. The default type is 1 (START).
     Values:
     enumerator START
         A process-start event.
     enumerator END
```

A process-end event.

Variables

```
key
```

RecordKey cnstream:: TraceEvent::key

The unique identification of a frame.

module_name

std::string cnstream::TraceEvent::module_name

The name of a module.

process_name

std::string cnstream::TraceEvent::process_name

The name of a process. A process can be a function call or a piece of code.

time

Time cnstream:: TraceEvent::time

The timestamp of an event.

level

enum cnstream::TraceEvent::Level cnstream::TraceEvent::level = Level::PIPELINE

type

enum cnstream::TraceEvent::Type cnstream::TraceEvent::type = Type::START

API Reference

TraceEvent

```
cnstream::TraceEvent::TraceEvent() = default
```

Constructs a TraceEvent object by using default constructor.

Returns No return value.

inline explicit cnstream::TraceEvent::TraceEvent(const RecordKey &key)

Constructs a TraceEvent object with a RecordKey instance.

Parameters key -- [in] The unique identification of a frame.

Returns No return value.

inline explicit cnstream::TraceEvent::TraceEvent(RecordKey &&key)

Constructs a TraceEvent object with a RecordKey using move semantics.

Parameters key -- [in] The unique identification of a frame.

Returns No return value.

cnstream::TraceEvent::TraceEvent(const TraceEvent &other) = default

Constructs a TraceEvent object with the copy of the contents of another object.

Parameters other -- [in] Another object used to initialize an object.

Returns No return value.

inline cnstream::TraceEvent::TraceEvent(TraceEvent &&other)

Constructs a TraceEvent object with the contents of another object using move semantics.

Parameters other -- [in] Another object used to initialize an object.

Returns No return value.

operator=

TraceEvent &cnstream:: TraceEvent:: operator=(const TraceEvent &other) = default

Replaces the contents with a copy of the contents of another TraceEvent object.

Parameters other -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

inline TraceEvent &cnstream::TraceEvent::operator=(TraceEvent &&other)

Replaces the contents with those of another TraceEvent object using move semantics.

Parameters other -- [in] Another object used to initialize the current object.

Returns Returns a lyalue reference to the current instance.

SetKey

```
inline TraceEvent &cnstream::TraceEvent::SetKey(const RecordKey &key)
```

Sets a unique identification for a frame.

Parameters key -- [in] The unique identification of a frame.

Returns Returns a lvalue reference to the current instance.

```
inline TraceEvent &cnstream::TraceEvent::SetKey(RecordKey &&key)
```

Sets a unique identification for a frame using move semantics.

Parameters key -- [in] The unique identification of a frame.

Returns Returns a lvalue reference to the current instance.

SetModuleName

Sets the name of a module.

Parameters module_name -- [in] The name of a module.

Returns Returns a lvalue reference to the current instance.

```
inline TraceEvent &cnstream::TraceEvent::SetModuleName(std::string &&module_name)
```

Sets the name of a module using move semantics.

Parameters module_name -- [in] The name of a module.

Returns Returns a lyalue reference to the current instance.

SetProcessName

Sets the name of a process.

Parameters process_name -- [in] The name of a process.

Returns Returns a lvalue reference to the current instance.

```
inline TraceEvent &cnstream::TraceEvent::SetProcessName(std::String &&process_name)
```

Sets the name of a process using move semantics.

Parameters process_name -- [in] The name of a process.

Returns Returns a lyalue reference to the current instance.

SetTime

```
inline TraceEvent &cnstream::TraceEvent::SetTime(const Time &time)
```

Sets the timestamp of this event.

Parameters time -- [in] The timestamp of the event.

Returns Returns a lyalue reference to the current instance.

```
inline TraceEvent &cnstream::TraceEvent::SetTime(Time &&time)
```

Sets the timestamp of this event using move semantics.

Parameters time -- [in] The timestamp of the event.

Returns Returns a lvalue reference to the current instance.

SetLevel

```
inline TraceEvent &cnstream::TraceEvent::SetLevel(const Level &level)
```

Sets the level of this event.

Parameters level -- [in] the level of the event.

Returns Returns a lvalue reference to the current instance.

SetType

```
inline TraceEvent &cnstream::TraceEvent::SetType(const Type &type)
```

Sets the type of this event.

Parameters type -- [in] The type of th event.

Returns Returns a lvalue reference to the current instance.

3.3 Video Analysis

3.3.1 Class CNDataFrame

class CNDataFrame: public NonCopyable

CNDataFrame is a class holding a data frame and the frame description.

Variables

```
cpu_data
std::shared_ptr<void> cnstream::CNDataFrame::cpu_data = nullptr
     A shared pointer to the CPU data.
mlu_data
std::shared_ptr<void> cnstream:: CNDataFrame::mlu_data = nullptr
     A shared pointer to the MLU data.
data
std::unique_ptr<CNSyncedMemory> cnstream:: CNDataFrame::data[CN_MAX_PLANES]
     Synchronizes data helper.
frame_id
uint64_t cnstream::CNDataFrame::frame_id = -1
     The frame index that incremented from 0.
fmt
CNDataFormat cnstream::CNDataFrame::fmt
     The format of the frame.
width
int cnstream::CNDataFrame::width
     The width of the frame.
height
int cnstream::CNDataFrame::height
     The height of the frame.
```

stride

 $\verb|intcnstream|: CNDataFrame|::stride[CN_MAX_PLANES]|$

The strides of the frame.

ctx

DevContext cnstream::CNDataFrame::ctx

The device context of SOURCE data (ptr_mlu/ptr_cpu).

deAllocator

std::unique_ptr<IDataDeallocator> cnstream::CNDataFrame::deAllocator_ = nullptr
The dedicated deallocator for CNDecoder buffer.

API Reference

CNDataFrame

```
cnstream::CNDataFrame::CNDataFrame() = default
```

Constructs an object.

Returns No return value.

~CNDataFrame

```
cnstream::CNDataFrame::~CNDataFrame() = default
```

Destructs an object.

Returns No return value.

GetPlanes

```
inline int cnstream::CNDataFrame::GetPlanes() const
```

Gets plane count for a specified frame.

Returns Returns the plane count of this frame.

GetPlaneBytes

```
size_t cnstream::CNDataFrame::GetPlaneBytes(int plane_idx) const
```

Gets the number of bytes in a specified plane.

Parameters plane_idx -- [in] The index of the plane. The index increments from 0. **Returns** Returns the number of bytes in the plane.

GetBytes

```
SiZe_t cnstream:: CNDataFrame::GetBytes() const
```

Gets the number of bytes in a frame.

Returns Returns the number of bytes in a frame.

CopyToSyncMem

Synchronizes the source data into :: CNSyncedMemory.

Parameters

- ptr_src -- [in] The source data's address. This API internally judges the address is MLU memory or not.
- dst_mlu -- [in] The flag shows whether synchronizes the data to MLU memory.

Note:

Sets the width,height,fmt,ctx,stride,dst_device_id,deAllocator_ before calling this function. There are 5 situations:

- a. Reuse codec's buffer and do not copy anything. Just assign the ptr_src to CNSyncedMemory mlu_ptr_.
- b. This API allocates MLU buffer, and copy the source MLU data to the allocated buffer as the MLU destination.
- c. This API allocates MLU buffer, and copy the source CPU data to the allocated buffer as the MLU destination.
- d. This API allocates CPU buffer, and copy the source MLU data to the allocated buffer as the CPU destination.
- e. This API allocates CPU buffer, and copy the source CPU data to the allocated buffer as the CPU destination. Whatever which situation happens, ::CNSyncedMemory doesn't own the buffer and it isn't responsible for releasing the data.

ImageBGR

CV::Mat cnstream::CNDataFrame::ImageBGR()

Converts data to the BGR format.

Returns Returns data with OpenCV mat type.

Note:

This function is called after CNDataFrame::CopyToSyncMem() is invoked.

HasBGRImage

inline bool cnstream::CNDataFrame::HasBGRImage()

Checks whether there is BGR image stored.

Returns Returns true if has BGR image, otherwise returns false.

CopyToSyncMemOnDevice

```
void cnstream::CNDataFrame::CopyToSyncMemOnDevice(int device_id)
```

Synchronizes source data to specific device, and resets ctx.dev_id to device_id when synced, for multi-device case.

Parameters device_id -- [in] The device id. **Returns** No return value.

3.3.2 Class CNInferObject

```
class CNInferObject
```

CNInferObject is a class holding the information of an object.

Variables

```
id
```

```
std::string cnstream::CNInferObject::id

The ID of the classification (label value).
```

track_id

```
std::string cnstream::CNInfer0bject::track_id The tracking result.
```

score

```
float cnstream::CNInferObject::score
    The label score.
```

bbox

```
CNInferBoundingBox cnstream::CNInferObject::bbox
```

The object normalized coordinates.

datas

```
std::map<int, any> cnstream::CNInferObject::datas
(Deprecated) User-defined structured information.
```

collection

Collection cnstream:: CNInferObject::collection
User-defined structured information.

API Reference

CNInferObject

```
cnstream::CNInferObject::CNInferObject() = default
```

Constructs an instance storing inference results.

Returns No return value.

~CNInferObject

```
cnstream::CNInferObject::~CNInferObject() = default
```

Constructs an instance.

Returns No return value.

AddAttribute

```
bool cnstream:: CNInferObject::AddAttribute(const std::string &key,

const CNInferAttr &value)
```

Adds the key of an attribute to a specified object.

Parameters

- key -- [in] The Key of the attribute you want to add to. See GetAttribute().
- value -- [in] The value of the attribute.

Returns Returns true if the attribute has been added successfully. Returns false if the attribute already existed.

Note:

Adds the key pairs of an attribute to a specified object.

Parameters attribute -- [in] The attribute pair (key, value) to be added.

Returns Returns true if the attribute has been added successfully. Returns false if the attribute has already existed.

Note:

This is a thread-safe function.

GetAttribute

CNInferAttr cnstream::CNInferObject::GetAttribute(const std::string &key)

Gets an attribute by key.

Parameters key -- **[in]** The key of an attribute you want to query. See AddAttribute().

Returns Returns the attribute key. If the attribute does not exist, CNInferAttr::id will be set to -1.

Note:

This is a thread-safe function.

AddExtraAttribute

 $\label{local_const_std} bool \ \texttt{cnst} \ \texttt{std::string \&key,} \\ \\ \text{const std::string \&value)}$

Adds the key of the extended attribute to a specified object.

Parameters

- key -- [in] The key of an attribute. You can get this attribute by key. See GetExtraAttribute().
- value -- [in] The value of the attribute.

Returns Returns true if the attribute has been added successfully. Returns false if the attribute has already existed in the object.

Note:

AddExtraAttributes

Adds the key pairs of the extended attributes to a specified object.

Parameters attributes -- [in] Attributes to be added.

Returns Returns true if the attribute has been added successfully. Returns false if the attribute has already existed.

Note:

This is a thread-safe function.

GetExtraAttribute

std::string cnstream::CNInferObject::GetExtraAttribute(const std::string &key)

Gets an extended attribute by key.

Parameters key -- [in] The key of an identified attribute. See AddExtraAttribute().

Returns Returns the attribute that is identified by the key. If the attribute does not exist, returns NULL.

Note:

This is a thread-safe function.

RemoveExtraAttribute

bool cnstream::CNInferObject::RemoveExtraAttribute(const std::string &key)

Removes an attribute by key.

Parameters key -- [in] The key of an attribute you want to remove. See AddAttribute.

Returns Return true.

Note:

GetExtraAttributes

StringPairs cnstream::CNInferObject::GetExtraAttributes()

Gets all extended attributes of an object.

Returns Returns all extended attributes.

Note:

This is a thread-safe function.

AddFeature

Adds the key of feature to a specified object.

Parameters

- key -- [in] The Key of feature you want to add the feature to. See GetFeature.
- value -- [in] The value of the feature.

Returns Returns true if the feature is added successfully. Returns false if the feature identified by the key already exists.

Note:

This is a thread-safe function.

GetFeature

CNInferFeature cnstream::CNInferObject::GetFeature(const std::String &key)

Gets an feature by key.

Parameters key -- [in] The key of an feature you want to query. See AddFeature. **Returns** Return the feature of the key. If the feature identified by the key is not exists, CNInferFeature will be empty.

Note:

GetFeatures

CNInferFeatures cnstream::CNInferObject::GetFeatures()

Gets the features of an object.

Returns Returns the features of an object.

Note:

This is a thread-safe function.

3.3.3 Class DataSource

class DataSource: public cnstream::SourceModule, public ModuleCreator<DataSource>
DataSource is a class to handle encoded input data.

Note:

It is always the first module in a pipeline.

API Reference

DataSource

explicit cnstream::DataSource(const std::string &moduleName)

Constructs a DataSource object.

Parameters moduleName -- [in] The name of this module.

Returns No return value.

~DataSource

cnstream::DataSource()

Destructs a DataSource object.

Returns No return value.

Open

virtual bool cnstream::DataSource::Open(ModuleParamSet paramSet) override

Initializes the configuration of the DataSource module.

This function will be called by the pipeline when the pipeline starts.

Parameters paramSet -- [in] The module's parameter set to configure a DataSource module.

Returns Returns true if the parammeter set is supported and valid, othersize returns false.

Close

virtual VOid cnstream::DataSource::Close() override

Frees the resources that the object may have acquired.

This function will be called by the pipeline when the pipeline stops.

Returns No return value.

CheckParamSet

Checks the parameter set for the DataSource module.

Parameters paramSet -- [in] Parameters for this module.

Returns Returns true if all parameters are valid. Otherwise, returns false.

GetSourceParam

inline DataSourceParam cnstream::DataSource::GetSourceParam() const

Gets the parameters of the DataSource module.

Returns Returns the parameters of this module.

Note:

This function should be called after Open function.

3.3.4 Class ESJpegMemHandler

class ESJpegMemHandler:public cnstream::SourceHandler

ESJpegMemHandler is a class of source handler for Jpeg bitstreams in memory.

Variables

impl

ESJpegMemHandlerImpl*cnstream::ESJpegMemHandler::impl_ = nullptr

API Reference

Create

Creates source handler.

Parameters

- module -- [in] The data source module.
- stream_id -- [in] The stream id of the stream.
- max_width -- [in] The maximum width of the image.
- max_height -- [in] The maximum height of the image.

Returns Returns source handler if it is created successfully, otherwise returns nullptr.

~ESJpegMemHandler

```
cnstream::ESJpegMemHandler()
```

The destructor of ESJpegMemHandler.

Returns No return value.

Open

```
virtual bool cnstream::ESJpegMemHandler::Open() override
```

Opens source handler.

Returns Returns true if the source handler is opened successfully, otherwise returns false.

Close

```
virtual VOid cnstream::ESJpegMemHandler::Close() override
```

Closes source handler.

Returns No return value.

Write

```
int cnstream::ESJpegMemHandler::Write(ESPacket *pkt)
```

Sends data in frame mode.

Parameters pkt -- [in] The data packet.

Returns Returns 0 if the data is written successfully. Returns -1 if failed to write data. The possible reason is the handler is closed or the data is nullptr.

3.3.5 Class ESMemHandler

```
class ESMemHandler: public cnstream::SourceHandler
```

ESMemHandler is a class of source handler for H264/H265 bitstreams in memory (with prefix-start-code).

Datatypes Reference

```
enum DataType
enum DataType {
    INVALID = 0,
    H264 = 1,
    H265 = 2,
};
enum cnstream:: ESMemHandler::DataType
    Enumeration variables describing ES data type.
    Values:
    enumerator INVALID
        Invalid data type.
    enumerator H264
        The data type is H264.
    enumerator H265
        The data type is H265.
```

Variables

API Reference

Create

Creates source handler.

Parameters

• module -- [in] The data source module.

- stream_id -- [in] The stream id of the stream.
- maximum_resolution -- **[in]** The maximum video resolution for variable video resolutions. See *MaximumVideoResolution* for detail.

Returns Returns source handler if it is created successfully, otherwise returns nullptr.

~ESMemHandler

```
cnstream::ESMemHandler()
```

The destructor of ESMemHandler.

Returns No return value.

Open

```
virtual bool cnstream::ESMemHandler::Open() override
```

Opens source handler.

Returns Returns true if the source handler is opened successfully, otherwise returns false.

Stop

```
virtual void cnstream::ESMemHandler::Stop() override
```

Stops source handler. The Close() function should be called afterwards.

Returns No return value.

Close

```
virtual VOid cnstream::ESMemHandler::Close() override
```

Closes source handler.

Returns No return value.

SetDataType

```
int cnstream::ESMemHandler::SetDataType(DataType type)
```

Sets data type.

Parameters type -- [in] The data type.

Returns Returns 0 if data type is set successfully, otherwise returns -1.

Note:

This function must be called before Write function.

Write

```
int cnstream::ESMemHandler::Write(ESPacket *pkt)
```

Sends data in frame mode.

Parameters pkt -- [in] The data packet

Returns Returns 0 if the data is written successfully. Returns -1 if failed to write data. The possible reasons are the handler is closed, the end of the stream is received, the data is nullptr and the data is invalid, so that the video infomations can not be parsed from it.

Sends data in chunk mode.

Parameters

- buf -- [in] The data buffer
- len -- [in] The length of the data

Returns Returns 0 if the data is written successfully. Returns -1 if failed to write data. The possible reasons are the handler is closed, the end of the stream is received and the data is invalid, so that the video infomations can not be parsed from it.

WriteEos

```
int cnstream::ESMemHandler::WriteEos()
```

Sends the end of the stream.

The data remains in the parser will be dropped. Call this function, when the data of a stream is not completely written and the stream needed to be removed.

Returns Returns 0 if the end of the stream is written successfully. Returns -1 if failed to write data. The possible reason is the handler is closed.

3.3.6 Class FileHandler

```
class FileHandler: public cnstream::SourceHandler
```

FileHandler is a class of source handler for video with format mp4, flv, matroska and USBCamera ("/dev/videoxxx").

Variables

impl

FileHandlerImpl *cnstream::FileHandler::impl_ = nullptr

API Reference

Create

Creates source handler.

Parameters

- module -- [in] The data source module.
- stream_id -- [in] The stream id of the stream.
- filename -- [in] The filename of the stream.
- framerate -- [in] Controls sending the frames of the stream with specific rate.
- loop -- [in] Loops the stream.
- maximum_resolution -- **[in]** The maximum video resolution for variable video resolutions. See MaximumVideoResolution for detail.

Returns Returns source handler if it is created successfully, otherwise returns nullptr.

~FileHandler

```
cnstream::FileHandler()
```

The destructor of FileHandler.

Returns No return value.

Open

```
virtual bool cnstream::FileHandler::Open() override
```

Opens source handler.

Returns Returns true if the source handler is opened successfully, otherwise returns false.

Stop

```
virtual VOid cnstream::FileHandler::Stop() override
```

Stops source handler. The Close() function should be called afterwards.

Returns No return value.

Close

```
virtual VOid cnstream::FileHandler::Close() override
```

Closes source handler.

Returns No return value

3.3.7 Class RawImgMemHandler

class RawImgMemHandler:public cnstream::SourceHandler

RawImgMemHandler is a class of source handler for raw image data in memory.

Note:

This handler will not send data to MLU decoder as the raw data has been decoded.

Variables

impl

RawImgMemHandlerImpl *cnstream::RawImgMemHandler::impl_ = nullptr

API Reference

Create

Creates source handler.

Parameters

- module -- [in] The data source module.
- stream_id -- [in] The stream id of the stream.

Returns Returns source handler if it is created successfully, otherwise returns nullptr.

~RawImgMemHandler

```
cnstream::RawImgMemHandler()
```

The destructor of RawImgMemHandler.

Returns No return value.

Open

```
virtual bool cnstream::RawImgMemHandler::Open() override
```

Opens source handler.

Returns Returns true if the source handler is opened successfully, otherwise returns false.

Close

```
virtual void cnstream::RawImqMemHandler::Close() override
```

Closes source handler.

Returns No return value.

Write

Sends raw image with cv::Mat. Only BGR data with 8UC3 type is supported, and data is continuous.

Parameters

- mat_data -- [in] The bgr24 format image data.
- pts -- [in] The pts for mat_data, should be different for each image.

Returns Returns 0 if the data is written successfully. Returns -1 if failed to write data. The possible reason is the end of the stream is received or failed to process the data. Returns -2 if the data is invalid.

Note:

Sends nullptr after all data are sent.

Sends raw image with image data and image infomation, support formats: bgr24, rgb24, nv21 and nv12.

Parameters

- data -- [in] The data of the image, which is a continuous buffer.
- size -- [in] The size of the data.
- pts -- [in] The pts for raw image, should be different for each image.
- width -- [in] The width of the image.
- height -- [in] The height of the image.
- pixel_fmt -- [in] The pixel format of the image. These formats are supported, bgr24, rgb24, nv21 and nv12.

Returns Returns 0 if the data is written successfully. Returns -1 if failed to write data. The possible reason is the end of the stream is received or failed to process the data. Returns -2 if the data is invalid.

Note:

Sends nullptr as data and passes 0 as size after all data are sent.

3.3.8 Class RtspHandler

class RtspHandler: public cnstream::SourceHandler
RtspHandler is a class of source handler for rtsp stream.

Variables

impl

RtspHandlerImpl *cnstream::RtspHandler::impl_ = nullptr

API Reference

Create

Creates source handler.

Parameters

- module -- [in] The data source module.
- stream_id -- [in] The stream ID of the stream.
- url_name -- [in] The url of the stream.
- use_ffmpeg -- [in] Uses ffmpeg demuxer if it is true, otherwise uses live555 demuxer.
- reconnect -- [in] It is valid when "use_ffmpeg" set false.
- maximum_resolution -- [in] The maximum video resolution for variable video resolutions. See MaximumVideoResolution for detail.

Returns Returns source handler if it is created successfully, otherwise returns nullptr.

~RtspHandler

```
cnstream::RtspHandler::~RtspHandler()
```

The destructor of RtspHandler.

Returns No return value.

Open

```
virtual bool cnstream::RtspHandler::Open() override
```

Opens source handler.

Returns Returns true if the source handler is opened successfully, otherwise returns false.

Close

```
\verb|virtual VOid cnstream:: RtspHandler:: \texttt{Close()}| override
```

Closes source handler.

Returns No return value.

3.3.9 Class ObjPostproc

class ObjPostproc: public virtual ReflexObjectEx<ObjPostproc>
ObjPostproc is the base class of object post processing.

API Reference

\sim ObjPostproc

```
virtual cnstream::0bjPostproc::~ObjPostproc() = 0
```

Destructs an object.

Returns No return value.

Create

```
static ObjPostproc *cnstream::0bjPostproc::Create(const std::string &proc_name)
```

Creates a postprocess object with the given postprocess's class name.

Parameters proc_name -- [in] The postprocess class name.

Returns The pointer to postprocess object.

Init

Initializes postprocessing parameters.

Parameters params -- [in] The postprocessing parameters. **Returns** Returns ture for success, otherwise returns false.

SetThreshold

```
void cnstream::0bjPostproc::SetThreshold(const float threshold)
```

Sets threshold.

Parameters threshold -- [in] The value between 0 and 1. Returns No return value.

Execute

Executes post processing on neural network outputs.

Parameters

- net_outputs -- [in] Neural network outputs, and the data is stored on the host.
- model -- [in] Model information including input shape and output shape.
- finfo -- [inout] Smart pointer of CNFrameInfo to store processed data.
- pobj -- [in] The deduced object information.

Returns Returns 0 if successful, otherwise returns -1.

Note:

• This function is called by the Inferencer module when the parameter mem_on_mlu_for_postproc is set to false and obj_infer is set to true. See the Inferencer parameter description for details.

Execute post processing on neural network outputs.

Parameters

- net_outputs -- [in] Neural network outputs, and the data is stored on the MLU.
- model -- [in] Model information including input shape and output shape.
- obj_infos -- [inout] The batched frames's result of postprocessing.

Returns Returns 0 if successful, otherwise returns -1.

Note:

• This function is called by the Inferencer module when the parameter mem_on_mlu_for_postproc is set to true and obj_infer is set to true. See the Inferencer parameter description for details.

3.3.10 Class Postproc

class Postproc: public virtual ReflexObjectEx<Postproc>
 Postproc is the base class of post process.

API Reference

~Postproc

```
virtual cnstream::Postproc::~Postproc() = 0
```

Destructs an object.

Returns No return value.

Create

```
static Postproc *cnstream::Postproc::Create(const Std::String &proc_name)
```

Creates a postprocess object with the given postprocess's class name.

Parameters proc_name -- [in] The postprocess class name.

Returns The pointer to postprocess object.

Init

Initializes postprocessing parameters.

Parameters params -- [in] The postprocessing parameters.

Returns Returns ture for success, otherwise returns false.

SetThreshold

```
void cnstream::Postproc::SetThreshold(const float threshold)
```

Sets threshold.

 $\textbf{Parameters} \ \ \texttt{threshold} \ \text{--} \ \textbf{[in]} \ \ \textbf{The value between 0 and 1}.$

Returns No return value.

Execute

Executes postproc on neural network outputs.

Parameters

- net_outputs -- [in] Neural network outputs, and the data is stored on the host.
- model -- [in] Model information including input shape and output shape.
- package -- **[inout]** Smart pointer of *CNFrameInfo* to store processed data.

Returns Returns 0 if successful, otherwise returns -1.

Note:

• This function is called by the Inferencer module when the parameter mem_on_mlu_for_postproc is set to false and obj_infer is set to false. See the Inferencer parameter description for details.

Execute post processing on neural network outputs.

Parameters

- net_outputs -- [in] Neural network outputs, and the data is stored on the MLU.
- model -- [in] Model information including input shape and output shape.
- packages -- [inout] The batched frames's result of postprocessing.

Returns Returns 0 if successful, otherwise returns -1.

Note:

• This function is called by the Inferencer module when the parameter mem_on_mlu_for_postproc is set to true and obj_infer is set to false. See the Inferencer parameter description for details.

3.3.11 Class ObjPreproc

class ObjPreproc: public virtual ReflexObjectEx<ObjPreproc>
ObjPreproc is the base class of preprocess for object.

API Reference

\sim ObjPreproc

```
inline virtual cnstream::ObjPreproc()
```

Destructs an object.

Returns No return value.

Create

```
static ObjPreproc *cnstream:: ObjPreproc::Create(const std::string &proc_name)
```

Creates a preprocess object with the given preprocess's class name.

Parameters proc_name -- [in] The preprocess class name. **Returns** Returns the pointer to preprocess object.

Init

Initializes preprocessing parameters.

Parameters params -- [in] The preprocessing parameters. **Returns** Returns ture for success, otherwise returns false.

Execute

Executes preprocess on neural network inputs.

Parameters

- net_inputs -- [out] Neural network inputs.
- model -- [in] Model information including input shape and output shape.
- finfo -- [in] Smart pointer of CNFrameInfo which stores origin data.
- obj -- [in] The deduced object information.

Returns Returns 0 if successful, otherwise returns -1.

3.3.12 Class Preproc

class Preproc: public virtual ReflexObjectEx<Preproc>

Preproc is the base class of neural network preprocessing for inference module.

API Reference

\sim Preproc

```
inline virtual cnstream::Preproc::~Preproc()
```

Destructs an object.

Returns No return value.

Create

```
static Preproc *cnstream::Preproc::Create(const std::string &proc_name)
```

Creates a preprocess object with the given preprocess's class name.

Parameters proc_name -- [in] The preprocess class name.

Returns Returns the pointer to preprocess object.

Init

Initializes preprocessing parameters.

Parameters params -- [in] The preprocessing parameters.

Returns Returns ture for success, otherwise returns false.

Execute

Executes preprocess on neural network inputs.

Parameters

- net_inputs -- [out] Neural network inputs.
- model -- [in] Model information including input shape and output shape.
- package -- **[in]** Smart pointer of *CNFrameInfo* which stores origin data.

Returns Returns 0 if successful, otherwise returns -1.

3.3.13 Class VideoPostproc

class VideoPostproc: public virtual ReflexObjectEx<VideoPostproc>
 VideoPostproc is the base class of post processing classes for Inference2.

API Reference

\sim Video Postproc

```
virtual cnstream::VideoPostproc::~VideoPostproc() = 0
```

Destructs an object.

Returns No return value.

Create

```
static VideoPostproc *cnstream::VideoPostproc::Create(const std::string &proc_name)
```

Creates a postprocess object with the given postprocess's class name.

Parameters proc_name -- [in] The postprocess class name.

Returns Returns the pointer to postprocess object.

Init

Initializes postprocessing parameters.

Parameters params -- [in] The postprocessing parameters.

Returns Returns ture for success, otherwise returns false.

SetThreshold

void cnstream::VideoPostproc::SetThreshold(const float threshold)

Sets threshold.

Parameters threshold -- [in] The value between 0 and 1. Returns No return value.

Execute

Executes postprocessing on the model's output data.

Parameters

- output_data -- [out] The postprocessing result. The result of postprocessing should be set to it. You could set any type of data to this parameter and get it in UserProcess function.
- model_output -- [in] The neural network origin output data.
- model_info -- **[in]** The model information, such as input/output number and shape.

Returns Returns true if successful, otherwise returns false.

Note:

This function is executed by infer server postproc processor. You could override it to develop custom postprocessing. To set any type of data to output_data, use this statement, e.g., int example_var = 1; output_data->Set(example_var);

3.3.14 Class VideoPreproc

class VideoPreproc: public virtual ReflexObjectEx<VideoPreproc> VideoPreproc is the base class of video preprocessing.

API Reference

~VideoPreproc

```
inline virtual cnstream::VideoPreproc::~VideoPreproc()
```

Destructs an object.

Returns No return value.

Create

```
static VideoPreproc *cnstream::VideoPreproc::Create(const std::string &proc_name)
```

Creates a preprocess object with the given preprocess's class name.

Parameters proc_name -- [in] The preprocess class name.

Returns The pointer to preprocess object.

Init

Initializes preprocessing parameters.

Parameters params -- [in] The preprocessing parameters.

Returns Returns ture for success, otherwise returns false.

${\bf Set Model Input Pixel Format}$

Sets model input pixel format.

Parameters fmt -- [in] The model input pixel format.

Returns No return value.

Execute

Executes preprocessing on the origin data.

Parameters

- model_input -- [out] The input of neural network.
- input_data [in] The raw input data. The user could get infer_server::video::VideoFrame object from it.
- model_info -- [in] The model information, e.g., input/output number, shape and etc.

Returns Returns true if successful, otherwise returns false.

Note:

The input_data holds infer_server::video::VideoFrame object. Use the statement to get video frame: const infer_server::video::VideoFrame& frame = input_data.GetLref<infer_server::video::VideoFrame>();. After preprocessing, you should set the result to model_output. For example, the model only has one input, then you should copy the result to model_input->buffers[0].MutableData() which is a void pointer.



4 API Reference

4.1 Framework Function

4.1.1 GetPathRelativeToTheJSONFile

std::string cnstream::GetPathRelativeToTheJSONFile(const std::string &path,

const ModuleParamSet ¶m_set)

Gets the complete path of a file.

If the path you set is an absolute path, returns the absolute path. If the path you set is a relative path, returns the path that appends the relative path to the specified JSON file path.

Parameters

- path -- [in] The path relative to the JSON file or an absolute path.
- param_set -- [in] The module parameters. The JSON file path is one of the parameters.

Returns Returns the complete path of a file.

4.1.2 GetMaxModuleNumber

uint32_t cnstream::GetMaxModuleNumber()

Gets the number of modules that a pipeline is able to hold.

Returns The maximum modules of a pipeline can own.

4.1.3 GetMaxStreamNumber

uint32_t cnstream::GetMaxStreamNumber()

Gets the number of streams that a pipeline can hold, regardless of the limitation of hardware resources.

Returns Returns the value of MAX_STREAM_NUM.

Note:

The factual stream number that a pipeline can process is always subject to hardware resources, no more than MAX_STREAM_NUM.

4.1.4 VersionString

```
const char *cnstream::VersionString()
```

Gets the CNStream version string.

Returns Returns the version string formatted as "v%major.%minor.%patch". e.g. "v3.5.1".

4.1.5 MajorVersion

const int cnstream::MajorVersion()

Gets the CNStream major version.

Returns Returns the major version, [0, MAXINT].

4.1.6 MinorVersion

const int cnstream::MinorVersion()

Gets the CNStream minor version.

Returns Returns the minor version, [0, MAXINT].

4.1.7 PatchVersion

const int cnstream::PatchVersion()

Gets the CNStream patch version.

Returns Returns the patch version, [0, MAXINT].

4.2 Video Analysis Function

4.2.1 CNGetPlanes

inline int cnstream::CNGetPlanes(CNDataFormat fmt)

Gets image plane number by a specified image format.

Parameters fmt -- [in] The format of the image.

Returns 0 Unsupported image format.

Returns > 0 Image plane number.

4.2.2 GetCNDataFramePtr

This helper will be deprecated in the future versions. Uses Collection::Get<CNDataFramePtr>(kCNDataFrameTag) instead.

4.2.3 GetCNInferObjsPtr

This helper will be deprecated in the future versions. Uses Collection::Get<CNInferObjsPtr>(kCNInferObjsTag) instead.

4.2.4 GetCNInferDataPtr

This helper will be deprecated in the future versions. Uses Collection::Get<CNInferDataPtr>(kCNInferDataTag) instead.



5 Release Notes

This release notes outlines CNStream API updates and documentation updates in CNStream Developer Guide.

5.1 CNStream Release Version 6.1.0

5.1.1 API Updates

This section lists API functions and fields that were added, changed, or removed.

• None.

5.2 CNStream Release Version 6.0.0

5.2.1 API Updates

- Changes on the Frame and FrameVa frameworks are as follows:
 - Removed ICNMediaImageMapper class.
 - Removed CNDataframe::user_data_.
 - Changed CNDataframe::ImageBGR return value from cv::Mat* to cv::Mat.
 - Changed CNDataframe::CopyToSyncMem parameters from (bool) to (void**, bool).
 - Added CNDataframe::collection.
- Changes on framework are as follows:
 - Removed Module::SetParentID.
 - Removed Module::SetParentId.
 - Removed Module::GetModuleMask.
 - Removed Module::SetParentID.
 - Removed Module::SetParentId.
 - Removed Module::GetModuleMask.
 - Removed SpinLock class.

- Added Collection class.
- Removed CnstreamError class.
- Added the contents of the following missing head files:
 - * cnstream_allocator.hpp
 - * cnstream_common.hpp
 - * cnstream_config.hpp
 - * cnstream_source.hpp
 - * cnstream_version.hpp
 - * postproc.hpp
 - * preproc.hpp
 - * video_postproc.hpp
 - * video_preproc.hpp

5.3 CNStream Release 2021-01-25 (Version 5.3.0)

5.3.1 API Updates

- Changes on the Frame and FrameVa frameworks are as follows:
 - Add Parameter CN_FRAME_FLAG_REMOVED to CNFrameFlag enum for identifying the stream to which the frame belongs is removed.
 - Changed the struct CNFrameInfo to a class and privately inherits from class NonCopyable.
 - Added the new payload parameter to the Create API, the default value of which is nullptr.
 - Added the new IsRemoved API for checking whether the stream to which the frame belongs is removed.
 - Changed the struct CNDataFrame to a class and privately inherits from class NonCopyable.
 - Added the new dst_mlu parameter to the CopyToSyncMem API, the default value of which is true.
 - Added the new struct CNInferObjs for holding objects inference result.
 - Added the new struct InferData contains the inputs, the outputs and the information of inference.
 - Added the new struct CNInferData for holding all InferData of one frame.
 - Added the new GetCNDataFramePtr API for getting the CNDataFramePtr object of one frame.
 - Added the new GetCNInferObjsPtr API for getting the CNInferObjsPtr object of one frame.
 - Added the new GetCNInferDataPtr API for getting the CNInferDataPtr object of one frame.
- Changes on the Module framework are as follows:
 - Added the new virtual OnEos API to notify the module that the EOS is arrived.
 - Added the new GetContainer API to get the container of the module.
 - Added the new GetProfiler API to get the profiler of the module.

- Removed the RecordTime API due to the PerfManager has been replaced to Profiler.
- Removed the GetPerfManager API due to the PerfManager has been replaced to Profiler.
- Changes on the Pipeline framework are as follows:
 - Added the new GetName API to get the name of the pipeline.
 - Added the new profiler_config parameter to the BuildPipeline API, the default value of which is a ProfilerConfig Object created by ProfilerConfig constructor.
 - The following APIs are removed due to the PerfManager has been replaced by Profiler:
 - * The CreatePerfManager API.
 - * The RemovePerfManager API.
 - * The AddPerfManager API.
 - * The PerfSqlCommitLoop API.
 - * The CalculatePerfStats API.
 - * The CalculateModulePerfStats API.
 - * The CalculatePipelinePerfStats API.
 - * The GetPerfManagers API.
 - Added the new IsProfilingEnabled API to check if profiling function is enabled.
 - Added the new IsTracingEnabled API to check if tracing function is enabled.
 - Added the new GetProfiler API to get the profiler.
 - Added the new GetTracer API to get the tracer.
 - Added the new IsRootNode API to check if the module is the root node of the pipeline.
 - Added the new IsLeafNode API to check if the module is the leaf node of the pipeline.
- Supported the Profiler with the related APIs.
- Replaced the PerfManager and PerfCalculator by Profiler.
- Changes on the SyncMem are as follows:
 - Removed the CNStreamMallocHost API.
 - Removed the CNSyncedMemory constructor.
 - Set the parameter mlu_ddr_chn with default value -1 of the CNSyncedMemory constructor.
 - Changed the default value of parameter mlu_ddr_chn of the SetMluDevContext API, from 0 to -1.
 - Removed the SetMluCpuData API which is used on MLU220_SOC platform.
- Supported the Inferencer2 module with the related APIs.
- Changes on the DataSource module are as follows:
 - Changes on the RawImgMemHandler class are as follows:
 - * Removed the Write API with one parameter cv::Mat* mat_data.
 - * Removed the Write API with five parameters unsigned char *data, int size, int width = 0, int height = 0, CNDataFormat pixel_fmt = CN_INVALID.
 - * Changed the parameters from cv::Mat* mat_data, uint64_t pts to const cv::Mat* mat_data, const uint64_t pts of the Write API.
 - * Changed the parameters from unsigned char *data, int size, uint64_t pts, int width = 0, int height = 0, CNDataFormat pixel_fmt

- = CN_INVALID to const uint8_t *data, const int size, const uint64_t pts, const int width = 0, const int height = 0, const CNDataFormat pixel_fmt = CN_INVALID of the Write API.
- Removed the UsbHandler class.

5.4 CNStream Release 2020-09-18 (Version 5.2.0)

5.4.1 API Updates

- Changes on the FrameVa are as follows:
 - Added the new HasBGRImage API for checking whether data frame is converted to BGR format and saved to CV format.
 - Added the new RemoveExtraAttribute API for removing an attribute by key.
 - Added the new GetExtraAttributes API for retrieving all extended attributes of an object.
 - Added the new GetFeature API for retrieving the feature of an object by key.
 - Added the new key parameter to the AddFeature API.
 - Renamed the AddExtraAttribute to AddExtraAttributes.
 - Changed the return type of the AddFeature API from void to bool.
 - Changed the return type of the GetFeatures API from ThreadSafeVector<CNInferFeature> to CNInferFeatures.
 - Added the new CNInferFeatures type.
 - Added the new StringPairs type.
 - Changed the struct CNInferFeature to vector<float> type.
 - Changed
 - the type of variable datas in struct CNInferObject from ThreadSafeUnorderedMap<int, any> to std::unordered_map<int, any>.
- Changes on the Frame framework are as follows:
 - Changed the type of variable datas in struct CNFrameInfo from ThreadSafeUnorderedMap<int, any> to std::unordered_map<int, any>.
- Changes on the Pipeline framework are as follows:
 - Added the new GetEndModule API for retrieving the end module of a pipeline.
- Changes on the PerfCalculator are as follows:
 - Added the new total_time variable in struct PerfStats.
- Changes on the PerfManager are as follows:
 - Added the new CreateDir API for creating directory.

5.5 CNStream Release 2020-07-10 (Version 5.0.0)

5.5.1 API Updates

- Changes on the DataSource module are as follows:
 - The following new data types are supported:
 - * Added the new ESPacket struct.
 - * Added the new FileHandler class.
 - * Added the new RtspHandler class.
 - * Added the new ESMemHandler class.
 - Parameter changes in DataSourceParam struct.
 - The following data type and API are removed due to function changes:
 - * The SourceType enum.
 - * The CreateSource API.
- Changes on the EventBus framework are as follows:
 - The cnstream_eventbus.hpp file is moved from the modules/core/include directory to the framework/core/include directory.
 - Added the new Start and Stop APIs to support starting and stopping an event bus thread.
 - Parameter changes in Event struct.
 - Removed the module parameter from the BusWatcher API.
 - Removed the watch_module parameter from the AddBusWatch API.
 - Removed EventType enum due to function changes.
- Changes on the Frame framework are as follows:
 - The cnstream_frame.hpp file is moved from the modules/core/include directory to the framework/core/include directory.
 - Added the new IsEos API to check if this is an eos frame.
 - Added the new SetStreamIndex API to support setting stream index.
 - Parameter changes in CNFrameInfo struct.
 - The following enums, structs, classes, and APIs are moved from the cnstream_frame.hpp file to the cnstream_frame_va.hpp file:
 - * The CNDataFormat enum.
 - * The DevContext struct.
 - * The MemMapType enum.
 - * The CNGetPlanes API.
 - * The IDataDeallocator class.
 - * The ICNMediaImageMapper class.
 - * The CNDataFrame struct.

- * The CNInferBoundingBox struct.
- * The CNInferAttr struct.
- * The CNInferFeature struct.
- * The CNInferObject struct.
- Added the new stream_id parameter to the MmapSharedMem, CopyToSharedMem, and ReleaseSharedMem APIs.
- Parameter changed in CNDataFrame struct.
- Changed CNInferFeature from a type to struct.
- Changed return value type of GetFeatures API.
- Changes on the Module framework are as follows:
 - The cnstream_module.hpp file is moved from the modules/core/include directory to the framework/core/include directory.
 - Added the new IModuleObserver class to support observing modules.
 - Added the new SetObserver, ParseByJSONStr, ParseByJSONFile, and ConfigsFromJsonFile APIs.
 - Removed SetPerfManagers and ClearPerfManagers APIs due to function changes.
 - The following enums, structs, classes, and APIs are moved from the <code>cnstream_module.hpp</code> file to the <code>cnstream_config.hpp</code> file:
 - * The ParamRegister class.
 - * The ParametersChecker class.
 - * The ModuleParamSet struct.
 - * The GetPathRelativeToTheJSONFile API.
 - * The Register API.
 - * The GetParams API.
 - * The IsRegisted API.
 - * The SetModuleDesc API.
- Changes on the Pipeline framework are as follows:
 - The cnstream_pipeline.hpp file is moved from the modules/core/include directory to the framework/core/include directory.
 - Added the new IdxManager class to support managing stream index.
 - Added the new final_print parameter to the CalculateModulePerfStats and CalculatePipelinePerfStats APIs.
 - Parameters are changed in StreamMsg struct.
 - Removed the following APIs due to the function changes:
 - * The Open API.
 - * The Close API.
 - * The Process API.
 - * The GetLinkIds API.
 - * The GetModuleParallelism API.

- * The NotifyStreamMsg API.
- Moved the CNModuleConfig struct from the cnstream_pipeline.hpp file to the cnstream_config.hpp file.
- Changes on the PerfManager are as follows:
 - The perf_manager.hpp file is moved from the modules/core/include directory to the framework/core/include directory.
 - The following new APIs are supported:
 - * Added the new GetSql API to support getting SQL handler.
 - * Added the new GetKeys API to support generating keys.
 - * Added the new GetEndTimeSuffix API to support getting the end time suffix.
 - * Added the new GetStartTimeSuffix API to support getting the start time suffix.
 - * Added the new GetPrimaryKey API to support getting the default primary key.
 - * Added the new GetDefaultType API to support getting the default perf type.
 - Removed the following data types and APIs due to the function changes:
 - * The PerfInfo struct.
 - * The Init API that contains the db_name, module_names, start_node and end_nodes parameters.
 - * The RegisterPerfType API that contains the type parameter.
 - * The CalculatePipelinePerfStats API.
 - * The GetCalculator API.
 - * The SetModuleNames API.
 - * The SetStartNode API.
 - * The SetEndNodes API.
 - * All CreatePerfCalculator APIs.
 - * All CalculatePerfStats APIs.
 - * All CalculateThroughput APIs.
- Changes on the PerfCalculator are as follows:
 - The perf_calculator.hpp file is moved from the modules/core/include directory to the framework/core/include directory.
 - The following new data types, classes, APIs are supported:
 - * The PerfCalculatorForModule, PerfCalculatorForPipeline, and PerfCalculatorForInfer classes, which inherits from PerfCalculator class.
 - * The PerfCalculationMethod class.
 - * The PerfUtils class.
 - * The PrintStreamId API to print stream id.
 - * The PrintStr API to print string.
 - * The PrintTitle API to print title.
 - * The PrintTitleForLatestThroughput API to print title for latest throughput.
 - * The PrintTitleForAverageThroughput API to print title for average throughput.

- * The PrintTitleForTotal API to print 'total'.
- * The SetPerfUtils API to set the PerfUtils for getting data from database.
- * The GetPerfUtils API to get the PerfUtils.
- * The CalcAvgThroughput API to calculate average throughput.
- * The GetAvgThroughput API to get average throughput.
- * The CalculateFinalThroughput API to calculate final throughput.
- * The virtual CalcLatency API to calculate latency.
- * The virtual CalcThroughput API to calculate throughput.
- * The SetPrintThroughput API to set whether print throughput inside perf calculator.
- Added the new width parameter to the PrintLatency API.
- Added the new width parameter to the PrintThroughput API.
- Added the new sql_name and perf_type parameters to the GetLatency API.
- Added the new sql_name and perf_type parameters to the GetThroughput API.
- Parameter changes in PerfStats struct.
- Changed the return type of the GetThroughput API from PerfStats to std::vector<PerfStats>.
- The following APIs are removed due to function changes:
 - * The PrintPerfStats API.
 - * The CalcLatency API.
 - * The CalcThroughputByTotalTime API.
 - * The CalcThroughputByEachFrameTime API.
 - * The SearchFromDatabase API.

5.6 CNStream Release 2020-05-25 (Version 4.5.0)

5.6.1 API Updates

- The following API is supported in the Frame framework:
 - Added the new CopyToSyncMemOnDevice API to synchronize source data to a specified device.
- The following APIs are supported in the Module framework:
 - Added the new ClearPerfManagers API to clear all performance managers.
- Supported the RtspSink module with the related APIs.

5.7 Release 2020-04-16 (Version 4.4.0)

5.7.1 API Updates

This section lists API functions and fields that were added, changed, or removed.

- The following APIs are supported in Frame framework for multi-process function:
 - Added the new MmapSharedMem API to map shared memory.
 - Added the new UnMapSharedMem API to unmap shared memory.
 - Added the new CopyToSharedMem API to copy source-data to shared memory.
 - Added the new ReleaseSharedMem API to release shared memory.
- The following APIs are supported in Module framework for the performance measurement function:
 - Added the new SetPerfManagers API to set PerfManagers.
 - Added the new GetPerfManager API to retrieve PerfManager by stream id.
 - Added the new ClearPerfManagers API to clear PerfManagers.
- The following APIs are supported in Pipeline framework for the performance measurement function:
 - Added the new CreatePerfManager API to create PerfManager for each stream to measure performance of modules and pipeline.
 - Added the new PerfSqlCommitLoop API to commit sqlite events to increase the speed of inserting data to the database.
 - Added the new CalculatePerfStats API to calculate performance of modules and pipeline, and print performance statistics.
 - Added the new CalculateModulePerfStats API to calculate performance of modules, and print performance statistics.
 - Added the new CalculatePipelinePerfStats API to calculate performance of pipeline, and print performance statistics.
 - Removed the PrintPerformanceInformation API due to function changes.

5.7.2 Doc Updates

This section lists the documentation updates that were made in this version:

- Optimized the description of the APIs.
- Added the missing description of APIs and data types.

5.8 Release 2020-02-24

5.8.1 API Updates

This section lists API functions and fields that were added, changed, or removed.

- The following APIs are supported in Frame framework:
 - Supported the new virtual GetMediaImage API.
 - Supported the new virtual GetPitch API.
 - Supported the new virtual GetCpuAddress API.
 - Supported the new virtual GetDevAddress API.
 - Supported the new virtual ~ICNMediaImageMapper API.
 - Parameter changes in DevContext struct.
- The following APIs are supported in SyncMem:
 - Supported the new SetMluCpuData API to set the CPU and MLU data for MLU220SOC only.
 - Supported the new mlu_data and cpu_data parameters to the SetMluCpuData API.

5.9 Release 2019-12-31

5.9.1 API Updates

- The following APIs are supported in Module framework:
 - Supported the new IsRegisted API for checking if a module parameter is registered or not.
 - Supported the new SetModuleDesc API for setting module description.
 - Supported the new GetModuleDesc API for getting module description.
 - Supported the new CheckParamSet API for checking ParamSet in a module.
 - Supported the new GetRegisted API for getting all registered modules name.
 - Supported the new CheckPath API for checking path of a configuration file.
 - Supported the new IsNum API for checking if a parameter is a number.
- The following APIs are supported in Inferencer module:
 - Supported the new CheckParamSet API for checking ParamSet in Inferencer module.
- The following APIs are supported in DataSource module:
 - Supported the new CheckParamSet API for checking ParamSet in DataSource module.
- The following APIs are supported in Tracker module:
 - Supported the new CheckParamSet API for checking ParamSet in Tracker module.