ONNC-CIM An End-to-End Crossbar-Based CIM Simulator

Jen-ho Kuo & Yu-Jie Wang I May 2020 Skymizer Taiwan Inc.





A Joint Work with the Embedded Computing Lab @ CSIE, National Taiwan University

Meng-Yao Lin, Wei-Ting Lin, Tzu-Hsien Yang, I-Ching Tseng, Hsiang-Yun Cheng, Chia-Lin Yang




Outline

- Project overview
- Device Error Model
- How to build and run ONNC-CIM
- How to create a user application in the stand-alone mode
- How to support a new operator in ONNC-CIM




Project Overview



- Support ONNX Operator v1.3.0
- Support full-model simulation
 - CrossBar device model for Conv and Gemm
 - Fastsim (behavior model) for Other operators
- Usages
 - Build as a library in the Standalone mode
 - Build with an ONNC frontend in the ONNC mode
- Extendibility
 - Support adding new operators that use crossbar devices
 - A unified JSON format for device model



CrossBar Unit



CIM simulator

- Compute Unit has several Crossbar Units
- Crossbar Unit has
 - WordLine Driver (DAC)
 - Crossbar Array
 - Bitline Receiver (ADC)

CrossBar Array

The resistor could be configured by vector W with given quantized parameters

WordLine Driver

Repeatedly accepts vector X and quantizes into given length of bits

Bitline Receiver

- For each cycle, wordline driver electrifies maximum
 OUSize of wordlines of bits into crossbar array
- Amplification will be sensed with error model simulation
- Final result is then added and shifted cycle-by-cycle



How to Build and Run ONNC-CIM

- Prerequisite
 - Docker
 - ONNC Community Docker image
- Clone the onnc-cim project from GitHub
 \$ git clone https://github.com/onnc/onnc-cim.git && cd onnc-cim
- Run the container with
 \$ docker run -it -v `pwd`:/onnc/onnc --cap-add=SYS_PTRACE --security-opt seccomp=unconfined onnc/onnc-community:latest



Step to Build onnc-cim in Stand-alone mode

- 1. Create build folder and compile onnc-cim
 - \$ mkdir -p /onnc/onnc-cimHW.build
 - \$ cd /onnc/onnc-cimHW.build
 - \$ cmake -DCMAKE_BUILD_TYPE=Release /onnc/onnc/skysim/onnc-cimHW
 - \$ make -j8
- 2. Install the built library
 - \$ sudo make install
 - \$ sudo Idconfig



Build Options

- DCMAKE_BUILD_TYPE
 - DCMAKE_BUILD_TYPE=Release
 - DCMAKE_BUILD_TYPE=Debug
- DBUILD_TESTS=ON
 - Test cases will be built to a single test_all program in tests folder.
 - ./tests/test_all share/cimConfig.json



Testing onnc-cimHW in stand-alone mode

- You may find a test program, "main", in the example folder
- Run simulation with a device configuration file, "cimConfig.json"
 \$./example/main ./share/cimConfig.json

```
onnc@2cc187bff70a:/onnc/onnc-cimHW.build$ ./example/main ./share/cimConfig.jsonResult:
673.5, 673.5, 673.5, 673.5, 673.5,
```



Step to Build onnc-cim in onnc mode

- 1. build onnc-cim and install the library in the docker container (page 10)
- 2. build onnc with the onnc-cim library

\$ cd /onnc/onnc-umbrella/build-normal

\$ smake -j8 install



Testing onnc-cim in onnc mode

Example to use nn on MNIST

\$ onnc-cim -mquadruple cim /onnc/onnc-cimHW.build/share/nn_mnist/model.onnx --cim-interpreter-input /onnc/onnc-cimHW.build/share/nn_mnist/test_data_set_0/input_2.pb --cim-config /onnc/onnc-cimHW.build/share/cimConfig.json

```
onnc@2cc187bff70a:/onnc/onnc-umbrella/build-normal$ onnc-cim -mquadruple cim /onnc/onnc-cimHW.build/share/nn_mnist/model.onnx --cim-interpreter-input /onnc/onnc-cimHW.build/share/nn_mnist/test_data_set_0/input_2.pb --cim-config /onnc/onnc-cimHW.build/share/cimConfig.json

[v1] weight memory: 23992


[v1] internal memory: 77312

[v1] total inference time: 954253900 ns

[-42.645618, -225.843338, 1401.953369, -45.595074, -79.142662, -206.296021, -237.601776, -79.743721, -108.739471, -234.470078, ]
```



How to write a program for using the stand-alone library






Initialize simulator

/onnc/onnc/skysim/onnc-cimHW/example/main.cc

```
skysim/cimHWSim/example/main.cc 0 → 100644 t
      8 + #include <cimHWOp.hh>
      9 + #include <cimHWSimulator.hh>
      10 + #include <iostream>
      11 + #include <vector>
      12 + using namespace cimHW;
  skysim/cimHWSim/example/main.cc 0 → 100644 1
      33 +
      34 + // initialize simulator
      35 + cimHWSimulator ops;
```



Decompose a model into operators





- 1. Prepare input, output, and activation tensors
- Specify operator attributes
- 3. Call onnc-cimHW runtime API and get output tensors



Prepare input, output, and activation tensors



Prepare input, output, and activation tensors

```
▼ | skysim/cimHWSim/example/main.cc 0 → 100644 | C
      D1 + // Kernet(1X3)
            const std::vector<dim_type> weight_shape {3, 1, 3, 3};
     53 + const_element_type weight[] = {
     54 + 1.5, 1.0, 0.5,
     55 + 1.5, 1.0, 0.5,
     56 + 1.5, 1.0, 0.5,
      57 +
     58 + 1.5, 1.0, 0.5,
      59 + 1.5, 1.0, 0.5,
      60 + 1.5, 1.0, 0.5,
      61 +
      62 + 1.5, 1.0, 0.5,
     63 + 1.5, 1.0, 0.5,
      64 + 1.5, 1.0, 0.5
     65 + };
```



Specify operator attributes



Call onnc-cimHW function and get output

```
skysim/cimHWSim/example/main.cc 0 → 100644 t
            ops.cimHW Conv float(
              reinterpret_cast<void*>(&configFile),
    86 +
                         intput, input_shape.size() , input_shape.data(),
                         weight, weight_shape.size() , weight_shape.data(),
    87 +
    88 +
                         bias , bias_shape.size() , bias_shape.data(),
                         conv1 , conv1_shape.size() , conv1_shape.data(),
             dilations.data(), dilations.size(),
             group,
    93 + kernel.data(), kernel.size(),
    94 + pads.data(), pads.size(),
           strides.data(), strides.size()
    96 + );
```



How to implement a new operator

- 1. Create a new operator class from the template
- 2. Register to desired factory class
- 3. Add the new file to the building system
- 4. Rebuild



- \$ cp lib/op.template.hh lib/matmul.hh
- replace \${OperatorName} => MatMul
- replace \${argument_list}
 - skysim/onnc-cimHW/include/abstractOpFactory.hh
 - 2nd parameter of create\${OperatorName}Op function

```
+ #pragma once
    + #include "hardware/ComputeUnit.hh"
    + #include <cimHWOp.hh>
    + namespace cimHW {
13
      class cimHw${OperatorName}0p : public cimHWOp {
      public:
        cimHW${OperatorName}(p(
17
          const std::string &configFile
         ${argument_list)
18
19
20
       virtual void simulate() final;
22
    + private:
24
       // Use a compute unit
       ComputeUnit
                                   m cimCU;
    + };
28
29 + } // namespace cimHW
      \ No newline at end of file
```

- op.template.hh
 - Add member for computing & output

```
20
        virtual void simulate() final;
22
23
    + private:
                                                                      element_type*
                                                                                           m_output_Y;
24
                                                                      MatrixXfRowMajor
                                                                                           m_matrix_A;
25
      // Use a compute unit
                                                                     MatrixXfRowMajor
                                                                                           m_matrix_B;
26
        ComputeUnit
                                      m_cimCU;
    + };
28
29 + } // namespace cimHW
      \ No newline at end of file
```



\$ cp lib/op.template.cc lib/matmul.cc replace \${OperatorName} + #include "\${OperatorName}.hh replace \${argument_list} + #include "diagnostic/msgHandling.hh" + #include <Eigen/Dense> skysim/onnc-cimHW/include/abstractOpFactory.hh 11 2nd parameter of create\${OperatorName}Op function + namespace cimHW { 13 cimhws{OperatorName}Op::cinHWs{OperatorName}Op ,const_element_type* input_A const std::string &configFile ,const_dim_type input_A_ndim, const_dim_type* input_A_dims \${argument_list} ,const_element_type* input_B ,const_dim_type input_B_ndim, const_dim_type* input_B_dims ,element_type* output_Y : cimHWOr ("\${OperatorName}") ,const_dim_type output_Y_ndim, const_dim_type* output_Y_dims , m_cimCU(configFile) verbose1(opName()); + void cimbws{OperatorName}Op::simulate() // copy back to output //memcpy(m_output_Y, result.data(), sizeof(numType) * ; 28 + }

30 + } // namespace cimHW

op.template.cc

```
8 + #include "${OperatorName}.hh"
 9 + #include "diagnostic/msgHandling.hh"
10 + #include <Eigen/Dense>
11 +
    + namespace cimHW {
13 +
    + cimHW${OperatorName}Op::cimHW${OperatorName}Op(
       const std::string &configFile
          ${argument_list}
           : cimHWOp("${OperatorName}")
       , m cimCU(configFile)
                                                      m_matrix_A = Eigen::Map<const MatrixXfRowMajor>(input_A, input_A_dims[0], input_A_dims[1]);
                                                      m_matrix_B = Eigen::Map<const MatrixXfRowMajor>(input_B, input_B_dims[0], input_B_dims[1]);
21 + verbose1(opName());
24 + void cimHW${OperatorName}Op::simulate()
25 + {
26 + // copy back to output
27 + //memcpy(m_output_Y, result.data(), sizeof(numType) *;
28 + }
29 +
30 + } // namespace cimHW
```



op.template.cc



Register to desired factory class

- skysim/onnc-cimHW/lib/factory/cimHWOpFactory.hh
 - Add declaration
 - replace \${argument_list} skysim/onnc-cimHW/include/abstractOpFactory.hh
 - 2nd parameter of create\${OperatorName}Op function

```
+ // virtual std::unique_ptr<cimHWOp> create ${OperatorName}Op(
+ // void* context
+ // ${argument_list} , const_element_type* input_A
- const_dim_type input_A_ndim, const_dim_type* input_A_dims
- const_dim_type input_B_ndim, const_dim_type* input_B_dims
- const_dim_type output_Y_ndim, const_dim_type* output_Y_dims
```



Register to desired factory class

- skysim/onnc-cimHW/lib/factory/cimHWOpFactory.cc
 - Add include

```
7  + //===
8  + #include "cimHWOpFactory.hh"
9  + #include "../conv.hh"
10  + #include "../gemm.hh"
11  +
12  + namespace cimHW {
13  +
#include "../matmul.hh"
```



Register to desired factory class

- skysim/onnc-cimHW/lib/factory/cimHWOpFactory.cc
 - Add definition
 - replace \${OperatorName
 - replace \${argument_list}
 - remove type in 2nd \${argument_list}

```
77 +
78 + // std::unique_ptr<cimHWOp> cimHWOpFactory::create${OperatorName}
                                         ,const_element_type* input_A
                                           ,const_dim_type input_A_ndim, const_dim_type* input_A_dims
                                           ,const_element_type* input_B
                                           ,const_dim_type input_B_ndim, const_dim_type* input_B_dims
           const std::string* cimCon
                                           ,element_type* output_Y
           return std::make_unique<ci
                                           ,const_dim_type output_Y_ndim, const_dim_type* output_Y_dims
             *cimConfig
             ${argument_list
                                           , input_A, input_A_ndim, input_A_dims
                                          , input_B, input_B_ndim, input_B_dims
                                           , output_Y,output_Y_ndim, output_Y_dims
90 + } // namespace cimHW
```



Adding the new file to building system

Add the matmul.cc to skysim/onnc-cimHW/lib/CMakeLists.txt



Rebuild

- \$ cd /onnc/onnc-cimHW.build
 - \$ make;
 - \$ sudo make install
- Run a test case to verify the implementation
- \$./example/matmul-layer share/cimConfig.json







