Sony ILX-LR1 Remote Control GUI (Python + RemoteCli)

Cyprien GAY - May 2025

Overview

This tool provides a graphical interface (built with Python and Tkinter) to control a **Sony ILX-LR1** camera via the RemoteCli.exe tool included in the official Sony Camera Remote SDK.

The interface allows you to:

- View RemoteCli console output in real time.
- Interact manually or through buttons to send commands.
- Automate actions such as autofocus and interval-based photo capture.
- Avoid manual menu navigation: the script enters/exits the correct submenus automatically.

Requirements

- RemoteCli.exe (included in the official Sony SDK)
- Windows 10 or higher
- Python 3.8 or newer
- Tkinter module (pip install tk)
- A Sony ILX-LR1 camera connected via USB or Ethernet

How It Works

Startup

- 1. The script launches RemoteCli.exe as a subprocess.
- 2. The user selects the camera manually (as prompted by RemoteCli).
- 3. The user enters **Remote Control Mode**.
- 4. After this, the Python interface takes over to control the menus automatically.

Button Functions

- Send Sends any typed command directly to RemoteCli. Pressing Enter also work.
- Focus Enters the "Shutter/Rec Operation Menu" and executes autofocus.
- Focus + Photo Executes both autofocus and photo trigger in sequence.
- Auto Starts/stops automatic photo capture every second.
- Quitter Gracefully shuts down RemoteCli and closes the GUI.

Automatic Navigation

Before executing any photo or focus action, the script automatically:

- 1. Enters the Shutter/Rec Operation Menu by sending 1.
- 2. Sends the corresponding command:
 - $1 \rightarrow \text{Shutter Release}$
 - $2 + y \rightarrow \text{Half-press for autofocus}$
 - $3 + y \rightarrow Half + Full press (focus + photo)$
- 3. Exits the shutter menu with 0.

Installation

- 1. Make sure the Sony ILX-LR1 is powered on and connected via USB.
- 2. On the camera:
 - Go to Setup → USB Connection → PC Remote Function
 - Make sure Authentication Setting = Off
- 3. In the Remote Function menu, select **Pairing** and ensure the PC is properly paired.
- 4. Set the path to RemoteCli.exe in the Python script.
- 5. Launch the GUI:

```
python remotecli_gui.py
```

Common Issues and Fixes

"I don't see the camera"

- Verify the USB cable and camera power.
- On the camera, check:
 - Setup → USB Connection → Authentication Setting is set to Off.

"Connection is refused"

- On the camera, go to PC Remote Function → Pairing
- Perform pairing again and then restart the script.

"Photo doesn't trigger in AF mode"

- Make sure the subject is in clear focus and well-lit.
- Use the **Focus** button before capturing photos.
- Check that the Focus Mode is set to AF-S (Single-shot autofocus).
- Also check that no settings (like shutter speed or drive mode) prevent capture.