# **Audio Controller**

## **Contents**

1	Introduction	1
2	Controller interface	1
	2.1 Port Descriptions	1
	2.2 Interface description	2
3	Controller operation	2
4	Audio data format and analog-digital conversion	3
	4.1 Digital to analog conversion	3
	4.2 Analog to digital conversion	3
5	Audio controller demonstration	1

## **List of Figures**

1	Audio controller (by default, AUDIO_DATA_WIDTH is equal to 32)	1
2	Protocol for sending audio data	2
3	Protocol for receiving audio data	2
4	Digital to analog audio conversion process	3
5	Analog to digital audio conversion process	4

#### 1 Introduction

The audio controller provides a simple interface to the Audio CODEC chip present on the DE2 board. The controller handles the data transmission to and from the chip. The chip configuration is handled by the separate configuration module. The configuration module must be instantiated separately when using the audio controller.

This document will describe the interface and operation of the audio controller and give an overview of the audio data format required to encode the sound waves.

You can download the source code (in Verilog) for the audio controller here.

#### 2 Controller interface

#### 2.1 Port Descriptions




Figure 1: Audio controller (by default, AUDIO\_DATA\_WIDTH is equal to 32)

The audio controller interface is illustrated in Figure 1, with inputs shown on the left, outputs and bidirectional lines on the right. Ports are used as follows:

- CLOCK\_50 system clock input, must be 50MHz for the timing control to work properly.
- reset the active-high reset.
- AUD\_ADCDAT, AUD\_DACDAT, AUD\_BCLK, AUD\_ADCLRCK, AUD\_DACLRCK, I2C\_SDAT, I2C\_SCLK and AUD\_XCK off-chip lines to be connected to the correspondingly named pins, as defined in this file.
- clear\_audio\_in\_memory clear the audio input buffer.
- clear\_audio\_out\_memory clear the audio output buffer.

#### PORTS FOR RECEIVING DATA

• left\_channel\_audio\_in and right\_channel\_audio\_in - Audio data received from the external source.

- read\_audio\_in Read enable signal. The audio input data, if available, will be placed on the data lines on the next clock cycle. This is a level-sensitive signal, which means a new sample of data will be retrieved on every edge, as long as read\_audio\_in is high.
- audio\_in\_available indicates whether the input data is available or not. Reads will have no effect unless this signal is high.

#### PORTS FOR SENDING DATA

- left\_channel\_audio\_out and right\_channel\_audio\_out Audio data for playback.
- write\_audio\_out enable signal for writing the new data. Level-sensitive, data is written on every clock edge when this signal is high.
- audio\_out\_allowed indicates when the data may be written. Write will have no effect unless this signal is high.

#### 2.2 Interface description

The audio controller is capable of a full-duplex audio input and output. The data ports are 32-bit wide by default and are connected to the data buffers. The clear\_audio\_in\_memory and clear\_audio\_out\_memory signals may be used to clear the buffers, and the audio\_in\_available and audio\_out\_allowed signals indicate the availability of the data (in the case of input) or the free space (in the case of output) in the buffers. The data itself is a signed integer representing one audio sample. All the signals are synchronized to the same clock. The interface protocol for sending and receiving data is illustrated in Figure 2 and Figure 3, respectively.




Figure 2: Protocol for sending audio data




Figure 3: Protocol for receiving audio data

## 3 Controller operation

The audio controller consists of two main parts: the input module and the output module. This section will provide a short overview of each.

The audio input and output modules consist of the shift registers connected to the data buffers.

In the case of the audio output, the data received from the user is buffered and then shifted-out to the audio chip at the appropriate rate. The audio chip then feeds this data directly to the DACs.

In the case of the audio input, the process is reversed: the data received from the audio chip is shifted-in and placed in the data buffers. The data comes directly from the ADCs on-board the audio chip.

### 4 Audio data format and analog-digital conversion

The audio controller uses the raw PCM data streams, both for the input and for the output. The PCM data stream is essentially a sequence of numbers representing the intensity of the signal at a given moment. Each of these numbers is called a sample. The sound may be represented (i.e., sampled) by a sequence of the samples. This sequence has a frequency associated with it, which tells the rate at which the original signal was sampled. This sampling rate is necessary for the correct signal reconstruction.

For the audio controller the default sampling rate is 48kHz with a default sample size of 32 bits. Furthermore, there are 2 channels both for the input and for the output. The sampling rate and sample size may be changed at configuration time if necessary. The audio samples are presented as the 2's-complement signed integers.

#### 4.1 Digital to analog conversion

For the audio playback, the PCM data is fed directly to the DACs, which convert the value to a voltage. This analog voltage output is connected to the Line-out jack on the DE2 board which can then drive the headphones or the speakers. This process is illustrated in Figure 4.




Figure 4: Digital to analog audio conversion process

#### 4.2 Analog to digital conversion

For the audio input (or recording), the process is reversed. You can have either the microphone connected to the Mic jack on the DE2 board, or some other device connected to the Line-in jack (but not both at the same time). These jacks are connected to the inputs of the ADCs, which convert the voltage to the digital value. This value is then transmitted to the audio controller. This process is illustrated in Figure 5.




Figure 5: Analog to digital audio conversion process

#### 5 Audio controller demonstration

The sample circuit using the audio controller is available here. You are provided with the full Quartus project and the .sof file already compiled and ready to be programmed.

The purpose of the circuit is very simple. Its main function is to generate a few different frequency signals and play them using the audio controller. The signal frequency is selected with the switches 0 to 3 on the DE2 board. Upon connecting the Line-out output to the speakers, you should be able to hear the sounds with a few different frequencies, depending on how the switches are set. When all four switches are off, there is no sound generated.

The secondary function of the circuit is to superimpose the microphone input on the generated signal. If you connect the microphone to the Mic jack, you should be able to hear the sound from the microphone superimposed on the signal that the circuit is generating.