Underactuated Robots Lecture 5: Legged Robot Models

Nicola Scianca

September 2024


outline

- full dynamic model
- Newton-Euler equations
- centroidal dynamics
- single-rigid-body dynamics
- zero moment point
- linear inverted pendulum



full dynamic model

- we know how to express the dynamics of a manipulator using Lagrangian dynamics
- we can do the same for a legged robot, but we must carefully choose the configuration variables
- the joint configuration is not sufficient! we must also express the position and orientation of the robot in the world



full dynamic model

- the **floating base** is a particular robot link (usually the torso), whose coordinates $(p_0, r_0) \in SE(3)$ represent the absolute position and orientation of the robot
- typically, this is represented as a position vector, and a quaternion for the orientation

$$p_0 = (x_0, y_0, z_0), \quad r_0 = a_0 + b_0 \mathbf{i} + c_0 \mathbf{j} + d_0 \mathbf{k}$$

the floating base linear and angular velocities are

$$\dot{p}_0 = (\dot{x}_0, \dot{y}_0, \dot{z}_0), \quad \omega_0 = (\omega_0^x, \omega_0^y, \omega_0^z)$$

full dynamic model

the full dynamic model can be expressed in the familiar form

$$M(q)\ddot{q} + n(q,\dot{q}) = S\tau + \sum_{i} J_i^T f_i$$

- M(q) is the mass matrix
- ullet $n(q,\dot{q})$ collects the Coriolis/centrifugal and gravity terms
- S maps torques to coordinates. in particular, the lines corresponding to the floating base coordinates are zero because the base is not actuated
- $J_i^T f_i$ is the effect of the *i*-th contact force, i.e., ground reaction force on one foot

partial and simplified models

- the full dynamic model is very complex and nonlinear
- sometimes, it is better to opt for a simpler model, that captures only the essential aspects of the dynamics
- the simplified models can be derived from the full model, but it is much easier to start from scratch, by writing the Newton-Euler equations

Newton-Euler equations

- the Newton-Euler equations describe the dynamics of the robot as a whole, in terms of balance of forces and momenta
- force balance: the sum of all forces is equal to the acceleration of the Center of Mass (CoM) p_c

$$m\ddot{p}_c = mg + \sum_i f_i$$

• moment balance: the sum of the moment of each force is equal to the derivative of the angular momentum L_c


$$\dot{L}_c = (p_c - p_c) \times g + \sum_i (p_i - p_c) \times f_i$$

centroidal dynamics

 the Newton-Euler equations describe the centroidal dynamics of the robot


$$m\ddot{p}_c = mg + \sum_i f_i,$$
 $\dot{L}_c = \sum_i (p_i - p_c) \times f_i$

 they can be seen as the dynamics of a variable inertia ellipsoid around the CoM



single-rigid-body dynamics

- ullet the angular momentum L_c is a complicated object because the internal configuration of a robot is changing
- one way of simplifying the model is to assume that the angular momentum comes from the motion of a rigid body
- the orientation of this rigid body could be mapped to the orientation of the torso, or the entire robot upper body



single-rigid-body dynamics

 velocity of a rigid body: linear velocity of its CoM and angular velocity (expressed in the local frame)

$$\dot{p}_c = (\dot{p}_c^x, \dot{p}_c^y, \dot{p}_c^z), \qquad \omega = (\omega^x, \omega^y, \omega^z),$$


the variation of angular momentum of a rigid body is

$$L_c = I\dot{\omega} + \omega \times (I\omega)$$

then rotational part of the dynamics can be written as

$$I\dot{\omega} + \omega \times (I\omega) = \sum_{i} (p_i - p_c) \times f_i$$

- the zero-moment point (ZMP) is an alternative way of encoding information on the contact forces
- it represents the point of application of the resultant ground reaction force (GRF)
- in statics, we can tell if a body is balanced by checking if the ground projection of the CoM is inside the base of support, in dynamics, we do something similar with the ZMP



ullet by definition, the sum of the moments of contact forces with respect to the ZMP p_z is zero

$$\sum_{i} (p_i - p_z) \times f_i = 0$$

- let's assume that p_z , as well as all contact points p_i , are on flat horizontal ground
- \bullet all the vectors (p_i-p_z) are horizontal, which means that the vector product with horizontal components of f_i are zero

the horizontal components of the above equation are

$$\sum_{i} (p_{i}^{x,y} - p_{z}^{x,y}) \times f_{i}^{z} = 0$$

$$p_{z}^{x,y} \sum_{i} f_{i}^{z} = \sum_{i} p_{i}^{x,y} f_{i}^{z}$$

$$p_{z}^{x,y} = \frac{\sum_{i} p_{i}^{x,y} f_{i}^{z}}{\sum_{i} f_{i}^{z}}$$

this is the position of the ZMP on flat ground

• if we denote the total vertical force as $f_z = \sum_i f_i^z$, we can write the position of the ZMP as

$$\boxed{p_z^{x,y} = \sum_i p_i^{x,y} \frac{f_i^z}{f_z}}$$

this is a weighted sum of the position of the contact points

ullet the coefficients f_i/f_z are positive because forces point up \uparrow

$$\frac{f_i^z}{f_z} \ge 0, \qquad \qquad \sum_i \frac{f_i^z}{f_z} = 1$$

 thus, the ZMP position is a convex combination of the contact points

- because the contact forces are unidirectional (they only point up), the ZMP must be inside the convex hull of the contact surface
- this region is called the support polygon







ZMP dynamics

let's go back to the moment balance equation

$$\dot{L}_c = \sum_i (p_i - p_c) \times f_i$$

add and subtract this term to make the ZMP appear

$$\dot{L}_c = \sum_i (p_i - p_c) \times f_i + \sum_i (p_c - p_z) \times f_i - \sum_i (p_c - p_z) \times f_i$$

$$= \sum_i (p_i - p_z) \times f_i - (p_c - p_z) \times \sum_i f_i$$

 the first term is zero because of the definition of ZMP, in the second term we recover the sum of contact forces

ZMP dynamics

• the sum of contact forces is given by the first of the Newton-Euler equations $m\ddot{p}_c = mg + \sum_i f_i$

$$\dot{L}_c = -m(p_c - p_z) \times (\ddot{p}_c - g)$$

 in particular, we are interested in the x and y components of this equation

$$\begin{split} \dot{L}_c^x &= -m(p_c^y - p_z^y)(\ddot{p}_c^z - g^z) + m(p_c^z - p_z^z)(\ddot{p}_c^y - g^y) \\ \dot{L}_c^y &= m(p_c^x - p_z^x)(\ddot{p}_c^z - g^z) - m(p_c^z - p_z^y)(\ddot{p}_c^x - g^y) \end{split}$$

ZMP dynamics

• the dynamics of the CoM can be expressed in terms of the position of the ZMP (g^z is -g, because it is pointing down)

$$\ddot{p}_{c}^{y} = \frac{\ddot{p}_{c}^{z} + g}{p_{c}^{z}} (p_{c}^{y} - p_{z}^{y}) + \frac{\dot{L}_{c}^{x}}{mp_{c}^{z}}$$
$$\ddot{p}_{c}^{x} = \frac{\ddot{p}_{c}^{z} + g}{p_{c}^{z}} (p_{c}^{x} - p_{z}^{x}) - \frac{\dot{L}_{c}^{y}}{mp_{c}^{z}}$$

this can be written compactly as

$$\ddot{p}_c^y = \frac{\ddot{p}_c^z + g}{p_c^z} (p_c^{x,y} - p_z^{x,y}) + R \frac{\dot{L}_c^{x,y}}{mp_c^z}, \qquad R = \begin{pmatrix} 0 & -1\\ 1 & 0 \end{pmatrix}$$

where R is a $\pi/2$ rotation matrix

linear inverted pendulum

- two simplifying assumptions: CoM height is constant $z_c = h$; internal angular momentum derivative is zero $\dot{L}_c = 0$
- the ZMP-CoM dynamics becomes

$$\ddot{p}_{c}^{x,y} = \frac{\ddot{p}_{c}^{z} + g}{p_{c}^{z}} (p_{c}^{x,y} - p_{z}^{x,y}) + R \frac{\dot{L}_{c}^{x,y}}{mp_{c}^{z}}$$



linear inverted pendulum

the linear inverted pendulum (LIP) dynamics is

$$\vec{p}_c^{x,y} = \eta^2 (p_c^{x,y} - p_z^{x,y}) \qquad \eta = \sqrt{\frac{g}{h}}$$

- significance: the ZMP pushes away the CoM
- it is an unstable dynamics: this makes sense because it represents the essence of the dynamics of balancing