## Formula Sheet Additions

Nidal Boorany

May 1, 2024

## 1 Butterworth Formulae

Transfer Function of a Butterworth Filter:

$$|H(s)| = \frac{G_0}{\sqrt{1 + (\frac{\omega}{\omega_c})^{2N}}}$$

Order Calculation from Pass and Stop Band Values:

$$N = \log \frac{10^{-\frac{G_s}{10} - 1}}{10^{-\frac{G_p}{10} - 1}} \div 2\log \frac{\omega_s}{\omega_p}$$

## 2 Chebyshev Formulae

Gain of the Transfer Function:

$$|H(\omega)| = \frac{G_0 k_0}{(1 + \epsilon^2 T_N^2(\frac{\omega}{\omega_c}))^{\frac{1}{2}}}$$

Order of Chebyshev Calculation:

$$N = \frac{1}{\cosh^{-1}(\omega_s/\omega_p)} \cosh^{-1} \left[ \frac{10^{-\hat{G}_s/10} - 1}{10^{-\hat{r}/10} - 1} \right]^{1/2}$$

$$\epsilon_{dB} = r = \sqrt{1 + \epsilon^2}$$

Gain Correction Factor:

$$k_N = \begin{cases} a_0 & Nodd \\ \frac{a_0}{\sqrt{1+\epsilon^2}} = \frac{a_0}{10^{\frac{\hat{r}}{20}}} & Neven \end{cases}$$

## 3 Low Pass Filters to Other Forms

Low Pass to Band Pass Filter:

$$s \to \omega_c \times \frac{s^2 + \omega_H \omega_L}{s \times (\omega_H - \omega_L)}$$

Low Pass to Low Pass Filter:

$$s \to \omega_c \times \frac{s^2 + \omega_H \omega_L}{s \times (\omega_H - \omega_L)}$$