

EnOcean Equipment Profiles

REVISION HISTORY

Ver.	Editor	Change	Date
2.6.8	NM	Last xml edition of the EEP-Specification	Dec 31, 2017

Copyright © EnOcean Alliance Inc. (2019). All rights reserved.

The information within this document is the property of the EnOcean Alliance and its use and disclosure are restricted. Elements of the EnOcean Alliance specifications may also be subject to third party intellectual property rights, including without limitation, patent, copyright or trademark rights (such a third party may or may not be a member of the EnOcean Alliance.)

The EnOcean Alliance is not responsible and shall not be held responsible in any manner for identifying or failing to identify any or all such third party intellectual property rights. This document and the information contained herein are provided on an "as is" basis and the EnOcean Alliance disclaims all warranties express or implied, including but not limited to

- (1) any warranty that the use of the information herein will not infringe any rights of third parties (including any intellectual property rights, patent, copyright or trademark rights, or
- (2) any implied warranties of merchantability, fitness for a particular purpose, title or non-infringement.

In no event will the EnOcean Alliance be liable for any loss of profits, loss of business, loss of use of data, interruption of business, or for any other direct, indirect, special or exemplary, incidental, punitive or consequential damages of any kind, in contract or in tort, in connection with this document or the information contained herein, even if advised of the possibility of such loss or damage. All Company, brand and product names may be trademarks that are the sole property of their respective owners.

The above notice and this paragraph must be included on all copies of this document that are made.

The EnOcean Alliance "EnOcean Equipment Profiles definitions" are available free of charge to companies, individuals and institutions for all non-commercial purposes (including educational research, technical evaluation and development of non-commercial tools or documentation.)

This specification includes intellectual property ("IPR") of the EnOcean Alliance and joint intellectual properties ("joint IPR") with contributing member companies. No part of this

EnOcean Equipment Profiles Page 1/9

enocean°alliance No Wires. No Batteries. No Limits.

System Specification

specification may be used in development of a product or service for sale without being a participant or promoter member of the EnOcean Alliance and/or joint owner of the appropriate joint IPR.

These errata may not have been subjected to an Intellectual Property review, and as such, may contain undeclared Necessary Claims.

EnOcean Alliance Inc. 2400 Camino Ramon, Suite 375 San Ramon, CA 94583 USA Graham Martin Chairman & CEO EnOcean Alliance

EnOcean Equipment Profiles

enocean alliance No Wires, No Batteries, No Limits,

System Specification

D2-31: Automated Meter Reading Gateway

The automated meter reading gateway is a device that connects to various counters such as heating, water, gas or electrical energy meters. The meters may be connected to the gateway by one or several of these interface types: M-Bus, D0, S0 (see appendix). The gateway reports the continuous energy or flow volume meter reading of each of the connected metering devices. Typically the measured variables consist of a momentary value and an accumulated value. The transmission of separated consumption import and export values is supported, too.

Data exchange

Direction: bidirectional

Addressing: ADT inbound, broadcast outbound Communication trigger: event- & time-triggered

Communication interval: minimum 1-1000 s (configuration item), maximum 1000 s

Trigger event: heartbeat 1000 s, value change in "Status/Error", "Meter Reading" while respecting the minimum

reporting interval

Tx delay: 500 ms (maximum response time, first telegram)
Rx timeout: 0 ms (minimum time between two received messages)

Teach-in method: Universal teach-in (outbound)

Encryption required: no Security level format: 0

Telegram Definition

The telegram definition is inherited from profile D2-30-xx and thus identical to the definition there.

EEP Family Table

Supported function	Type 0x00	Type 0x01
Number of supported MBUS meters	10	16
Number of supported S0 meters	2	0
Number of supported D0 meters	2	0

Description of the meter interfaces

S0-Interface:

The S0-Interface is a two-wire connection designed for the transmission of monotonously rising measurement data. The standard is defined in EN 62053-31. The meter device transmits a fixed number of pulses per physical meter unit. The number of pulses per unit is defined by the meter manufacturer and depends on the necessary precision of the meter system. The pulses are output as currency variations, where a value lower than 3 mA corresponds to a logical 0. The sender output is mostly realized by a transistor or an opto-coupler, which needs to be supplied by a voltage of 27-30 V. Polarity must be respected.

D0-Interface:

The D0-interface is an optical metering interface defined in EN62056-61. It allows the unidirectional readout of metering data at a rate of 9600 Baud, using telegrams with start bit, 7 data bits, parity and a stop bit. One of the protocols SML (Smart Message Language) or DLMS (Device Language Message Specification, EN62056-21) can be used for coding the data. A D0-Meter can deliver consumption data as well as various system data. The source and type of a data point is indicated by the standardized OBIS-codes.

MBUS-Interface:

The M-Bus (Meter-Bus) is a bidirectional field bus for the communication with consumption meters. It is described in standard EN13757. Typically there can be connected up to 250 devices in one M-Bus network. There is a common master in the network, who periodically collects the meter data from its slaves. The network may be implemented either as two-wire cable network allowing remote powering of the slaves or as wireless network. The protocol operates at 300 to 9600 Baud and codes the data bytes with start bit, 8 data bits, parity and a stop bit. The data records sent by a metering slave deliver in their header field the coding information of the following data field (value size, measurement medium, unit, multiplier). The master can address a single slave by its primary address (1...250), which must be assigned during network configuration, or by its secondary address, which is a unique device identification number assigned by the device manufacturer.

References:

M-Bus documentation: www.m-bus.com

SML specification: www.vde.com/de/fnn/arbeitsqebiete/messwesen/Sym2/Seiten/default.aspx

DLMS User Association: www.dlms.com

EnOcean Equipment Profiles Page 3/9



RORG	D2	VLD Telegram
FUNC	31	Automated Meter Reading Gateway
TYPE	01	Type 0x01 (description: see table)

Submitter: MSR-Solutions

CMD 0x6 - Set meter configuration / MBUS (BUS = 1)

This message is sent to a metering device gateway to configure the meter settings for one channel.

Sender: controller; send type: broadcast or addressed.

Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit
0	4	Report	RM	Minimum auto reporting interval	Enum:		•
		measurement			0: No auto re	porting	_
					1: Min. 1 s interval		
					2: Min. 3 s in	terval	
					3: Min. 10 s i	nterval	
					4: Min. 30 s i	nterval	_
					5: Min. 100 s	interval	_
					6: Min. 300 s	interval	_
					7: Min. 1000	s interval	_
					815: Reserved		
4	4	Command ID	CMD	Command identifier	Enum:		
					0x06: ID 06		
8	1	Not Used (= 0)					
9	2	Meter bus type	BUS	The meter bus that should be	Enum:		
				configured	0: Reserved		
					1: MBUS		
					2: S0		
					3: D0		
11	5	Meter channel index	MCH	The meter number of given bus that should be configured	030	030	1
16	2	Not Used (= 0)					
18	3	Meter 1 units	UNIT1	Physical units of first measured	Enum:		
				quantity (imported value)	0: No reading (unconfigured	l)
					1: Current value value kWh	W, accumu	lated
					2: Current value value Wh	e W, accumu	lated
					3: Accumulated	value kWh	only
					4: Current value accumulated		
					5: Current value accumulated		
					6: Accumulated		nly
					7: Digital count	er	

EnOcean Equipment Profiles Page 4/9



21	3	Meter 2 units	UNIT2	Physical units of second measured quantity (exported value)	Enum: 0: No reading (unconfigured)
					Current value W, accumulated value kWh
					2: Current value W, accumulated value Wh
					3: Accumulated value kWh only
					4: Current value m3/h, accumulated value m3
					5: Current value dm3/h, accumulated value dm3
					6: Accumulated value m3 only
					7: Digital counter
24	8	Primary Address	ADDR	The primary MBUS address of the meter	1250 1250 1
32	40	Not Used (= 0)			

CMD 0x6 - Set meter configuration / S0 (BUS = 2)

Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit
0	4	Report	RM	Minimum auto reporting interval	Enum:		
		measurement			0: No auto repo	orting	
					1: Min. 1 s inter	rval	
					2: Min. 3 s inter	rval	
					3: Min. 10 s int	erval	
					4: Min. 30 s int	erval	
					5: Min. 100 s in	iterval	
					6: Min. 300 s in	iterval	
					7: Min. 1000 s	interval	
					815: Reserved		
4	4	Command ID	CMD	Command identifier	Enum:		
					0x06: ID 06		
8	1	Not Used (= 0)					
9	2	Meter bus type	BUS	The meter bus that should be	Enum:		
				configured	0: Reserved		
					1: MBUS		
					2: S0		
					3: D0		
11	5	Meter channel index	MCH	The meter number of given bus that should be configured	030	030	1
16	2	Not Used (= 0)					

EnOcean Equipment Profiles Page 5/9



18	3	Meter 1 units	UNIT1	Physical units of first measured	Enum:
				quantity (imported value)	0: No reading (unconfigured)
				(mps) ted value)	Current value W, accumulated value kWh
					2: Current value W, accumulated value Wh
					3: Accumulated value kWh only
					4: Current value m3/h, accumulated value m3
					5: Current value dm3/h, accumulated value dm3
					6: Accumulated value m3 only
					7: Digital counter
21	3	Meter 2 units	UNIT2	Physical units of second	Enum:
				measured quantity (exported value)	0: No reading (unconfigured)
					Current value W, accumulated value kWh
					2: Current value W, accumulated value Wh
					3: Accumulated value kWh only
					4: Current value m3/h, accumulated value m3
					5: Current value dm3/h, accumulated value dm3
					6: Accumulated value m3 only
					7: Digital counter
24	2	Factor of number of	FACP	The factor for the number of	Enum:
		pulses		pulses per value in UNIT1	0: 1
					1: 0.1
					2: 0.01 3: 0.001
26	14	Number of pulses	NOP	The number of pulses per value	5. 0.001 Enum:
_0		Transcr or pulses		in UNIT1* FACP	0: Do not change the current setting of NOP
					Number of pulses per unit 116383: (EEP 2.6.5: 1 16383 ± 65535)
40	32	Preset value	RST	Preset the accumulated value to	Enum:
				this value	New preset value 04294967294:
					0xFFFFFFFF: Do not change the current value

EnOcean Equipment Profiles Page 6/9



CMD 0x6 - Set meter configuration / D0 (BUS = 3)

A	Offset	Size	Data	ShortCut	Description	Valid Range Scale	Unit
1				RM	-		
2: Min. 3 s interval 3: Min. 10 s interval 4: Min. 30 s interval 4: Min. 30 s interval 5: Min. 100 s interval 6: Min. 30 s interval 8: Min. 10 s interval 7: Min. 100 s interval 8: Min. 10 s interval 8: Min. 10 s interval 8: Min. 10 s interval 8: Min. 100 s interval 8: Min. 100 s interval 7: Min. 1000 s interval 8: Min. 100 s interval 8: Min. 10 s interval 9: Min. 10 s inter			measurement			0: No auto reporting	
Second S						1: Min. 1 s interval	
4						2: Min. 3 s interval	
Second S							
Command ID							
A							
4							
Not Used (= 0) Not Used (= 0)			C	CMD	C		
1	4	4	Command ID	CMD	Command identifier		
9 2 Meter bus type Proofigured The meter bus that should be configured Proofigured Proofi	0	1	Not Hood (- 0)			0x06:1D 06	
Configured Con				DITE	The motor bus that should be	Faum	
The meter number of given bus that should be configured 1	9	2	Meter bus type	505			
11 5 Meter channel index MCH The meter number of given bus that should be configured 030 1					- Connigured		
The meter number of given bus index Not Used (= 0) 1 1 2 Not Used (= 10 Index of the should be configured 1 1 1 1 1 1 1 1 1							
11 5 Meter channel index MCH intex that should be configured 030 030 1							
Index	11	5	Meter channel	мсн	The meter number of given hus		1
16 2 Not Used (= 0)	11	,		ricii		050	
quantity (imported value) 1: Current value W, accumulated value kWh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h, accumulated value m3 5: Current value dm3/h, accumulated value dm3 6: Accumulated value m3 6: Accumulated value m3 only 7: Digital counter 21 3 Meter 2 units UNIT2 Physical units of second measured quantity (exported value) 1: Current value w, accumulated value wh 2: Current value W, accumulated value kWh 2: Current value W, accumulated value Wh 3: Accumulated value Wh only 4: Current value kWh only 4: Current value w, accumulated value whonly 4: Current value would who only 4: Current value m3/h,	16	2	Not Used (= 0)		, 3		
Current value W, accumulated value kWh	18	3		UNIT1	Physical units of first measured	Enum:	
1: Current value W, accumulated value kWh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h, accumulated value m3 5: Current value dm3/h, accumulated value dm3 6: Accumulated value m3 only 7: Digital counter 21 3 Meter 2 units UNIT2 Physical units of second measured quantity (exported value) Physical units of second measured quantity (exported value) 1: Current value W, accumulated value kWh 2: Current value W, accumulated value kWh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h,						0: No reading (unconfigured)	
Value kWh 2: Current value W, accumulated value Wh only 4: Current value m3/h, accumulated value m3 5: Current value dm3/h, accumulated value dm3 6: Accumulated value m3 only 7: Digital counter 21 Amount of the provided value value who now the provided value value who now the provided value who now th					(imported value)		
Value Wh 3: Accumulated value kWh only 4: Current value m3/h, accumulated value m3 5: Current value dm3/h, accumulated value dm3 6: Accumulated value dm3 6: Accumulated value m3 only 7: Digital counter							ed
3: Accumulated value kWh only 4: Current value m3/h, accumulated value m3 5: Current value dm3/h, accumulated value dm3 6: Accumulated value m3 only 7: Digital counter 21 3 Meter 2 units UNIT2 Physical units of second measured quantity (exported value) Enum: 0: No reading (unconfigured) 1: Current value W, accumulated value kWh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h,							ed
accumulated value m3 5: Current value dm3/h, accumulated value m3 6: Accumulated value m3 only 7: Digital counter 21							у
accumulated value m3 5: Current value dm3/h, accumulated value m3 6: Accumulated value m3 only 7: Digital counter 21						4: Current value m3/h.	
accumulated value dm3 6: Accumulated value m3 only 7: Digital counter 21							
6: Accumulated value m3 only 7: Digital counter 21 3 Meter 2 units UNIT2 Physical units of second measured quantity (exported value) 1: Current value W, accumulated value Wh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h,							
21 3 Meter 2 units UNIT2 Physical units of second measured quantity (exported value) 21 1: Current value W, accumulated value Wh 22 2: Current value W, accumulated value Wh 33 3: Accumulated value kWh only 44 4: Current value m3/h,							
21 3 Meter 2 units UNIT2 Physical units of second measured quantity (exported value) 1: Current value W, accumulated value Wh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h,						6: Accumulated value m3 only	
quantity (exported value) 1: Current value W, accumulated value kWh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h,						7: Digital counter	
(exported value) 1: Current value W, accumulated value kWh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h,	21	3	Meter 2 units	UNIT2	Physical units of second measured	Enum:	
value kWh 2: Current value W, accumulated value Wh 3: Accumulated value kWh only 4: Current value m3/h,						0: No reading (unconfigured)	
value Wh 3: Accumulated value kWh only 4: Current value m3/h,							ed
3: Accumulated value kWh only 4: Current value m3/h,						2: Current value W, accumulate	ed
							у
						4: Current value m3/h,	

EnOcean Equipment Profiles Page 7/9



					5: Current value dm3/h, accumulated value dm3 6: Accumulated value m3 only 7: Digital counter
24	8	D0 Protocol	PROT	The D0 protocol that should be used for that meter	Enum: 0: Auto detect 1: SML (Smart Message Language)
					2: DLMS (Device Language Message Specification) Reserved 3255:
32	40	Not Used (= 0)			

CMD 0x7 - Meter Status Query

This message is sent to a metering device gateway to query the status of a meter. Sender: controller; send type: broadcast or addressed; expected response: CMD 0x8.

Offset	Size	Data	ShortCut	Description	Valid Range Scale Unit		
0	4	Not Used (= 0)					
4	4	Command ID	CMD	Command identifier	Enum:		
					0x07: ID 07		
8	1	Not Used (= 0)					
9	2	Meter bus type	BUS	The meter bus type that is queried	Enum:		
					0: Reserved		
					1: MBUS		
					2: S0		
					3: D0		
11		Meter channel		The meter channel of given bus that status is	Enum:		
		index		queried	Meter channel		
					030:		
					31: All valid		
					channels		

EnOcean Equipment Profiles Page 8/9



CMD 0x8 - Meter reading report / status response

This message is sent by a metering device gateway to report the meter values for each configured channel. It is sent if one of the following events occurs:

- Message 'meter status query' has been received (CMD 0x7)
- Status or meter reading of one channel has changed and auto reporting was configured by signal RM.

Sender: sensor; send type: broadcast; maximum send delay 1 s.

Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit
0	1	Not Used (= 0))			•	
1	3	Meter status / error	MSTAT	Meter channel status	Enum: 0: No fault 1: General error 2: Bus unconfigured 3: Bus unconnected		
					6: Unknowi	tcut inication timeout in protocol or ation mismatch alization running	_
4	4	Command ID	CMD	Command identifier	Enum: 0x08: ID 08	_	
8	1	Not Used (= 0))		5A00112 00		
9	2	Meter bus type	BUS	The used bus of the meter status response	Enum: 0: Reserver 1: MBUS 2: S0 3: D0	<u>d</u>	
11	5	Meter channel index	МСН	The meter number of given bus that status is reported	030	030	1
16	3	Not Used (= 0))				•
19	2	Value selection	VSEL	The selection of the reported value	1: Meter 1 2: Meter 2	Current value Accumulated val Current value Accumulated val	
21	3	Value unit	VUNIT	The unit of the reported value	Enum: 0: W 1: Wh 2: kWh 3: m3/h 4: dm3/h 5: m3 6: dm3 7: 1 (digital	l counter)	
24	32	Meter reading value	VAL	The reported value	0429496729	04294967295	According to VUNIT

EnOcean Equipment Profiles Page 9/9