

## **EnOcean Equipment Profiles**

#### **REVISION HISTORY**

Ver.	Editor	Change	Date
2.6.8	NM	Last xml edition of the EEP-Specification	Dec 31, 2017

Copyright © EnOcean Alliance Inc. (2019). All rights reserved.

The information within this document is the property of the EnOcean Alliance and its use and disclosure are restricted. Elements of the EnOcean Alliance specifications may also be subject to third party intellectual property rights, including without limitation, patent, copyright or trademark rights (such a third party may or may not be a member of the EnOcean Alliance.)

The EnOcean Alliance is not responsible and shall not be held responsible in any manner for identifying or failing to identify any or all such third party intellectual property rights. This document and the information contained herein are provided on an "as is" basis and the EnOcean Alliance disclaims all warranties express or implied, including but not limited to

- (1) any warranty that the use of the information herein will not infringe any rights of third parties (including any intellectual property rights, patent, copyright or trademark rights, or
- (2) any implied warranties of merchantability, fitness for a particular purpose, title or non-infringement.

In no event will the EnOcean Alliance be liable for any loss of profits, loss of business, loss of use of data, interruption of business, or for any other direct, indirect, special or exemplary, incidental, punitive or consequential damages of any kind, in contract or in tort, in connection with this document or the information contained herein, even if advised of the possibility of such loss or damage. All Company, brand and product names may be trademarks that are the sole property of their respective owners.

The above notice and this paragraph must be included on all copies of this document that are made.

The EnOcean Alliance "EnOcean Equipment Profiles definitions" are available free of charge to companies, individuals and institutions for all non-commercial purposes (including educational research, technical evaluation and development of non-commercial tools or documentation.)

This specification includes intellectual property ("IPR") of the EnOcean Alliance and joint intellectual properties ("joint IPR") with contributing member companies. No part of this

EnOcean Equipment Profiles Page 1/6

# enocean°alliance No Wires. No Batteries. No Limits.

# **System Specification**

specification may be used in development of a product or service for sale without being a participant or promoter member of the EnOcean Alliance and/or joint owner of the appropriate joint IPR.

These errata may not have been subjected to an Intellectual Property review, and as such, may contain undeclared Necessary Claims.

EnOcean Alliance Inc. 2400 Camino Ramon, Suite 375 San Ramon, CA 94583 USA Graham Martin Chairman & CEO EnOcean Alliance

**EnOcean Equipment Profiles** 



## D2-34: Heating Actuator

#### Submitter: AWAG Elektrotechnik AG

#### Description

The profile is used to monitor and control a simple heating actuator. The actuator compares the current room temperature with a target temperature (set point) and accordingly switches on and off the heating.

The set point is either taken from a room operating panel (see A5-10-xx profiles) or can be configured by a radio command. A specific set point can be set as well as a relative shift to the panel value. The override can be temporary or permanent.

#### Data exchange

#### 1. Status update on heartbeat or opmode change:

Direction: unidirectional Addressing: broadcast

Communication trigger: heartbeat or operation mode change Communication interval: heartbeat configurable: off / 30 sec / 3 min

Trigger event: opmode change or heartbeat

Tx delay: n/a Rx timeout: n/a

# 2. Status response and set point response are replies to the corresponding requests. A request for all channels results in a separate reply for each channel:

Direction: bidirectional Addressing: unicast (ADT) Communication trigger: request Communication interval: n/a

Trigger event: n/a Tx delay: 500 ms Rx timeout: 500 ms

# 3. Set point configuration is a unconfirmed request (per channel). Success can be determined by a set point query:

Direction: unidirectional Addressing: unicast (ADT) Communication trigger: request Communication interval: n/a

Trigger event: n/a Tx delay: n/a Rx timeout: n/a

#### Teach-in

Teach-in method: Universal teach-in (UTE)

#### Security

Encryption supported: no Security level format: -

#### VLD Family Table:

Each TYPE has to support every command / parameter that is marked in its column!

Supported command	Type 00	Type 01	Type 02
No. of output channels	1	2	8
Status broadcast	X	Х	Х
Query/Reply status	X	Χ	Χ
Configure set point	X	X	Х
Query/Reply set point	Χ	X	X

EnOcean Equipment Profiles Page 3/6



Supported parameter	Type 00	Type 01	Type 02
Current room temperature	X	Χ	Χ
Currently active set point	X	Х	X
Panel set point	X	Χ	Χ
Operation mode	X	X	X
Set point configuration	X	X	Χ
Set point override value	Х	Х	Х
Set point shift value	X	Х	X
Set point override duration	X	Х	Х

The list of parameters could be structured following the features that always include a certain group of parameters.

#### Appendix:


Depending on the value of CFG, the set point is evaluated differently:

- 0: Current set point = room panel value
- ... SHF, OVR and DUR are ignored
- 1: Current set point = OVR
- ... SHF is ignored, fallback to room panel value after DUR
- 2: Current set point = room panel value + SHF
- ... OVR is ignored, fallback to room panel value after DUR
- 3: Current set point = room panel value SHF
- ... OVR is ignored, fallback to room panel value after DUR

RORG	D2	VLD Telegram
FUNC	34	Heating Actuator
TYPE	02	8 Output Channels

Submitter: AWAG Elektrotechnik AG

## CMD 0x3 - Actuator Status Query




Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit
0	5	Channel	CHN	Channel address	Enum:		
					0x000x1D:  0x1E: All channels suppodevice	orted by the	130 CHN
					0x1F: Not used		
5	7	Not Used (=	0)				
12	4			Command	Enum:	_	
		ID		identifier	3: Status query command		

EnOcean Equipment Profiles Page 4/6




## CMD 0x4 - Actuator Status Response



Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit
0	9	Temperature	TMP	Current room	Enum:		
		temperature		temperature	0400:	°C	
					0	+40	
					0x1FF: Unknown		
9	9	Set point	SP	Currently active set point	0400	0+40	°C
18		Operation	OPM	Current mode valid for	Enum:		
		Mode		the channel	0x0: Off (deactiv	ated)	
					0x1: Temperature	unknown	
					0x2: No heating		
					0x3: Heating req	uired	
					0x40xF: Not used		
22	5	Channel	CHN	Channel address	Enum:		
					0x000x1D:		130 CHN
					0x1E: All channe the device	els supported by	
					0x1F: Not used		
27	1	Not Used (= 0	)				
28	4	Command ID	CMD	Command identifier	Enum:		
					4: Status response of	ommand	

## CMD 0x5 - Actuator Set Point Configuration




Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit	
0	2	Configuration	CFG	How set point is evaluated Enum:				
				(see appendix)	0: Room panel value			
					1: Override with OVR		_	
					2: Add SHF to panel	value		
					3: Subtract SHF from	panel value		
2	6	Duration	DUR	Duration of the override until	Enum:			
				fallback to room panel value	0: Endless			
					163:	h		
					163			
8	7	Set point	SHF	Set point shift value	0100	010	K	
15	9	Set point	OVR	Set point override value	0400	0+40	°C	
24	5	Channel	CHN	Channel address	Enum:			
					0x000x1D: 1		.30 CHN	
					0x1E: All channel supported device	_		
					0x1F: Not used			
29	7	Not Used (=	0)		OATI. Not used			
36	4	Command ID	CMD	Command identifier	Enum:			
					5: Set point configura	ation comman	1	

EnOcean Equipment Profiles Page 5/6



#### CMD 0x6 - Actuator Set Point Query



Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit	
0	5	Channel	CHN	Channel address	Enum:			
					0x000x1D:  0x1E: All channels support	ed by the	130 CHN	
					device			
					0x1F: Not used			
5	7	Not Used (= 0)						
12	4				Enum:	_		
		ID		identifier	6: Set point query command			

## CMD 0x7 - Actuator Set Point Response



Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit
0	2	Configuration	CFG	How set point is evaluated	Enum:		
				(see appendix)	0: Room panel value		
					1: Override with OVF	₹	
					2: Add SHF to panel	value	
					3: Subtract SHF fron	n panel value	:
2	6	Duration	DUR	Remaining override time until	Enum:		
				fallback to room panel value	0: Expired (CFG =	0)	
					163:	ı	า
						163	
8	9	Set point	PNL	Set point provided by room panel	0400	0+40	°C
17	7	Set point	SHF	Set point shift value	0100	010	K
24	9	Set point	OVR	Set point override value	0400	0+40	°C
33	5	Channel	CHN	Channel address	Enum:		
					0x000x1D:	:	130 CHN
					0x1E: All channe supported device		
					0x1F: Not used		
38	6	Not Used (=	0)				
44	4	Command ID	CMD	Command identifier	Enum:		
					7: Set point respons	e command	

EnOcean Equipment Profiles Page 6/6