

EnOcean Equipment Profiles

REVISION HISTORY

Ver.	Editor	Change	Date
2.6.8	NM	Last xml edition of the EEP-Specification	Dec 31, 2017

Copyright © EnOcean Alliance Inc. (2019). All rights reserved.

The information within this document is the property of the EnOcean Alliance and its use and disclosure are restricted. Elements of the EnOcean Alliance specifications may also be subject to third party intellectual property rights, including without limitation, patent, copyright or trademark rights (such a third party may or may not be a member of the EnOcean Alliance.)

The EnOcean Alliance is not responsible and shall not be held responsible in any manner for identifying or failing to identify any or all such third party intellectual property rights. This document and the information contained herein are provided on an "as is" basis and the EnOcean Alliance disclaims all warranties express or implied, including but not limited to

- (1) any warranty that the use of the information herein will not infringe any rights of third parties (including any intellectual property rights, patent, copyright or trademark rights, or
- (2) any implied warranties of merchantability, fitness for a particular purpose, title or non-infringement.

In no event will the EnOcean Alliance be liable for any loss of profits, loss of business, loss of use of data, interruption of business, or for any other direct, indirect, special or exemplary, incidental, punitive or consequential damages of any kind, in contract or in tort, in connection with this document or the information contained herein, even if advised of the possibility of such loss or damage. All Company, brand and product names may be trademarks that are the sole property of their respective owners.

The above notice and this paragraph must be included on all copies of this document that are made.

The EnOcean Alliance "EnOcean Equipment Profiles definitions" are available free of charge to companies, individuals and institutions for all non-commercial purposes (including educational research, technical evaluation and development of non-commercial tools or documentation.)

This specification includes intellectual property ("IPR") of the EnOcean Alliance and joint intellectual properties ("joint IPR") with contributing member companies. No part of this

EnOcean Equipment Profiles Page 1/8

enocean°alliance No Wires. No Batteries. No Limits.

System Specification

specification may be used in development of a product or service for sale without being a participant or promoter member of the EnOcean Alliance and/or joint owner of the appropriate joint IPR.

These errata may not have been subjected to an Intellectual Property review, and as such, may contain undeclared Necessary Claims.

EnOcean Alliance Inc. 2400 Camino Ramon, Suite 375 San Ramon, CA 94583 USA Graham Martin Chairman & CEO EnOcean Alliance

EnOcean Equipment Profiles



D2-14: Multi Function Sensors

TYPE 00 ... 24 Submitter: Perfactory

TYPE 30 ... 31 Submitter: Nexelec

Description:

Indoor Smarthome Multisensor

These EEPs describe a family of smarthome multi-functional sensors with optional Touch Button devices. Each device/member of the family is equipped with a different set of sensors to measure ambient environmental parameters, e.g. temperature, humidity, light level etc.

Some family-members are equipped with buttons in addition to the sensors. The response to pressing a button can be defined freely.

Sensor fault mode status (COA / SMA):

A smoke sensor failure prevents operation of a smoke / CO alarm signal. The smoke / CO sensor is supervised and a failure activates this flag.

Smoke Alarm Condition analysis:

The smoke alarm might be activated by improper environmental conditions like dust, humidity, etc. The product will activate flags if some of these conditions are observed at the moment of alarm activation.

- Maintenance: the flag is set if there is a lack of maintenance
- Temperature: the flag is set if the temperature may cause the alarm
- Humidity: the flag is set if the relative humidity may cause the alarm

!!! An activated flag doesn't mean that there is no smoke. It is dangerous to suspect a false alarm as the smoke preceding the onset of the flames are toxic and may cause you to lose consciousness: despite the absence of flames, a fire may blaze up in a few minutes. Nexelec recommends to analyse the environmental condition of a smoke alarm after the disappearance of the smoke alarm signal.

CO Alarm Condition analysis:

The CO alarm might be activated by improper environmental conditions like dust, humidity, etc. The product will activate flags if some of these conditions are observed at the moment of alarm activation.

- Maintenance: the flag is set if there is a lack of maintenance
- Temperature: the flag is set if the temperature may cause the alarm
- Humidity: the flag is set if the relative humidity may cause the alarm

!!! An activated flag doesn't mean that there is no CO. It is dangerous to suspect a false alarm. Nexelec recommends to analyse the environmental condition of a CO alarm after the disappearance of the CO alarm signal.

EEP Properties defined by the submitter:

Data exchange

Direction: unidirectional Addressing: broadcast

Communication trigger: event- & time-triggered

Communication interval: According to configuration ((non-)autonomous operation, battery status, etc.)

Trigger event: change of value (configuration-dependent) over threshold

Tx delay: -Rx timeout: -

Teach-in

Teach-in method: Universal teach-in (UTE)

Security

Encryption supported: no Security level format: -

EnOcean Equipment Profiles Page 3/8



Parameters applied by EEP family members:

Each member of the family transports at least one or more parameters it its messages as defined later. The parameters are defined in the following table; these are the "building blocks" of the telegrams.

Name	ShortCut	Size	Description	Valid Range	Scale	Unit
Massace ID	MSGID		Massace ID	0 255		
Message ID	MSGID	8	Message ID	0 255		
Temperature	TMP8	8	Temperature	0 250	Linear, range sensor (TYPE) dependent	°C
remperature	TMPO	0	Status of Temperature Sensor	Enum: 251 254: R	eserved	
				255: Error		
T	TMDO		Temperature	0 500	Linear, range sensor (TYPE) dependent	°c
Temperature	TMP9	9	Status of	Enum:		
			Temperature Sensor	501 510: R	eserved	
				511: Error		
			rel. Humidity (linear)	0 200	0 100	%
Humidity	ним	8	Status of Humidity Sensor	Enum: 201 254: Reserved 255: Error		
				233. [110]		
	ILL	17	Illumination (linear)	0 100,000 0 100,000 lx		
Illumination			Status of Illumination Sensor	Enum: 100,001 131,070: Reserved		
				131,071: Erro	r	
Energy Storage	ES	2	Energy Storage Status	Enum: 0: High 1: Medium 2: Low 3: Critical		
				3. Critical		
			VOC in CO2 equivalents (linear)	0 250	0 2,000	ppm/e
voc	VOC	8	TVOC (linear)	0 250	0 1,150	ppb
VOC	VOC	8	Status of VOC Sensor	Enum: 251 254: R	eserved	
			211001	255: Error		
CO2			CO2 (linear)	0 250	Sensor dependent, e.g. 0 2,000	ppm
CO2	C02	8	Status of CO2 Sensor	Enum: 251 254: Reserved 255: Error		



со	со	8	CO (linear)	0 200 Sensor dependent, e.g. 0 1,000 ppm			
CO	100	8		Enum:			
			Status of CO Sensor	201 254: Reserved			
				255: Error			
			Barometer (linear)	0 500 600 1,000 hPa			
				Enum:			
Barometer	BAR	9	Status of Barometer Sensor	501 510: Reserved			
			Daronieter Sensor	511: Error			
	<u>'</u>		•				
				Enum:			
				0: Present			
Presence	PR	2	Presence Detector	1: Not present			
				2: Not detectable			
				3: Presence Detector error			
				Enum:			
			Button A	0: Button A released			
Button A	BA	2		1: Button A pressed			
				2: Reserved			
				3: Button A error (state not detectable)			
				Enum:			
			Button B	0: Button B released			
Button B	BB	2		1: Button B pressed			
Dutton D		_		2: Reserved			
				3: Button B error (state not detectable)			
				Enum:			
		1	Smoke Alarm status	0: Smoke Alarm non-activated			
		-	Sillotto Atlantii Status	1: Smoke Alarm activated			
				Enum:			
		1	Sensor fault mode	0: Sensor Fault mode non-activated			
		-	status	1: Sensor Fault mode activated			
			Smoke Alarm	Enum:			
		1	Condition analysis:	0: Maintenance OK			
		-	Maintenance	1: Maintenance not done			
Smoke Alarm	SMA		Smoke Alarm	Enum:			
		1	Condition analysis:	0: Humidity range OK			
			Humidity	1: Humidity range NOK			
			Smoke Alarm	Enum:			
		1	Condition analysis:	0: Temperature range OK			
		1	Temperature	1: Temperature range NOK			
				0 250 0 250 Week			
			Time since last	Enum:			
		8	maintenance	251 254: Reserved			
				255: Error			



				Enum:			
		1	CO Alarm status	0: CO Alarm n			
				1: CO Alarm activated			
			Sensor fault mode	Enum:			
		1	status	0: Sensor Fault mode non-activated			
			Status	1: Sensor Fau	It mode activated	i	
			CO Alarm	Enum:			
		1	Condition analysis:	0: Maintenand	e OK		
			Maintenance	1: Maintenand	e not done		
CO Alarm	COA		CO Alarm	Enum:			
		1	Condition analysis:	0: Humidity ra	nge OK		
			Humidity	1: Humidity ra			
			00.41	Enum:	go ivo k		
		1	CO Alarm Condition analysis:	0: Temperatur	re range OK		
		1	Temperature	1: Temperatur			
			Tomperature	-		Week	
				0 250	0 250	Week	
		8	Time since last maintenance	Enum:			
			maintenance	251 254: Re	eserved		
				255: Error			
	RPLT				Product		
Daniel de		8	Countdown time until product end of life	0 250	dependent,	Month	
Remaining Product Life					e.g. 0 250		
Time				Enum:			
				251 254: Reserved			
				255: Error			
				Enum:			
	HCI	2	Comfort Index based on temperature and humidity	0: Good			
Hygrothermal				1: Medium			
Comfort Index				2: Bad			
				3: Error			
				3. EII0I			
				F			
				Enum:			
				0: Optimal air			
			Indoor Air quality	1: Dry Air rang			
T/Hum, Indoor			analysis based on	2: High humid			
Air Analysis	IAQTH	3	temperature and		rature and humic		
			humidity		e or Humidity ou	t of	
				analysis range			
				5 6: Reserve	ed		
				7: Error			
				Enum:			
		2	Indoor Air quality analysis based on CO	0: Good			
CO Indoor Air	IAQCO			1: Medium			
Analysis	1.1000			2: Bad			
				3: Error			
				51 21131			

enocean alliance No Wires. No Batteries. No Limits.

System Specification

EEP Family Tables:

Each line in the Family Table describes a parameter which is part of the message(s) of the marked Family Members (= column in the table / TYPE).

Line Powered devices:

Туре	0x00	0x01	0x02	0x03	0x04	0x05
Temperature Sensor, TMP9	050	050		050	050	050
Humidity Sensor, HUM	Χ	Χ		X	X	Х
Illumination Sensor, ILL					X	Х
VOC Sensor [CO2-equiv.], VOC			02000	02000		02000
Freely Programmable Button A, BA		X				
Freely Programmable Button B, BB		X				

Туре	0x06	0x07	0x08	0x09	0x0A
Temperature Sensor, TMP9		050	050	050	050
Humidity Sensor, HUM		X	Χ	X	Χ
Illumination Sensor, ILL			X		Х
VOC Sensor [CO2-equiv.], VOC				02000	02000
CO2 Sensor, CO2	02000	02000	02000	02000	02000

Туре	0x0B	0x0C	0x0D	0x0E	0x0F	0x10
Temperature Sensor, TMP9	050		050	050	050	050
Humidity Sensor, HUM	X		Χ	X	X	X
VOC Sensor [CO2-equiv.], VOC			02000	02000		02000
VOC Sensor, TVOC	01150					
CO2 Sensor, CO2				02000		
CO2 Sensor, CO2		05000				
Barometer Sensor, BAR					X	
Room Occupancy Sensor, PR						X
Freely Programmable Button A, BA			X	X		

Autonomous devices (indoor):

Туре	0x1A	0x1B	0x1C	0x1D
Temperature Sensor, TMP9	050	050	050	050
Humidity Sensor, HUM	X	X	X	X
Illumination Sensor, ILL		X		X
Energy Storage Status, ES	Χ	X	X	X
Barometer Sensor, BAR			X	X

Туре	0x30	0x31
Temperature Sensor, TMP8	050	050
Humidity Sensor, HUM	X	X
Smoke Alarm, SMA	X	
CO Alarm, COA		X
CO Sensor, CO		01000
Energy Storage Status, ES	Х	X
Remaining Product Life Time, RPLF	120	120
Hygrothermal Comfort Index, HCI	X	X
T/Hum. Indoor Air Analysis, IAQTH	X	X
CO Indoor Air Analysis, IAQCO		X

Autonomous devices (outdoor):

Туре	0x20	0x21	0x22	0x23	0x24
Temperature Sensor, TMP9	-4060	-4060	-4060	-4060	
Humidity Sensor, HUM	Х		Х		
Illumination Sensor, ILL	X			X	X
Energy Storage Status, ES	X	Χ	X	X	X


EnOcean Equipment Profiles Page 7/8



RORG	D2	VLD Telegram
FUNC	14	Multi Function Sensors
TYPE	06	Sensor for CO2, line-powered

Submitter: Perfactory

TYPE 0x06 - Sensor for CO2, line-powered



Offset	Size	Data	ShortCut	Description	Valid Range	Scale	Unit
0	8	CO2	CO2	CO2 (linear)	Enum:		
					0250:		ppm
				Status of CO2 Sensor		02000)
					251254: Reserve	d	
					255: Error		

EnOcean Equipment Profiles Page 8/8