# Superconducting Circuits - Equation Glossary

Instantaneous Energy

Circuit Flux (Faraday's Law)

Voltage-Inductance-Current Relation

Zero Point Charge Fluctuation

Flux-Inductance-Current Relation

Current-Capacitance-Voltage Relation

LC-Circuit Impedance

Admittance-Impedance relation

**Josephson Relation #1** 

**Josephson Relation #2** 

Purcell limit on qubit lifetime

Cooper-Pair Box Hamiltonian

#### **Instantaneous Energy**

$$E(t) = \int_{-\infty}^t V(t') I(t') \, \mathrm{dt'}$$

## Circuit Flux (Faraday's Law)

$$\phi(t) = \int_{-\infty}^t V(t') \mathrm{dt'}$$

### **Voltage-Inductance-Current Relation**

$$V = L rac{dI}{dt} \sim \hat{n} \sim \hat{q} = -i Q_{zpf} (\hat{a} - \hat{a}^\dagger)$$

### **Zero Point Charge Fluctuation**

$$Q_{zpf}=\sqrt{rac{\hbar}{2Z}}$$

#### Flux-Inductance-Current Relation

$$\Phi = LI \sim (\hat{a} + \hat{a}^\dagger)$$

**Current-Capacitance-Voltage Relation** 

$$I = C \frac{dV}{dt}$$

**LC-Circuit Impedance** 

$$Z=\sqrt{rac{L}{C}}$$

**Admittance-Impedance relation** 

$$Y(\omega)=Z^{-1}(\omega)$$

**Josephson Relation #1** 

$$I(t) = I_c \sin(\varphi(t))$$

**Josephson Relation #2** 

$$rac{\partial arphi}{\partial t} = rac{2eV(t)}{\hbar}$$

**Purcell limit on qubit lifetime** 

$$T_1=Q_{qb}/\omega_{qb}$$

**Cooper-Pair Box Hamiltonian** 

$$H_{CPB} = 4E_C(\hat{n}-n_g)^2 - E_J\cos(\hat{arphi})$$