# **Velocity Profile Generation**

Course 4, Module 7, Lesson 5



#### **Behavioural Planner Reference Velocity**


- Need to compute reference velocity
- Can use the speed limit of the road as a starting point
- Behavioural planner maneuver will also influence reference velocity
  - o E.g. a stopping maneuver requires us to stop





### **Dynamic Obstacles**


- Lead dynamic obstacles regulate our speed to prevent collisions
- Time to collision is an important metric to preserve when driving with lead vehicles
- Need to reach the red point at lead vehicle speed to ensure there is no collision



$$TTC = \frac{v_{ego} - v_{lead}}{s}$$


#### **Curvature and Lateral Acceleration**

- Curvature recorded at intermediate points,  $\kappa_i$
- Velocity bounded by maximum lateral acceleration from comfort rectangle
- Final velocity selected as minimum of BP reference, lead vehicle speed and curvature speed limit



## **Linear Ramp Profile**

- Simplest shape is a linear ramp to our desired velocity
- We know the total arc length of our path s and our initial and final speed  $v_0$  an  $v_f$



## **Linear Ramp - Acceleration Calculation**


- Can calculate acceleration using initial and final velocity as well as path arc length
  - Need to be sure acceleration values don't exceed our comfort rectangle as discussed in Module 1
- If we clamp our acceleration, we can recompute the final velocity using the clamped acceleration for a

$$\frac{v_f^2 - v_0^2}{2s} = a$$

$$\sqrt{2as + v_0^2} = v_f$$

# **Linear Ramp - Velocity Calculation**


• For a given acceleration, we can then compute the velocity at each point by using the accumulated arc length  $s_i$  up to that point



$$\sqrt{2as_i + v_0^2} = v_{f_i}$$

## **Trapezoidal Profile**

- Alternative profile is trapezoidal, car decelerates to slower speed before stopping
  - Useful for stop sign scenarios
- Deceleration chosen to be well within comfort rectangle to maximize passenger comfort




## **Trapezoidal Profile - First Segment**

- First step is to determine distance required to reach transit velocity  $v_t$  using gentle deceleration  $a_0$
- Can then compute linear deceleration for all points up to point of reaching transit speed

$$\frac{v_t^2 - v_0^2}{2a_0} = s_a$$


$$\sqrt{2a_0 s_i + v_0^2} = v_{f_i}$$



## **Trapezoidal Profile - Third Segment**

- Can repeat a similar process to reach a stop from  $v_t$  using gentle deceleration  $a_0$
- Need to first find point of initial deceleration  $s_b$
- The points in between 1st and 3rd segment have constant velocity  $\boldsymbol{v}_t$

$$\frac{\frac{0-v_t^2}{2a_0} = s_f - s_b}{\sqrt{2a_0(s_i) - s_b) + v_t^2} = v_{f_i}}$$




# **Trapezoidal Profile - All Segments**

 Bringing in the constant velocity transit section, we have our full trapezoidal velocity profile

$$v_{fi} = \begin{cases} \sqrt{2a_0 s_i + v_i^2}, & s_i \le s_a & \frac{\varepsilon}{s_0} \\ v_t, & s_a \le s_i \le s_b \\ \sqrt{2a_0 (s_i - s_b) + v_i^2}, & s_b \le s_i \le s_f \end{cases}$$

$$s_a \le s_i \le s_b$$

$$s_b \le s_i \le s_f$$



High-order nethods: Signadratic velocity planners

### **Summary**

- Discussed how to incorporate behavioural planner reference velocity into velocity generation
- Discussed how to use TTC to inform velocity profile generation
- Integrated lateral acceleration constraints into velocity profile generation
- Showed how to calculate linear and trapezoidal ramp velocity profiles



