Lab4-1 Report

Explanation of your firmware code:

- 1. 對 inputbuffer 與 outputsignal 進行 initialize。
- 2. 完成 fir 的運算,inputbuffer 進行類似 shift register 的行為來進行 input data 對 tap coefficients 的 alignment。Tap coefficients 會與對應 inputbuffer 位置的 data 相乘得出 partial sum,而 outputsignal 則作為儲存 FIR output result 的變數累加 fir 運算的 partial sum 取得單點 result。重複 N 次計算得到所有 outputsignal 並 return。

```
#include "fir.h"

Comment Code
void __attribute__ ( ( section ( ".mprjram" ) ) ) initfir() {
    //initial your fir
    for (int i = 0; i < N; i++) {
        inputbuffer[i] = 0;
        outputsignal[i] = 0;
    }
}

Comment Code
int* __attribute__ ( ( section ( ".mprjram" ) ) ) fir(){
    initfir();
    //write down your fir
    for (int i = 0; i < N; i++) {
        for (int j = N-1; j > 0; j--) {
            inputbuffer[j] = inputbuffer[j] * taps[j];
            outputsignal[i] += inputbuffer[0] * taps[0];
        }
        inputbuffer[0] = inputsignal[i];
        outputsignal[i] += inputbuffer[0] * taps[0];
}

return outputsignal;
```

Explanation of your assembly code:

在 counter_la_fir.c 中的 main 裡面,首先讓 mprj_io pin 在對應的 GPIO address 存取值,可以看到圖中標記的 0x2600003c 為在caravel.h 中定義好的位置,從assembly code 中可以看出,先計算 offset 將 address 給入 a5 register,再計算 GPIO 位置給如

a4,最後將 a4 存回 a5 所代表的位置。

```
#define GPIO_MODE_MGMT_STD_OUTPUT 0x1809
#define GPIO_MODE_USER_STD_OUTPUT 0x1808
```

```
1000050c: 00002737
                             lui a4,0x2
                             addi a4,a4,-2040 # 1808 < fstack+0x1208>
10000510: 80870713
10000514: 00e7a023
                             sw a4.0(a5)
10000518: 260007b7
                             lui a5,0x26000
1000051c: 03078793
                             addi a5,a5,48 # 26000030 < esram rom+0x15fff828>
10000520: 00002737
                             lui a4,0x2
10000524: 80870713
                             addi a4,a4,-2040 # 1808 < fstack+0x1208>
10000528: 00e7a023
                             sw a4,0(a5)
1000052c: 260007b7
                             lui a5,0x26000
10000530: 02c78793
                             addi a5,a5,44 # 2600002c < esram rom+0x15fff824>
10000534: 00002737
                             lui a4,0x2
10000538: 80870713
                             addi a4,a4,-2040 # 1808 < fstack+0x1208>
1000053c: 00e7a023
                             sw a4.0(a5)
10000540: 260007b7
                             lui a5,0x26000
10000544: 02878793
                             addi a5,a5,40 # 26000028 < esram rom+0x15fff820>
10000548: 00002737
                             lui a4,0x2
1000054c: 80870713
                             addi a4,a4,-2040 # 1808 < fstack+0x1208>
10000550: 00e7a023
                             sw a4.0(a5)
10000554: 260007b7
                             lui a5,0x26000
10000558: 02478793
                             addi a5,a5,36 # 26000024 <_esram_rom+0x15fff81c>
1000055c: 00002737
                             lui a4,0x2
10000560: 80870713
                             addi a4,a4,-2040 # 1808 < fstack+0x1208>
10000564: 00e7a023
                             sw a4,0(a5)
10000568: 260007b7
                             lui a5,0x26000
1000056c: 03c78793
                             addi a5,a5,60 # 2600003c <_esram_rom+0x15fff834>
10000570: 00002737
                             lui a4,0x2
10000574: 80970713
                             addi a4,a4,-2039 # 1809 < fstack+0x1209>
10000578: 00e7a023
                             sw a4,0(a5)
1000057c: f00067b7
                             lui a5,0xf0006
```

```
reg_mprj_io_31 = GPIO MODE MGMT STD OUTPUT;
reg_mprj_io_30 = GPIO_MODE_MGMT_STD_OUTPUT;
reg_mprj_io_29 = GPIO_MODE_MGMT_STD_OUTPUT;
reg_mprj_io_27 = GPIO_MODE_MGMT_STD_OUTPUT;
reg_mprj_io_25 = GPIO MODE MGMT STD OUTPUT;
reg_mprj_io_24 = GPIO MODE MGMT STD OUTPUT;
reg mprj io 23 = GPIO MODE MGMT STD OUTPUT;
reg mprj io 22 = GPIO MODE MGMT STD OUTPUT;
reg mprj io 20 = GPIO MODE MGMT STD OUTPUT;
reg mprj io 19 = GPIO MODE MGMT STD OUTPUT;
reg mprj io 18 = GPIO MODE MGMT STD OUTPUT;
reg mprj io 17 = GPIO MODE MGMT STD OUTPUT;
req mprj io 16 = GPIO MODE MGMT STD OUTPUT;
reg mprj io 15 = GPIO MODE USER STD OUTPUT;
reg mprj io 14 = GPIO MODE USER STD OUTPUT;
reg mprj io 13 = GPIO MODE USER STD OUTPUT;
reg mprj io 12 = GPIO MODE USER STD OUTPUT;
reg mprj io 11 = GPIO MODE USER STD OUTPUT;
reg mprj io 10 = GPIO MODE USER STD OUTPUT;
reg mprj io 9 = GPIO MODE USER STD OUTPUT;
reg mprj io 8 = GPIO MODE USER STD OUTPUT;
reg_mprj_io_7 = GPIO MODE USER STD OUTPUT;
reg_mprj_io_5 = GPIO MODE USER STD OUTPUT;
reg_mprj_io_4 = GPIO_MODE_USER_STD_OUTPUT;
reg mprj io 3 = GPIO MODE USER STD OUTPUT;
reg mprj io 2 = GPIO MODE USER STD OUTPUT;
reg mprj io 1 = GPIO MODE USER STD OUTPUT:
reg mprj io 0 = GPIO MODE USER STD OUTPUT:
reg mprj io 6 = GPIO MODE MGMT STD OUTPUT;
```

以下這段則是執行右邊中所描述的

firmware code

```
// Now, apply the configuration
reg_mprj_xfer = 1;
while (reg_mprj_xfer == 1);
```

```
lui a5,0xf0006
1000057c: f00067b7
                              li a4,1
10000580: 00100713
10000584: 00e7a023
                              sw a4,0(a5) # f0006000 < esram+0xb8005e08>
10000588: 260007b7
                              lui a5,0x26000
1000058c: 00100713
                              li a4,1
10000590: 00e7a023
                              sw a4,0(a5) # 26000000 < esram rom+0x15fff7f8>
10000594: 00000013
                              nop
10000598: 260007b7
                              lui a5,0x26000
1000059c: 0007a703
                              lw a4,0(a5) # 26000000 < esram_rom+0x15fff7f8>
100005a0: 00100793
                              li a5,1
100005a4: fef70ae3
                             beg a4,a5,10000598 <main+0x2ac>
```

接下來依照 main function 中描述,對不同 address 進行寫入:

```
100005a8: f00037b7
100005ac: 00c78713
                                 lui a5,0xf000
                                  addi a4,a5,12 # f000300c <_esram+0xb8002e14>
                                 li a5,0
sw a5,0(a4)
100005b0: 00000793
100005b8: f0003737
100005bc: 01c70713
                                 lui a4,0xf0003
                                 addi a4,a4,28 # f000301c <_esram+0xb8002e24>
                                 sw a5,0(a4)
lui a5,0xf0003
100005c0: 00f72023
100005c4: f00037b7
                                addi a4,a5,8 # f0003008 <_esram+0xb8002e10>
li a5,-1
100005c8: 00878713
100005cc: fff00793
100005d0: 00f72023
100005d4: f0003737
                                 lui a4,0xf0003
                                 addi a4,a4,24 # f0003018 <_esram+0xb8002e20>
100005dc: 00f72023
                                 sw a5,0(a4)
lui a5,0xf0003
                                 addi a4,a5,4 # f0003004 <_esram+0xb8002e0c>
li a5,0
100005e4: 00478713
100005e8: 00000793
                                 sw a5,0(a4)
lui a4,0xf0003
100005ec: 00f72023
100005f0: f0003737
100005f4: 01470713
                                 addi a4,a4,20 # f0003014 <_esram+0xb8002e1c>
100005f8: 00f72023
                                 sw a5,0(a4)
100005fc: f0003737
                                li a5,0
sw a5,0(a4) # f0003000 <_esram+0xb8002e08>
10000600: 00000793
10000604: 00f72023
10000608: f0003737
                                 lui a4.0xf0003
                                 addi a4,a4,16 # f0003010 <_esram+0xb8002e18>
1000060c: 01070713
10000610: 00f72023
10000614: 260007b7
                                 sw a5,0(a4)
lui a5,0x26000
                                 addi a5,a5,12 # 2600000c <_esram_rom+0x15fff804>
lui a4,0xab400
10000618: 00c78793
1000061c: ab400737
                                 sw a4,0(a5)
lui a5,0xf0003
10000620: 00e7a023
10000624: f00037b7
                                 addi a5,a5,56 # f0003038 <_esram+0xb8002e40>
1000062c: 0007a023
                                 sw zero,0(a5)
                                 lui a5,0xf0003
 10000634: 00878713
                                 addi a4,a5,8 # f0003008 < esram+0xb8002e10>
1000063c: 00f72023
                                 sw a5,0(a4) # ab400000 <_esram+0x733ffe08>
 10000640: f0003737
                                 lui a4,0xf0003
10000644: 01870713
                                  addi a4,a4,24 # f0003018 <_esram+0xb8002e20>
  0000648: 00f72023
```

之後呼叫 fir function, 並將結果寫入 reg mprj datal 所對應的 address:

```
int* tmp = fir();

reg_mprj_datal = *tmp << 16;
reg_mprj_datal = *(tmp+1) << 16;
reg_mprj_datal = *(tmp+2) << 16;
reg_mprj_datal = *(tmp+3) << 16;
reg_mprj_datal = *(tmp+4) << 16;
reg_mprj_datal = *(tmp+5) << 16;
reg_mprj_datal = *(tmp+6) << 16;
reg_mprj_datal = *(tmp+7) << 16;
reg_mprj_datal = *(tmp+8) << 16;
reg_mprj_datal = *(tmp+8) << 16;
reg_mprj_datal = *(tmp+9) << 16;
reg_mprj_datal = *(tmp+9) << 16;</pre>
```

initfir function's assembly code:

```
38000024 <initfir>:
38000024: fe010113
                                sw s0,28(sp)
addi s0,sp,32
38000028: 00812e23
3800002c: 02010413
38000030: fe042623
                                 j 3800006c <initfir+0x48>
38000034: 0380006f
 38000038: 05c00713
                                lw a5,-20(s0)
slli a5,a5,0x2
3800003c: fec42783
38000040: 00279793
38000044: 00f707b3
                                 sw zero,0(a5)
li a4,136
38000048: 0007a023
3800004c: 08800713
38000050: fec42783
                                slli a5,a5,0x2
38000054: 00279793
 38000058: 00f707b3
                                 add a5,a4,a5
3800005c: 0007a023
                                sw zero,0(a5)
lw a5,-20(s0)
38000060: fec42783
38000064: 00178793
38000068: fef42623
                                 sw a5,-20(s0)
lw a4,-20(s0)
3800006c: fec42703
38000070: 00a00793
38000074: fce7d2e3
                                 bge a5,a4,38000038 <initfir+0x14>
38000078: 00000013
3800007c: 00000013
38000084 02010113
                                 addi sp,sp,32
38000088: 00008067
```

fir function's assembly code:

```
800008c: fe010113
                                               addi sp,sp,-32
                                                                                                                                              li a3,136
lw a5,-20(s0)
slli a5,a5,0x2
add a5,a3,a5
                                              sw ra,28(sp)
sw s0,24(sp)
                                                                                                    8000134: 08800693
38000090: 00112e23
                                                                                                   38000138: fec42783
8000094: 00812c23
                                              sw s1,20(sp)
addi s0,sp,32
38000098: 00912a23
                                                                                                                                              sw a4,0(a5)
lw a5,-24(s0)
addi a5,a5,-1
sw a5,-24(s0)
lw a5,-24(s0)
                                                                                                   8000144: 00e7a023
380000a0: f85ff0ef
                                               ial ra.38000024 <initfir>
                                              sw zero, -20(s0)
j 380001d0 <fir+0x144>
li a5,10
                                                                                                   38000148: fe842783
380000a4: fe042623
                                                                                                  38000146: fff78793
38000150: fef42423
38000154: fe842783
380000a8: 1280006f
380000ac: 00a00793
                                                                                                                                              li a5,380000b8 <fir+0x2c>
li a4,44
lw a5,-20(s0)
slli a5,a5,0x2
                                                                                                  38000158: f6f040e3
                                              j 38000154 <fir+0xc8>
lw a5,-24(s0)
addi a5,a5,-1
                                                                                                 38000158: 10104063
3800015c: 02c00713
38000160: fec42783
38000164: 00279793
380000b4: 0a00006f
80000b8: fe842783
80000bc: fff78793
                                                                                                                                              add a5,a4,a5
lw a4,0(a5)
li a5,92
sw a4,0(a5)
li a4,136
                                              li a4,92
slli a5,a5,0x2
380000c0: 05c00713
                                                                                                  38000168: 00f707b3
                                                                                                  3800016c: 0007a703
38000170: 05c00793
38000174: 00e7a023
380000c8: 00f707b3
                                              add a5.a4.a5
                                              lw a4,0(a5)
li a3,92
                                                                                                  38000178: 08800713
                                                                                                                                             li a4,136

lw a5,-20(s0)

slli a5,a5,0x:

add a5,a4,a5

lw s1,0(a5)

li a5,92

lw a4,0(a5)

li a5,0

lw a5,0(a5)
80000d0: 05c00693
                                                                                                  38000178: 08800713
3800017c: fec42783
38000180: 00279793
38000184: 00f707b3
                                              lw a5,-24(s0)
slli a5,a5,0x2
380000d4: fe842783
80000d8: 00279793
380000dc: 00f687b3
                                              add a5.a3.a5
                                                                                                   38000188: 0007a483
                                              sw a4,0(a5)
li a4,136
80000e0: 00e7a023
                                                                                                  3800018c: 05c00793
38000190: 0007a703
38000194: 00000793
80000e4: 08800713
                                              lw a5,-20(s0)
slli a5,a5,0x2
380000e8: fec42783
                                                                                                   38000198: 0007a783
                                                                                                 3800019c: 00078593
380001a0: 00070513
380001a4: e5dff0ef
                                                                                                                                              mv a1,a5
mv a0,a4
jal ra,38000000 <__mulsi3>
380000f0: 00f707b3
                                              add a5.a4.a5
                                              lw s1,0(a5)
li a4,92
80000f8: 05c00713
                                              lw a5,-24(s0)
slli a5,a5,0x2
380000fc: fe842783
                                                                                                   380001a8: 00050793
                                                                                                                                              mv a5,a0
add a4,s1,a5
                                                                                                  380001ac: 00f48733
8000100: 00279793
                                                                                                                                              li a3,136
lw a5,-20(s0)
slli a5,a5,0x2
38000104: 00f707b3
                                              add a5.a4.a5
                                              lw a3,0(a5)
li a4,0
                                                                                                   380001b8: 00279793
800010c: 00000713
                                                                                                  380001c0: 00f687b3
380001c0: 00e7a023
380001c4: fec42783
                                                                                                                                              add a5,a3,a5
sw a4,0(a5)
lw a5,-20(s0)
                                              lw a5,-24(s0)
slli a5,a5,0x2
38000110: fe842783
                                                                                                                                                                                             380001e0: 00078513
                                              add a5.a4.a5
38000118: 00f707b3
                                                                                                   380001c8: 00178793
                                                                                                                                              addi a5,a5,1
                                                                                                                                              sw a5,-20(s0)
lw a4,-20(s0)
li a5,10
                                                                                                  380001cc: fef42623
                                                                                                                                                                                             380001e8: 01812403
8000120: 00078593
                                                                                                   380001d0: fec42703
380001d4: 00a00793
                                                                                                                                                                                             380001ec: 01412483
380001f0: 02010113
                                              mv a1,a5
                                              mv a0,a3
jal ra,38000000 <__mulsi3>
38000124: 00068513
                                                                                                                                              bge a5,a4,380000ac <fir+0x20> 380001f4: 00008067
```

mv a0,a5 lw ra,28(sp)

lw s0,24(sp) lw s1,20(sp) Where 38000000 is the starting address of multiplication function.

How does it execute a multiplication in assembly code?

以下這段則為 fir.c 中使用到的 multiplication 的 assembly code block,這個 function 用 a0 與 a1 作為 function 的 argument 將參數給進來,其中 a0 作為被乘數先給入 a2,再將 a0 歸零用來累加,而 a1 會透過不斷掃描 LSB,若為 1 則進行累加 (add a2 to a0),若為 0 則不累加,並在掃描後進行 shift (a1 & a2),直到 a1 值為零後即完成累加。這裡利用 shift right 及 and operation with 1 來確定乘數中那些位置為 1,即為會產生乘積的位置。利用 shift left 及 add 來進行乘積的進位及累加。以拆解的方式完成乘法運算。

```
Disassembly of section .mprjram:
38000000 < mulsi3>:
38000000: 00050613
                             mv a2,a0
38000004: 00000513
                             li a0,0
38000008: 0015f693
                             andi a3,a1,1
3800000c: 00068463
                             beqz a3,38000014 < mulsi3+0x14>
38000010: 00c50533
                             add a0,a0,a2
                             srli a1,a1,0x1
38000014: 0015d593
38000018: 00161613
                             slli a2,a2,0x1
3800001c: fe0596e3
                             bnez a1,38000008 < mulsi3+0x8>
38000020: 00008067
                             ret
```

What address allocate for user project and how many space is required to allocate to firmware code:


The space allocated for the user project is based from 0x38000000 to 0x383FFFFF. The space required to allocate for our fir firmware code is from 0x38000000 to 0x380001F7, total 504 bytes.

```
38000150: fef42423
                            sw a5,-24(s0)
38000154: fe842783
                            lw a5,-24(s0)
38000158: f6f040e3
                            bgtz a5,380000b8 <fir+0x2c>
3800015c: 02c00713
                            li a4,44
38000160: fec42783
                            lw a5,-20(s0)
38000164: 00279793
                            slli a5,a5,0x2
38000168: 00f707b3
                            add a5,a4,a5
3800016c: 0007a703
                           lw a4,0(a5)
38000170: 05c00793
                            li a5,92
38000174: 00e7a023
                            sw a4,0(a5)
38000178: 08800713
                            li a4,136
                            lw a5,-20(s0)
3800017c: fec42783
                            slli a5,a5,0x2
38000180: 00279793
                           add a5,a4,a5
38000184: 00f707b3
38000188: 0007a483
                            lw s1,0(a5)
3800018c: 05c00793
                           li a5,92
38000190: 0007a703
                           lw a4,0(a5)
38000194: 00000793
                            li a5,0
38000198: 0007a783
                           lw a5,0(a5)
3800019c: 00078593
                            mv a1,a5
380001a0: 00070513
                           mv a0,a4
380001a4: e5dff0ef
                           jal ra,38000000 < mulsi3>
380001a8: 00050793
                            mv a5,a0
380001ac: 00f48733
                            add a4,s1,a5
380001b0: 08800693
                           li a3,136
                          lw a5,-20(s0)
380001b4: fec42783
                           slli a5,a5,0x2
380001b8: 00279793
380001bc: 00f687b3
                           add a5,a3,a5
380001c0: 00e7a023
                           sw a4,0(a5)
380001c4: fec42783
                           lw a5,-20(s0)
                           addi a5,a5,1
380001c8: 00178793
380001cc: fef42623
                            sw a5,-20(s0)
380001d0: fec42703
                           lw a4,-20(s0)
380001d4: 00a00793
                            li a5,10
380001d8: ece7dae3
                           bge a5,a4,380000ac <fir+0x20>
380001dc: 08800793
                            li a5,136
380001e0: 00078513
                            mv a0,a5
380001e4: 01c12083
                           lw ra,28(sp)
380001e8: 01812403
                            lw s0,24(sp)
380001ec: 01412483
                            lw s1,20(sp)
380001f0: 02010113
                            addi sp,sp,32
380001f4: 00008067
                            ret
Disassembly of section .riscv.attributes:
```

If we consider the main function defined in counter_la_fir.c, the space allocated for the main firmware code is from 0x100002ec to 0x100007ab, total 1216 bytes. Hence, the total space for the firmware code is 1216 + 504 = 1720 bytes.

```
100002ec <main>:
100002ec: fe010113
                             addi sp,sp,-32
100002f0: 00112e23
                             sw ra,28(sp)
100002f4: 00812c23
                             sw s0,24(sp)
                             addi s0,sp,32
100002f8: 02010413
100002fc: 260007b7
                             lui a5,0x26000
10000300: 0a078793
                             addi a5,a5,160 # 260000a0 <_esram_rom+0x15fff898>
10000304: 00002737
                             lui a4,0x2
10000308: 80970713
                             addi a4,a4,-2039 # 1809 < fstack+0x1209>
1000030c: 00e7a023
                             sw a4,0(a5)
10000310: 260007b7
                             lui a5,0x26000
10000314: 09c78793
                             addi a5,a5,156 # 2600009c <_esram_rom+0x15fff894>
                              slli a4,a5,0x10
10000778: 01079713
1000077c: 260007b7
                              lui a5,0x26000
10000780: 00c78793
                             addi a5,a5,12 # 2600000c < esram rom+0x15fff804>
10000784: 00e7a023
                             sw a4,0(a5)
10000788: 260007b7
                             lui a5,0x26000
1000078c: 00c78793
                             addi a5,a5,12 # 2600000c <_esram_rom+0x15fff804>
10000790: ab510737
                             lui a4,0xab510
10000794: 00e7a023
                             sw a4,0(a5)
10000798: 00000013
                             nop
1000079c: 01c12083
                             lw ra,28(sp)
100007a0: 01812403
                             lw s0,24(sp)
100007a4: 02010113
                             addi sp,sp,32
100007a8: 00008067
                              ret
```

Waveform of user-bram and Wishbond interface:



When wbs_cyc_i and wbs_stb_i pulled high, the signals at the wishbond ports are valid. Wbs we i determines whether the transmission is read (wbs we i = 0) or write

(wbs_we_i = 1). Wbs_dat_i is the data being written in and the wbs_dat_o is the data being read out. Wbs_sel_i indicates where valid data is placed on the [wbs_dat_i] signal array during WRITE cycles, and where it should be present on the [wbs_dat_o] signal array during READ cycles. Wbs_adr_i indicates where the read or write transmission take place. Wbs_ack_o is the finish response which stands for the end of the transaction sent back from the wishbond slave.

FSM:



When the counter stays at 0, the state is idle, meaning that no transferring occurs. When counter start counting, the state is processing. When the counter is at DELAY+2, the state is response, and the wishbond slave will return ack and data to the master. The state will go back to idle after response.